# OMRON

# Machine Automation Controller NJ-series

# **Motion Control Instructions Reference Manual**

NJ501-1300

NJ501-1400

NJ501-1500



# © OMRON, 2011 All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON. No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

## Introduction

Thank you for purchasing an NJ-series CPU Unit.

This manual describes the motion control instructions. Please be sure you sufficiently understand the operations and handling procedures, and use the Motion Control Function Module (abbreviated as "MC Function Module") correctly.

Use this manual together with the user's manuals for the NJ-series CPU Unit.

When you have finished reading this manual, keep it in a safe location where it will be readily available for future use.

#### **Intended Audience**

This manual is intended for the following personnel, who must also have knowledge of electrical systems (an electrical engineer or the equivalent).

- Personnel in charge of introducing FA systems.
- · Personnel in charge of designing FA systems.
- Personnel in charge of installing and maintaining FA systems.
- · Personnel in charge of managing FA systems and facilities.

For programming, this manual is intended for personnel who understand the programming language specifications in international standard IEC 61131-3 or Japanese standard JIS B3503.

#### **Applicable Products**

This manual covers the following products.

- NJ-series CPU Units
  - NJ501-1300
  - NJ501-1400
  - NJ501-1500


## **Relevant Manuals**

There are three manuals that provide basic information on the NJ-series CPU Units: the NJ-series CPU Unit Hardware User's Manual, the NJ-series CPU Unit Software User's Manual (this manual), and the NJ-series Instructions Reference Manual.

Most operations are performed from the Sysmac Studio Automation Software. Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for information on the Sysmac Studio.

Other manuals are necessary for specific system configurations and applications.

Read all of the manuals that are relevant to your system configuration and application to make the most of the NJ-series CPU Unit.



# **Manual Configuration**

# NJ-series CPU Unit Hardware User's Manual (Cat. No. W500)

Section	Description
Section 1 Introduction	This section provides an introduction to the NJ-series Controllers and their features, and gives the NJ-series Controller specifications.
Section 2 System Configuration	This section describes the system configuration used for NJ-series Controllers.
Section 3 Configuration Units	This section describes the parts and functions of the configuration devices in the NJ-series Controller configuration, including the CPU Unit and Configuration Units.
Section 4 Installation and Wiring	This section describes where and how to install the CPU Unit and Configuration Units and how to wire them.
Section 5 Troubleshooting	This section describes the event codes, error confirmation methods, and corrections for errors that can occur.
Section 6 Inspection and Maintenance	This section describes the contents of periodic inspections, the service life of the Battery and Power Supply Units, and replacement methods for the Battery and Power Supply Units.
Appendices	The appendices provide the specifications of the Basic I/O Units, Unit dimensions, load short-circuit protection detection, line disconnection detection, and measures for EMC Directives.

# NJ-series CPU Unit Software User's Manual (Cat. No. W501)

Section	Description
Section 1 Introduction	This section provides an introduction to the NJ-series Controllers and their features, and gives the NJ-series Controller specifications.
Section 2 CPU Unit Operation	This section describes the variables and control systems of the CPU Unit and CPU Unit status.
Section 3 I/O Ports, Slave Configuration, and Unit Configuration	This section describes how to use I/O ports, how to create the slave configuration and unit configuration and how to assign functions.
Section 4 Controller Setup	This section describes the initial settings of the function modules.
Section 5 Designing Tasks	This section describes the task system and types of tasks.
Section 6 Programming	This section describes programming, including the programming languages and the variables and instructions that are used in programming.
Section 7 Simulation, Transferring Projects to the Physical CPU Unit, and Opera- tion	This section describes simulation of Controller operation and how to use the results of simulation.
Section 8 CPU Unit Status	This section describes CPU Unit status.
Section 9 CPU Unit Functions	This section describes the functionality provided by the CPU Unit.
Section 10 Communications Setup	This section describes how to go online with the CPU Unit and how to connect to other devices.
Section 11 Example of Actual Application Procedures	This section describes the procedures that are used to actually operate an NJ-series Controller.
Section 12 Troubleshooting	This section describes the event codes, error confirmation methods, and corrections for errors that can occur.
Appendices	The appendices provide the CPU Unit specifications, task execution times, system-defined variable lists, data attribute lists, CJ-series Unit memory information, CJ-series Unit memory allocation methods, and data type conversion information.

#### NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507)

Section	Description
Section 1 Introduction to the Motion Control Function Module	This section describes the features, system configuration, and application flow for the Motion Control Function Module.
Section 2 Motion Control Configuration and Principles	This section outlines the internal structure of the CPU Unit and describes the configuration and principles of the MC Function Module.
Section 3 Configuring Axes and Axes Groups	This section describes the concept of axes and axes groups, the settings for axes that are required for the MC Test Run operations to function on the Sysmac Studio, and the instructions for creating and configuring axes and axes groups using the Sysmac Studio.
Section 4 Checking Wiring from the Sysmac Studio	This section describes the MC Test Run operations of the Sysmac Studio. You can use the MC Test Run operations to monitor sensor signals, check Servomotor wiring, and more, all without any programming.
Section 5 Motion Control Parameters	This section provides information on the axis parameters and axes group parameters that are used for motion control.
Section 6 Motion Control Programming	This section provides the specifications of a motion control program and the operating procedures that are required up through actual program development.
Section 7 Manual Operation	This section describes manual operation when the MC Function Module is used together with an OMRON G5-series Servo Drive.
Section 8 Homing	This section describes homing.
Section 9 Motion Control Functions	This section describes the motion control functions that are used when connected to OMRON G5-series Servo Drives with built-in EtherCAT communications.
Section 10 Sample Programming	This section describes basic application methods for homing, error monitoring, and other functions, and provides programming samples for absolute positioning, cam operation, and other axis operations.
Section 11 Troubleshooting	This section describes the items to check when problems occur in the MC Function Module. It includes error diagnosis and countermeasures for error indications, and error diagnosis and countermeasures for operating conditions.
Appendices	The appendices describe settings and connection methods for OMRON G5-series Servo Drive objects.


# NJ-series Motion Control Instructions Reference Manual (Cat. No. W508) (This Manual)

Section	Description
Section 1 Introduction to Motion Control Instructions	This section gives an introduction to motion control instructions supported by NJ-series CPU Units.
Section 2 Variables and Instructions	This section describes the variables and instructions for the Motion Control Function Module.
Section 3 Axis Command Instructions	This section describes the instructions that are used to perform single-axis control for the MC Function Module.
Section 4 Axes Group Instructions	This section describes the instructions to perform multi-axes coordinated control for the MC Function Module.
Section 5 Common Command Instructions	This section describes the instructions that are used for both axes and axes groups.
Appendices	The appendices describe the error codes that are generated by the instructions.

# **Manual Structure**

#### **Page Structure**

The following page structure is used in this manual.



Note: This page is for illustration only. It does not represent a specific page in this manual.

#### **Special Information**

Special information in this manual is classified as follows:



#### **Precautions for Safe Use**

Precautions on what to do and what not to do to ensure safe usage of the product.



#### **Precautions for Correct Use**

Precautions on what to do and what not to do to ensure proper operation and performance.



# Additional Information

Additional information to read as required.

This information is provided to increase understanding or make operation easier.

**Note** References are provided to more detailed or related information.

# **Sections in this Manual**

			1
1	Introduction to Motion Control Instructions		2
		_///	3
2	Variables and Instructions	_/ /	4
3	Axis Command Instructions	_//	5
4	Axes Group Instructions		A
5	Common Command Instructions		1
Α	Appendices		
1	Index		

Sections in this Manual

# **CONTENTS**

	Intro	duction	1
	Rele	evant Manuals	2
	Man	ual Configuration	3
	Man	ual Structure	5
	Sect	tions in this Manual	7
	Rea	d and Understand this Manual	. 13
;	Safe	ety Precautions	. 17
	Pred	cautions for Safe Use	. 18
	Pred	cautions for Correct Use	. 19
	Reg	ulations and Standards	. 20
	Unit	Versions	. 22
	Rela	ited Manuals	. 25
	Revi	ision History	. 27
Sectio	n 1	Introduction to Motion Control Instructions	
	1-1	Motion Control Instructions	. 1-2 . 1-3
	1-2	Basic Information on Motion Control Instructions  Motion Control Instruction Names  Languages for Motion Control Instructions  Motion Control Instruction Locations  Multi-execution of Motion Control Instructions  Online Editing of Motion Control Instructions  Changes in the Operating Mode of the CPU Unit	. 1-9 . 1-9 1-10 1-18 1-19
Sectio	n 2	Variables and Instructions	
;	2-1	Variables  MC Common Variables  Axis Variables  Axes Group Variables  Input Variables for Motion Control Instructions  Output Variables for Motion Control Instructions  In-Out Variables for Motion Control Instructions	. 2-3 . 2-4 . 2-8 2-10 2-2
:	2-2	Instructions Common Commands Axis Commands Axes Group Commands	2-24 2-25

2-3	PDO Mapping 2-	
	Required Objects	
	Objects Required for Specific Instructions	28
<b>.</b>		
Section 3	3 Axis Command Instructions	
		_
MC <sub>.</sub>	_Power3	
	Variables	
	Function	
MC <sub>.</sub>	_MoveJog	
	Variables	
	Function	
MC.	_Home	
	Variables	
	Function3-	
MC.	_Move3-	
	Variables3-	36
	Function	38
MC.	_MoveAbsolute	41
	Variables3-	41
	Function	43
	Sample Programming 1	51
	Sample Programming 2	59
MC	_MoveRelative3-	86
	Variables	68
	Function	70
MC	_MoveVelocity	75
	Variables	
	Function	77
	Sample Programming3-	82
MC	MoveZeroPosition	
	Variables	90
	Function3-	
MC	MoveFeed	
-	 Variables	
	Function	01
	Sample Programming	
MC	_Stop	
-	 Variables	
	Function	
MC	ImmediateStop	
-	 Variables	
	Function	
МС	_SetPosition	
	Variables	
	Function	
МС	_SetOverride	
	Variables	
	Function	
МС	_ResetFollowingError	
•	Variables	
	Function	
MC	_Camin	
1410	Variables	
	Function	
	Sample Programming 1	
	Sample Programming 2	
МС	CamOut	
IVIC	Variables	
	Function	
MC	_Gearin	
IVIC		
	valiables	J

	Function 3	3-209
	Sample Programming	
N	MC_GearInPos 3	_
	Variables	
	Function	
	Sample Programming	
IV	MC_GearOut 3	
	Variables	
R.	AC MoveLink	
IV	Variables	
	Function	
	Sample Programming	
N	MC CombineAxes	
	Variables	3-272
	Function 3	3-275
IV	MC_Phasing 3	-283
	Variables	3-283
	Function	
N	MC_TorqueControl	
	Variables	
	Function	
N	MC_SetTorqueLimit 3	
	Variables	
B.	Function	
IV	MC_ZoneSwitch 3	
	Variables	
I.	MC TouchProbe	
	Variables	
	Function	
	Sample Programming	
N	MC AbortTrigger 3	
	Variables	
	Function 3	3-335
IV	MC_AxesObserve 3	-338
	Variables	
	Function	
N	MC_SyncMoveVelocity	
		3-344
	Function	
IV	MC_Reset	
	Variables	
	FullCuoti	5-333
Section	1 4 Axes Group Instructions	
IV	ИС_GroupEnable	. 4-2
	Variables	
	Function	
IV	MC_GroupDisable	
	Variables	
_	Function	
N	MC_MoveLinear	
	Variables	
	Function	
B.	Sample Programming	
IV	Variables	
	Function	
R.	MC MoveLinearRelative	
IV	Variables	
	TAINANIOO	. 00

	N/C	Function	
	IVIC_	MoveCircular2D	
		Function	
		Sample Programming	
	мс	GroupStop	
	•_	Variables	
		Function	
	MC (	GroupImmediateStop	
	_	Variables	4-75
		Function	4-76
	MC_	GroupSetOverride	. 4-80
		Variables	4-80
		Function	4-81
	MC_	GroupReset	. 4-84
		Variables	4-84
		Function	4-85
		SetCamTableProperty Variables Function SaveCamTable	5-2 5-3
		Variables	5-8
		Function	5-9
	MC_	Write	. 5-12
		Variables	
		Function	
		Sample Programming	5-15
Apper	ndic	ees	
	A-1	Error Codes	A-2
	۸_2	Error Code Details	Λ_1Ω
	A-Z	Lifor Code Details	.A-19
Index			

### Read and Understand this Manual

Please read and understand this manual before using the product. Please consult your OMRON representative if you have any questions or comments.

#### Warranty and Limitations of Liability

#### WARRANTY

OMRON's exclusive warranty is that the products are free from defects in materials and workmanship for a period of one year (or other period if specified) from date of sale by OMRON.

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, REGARDING NON-INFRINGEMENT, MERCHANTABILITY, OR FITNESS FOR PARTICULAR PURPOSE OF THE PRODUCTS. ANY BUYER OR USER ACKNOWLEDGES THAT THE BUYER OR USER ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. OMRON DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED.

#### LIMITATIONS OF LIABILITY

OMRON SHALL NOT BE RESPONSIBLE FOR SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE, OR STRICT LIABILITY.

In no event shall the responsibility of OMRON for any act exceed the individual price of the product on which liability is asserted.

IN NO EVENT SHALL OMRON BE RESPONSIBLE FOR WARRANTY, REPAIR, OR OTHER CLAIMS REGARDING THE PRODUCTS UNLESS OMRON'S ANALYSIS CONFIRMS THAT THE PRODUCTS WERE PROPERLY HANDLED, STORED, INSTALLED, AND MAINTAINED AND NOT SUBJECT TO CONTAMINATION, ABUSE, MISUSE, OR INAPPROPRIATE MODIFICATION OR REPAIR.

### **Application Considerations**

#### SUITABILITY FOR USE

OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of products in the customer's application or use of the products.

At the customer's request, OMRON will provide applicable third party certification documents identifying ratings and limitations of use that apply to the products. This information by itself is not sufficient for a complete determination of the suitability of the products in combination with the end product, machine, system, or other application or use.

The following are some examples of applications for which particular attention must be given. This is not intended to be an exhaustive list of all possible uses of the products, nor is it intended to imply that the uses listed may be suitable for the products:

- Outdoor use, uses involving potential chemical contamination or electrical interference, or conditions or uses not described in this manual.
- Nuclear energy control systems, combustion systems, railroad systems, aviation systems, medical
  equipment, amusement machines, vehicles, safety equipment, and installations subject to separate
  industry or government regulations.
- Systems, machines, and equipment that could present a risk to life or property.

Please know and observe all prohibitions of use applicable to the products.

NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCTS ARE PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

#### PROGRAMMABLE PRODUCTS

OMRON shall not be responsible for the user's programming of a programmable product, or any consequence thereof.

#### **Disclaimers**

#### CHANGE IN SPECIFICATIONS

Product specifications and accessories may be changed at any time based on improvements and other reasons.

It is our practice to change model numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the products may be changed without any notice. When in doubt, special model numbers may be assigned to fix or establish key specifications for your application on your request. Please consult with your OMRON representative at any time to confirm actual specifications of purchased products.

#### **DIMENSIONS AND WEIGHTS**

Dimensions and weights are nominal and are not to be used for manufacturing purposes, even when tolerances are shown.

#### PERFORMANCE DATA

Performance data given in this manual is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of OMRON's test conditions, and the users must correlate it to actual application requirements. Actual performance is subject to the OMRON Warranty and Limitations of Liability.

#### **ERRORS AND OMISSIONS**

The information in this manual has been carefully checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical, or proofreading errors, or omissions.

Read and Understand this Manual

# **Safety Precautions**

Refer to the following manuals for safety precautions.

- NJ-series CPU Unit Hardware User's Manual (Cat. No. W500)
- NJ-series CPU Unit Software User's Manual (Cat. No. W501)

# **Precautions for Safe Use**

Refer to the following manuals for precautions for correct use.

- NJ-series CPU Unit Hardware User's Manual (Cat. No. W500)
- NJ-series CPU Unit Software User's Manual (Cat. No. W501)

# **Precautions for Correct Use**

Refer to the following manuals for precautions for safe use.

- NJ-series CPU Unit Hardware User's Manual (Cat. No. W500)
- NJ-series CPU Unit Software User's Manual (Cat. No. W501)

# Regulations and Standards

#### **Conformance to EC Directives**

#### **Applicable Directives**

- EMC Directives
- · Low Voltage Directive

#### **Concepts**

#### EMC Directive

OMRON devices that comply with EC Directives also conform to the related EMC standards so that they can be more easily built into other devices or the overall machine. The actual products have been checked for conformity to EMC standards.\*

Whether the products conform to the standards in the system used by the customer, however, must be checked by the customer. EMC-related performance of the OMRON devices that comply with EC Directives will vary depending on the configuration, wiring, and other conditions of the equipment or control panel on which the OMRON devices are installed. The customer must, therefore, perform the final check to confirm that devices and the overall machine conform to EMC standards.

\* Applicable EMC (Electromagnetic Compatibility) standards are as follows: EMS (Electromagnetic Susceptibility): EN 61131-2 and EN 61000-6-2 EMI (Electromagnetic Interference): EN 61131-2 and EN 61000-6-4 (Radiated emission: 10-m regulations)

#### Low Voltage Directive

Always ensure that devices operating at voltages of 50 to 1,000 VAC and 75 to 1,500 VDC meet the required safety standards. The applicable directive is EN 61131-2.

#### Conformance to EC Directives

The NJ-series Controllers comply with EC Directives. To ensure that the machine or device in which the NJ-series Controller is used complies with EC Directives, the Controller must be installed as follows:

- The NJ-series Controller must be installed within a control panel.
- You must use reinforced insulation or double insulation for the DC power supplies connected to DC Power Supply Units and I/O Units.
- NJ-series Controllers that comply with EC Directives also conform to the Common Emission Standard (EN 61000-6-4). Radiated emission characteristics (10-m regulations) may vary depending on the configuration of the control panel used, other devices connected to the control panel, wiring, and other conditions.

You must therefore confirm that the overall machine or equipment complies with EC Directives.

#### **Conformance to Shipbuilding Standards**

The NJ-series Controllers comply with the following shipbuilding standards. Applicability to the shipbuilding standards is based on certain usage conditions. It may not be possible to use the product in some locations. Contact your OMRON representative before attempting to use a Controller on a ship.

#### Usage Conditions for NK and LR Shipbuilding Standards

- The NJ-series Controller must be installed within a control panel.
- · Gaps in the door to the control panel must be completely filled or covered with gaskets or other
- The following noise filter must be connected to the power supply line.

#### **Noise Filter**

Manufacturer	Model
Cosel Co., Ltd.	TAH-06-683

#### **Trademarks**

- Sysmac and SYSMAC are trademarks or registered trademarks of OMRON Corporation in Japan and other countries for OMRON factory automation products.
- · Windows, Windows 98, Windows XP, Windows Vista, and Windows 7 are registered trademarks of Microsoft Corporation in the USA and other countries.
- EtherCAT® is a registered trademark of Beckhoff Automation GmbH for their patented technology.
- The SD logo is a trademark of SD-3C, LLC.



Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.

#### Software Licenses and Copyrights

This product incorporates certain third party software. The license and copyright information associated with this software is available at http://www.fa.omron.co.jp/nj\_info\_e/.

## **Unit Versions**


#### **Unit Versions**

A "unit version" has been introduced to manage CPU Units in the NJ Series according to differences in functionality accompanying Unit upgrades.

#### **Notation of Unit Versions on Products**

The unit version is given on the ID information label of the products for which unit versions are managed, as shown below.

Example for NJ-series NJ501-



Lot number and serial number MAC address

The following information is provided on the ID information label.

Item	Description	
Unit model	del Gives the model of the Unit.	
Unit version	Gives the unit version of the Unit.	
Lot number and	Gives the lot number and serial number of the Unit.	
serial number	DDMYY: Lot number, □: For use by OMRON, xxxx: Serial number	
	"M" gives the month (1 to 9: January to September, X: October, Y: November, Z: December)	
MAC address	address Gives the MAC address of the built-in port on the Unit.	

#### Confirming Unit Versions with Sysmac Studio

You can use the Unit Production Information on the Sysmac Studio to check the unit version of the CPU Unit, CJ-series Special I/O Units, CJ-series CPU Bus Units, and EtherCAT slaves. The unit versions of CJ-series Basic I/O Units cannot be checked from the Sysmac Studio.


#### CPU Unit and CJ-series Units

1 Double-click CPU/Expansion Racks under Configurations and Setup in the Multiview Explorer. Or, right-click CPU/Expansion Racks under Configurations and Setup and select *Edit* from the menu.

The Unit Editor is displayed for the Controller Configurations and Setup layer.

**2** Right-click any open space in the Unit Editor and select **Production Information**.

The Production Information Dialog Box is displayed.





Simple Display

**Detailed Display** 

In this example, "Ver.1.0" is displayed next to the unit model.

The following items are displayed.

CPU Unit	CJ-series Units
Unit model	Unit model
Unit version	Unit version
Lot number	Lot number
	Rack number, slot number, and unit number


#### EtherCAT Slaves

1 Double-click EtherCAT under Configurations and Setup in the Multiview Explorer. Or, right-click EtherCAT under Configurations and Setup and select *Edit* from the menu.

The EtherCAT Configuration Tab Page is displayed for the Controller Configurations and Setup layer.

2 Right-click the master in the EtherCAT Configurations Editing Pane and select Display Production Information.

The Production Information Dialog Box is displayed.



The following items are displayed.

Node address

Type information\*

Serial number

\* If the model number cannot be determined (such as when there is no ESI file), the vendor ID, product code, and revision number are displayed.

#### **Unit Version Notation**

In this manual, unit versions are specified as shown in the following table.

Product nameplate	Notation in this manual	Remarks
"Ver.1.0" or later to the right of the lot number	Unit version 1.0 or later	Unless unit versions are specified, the information in this manual applies to all unit versions.

# **Related Manuals**


The following manuals are related to the NJ-series Controllers. Use these manuals for reference.

Manual name	Cat. No.	Model numbers	Application	Description
NJ-series CPU Unit Hardware User's Manual	W500	NJ501-□□□□	Learning the basic specifications of the NJ-series CPU Units, including introductory information, designing, installation, and maintenance. Mainly hardware information is provided.	An introduction to the entire NJ-series system is provided along with the following information on a Controller built with an NJ501 CPU Unit.  • Features and system configuration  • Introduction  • Part names and functions  • General specifications  • Installation and wiring  • Maintenance and inspection  Use this manual together with the NJ-series CPU Unit Software User's Manual (Cat. No. W501).
NJ-series CPU Unit Soft- ware User's Manual	W501	NJ501-□□□	Learning how to program and set up an NJ-series CPU Unit. Mainly software information is provided.	The following information is provided on a Controller built with an NJ501 CPU Unit.  CPU Unit operation  CPU Unit features  Initial settings  Programming based on IEC 61131-3 language specifications Use this manual together with the NJ-series CPU Unit Hardware User's Manual (Cat. No. W500).
NJ-series CPU Unit Motion Control User's Manual	W507	NJ501-□□□□	Learning about motion control settings and programming concepts.	The settings and operation of the CPU Unit and programming concepts for motion control are described. Use this manual together with the <i>NJ-series CPU Unit Hardware User's Manual</i> (Cat. No. W500) and <i>NJ-series CPU Unit Software User's Manual</i> (Cat. No. W501).
NJ-series Instructions Reference Manual	W502	NJ501-□□□□	Learning about the specifi- cations of the instruction set that is provided by OMRON.	The instructions in the instruction set (IEC 61131-3 specifications) are described. When programming, use this manual together with the NJ-series CPU Unit Hardware User's Manual (Cat. No. W500) and NJ-series CPU Unit Software User's Manual (Cat. No. W501).
NJ-series Motion Control Instructions Reference Manual	W508	NJ501-□□□□	Learning about the specifi- cations of the motion con- trol instructions that are provided by OMRON.	The motion control instructions are described. When programming, use this manual together with the <i>NJ-series CPU Unit Hardware User's Manual</i> (Cat. No. W500), NJ-series CPU Unit Software User's Manual (Cat. No. W501) and <i>NJ-series CPU Unit Motion Control User's Manual</i> (Cat. No. W507).
CJ-series Special Unit Manuals for NJ-series CPU Unit	W490 W498 W499 W491 Z317 W492 W494 W497	CJ1W-	Learning how to use CJ- series Units with an NJ- series CPU Unit.	The methods and precautions for using CJ-series Units with an NJ501 CPU Unit are described, including access methods and programming interfaces. Manuals are available for the following Units.  Analog I/O Units, Insulated-type Analog I/O Units, Temperature Control Units, ID Sensor Units, High-speed Counter Units, Serial Communications Units, and DeviceNet Units.  Use these manuals together with the NJ-series CPU Unit Hardware User's Manual (Cat. No. W500) and NJ-series CPU Unit Software User's Manual (Cat. No. W501).

Manual name	Cat. No.	Model numbers	Application	Description
NJ-series CPU Unit Built- in EtherCAT Port User's Manual	W505	NJ501-□□□	Using the built-in EtherCAT port on an NJ-series CPU Unit.	Information on the built-in EtherCAT port is provided. This manual provides an introduction and provides information on the configuration, features, and setup.  Use this manual together with the <i>NJ-series CPU Unit Hardware User's Manual</i> (Cat. No. W500) and <i>NJ-series CPU Unit Software User's Manual</i> (Cat. No. W501).
NJ-series CPU Unit Built- in EtherNet/IP Port User's Manual	W506	NJ501-□□□	Using the built-in Ether- Net/IP port on an NJ-series CPU Unit.	Information on the built-in EtherNet/IP port is provided. Information is provided on the basic setup, tag data links, and other features.  Use this manual together with the <i>NJ-series CPU Unit Hardware User's Manual</i> (Cat. No. W500) and <i>NJ-series CPU Unit Software User's Manual</i> (Cat. No. W501).
NJ-series Troubleshoot- ing Manual	W503	NJ501-□□□	Learning about the errors that may be detected in an NJ-series Controller.	Concepts on managing errors that may be detected in an NJ-series Controller and information on individual errors are described.  Use this manual together with the NJ-series CPU Unit Hardware User's Manual (Cat. No. W500) and NJ-series CPU Unit Software User's Manual (Cat. No. W501).
Sysmac Studio Version 1 Operation Manual	W504	SYSMAC- SE2□□□	Learning about the operating procedures and functions of the Sysmac Studio.	Describes the operating procedures of the Sysmac Studio.
CX-Integrator CS/CJ/CP/NSJ-series Network Configuration Tool Operation Manual	W464		Learning how to configure networks (data links, rout- ing tables, Communica- tions Unit settings, etc.).	Describes operating procedures for the CX-Integrator.
CX-Designer User's Manual	V099		Learning to create screen data for NS-series Programmable Terminals.	Describes operating procedures for the CX- Designer.
CX-Protocol Operation Manual	W344		Creating data transfer protocols for general-purpose devices connected to CJ-series Serial Communications Units.	Describes operating procedures for the CX-Protocol.

# **Revision History**

A manual revision code appears as a suffix to the catalog number on the front and back covers of the manual.



Revision code	Date	Revised content
01	July 2011	Original production

**Revision History** 



# **Introduction to Motion Control Instructions**

This section gives an introduction to motion control instructions supported by NJ-series CPU Units.

I <b>-1</b>	<b>Motion Control Instructions</b>	1	1-2
<b>I-2</b>	Basic Information on Motion	Control Instructions	1-9

#### **Motion Control Instructions** 1-1

Motion control instructions are used in the user program to execute motion controls for an NJ-series Controller. These instructions are defined as function blocks.

The motion control instructions of the MC Function Module are based on the technical specifications of function blocks for PLCopen motion control.

There are two types of motion control instructions: PLCopen-defined instructions and instructions that are unique to the MC Function Module. This section provides an overview of the PLCopen motion control function blocks and motion control instructions.

For details on motion control instructions, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

#### **Function Blocks for PLCopen Motion Control**

PLCopen standardizes motion control function blocks to define a program interface for the languages specified in IEC 61131-3 (JIS B 3503). Single-axis positioning, electronic cams, and multi-axis coordinated control are defined along with basic procedures for executing instructions.

By using PLCopen motion control function blocks, programming can be more easily reused without hardware dependence. Costs for training and support are also reduced.



#### **Additional Information**

#### **PLCopen**

PLCopen is a promotion body for IEC 61131-3 that has its headquarters in Europe and a worldwide membership structure. IEC 61131-3 is an international standard for PLC programming. PLCopen Japan is the promotion committee for the Japanese market and consists of members that have concerns related to the Japanese market.

• The website of headquarters of PLCopen in Europe is http://www.plcopen.org/.

#### **Overview of Motion Control Instructions**

This section describes items defined in the technical specifications of function blocks for PLCopen motion control and provides an overview of their application in the MC Function Module.

#### Types of Motion Control Instructions

The following table list the different types of motion control instructions.

Classification	Туре	Functional group	Description
Instructions for com-	Common administra-	Cam tables	These instructions are used to control the common status of the MC Function Module, and to manipulate and monitor data.
mon commands	tion instructions	Parameters	
Instructions for axis commands	Single-axis motion instructions	Single-axis position control	These instructions move single axes.
		Single-axis velocity control	
		Single-axis torque control	
		Single-axis synchro- nized control	
		Single-axis manual operation	
	Single-axis adminis- tration instructions	Auxiliary functions for single-axis control	This instructions control or monitor axis status.
Instructions for axes group commands	Multi-axis motion instructions	Multi-axes coordinated control	These instructions perform coordinated movement of an axes group.
	Multi-axis administra- tion instructions	Auxiliary functions for multi-axes coordinated control	These instructions control or monitor axes group status.

#### **State Transitions**

State transitions are defined for axes, axes groups, and instruction execution. For details on the state and state transitions of the MC Function Module, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### **Execution and Status of Motion Control Instructions**

Variables that start instruction execution or that indicate the execution status are defined as common rules for the instructions. There are two input variables that start instruction execution: *Execute* and *Enable*. The output variables that indicate the execution status of an instruction include *Busy, Done, CommandAborted*, and *Error*.

For detailed specifications of the MC Function Module, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).



#### **Precautions for Correct Use**

The timing in the timing charts that are given in this manual may not necessarily be the same as the timing displayed for data traces on the Sysmac Studio.

Refer to the *NJ-series CPU Unit Software User's Manual* (Cat. No. W501) for details on data tracing.

#### Error Processing

You execute motion control instructions to implement motion control with the MC Function Module. When motion control instructions are executed, input parameters and instruction processing are checked for errors. If an error occurs in an instruction, the Error output variable from the instruction changes to TRUE and an error code is output to ErrorID output variable.


There are two ways that you can use to program processing of errors for motion control instructions.

#### Error Processing for Individual Instructions

You can use the Error and ErrorID output variables from the instruction to process errors that occur for each instruction.

The following example shows how to determine if an Illegal Axis Specification occurs for the instruction with the instance name PWR1. The instructions are programmed so that error processing is executed if NoAxisErr changes to TRUE.

Turning ON the Servo



Checking to See If the Specified Axis Exists


```
Pwr1_Err
                                              FΩ
                                                                                         NoAxisErr
                                                   EQ
   \dashv \vdash
                         Pwr1_ErrID -
                                         In1
                       WORD#5460 -
                                        In2
                                         In3
                                         In4
                                         In5
```

#### Error Processing for Different Types of Errors

You can use the error status that is provided by the system-defined variables for motion control to process each type of error separately.

The following example shows how to determine if a Slave Communications Error occurs for the axis that is called MC\_Axis000. The instructions are programmed so that error processing is executed if ConnectErr changes to TRUE.

Checking for Communications Errors between the CPU Unit and Servo Drive



# Changing Input Variables during Execution of Motion Control Instructions (Restarting Instructions)

If the values of the input variables to an instruction instance are changed while the motion control instruction is under execution and then *Execute* is changed to TRUE again, operation will follow the new values.

For details on re-execution of MC Function Module instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### Multi-execution of Instructions with BufferMode

A different instruction instance can be executed during axis motion. You can specify when a motion starts by setting an input variable called *BufferMode*. The following Buffer Modes are supported for *BufferMode*.

- Aborting: Abort (Aborting)
- Buffered: Standby (Buffered)
- Blending Low: Blending with the low velocity (*BlendingLow*)
- Blending Previous: Blending with the previous velocity (BlendingPrevious)
- · Blending Next: Blending with the next velocity (BlendingNext)
- Blending High: Blending with the high velocity (BlendingHigh)

In Aborting Mode, other motions are aborted and the function block is executed immediately. In other modes, the next instruction waits until an output variable such as *Done* or *InVelocity* from the currently executed instruction changes to TRUE. For *Buffered*, the next instruction is executed after the current instruction is executed and *Done* changes to TRUE. For the blending modes, two instruction motions are executed consecutively without pausing. The transition velocity between the two motions is selected from four modes.

For the MC Function Module, BufferMode is also referred to as multi-execution of instructions.

For details on multi-execution of instructions for the MC Function Module, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### **Structures Used for Motion Control**

Information required for motion control are defined as structures in PLCopen technical materials. Data type names and basic aspects are defined, but the contents of the structures are not defined.

The main data types defined in PLCopen and the data types used in the MC Function Module are shown in the following table.

Data type		Definition	
PLCopen	MC Function Module	Delinition	
AXIS_REF	_sAXIS_REF	This is a structure that contains information on the corresponding axis.	
AXES_GROUP_REF	_sGROUP_REF	This is a structure that contains information on the corresponding axes group.	
TRIGGER_REF	_sTRIGGER_REF	This is a structure that contains information on trigger inputs.	
		Trigger specifications	
		Detection pattern information (positive, negative, both, edge, level, pattern recognition, etc.)	
INPUT_REF		This is a structure that contains information relating to the input specifications. It may include virtual data. This data type is not used by the MC Function Module.	
OUTPUT_REF		This is a structure relating to physical outputs. This data type is not used by the MC Function Module.	

As shown in the above table, the MC Function Module uses some data types that are defined by PLCopen and some that are defined specifically for the MC Function Module.

Refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507) for definitions of the data types and structures that are handled by the MC Motion Module.

# **Precautions for Master and Auxiliary Axes in Synchronized Control**

Precautions that are related to sudden changes in velocity and conditions that lead to errors are given below for master and auxiliary axes in synchronized control.

# **Sudden Changes in Velocity**

When the velocity of the master or auxiliary axis changes suddenly when synchronized motion is started or during synchronized motion, the motion of the slave axis can change suddenly and sometimes place an excessive load on the machine. Take suitable precautions in the following cases because the velocity of the master or auxiliary axis may change suddenly.

- When one of the following four instructions is executed for the master or auxiliary axis:
  - MC\_ImmediateStop instruction
  - MC SetPosition instruction
  - MC ResetFollowingError instruction
  - MC SyncMoveVelocity (Cyclic Synchronous Velocity Control) instruction

To ensure that the slave axis does not move suddenly, set suitable input parameters and execution timing for the above instructions or execute them after synchronized control has been released.

- When the immediate stop input signal or limit stop input signal changes to TRUE for the master or auxiliary axis
- · When the Servo turns OFF for the master or auxiliary axis

When the Servo is turned OFF when the master or auxiliary axis is a vertical axis, the position of the axis may change suddenly. Take suitable measures to prevent the slave axis from moving suddenly, such as applying a brake to the master or auxiliary axis or turning OFF the Servo after synchronized control has been released.

When you change the control mode of the Servo Drive

Take suitable precautions for changes in the velocity when an instruction is executed. Set suitable input parameters for the instruction.

# **Conditions That Lead to Errors**

When any of the following four conditions occurs for the master or auxiliary axis when synchronized motion is started or during synchronized motion, a Master Axis Position Read Error or Auxiliary Axis Position Read Error occurs for the slave axis.

The *CommandAborted* output variable from the synchronized control instruction changes to TRUE at the same time.

- EtherCAT process data communications are not established.
- An EtherCAT Slave Communications Error occurs while EtherCAT communications are not established.
- An Absolute Encoder Current Position Calculation Failed error occurs.
- · The slave is disconnected.

The following occur if multi-execution of instructions is used for the synchronized control instruction for the slave axis.

- Even if the master or auxiliary axis is in one of the four conditions given above, multi-execution of instructions is acknowledged normally and the instruction is buffered.
- The motion for the buffered instruction is started as normal if none of the above four conditions exist.



# **Additional Information**

If the MC\_Home instruction is executed for the master or auxiliary axis or if the MC\_Power instruction is executed for an axis that uses an absolute encoder, the slave ignores the changes in position of the master or auxiliary axis. Therefore, the slave axis does not move suddenly when defining home.

# 1-2 Basic Information on Motion Control Instructions

This section describes basic specifications and restrictions for programming with motion control instructions for the MC Function Module built into the CPU Unit. For details on motion control instructions, refer to SECTION 3 Axis Command Instructions, Section 4 Axes Group Instructions, and Section 5 Common Command Instructions.

# **Motion Control Instruction Names**

All motion control instructions for the MC Function Module begin with "MC".

To see whether an instruction is defined by PLCopen or whether it is an instruction defined for the MC Function Module itself, refer to 2-1 Variables.

# **Languages for Motion Control Instructions**


Motion control instructions of the MC Function Module can be used in the following programming languages.

- Ladder diagrams (LD)
- Structured text (ST)

# Ladder Diagrams (LD)

Instruction instances of motion control instructions are located in ladder diagrams. The instruction instances can be named.

The following example shows the MC\_MoveAbsolute (Absolute Positioning) instruction.



- The axis variable name of the Servo Drive to control is specified with the in-out variable Axis.
- Motion conditions, such as the target position or target velocity, are specified with input variables.
- The status of the instruction or the status of the Servo Drive is output with output variables.
- If input parameters are omitted, input variables are set to default values.
- When you program in a ladder diagram, insert an input between the *Execute* or *Enable* input variable and the left bus bar. If the instruction is connected directly to the left bus bar without an input, an error occurs when the program is built.

# **Structured Text (ST)**

The instruction instance name is specified. Instruction variables are written from upper left to lower left, then upper right to lower right. The following example shows MC\_MoveAbsolute (Absolute Positioning).

```
MC_ABS_instance(
   Axis := MC Axis001,
   Execute := PTP_Absolute,
   Position := PTP Position,
   Velocity := PTP_Velocity,
   Acceleration := PTP_Acc,
   Deceleration := PTP Dec,
   Jerk := PTP_Jerk ,
   Direction := _mcNoDirection ,
   BufferMode := _mcAborting ,
   Axis => MC_Axis001,
   Done => PTP_Done
   );
```

## **Motion Control Instruction Locations**

This section describes the tasks in which motion control instructions can be located, and the differences in operation that can occur for different locations in the user program.

# Task Types

Motion control instructions can be used in the primary periodic task and in a periodic task with an execution priority of 16 (called a priority 16 periodic task).

Task type	Applicable?
Primary periodic task	ОК
Periodic task (execution priority: 16)	ОК
Periodic task (execution priority: 17)	No
Periodic task (execution priority: 18)	No

You can place motion control instructions both in the primary periodic task and in the priority-16 periodic task.

# **Function Block Definitions**

You can also use motion control instructions in user-defined function block definitions.




#### **Additional Information**

Design efficiency is improved through program structuring, and program visibility is improved if a process with multiple operations is treated as a single function block.

# **Master Control Regions**

The area in a ladder diagram between the Master Control Start instruction (MC) and the Master Control End instruction (MCR) is the master control region.





If a motion control instruction is located in the master control region, and the MC input condition is FALSE, the following will occur.

- Motion control instructions for which input variable *Enable* or *Execute* is connected directly to the left bus bar are executed with a FALSE value for *Enable* or *Execute*.
- Inline ST sections are executed normally.
- The values of the output parameters are updated as normal even when the *Enable* or *Execute* input variables to the motion control instructions are FALSE.

## Enable-type Motion Control Instructions


- Instructions located in master control regions are equivalent to the programming shown on the right in the following figure.
- When G0 is TRUE, MC\_Power is executed normally.
- When G0 is FALSE, MC\_Power is executed as if the Enable input variable was FALSE.





# Execute-type Motion Control Instructions

- Instructions located in master control regions are equivalent to the programming shown on the right in the following figure.
- When G0 is TRUE, MC MoveRelative is executed normally.
- When G0 is FALSE, MC MoveRelative is executed as if the Execute input variable was FALSE.
- Instructions executed when G0 is TRUE continue operation until completion, even if G0 changes to FALSE during operation. The values of output parameters are also updated in the normal way.



## **Precautions for Correct Use**

Execute-type motion control instructions are executed when G0 changes to TRUE. It is not recommended to use them in the master control region. If they must be used, be careful of the operation.



#### **Additional Information**

. The function of the MC (Master Control Start) instruction is disabled in ST. All instructions in ST are executed normally.

For details on the MC and MCR instructions, refer to the NJ-series Instructions Reference Manual (Cat. No. W502).

# **Motion Control Instructions in ST Structure Instructions**

This section describes the operation of motion control instructions when they are located in ST structures, such as IF, CASE, WHILE, or REPEAT structures.

When the evaluation result for the condition expression of an ST structure instruction is FALSE, the motion control instructions within the structure are executed as if the Enable or Execute input variable is FALSE.

If execution of an execute-type instruction is started and then the evaluation result changes to FALSE, processing is continued until it completed. In that case, however, the values of the output variables are not updated.



#### **Precautions for Correct Use**

The execution status of an execute-type instruction in an ST structure will not be clear if the evaluation result of the condition expression changes to FALSE during execution of the instruction. We therefore do not recommend using execution-type instructions in ST structures. If they must be used, be careful of the operation.



#### **Additional Information**

To switch the execution of an execute-type instruction with the condition expression, place only the Execute input parameter in the ST structure. Place the execute-type instruction itself outside of the ST structure.

For details on the ST structure instructions, refer to the NJ-series Instructions Reference Manual (Cat. No. W502).

# Treatment of REAL and LREAL Data

REAL and LREAL are floating-point decimal data types. This section describes how they are expressed and processed.

## REAL and LREAL Data Sizes


The data sizes of REAL data and LREAL data are different. REAL data has 32 bits and LREAL data has 64 bits.

## Floating-point Decimal Data Format

A real number in floating-point decimal format is expressed using a sign, exponent, and mantissa. When a real number is substituted in the following formulas, the value corresponding to 's' becomes the sign, 'e' the exponent, and 'f' the mantissa.

- REAL Data Number =  $(-1)^{2}e^{-127}(1 + f \times 2^{-23})$
- LREAL Data Number =  $(-1)^{s}2^{e-1023}(1 + f \times 2^{-52})$

The floating-point data format conforms to the IEEE754 standards. The following formats are used.



# Example: Expressing –86.625 as REAL Data

Setting the Sign

The number is negative, so s = 1.

**2** Binary Expression

The number 86.625 is 1010110.101 as a binary number.

**3** Normalized Binary Expression

When the above number is normalized, it becomes  $1.010110101 \times 2^6$ .

**4** Exponent Expression

From the previous equation, e-127 = 6. Therefore e = 133. The number 133 is 10000101 as a binary number. This expresses the exponent.

**5** Mantissa Expression

Numbers following the decimal point in 1.010110101 are 010110101. This number is expressed using 23 bits, but here there are insufficient digits. Therefore zeros are added. The 23-bit figure 


Therefore, –86.625 is expressed as shown in the following figure.

	Sign	Expone	nt	Mantissa	
REAL data (32 bits)	1	100001	01	010110101000000000000000	0
	31	30	23	22	0

## Valid Ranges

The valid ranges of REAL and LREAL are shown in the following table.

Data type	-∞	Negative numbers	0	Positive number	+∞
REAL	-∞	-3.402823e+38 to -1.175494e-38	0	+1.175494e-38 to +3.402823e+38	+∞
LREAL	-∞	-1.79769313486231e+308 to -2.22507385850720e-308	0	+2.22507385850720e-308 to +1.79769313486231e+308	+∞



# Special Numbers

Positive infinity, negative infinity, +0, -0, and nonnumeric data are called special numbers. Nonnumeric data is data that cannot be expressed in floating-point decimal format. They are not treated as numbers. Mathematically, +0 and -0 both mean the same as 0, but in data processing it is treated differently.

A detailed explanation is given later. The sign 's', exponent 'e', and mantissa 'f' for special numbers take on the following values.

Data type	Special number	Sign s	Exponent e	Mantissa f
REAL	+∞	0	255	0
	-∞	1	255	0
	+0	0	0	0
	-0	1	0	0
	Nonnumeric data		255	Not 0
LREAL	+∞	0	2047	0
	-∞	1	2047	0
	+0	0	0	0
	-0	1	0	0
	Nonnumeric data		2047	Not 0

#### Subnormal Numbers

Numbers that are very close to 0 (with very small absolute values) cannot be expressed using the floating-point decimal format. Subnormal numbers were introduced to expand the validity of numbers near 0. Subnormal numbers can be used to express numbers whose absolute values are smaller than numbers expressed in the normal data format.



## **Additional Information**

Values expressed in the normal data format are called normalized numbers or normal numbers.

Numbers with exponent e=0 and mantissa f ≠ 0 are considered subnormal numbers and their values are expressed in the following manner.

 REAL Data Number =  $(-1)^{s}2^{-126}$ (f × 2<sup>-23</sup>)

 LREAL Data Number =  $(-1)^{s}2^{-1022}(f \times 2^{-52})$ 

# Example: Expressing 0.75 x 2<sup>-127</sup> as REAL Data

1 Setting the Sign The number is positive, so s = 0.

**2** Binary Expression

The number 0.75 is 0.11 as a binary number.

**3** Mantissa Calculation From  $(0.11)_2 \times 2^{-127} = 2^{-126} (f \times 2^{-23}), f = (0.11)_2 \times 2^{22}$ .

4 Mantissa Expression

Therefore,  $0.75 \times 2^{-127}$  is expressed as shown in the following figure.

Subnormal numbers have fewer effective digits than normalized numbers. Therefore, if the calculation of a normalized number results in an subnormal number, or if an intermediate result is an subnormal number, the number of effective digits of the calculated result may be less than that of the normalized number.

## Data Processing

The floating-point decimal format is an approximate expression of a value, with a slight error from the actual value. There is a limit to the valid range of the value. For these reasons, the following process should be used for calculation.

## Rounding

If the actual value exceeds the effective digits of the mantissa, the value must be rounded according to the following rules.

- Of the values that can be expressed in floating-point decimal format, the value that is closest to the actual value is taken as the calculation result.
- If there are two values that are equally close to the actual value that can be expressed in floatingpoint decimal format, the value with the lowest significant 0 bit is taken as the calculation result. When there are two values that are equally close to the actual value, the actual value is exactly in the middle of the two values.

#### Overflows and Underflows

When the true absolute value exceeds the values that can be expressed by a floating-point data type, it is called an overflow. On the other hand, if the value is smaller than the values that can be expressed by a floating-point decimal data type, it is called an underflow.

- If the sign of the true value is positive, the processing result will be positive infinity when an overflow occurs. If the sign of the true value is negative, the processing result will be negative infinity when an overflow occurs.
- If the sign of the true value is positive, the processing result will be +0 when an underflow occurs. If the sign of the true value is negative, the processing result will be -0 when an overflow occurs.

# **Calculating with Special Numbers**

The following rules apply when calculating with special numbers. For details on special values, refer to *Special Numbers* on page 1-15.

- Adding positive infinity and negative infinity results in nonnumeric data.
- Subtracting infinity from infinity with the same signs results in nonnumeric data.
- Multiplying +0 by infinity or -0 by infinity results in nonnumeric data.
- Dividing +0 by +0, -0 by -0, or infinity by infinity results in nonnumeric data.
- Adding +0 and -0 results in +0.
- Subtracting +0 from +0, or -0 from -0 results in +0.
- · Basic arithmetic operations including nonnumeric data results in nonnumeric data.
- Comparison instructions such as the CMP instruction treat +0 and -0 as the same value.
- If a nonnumeric number is included in a comparison, the comparison instruction always returns "not equal."




#### **Precautions for Correct Use**

Floating-point decimal (LREAL) variables are used to set electronic gears, target positions, and other parameters of motion control instructions in the MC Function Module. For this reason, calculation results contain rounding errors. For example, if the MC\_MoveRelative (Relative Positioning) instruction is repeatedly executed, following error will accumulate. If the accumulated error becomes a problem, set the command unit to pulses, or specify an absolute position with the MC\_MoveAbsolute (Absolute Positioning) instruction.

# **Multi-execution of Motion Control Instructions**

This section describes executing multiple motion control instructions for the same axis within the same task period.

- In the following programming, instruction instances Move1 and Move2 start in the same task period when bit a turns ON.
- Instructions in a program are executed from the top. Therefore Move1 is started first, and then Move2 is started before Move1 is finished.
- This is considered multi-execution of motion control instructions (BufferMode). In this example, Blending is used to execute Move2 in relation to Move1.




For details on multi-execution of motion control instructions, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).



#### **Additional Information**

If the MC\_SetOverride (Set Override Factors) instruction is executed simultaneously in the same way as the instructions shown above, the override value is valid even when it is placed on the bottom. When different override values are set with the MC SetOverride (Set Override Factors) instruction, the following type of programming is recommended.



# **Online Editing of Motion Control Instructions**

You can perform the following online editing operations for motion control instructions from the Sysmac Studio.

Online editing operations				
Deleting motion control instructions				
Adding motion control instructions				
Adding input variables, output variables, and in-out variables to motion control instructions				
Changing input variables, output variables, and in-out variables in motion control instructions				
Deleting input variables, output variables, and in-out variables in motion control instructions.				



## **Precautions for Correct Use**

If instructions to stop the axis motion, such as MC\_Stop or MC\_GroupStop, are deleted while the axis is still moving, the axis may not stop depending on the contents of the user program. Make sure that it is safe to use the online editing before using it for motion control instructions.

# **Changes in the Operating Mode of the CPU Unit**

An NJ-series CPU Unit has two operating modes: PROGRAM mode and RUN mode. This section describes the operation of the MC Function Module when the operating mode changes.

# **Changes from RUN Mode to PROGRAM Mode**

- The motion control instruction that is under execution will be aborted. The *CommandAborted* output variable remains FALSE, but the operation is the same as when *CommandAborted* is TRUE.
- If the axis is moving, it will decelerate to a stop at the maximum deceleration. The Servo ON/OFF status will continue.
- If saving the cam table is in progress for the Cam Table Save instruction, the save operation contin-
- Motion control instructions located in a priority 16 periodic task perform the above process after the END instruction in the task is executed.

# Changes from PROGRAM Mode to RUN Mode

- The output variables of the motion control instructions are cleared.
- The axis decelerates to a stop when the mode changes from RUN mode to PROGRAM mode. If the operating mode is changed back to RUN mode while the axis is decelerating, the output variables from the motion control instruction are cleared. Therefore, CommandAborted of the motion control instruction that was under execution remains FALSE.



## **Additional Information**

- To enable accessing output variables for motion control instructions even after the operating mode changes, assign variables that have output parameters with a Retain attribute. By accessing the assigned output parameter, you can access the output variable immediately before the operating mode changes.
- The Servo ON/OFF status will continue even if the mode is changed.



# **Variables and Instructions**

This section describes the variables and instructions for the Motion Control Function Module.

2-1	Variables	. 2-2
2-2	Instructions	2-24
2-3	PDO Mapping	2-27

#### **Variables** 2-1

There are two types of variables for the MC Function Module.

The first type is system-defined variables, which you use to monitor axis status and some of the parameter settings. System-defined variables that are used by the MC Function Module are called systemdefined variables for motion control.

The second type is variables that are used to input arguments to motion control instructions and to output execution status from motion control instructions. Some input variables to motion control instruction are enumerated variables. With enumerated variables, selections are made from a set of enumerators. This section describes the variable types, the valid ranges of motion control instruction input variables, and the enumerated variables.

## System-defined Variables for Motion Control

Level 1	Level 2	Level 3	Description
System-defined variables	Device variables	MC Common variable	You can monitor the overall status of the MC Function Module.
		Axis Variables	You can monitor axis status and the settings of part of the axis parameters.
		Axes Group Variable	You can monitor axes group status and the settings of part of the axes group parameters.

For details on system-defined variables for motion control, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

#### Variables for Motion Control Instructions

Туре	Outline
Input variables	Instruction arguments
Output variables	Instruction execution status monitoring information
In-out variables	Specify data to process with the instruction



## **Additional Information**

- Data types that start with "\_e" are enumerations.
- Data types that start with "\_s" are structures.

For details on the data types that are handled by the MC Function Module, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

# **MC Common Variables**

The variable name \_*MC\_COM* is used for the MC Common Variables. The data type is \_sCOMMON\_REF, which is a structure. This section describes the configuration of the MC common variables and provides details on the members.

	Name	Data type	Meaning	Function
1C_C	MC	_sCOMMON_REF	MC Common Variable	
Sta	tus	_sCOMMON_REF_STA	MC Common Status	
	RunMode	BOOL	MC Run	TRUE during MC Function Module operation.
	TestMode	BOOL	MC Test Run	TRUE during test mode operation from the Sysmac Studio.
	CamTableBusy	BOOL	Cam Table Busy	TRUE while the Cam Table is being saved or on standby.
PFa	aultLvl	_sMC_REF_EVENT	MC Common Partial Fault	
	Active	BOOL	MC Common Partial Fault Active	TRUE while there is an MC common partial fault.
	Code	WORD	MC Common Partial Fault Code	Contains the code for an MC common partial fault. The upper four digits of the event code have the same value.
MF	aultLvl	_sMC_REF_EVENT	MC Common Minor Fault	
	Active	BOOL	MC Common Minor Fault Active	TRUE while there is an MC common minor fault.
	Code	WORD	MC Common Minor Fault Code	Contains the code for an MC common minor fault. The upper four digits of the event code have the same value.
Obs	sr	_sMC_REF_EVENT	MC Common Observation	
	Active	BOOL	MC Common Observation Active	TRUE while there is an MC common observation.
	Code	WORD	MC Common Observation Code	Contains the code for an MC common observation. The upper four digits of the event code have the same value.

# **Axis Variables**

The variable names of the system-defined axis Variables are \_MC\_AX[0..63]. The data type is \_sAXIS\_REF, which is a structure. This section describes the configuration of the Axis Variables and provides details on the members.

Name	Data type	Meaning	Function
_MC_AX[063]	_sAXIS_REF	Axis Variable	
Status	_sAXIS_REF_STA	Axis Status	
Ready	BOOL	Axis Ready-to-execute	TRUE when preparations for axis execution are finished and the axis is stopped. This variable gives the same status as _MC_AX[XX].Status.Standstill (TRUE: stopped).
Disabled	BOOL	Axis Disabled	TRUE while the Servo is OFF for the axis. This includes the following status. The following axis status are mutually exclusive. Only one of them can be TRUE at a time.
			Disabled, Standstill, Discrete, Continuous, Synchronized, Homing, Stopping, ErrorStop, and Coordinated
Standstill	BOOL	Standstill	TRUE while the Servo is ON for the axis.
Discrete	BOOL	Discrete Motion	TRUE while position control is executed toward the target position. This includes when the velocity is 0 because the override factor was set to 0 during a discrete motion.
Continuous	BOOL	Continuous Motion	TRUE during continuous motion without a target position. This state exists during velocity control and torque control. This includes when the velocity is 0 because the target velocity is set to 0 and when the velocity is 0 due to an override factor set to 0 during continuous motion.
Synchronized	BOOL	Synchronized Motion	TRUE during execution of synchronized control. This includes waiting for synchronization after changing to synchronized control instructions.
Homing	BOOL	Homing	TRUE when homing for the MC_Home instruction.
Stopping	BOOL	Deceleration Stopping	TRUE until the axis stops for a MC_Stop or MC_TouchProbe instruction. This includes when Execute is TRUE after the axis stops for an MC_Stop instruction. Axis motion instructions are not executed while decelerating to a stop. (CommandAborted is TRUE.)
ErrorStop	BOOL	Error Deceleration Stopping	This status exists when the axis is stopping or stopped for execution of the MC_ImdediateStop instruction or a minor fault (while _MC_AX[XX].MFaultLvI.Active is TRUE (Axis Minor Fault Active).  Axis motion instructions are not executed in this state (CommandAborted = TRUE).
Coordinated	BOOL	Coordinated Motion	TRUE when an axes group is enabled by a multi-axis coordinated control instruction.

	Name	Data type	Meaning	Function
Details .		_sAXIS_REF_DET	Axis Control Status*1	
	Idle	BOOL	Idle	TRUE when processing is not currently performed for the command value, except when waiting for in-position state.*2  Idle and InPosWaiting are mutually exclusive. They cannot both be TRUE at the same time.
	InPosWaiting	BOOL	In-position Waiting	TRUE when waiting for in-position state. The position check is performed when positioning the in-position check.
	Homed	BOOL	Home Defined	TRUE when home is defined. TRUE: Home defined. FALSE: Home not defined.
	InHome	BOOL	In Home Position	TRUE when the axis is in the range for home gives an AND of the following conditions.  • Home defined  • The actual current position is in the zero potion range with home as the center.  TRUE also when the zero position is passed while the axis is moving in command status.
	VelLimit	BOOL	Command Velocity Limit	TRUE while the axis velocity is held to the mamum velocity during synchronized control.
Dir		_sAXIS_REF_DIR	Command Direction*3	
	Posi	BOOL	Positive Direction	TRUE when there is a command in the positir direction.
	Nega	BOOL	Negative Direction	TRUE when there is a command in the negat direction.
Drv	Status	_sAXIS_REF_STA_DRV	Servo Drive Status*4	
	ServoOn	BOOL	Servo ON	TRUE when the Servomotor is powered.
	Ready	BOOL	Servo Ready	TRUE when the Servo is ready.
	MainPower	BOOL	Main Power	TRUE when the Servo Drive main power is C
	P_OT	BOOL	Positive Limit Input	TRUE when the positive limit input is enabled
	N_OT	BOOL	Negative Limit Input	TRUE when the negative limit input is enable
	HomeSw	BOOL	Home Proximity Input	TRUE when the home proximity input is enabled.
	Home	BOOL	Home Input	TRUE when the home input is enabled.*5
	ImdStop	BOOL	Immediate Stop Input	TRUE when the immediate stop input is enabled.
	Latch1	BOOL	External latch input 1	TRUE when latch input 1 is enabled.
	Latch2	BOOL	External latch input 2	TRUE when latch input 2 is enabled.
	DrvAlarm	BOOL	Drive Error Input	TRUE while there is a Servo Drive error.
	DrvWarning	BOOL	Drive Warning Input	TRUE while there is a Servo Drive warning.
	ILA	BOOL	Drive Internal Limiting	TRUE when the Servo Drive limiting function actually limits the axis. This corresponds to o of the following limits in the G5-series.*6 Torque limit Velocity limit Drive prohibit input Software limits
	CSP	BOOL	Cyclic Synchronous Position (CSP) Mode	TRUE when the Servo is ON at the Servo Dri and the current mode is CSP Mode.*7

	Name	Data type	Meaning	Function
	CSV	BOOL	Cyclic Synchronous Velocity (CSV) Mode	TRUE when the Servo is ON at the Servo Driv and the current mode is CSV Mode.*7
Ē	CST	BOOL	Cyclic Synchronous Torque (CST) Mode	TRUE when the Servo is ON at the Servo Drivand the current mode is CST Mode.*7
Cmc	t	_sAXIS_REF_CMD_ DATA	Axis Command Value	
	Pos	LREAL	Command Current Position	Contains the current value of the command potion. (Unit: command units) When the Servo is OFF and the mode is not position control mode, this variable contains the actual current position.
	Vel	LREAL	Command Current Velocity	Contains the current value of the command velocity. (Unit: command units/s) A plus sign is added when traveling in the positive direction, and a minus sign when traveling the negative direction. The velocity is calculate from the difference with the command current position. When the Servo is OFF and the modis not the position control mode, the velocity is calculated based on the actual current position.
	AccDec	LREAL	Command Current Acceleration/Decelera- tion	Contains the current value of the command acceleration/deceleration rate. (Unit: comman units/s²) The acceleration/deceleration rate is calculate from the difference with the command current velocity. A plus sign is added for acceleration, and a minus sign is added for deceleration. Ze when the command acceleration/deceleration rate of the instruction under execution is 0.
	Jerk	LREAL	Command Current Jerk	Contains the current value of the command je (Unit: command units/s³)  A plus sign is added when the absolute value acceleration/deceleration is increasing, and a minus sign is added when it is decreasing. Ze when the command acceleration/deceleration rate and command jerk of the instruction under execution is 0.
-	Trq	LREAL	Command Current Torque	Contains the current value of the command torque. (Unit: %) A plus sign is added when traveling in the postive direction, and a minus sign when traveling the negative direction. Contains the same val as the actual current torque except in torque control mode.
Act		_sAXIS_REF_ACT_DATA	Axis Current Value	
	Pos	LREAL	Actual Current Position	Contains the actual current position. (Unit: co mand units)
-	Vel	LREAL	Actual Current Velocity	Contains the actual current velocity. (Unit: cormand units/s) A plus sign is added when traveling in the postive direction, and a minus sign when traveling the negative direction.
-	Trq	LREAL	Actual Current Torque	Contains the current value of the actual torque (Unit: %) A plus sign is added when traveling in the postive direction, and a minus sign when traveling the negative direction.
MFa	ultLvl	_sMC_REF_EVENT	Axis Minor Fault	
ſ	Active	BOOL	Axis Minor Fault Active	TRUE while there is an axis minor fault.
=	Code	WORD	Axis Minor Fault Code	Contains the code for an axis minor fault. The upper four digits of the event code have the same value.

	Name	Data type	Meaning	Function
Obsr		_sMC_REF_EVENT	Axis Observation	
1	Active	BOOL	Axis Observation Active	TRUE while there is an axis observation.
(	Code	WORD	Axis Observation Code	Contains the code for an axis observation. The upper four digits of the event code have the same value.
Cfg		_sAXIS_REF_CFG	Axis Basic Settings*8	
,	AxNo	UINT	Axis Number	Contains the logical number of the axis. This number is accessed to recognize the axis number when accessing _sAXIS_REF.
1	AxEnable	_eMC_AXIS_USE	Axis Use	Shows if the axis is enabled or disabled.
				0: _mcNoneAxis (Undefined Axis)
				1: _mcUnusedAxis (Unused Axis)
				2: _mcUsedAxis (Used Axis)
1	АхТуре	_eMC_AXIS_TYPE	Axis Type	Contains the axis type. I/O wiring is not required for virtual axes.
				0: _mcServo (Servo Axis)
				1: _mcEncdr (Encoder Axis)
				2: _mcVirServo (Virtual Servo Axis)
				3: _mcVirEncdr (Virtual Encoder Axis)
1	NodeAddress	UINT	Node Address	Contains the EtherCAT slave address. A value of 16#FFFF indicates that there is no address.
Scale	)	_sAXIS_REF_SCALE	Unit Conversion Settings	*9
1	Num	UDINT	Command Pulse Count Per Motor Rotation	Contains the number of pulses per motor rotation for command positions.  The command value is converted to a number of pulses based on the electronic gear ratio.
Ī	Den	LREAL	Work Travel Distance Per Motor Rotation	Contains the workpiece travel distance per motor rotation for command positions.
ι	Units	_eMC_UNITS	Display Unit	Contains the display unit for command positions.
				0: _mcPls(pulse)
				1: _mcMm(mm)
				2: _mcUm(μm)
				3: _mcNm(nm)
				4: _mcDeg(degree)
				5: _mcInch(inch)

<sup>\*1</sup> Gives the control status of the command.

- \*3 Gives the command travel direction.
- \*4 Gives the status of the Servo Drive.
- \*5 This variable shows the status of the signal that is set for the Encoder Phase Z Detection setting of the digital inputs in the Detailed Settings Area of the Axis Basic Settings Display of the Sysmac Studio. You may not be able to map this signal to a PDO for a servo driver from another manufacturer. Refer to the manual for the servo driver.
- \*6 This variable shows the status of bit 11(internal limit active) of the Status word (6041 hex) mapped to a PDO. The condition for it to change to TRUE depends on the specifications of the Servo Drive. Refer to the manual for the servo driver.
- \*7 These variables are based on the value of the Modes of operation display (6061 hex) mapped to a PDO. The conditions for *CSP*, *CSV*, and *CST* to change to TRUE depend on the specifications of the Servo Drive. Refer to the manual for the servo driver. They are always FALSE if the Modes of operation display (6061 hex) is not mapped to a PDO.
- \*8 This variable shows the settings in the Axis Basic Settings.
- \*9 This variable shows the settings of the electronic gear ratio.

<sup>\*2</sup> This also includes states where processing is performed while in motion at velocity 0, during following error counter resets, during synchronized control, and during multi-axis coordinated motion.

# **Axes Group Variables**

The variable names of the system-defined Axes Group Variables are \_MC\_GRP[0..31]. The data type is \_sGROUP\_REF, which is a structure. This section describes the configuration of the Axes Group Variables and provides details on the members.

	Name	Data type	Meaning	Function
MC_GR[	031]	_sGROUP_REF	Axes Group Variable	
Stat	tus	_sGROUP_REF_STA	Axes Group Status	
	Ready	BOOL	Ready-to-execute	TRUE when the axes group is stopped and is ready to execute. The condition for being ready to execute is an AND of the following conditions.  Execution of the MC_Stop instruction is not in progress for a composition axis.  MC_GRP[XX].Status.Standby (Stopped) is TRUE.
				<ul> <li>The Servo is ON for the composition axes.</li> <li>_MC_AX[XX].Details.Homed is TRUE (home defined) for the composition axes.</li> </ul>
	Disabled	BOOL	Axes Group Disabled	TRUE when the axes group is disabled and stopped. The following axes group status are mutually exclusive. Only one of them can be TRUE at a time.  Disabled, Standstill, Moving, Stopping, and ErrorStop
	StandStill	BOOL	Standstill	TRUE when the axes group motion instruction is stopped. This is not related to the Servo ON/OFF status of the composition axes in the axes group.
	Moving	BOOL	Moving	TRUE while an axes group motion instruction is executed toward the target position. This includes in-position waiting status and when the velocity is 0 for an override.
	Stopping	BOOL	Deceleration Stopping	TRUE until the axes group stops for an MC_GroupStop instruction. This includes when <i>Execute</i> is TRUE after the axis stops for an MC_GroupStop instruction. Axes group motion instructions are not executed while decelerating to a stop. ( <i>CommandAborted</i> is TRUE.)
	ErrorStop	BOOL	Error Deceleration Stopping	TRUE while the axes group is stopping or stopped for the MC_GroupImmediateStop instruction or for an axes group minor fault (when _MC_GRP[XX].MFaultLvl.Active is TRUE). Axes group motion instructions are not executed in this state (CommandAborted = TRUE).
Deta	ails	_sGROUP_REF_DET	Axes Group Control Status	;*1
	Idle	BOOL	Idle	TRUE when processing is not currently performed for the command value, except when waiting for in-position state.*2  Idle and InPosWaiting are mutually exclusive. They cannot both be TRUE at the same time.
	InPosWaiting	BOOL	In-position Waiting	TRUE when any of the composition axes are waiting for in-position state. The in-position check performed when positioning for the in-position check.

	Name	Data type	Meaning	Function	
Cmd		_sGROUP_REF_CMD_D ATA	Axes Group Command Values		
ļ	Vel	LREAL	Command Interpolation Velocity	Contains the current value of the command interpolation velocity. The interpolation velocity is calculated from the difference with the interpolation command current position. A plus sign is added when traveling in the positive direction, and a minus sign is added when traveling in the negative direction. The value is 0 when the axes group is disabled.	
	AccDec	LREAL	Command Interpolation Acceleration/Deceleration	Contains the current value of the command interpolation acceleration/deceleration. The interpolation acceleration/deceleration rate is calculated from the difference with the command interpolation velocity. A plus sign is added for acceleration, and a minus sign is added for deceleration. The value is 0 when the axes group is disabled, or when the command acceleration/deceleration rate of the current axes group motion instruction is 0.	
MFa	aultLvl	_sMC_REF_EVENT	Axes Group Minor Fault		
	Active	BOOL	Axes Group Minor Fault Active	TRUE while there is an axes group minor fault.	
	Code	UINT	Axes Group Minor Fault Code	Contains the code for an axes group minor fault. The upper four digits of the event code have the same value.	
Obsr		_sMC_REF_EVENT	Axes Group Observation		
	Active	BOOL	Axes Group Observation Active	TRUE while there is an axes group observation.	
	Code	WORD	Axes Group Observation Code	Contains the code for an axes group observa- tion. The upper four digits of the event code have the same value.	
Cfg		_sGROUP_REF_CFG	Axes Group Basic Settings		
	GrpNo	UINT	Axes Group Number	Contains the logical number of the axes group. This number is accessed to recognize the axes group number when accessing _sGROUP_REF.	
	GrpEnable	_eMC_GROUP_USE	Axes Group Use	Shows if the axes group is enabled or disabled.  0: _mcNoneGroup (Undefined Axes Group)  1: _mcUnusedGroup (Unused Axes Group)  2: _mcUsedGroup (Used Axes Group)	
Kine	ematics	_sGROUP_REF_KIM	Kinematics Transformation	Settings*3	
•	GrpType	_eMC_GROUP_TYPE	Axis Composition	Gives the axis composition for multi-axes coordinated control.  0: _mcXY (two axes)  1: _mcXYZ (three axes)  2: _mcXYZU (four axes)	
	Axis[0]	UINT	Composition Axis Selection (Axis A0)	Gives the axis number that is assigned to axis A0.	
	Axis[1]	UINT	Composition Axis Selection (Axis A1)	Gives the axis number that is assigned to axis A1.	
	Axis[2]	UINT	Composition Axis Selection (Axis A2)	Gives the axis number that is assigned to axis A2.	
	Axis[3]	UINT	Composition Axis Selection (Axis A3)	Gives the axis number that is assigned to axis A3.	

<sup>\*1</sup> Gives the control status of the command.

<sup>\*2</sup> This also includes states where processing is performed while in motion at a velocity of 0.

<sup>\*3</sup> Gives the definition of the kinematic conversions for the axes group.

# **Input Variables for Motion Control Instructions**

The following tables list the input variables and the valid ranges for motion control instructions, and the valid ranges of enumerations.

# **Input Variables**

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when Execute changes to TRUE. Other input variables are also input when Execute changes to TRUE. If input values are changed, they will be updated when Execute changes to TRUE again. The output variables are valid as long as Execute remains TRUE even after the instruction is completed. Then, all output variables except for Error and ErrorID are disabled when Execute changes to FALSE. If Execute changes to FALSE before the instruction is completed, output variables are valid for at least one period.
Enable	Enable	BOOL	TRUE or FALSE	FALSE	The instruction function is enabled when Enable changes to TRUE and disabled when it changes to FALSE. While Enable is TRUE, the other input variables are input every period. If Enable changes to FALSE, all output variables except for Error and ErrorID are disabled.
Positive Enable	Positive Direction Enable	BOOL	TRUE or FALSE	FALSE	MC_MoveJog Instruction When this variable changes to TRUE, the axis starts moving in the positive direction. When it changes to FALSE, the axis stops moving. The Velocity, Acceleration, and Deceleration input variables to the MC_MoveJog instruction are read when PositiveEnable changes to TRUE.      MC_SetTorqueLimit Instruction When this variable changes to TRUE, the positive torque limit is enabled. When it changes to FALSE, the positive torque limit is disabled.

Name	Meaning	Data type	Valid range	Default	Description
Negative Enable	Negative Direction Enable	BOOL	TRUE or FALSE	FALSE	MC_MoveJog Instruction When this variable changes to TRUE, the axis starts moving in the negative direction. When it changes to FALSE, the axis stops moving. The Velocity, Acceleration, and Deceleration input variables to the MC_MoveJog instruction are read when NegativeEnable changes to TRUE.      MC_SetTorqueLimit Instruction When this variable changes to TRUE, the negative torque limit is enabled. When it changes to FALSE, the negative torque limit is disabled.
BufferMode	Buffer Mode Selection	_eMC_BUFFER_MOD E	0: _mcAborting 1: _mcBuffered 2: _mcBlendingLow 3: _mcBlendingPrevious 4: _mcBlendingNext 5: _mcBlendingHigh	0*1	Specifies the operation when executing more than one motion instruction.  0: Aborting 1: Buffered 2: Blend with low 3: Blend with previous 4: Blend with next 5: Blend with high
Velocity	Target Velocity	LREAL	Positive number*2	0	Specifies the target velocity.*3
Acceleration	Acceleration Rate	LREAL	Non-negative number	0	Specifies the acceleration rate.*4
Deceleration	Deceleration Rate	LREAL	Non-negative number	0	Specifies the deceleration rate.*4
Jerk	Jerk	LREAL	Non-negative number	0	Specifies the jerk.*5
Distance	Travel Distance	LREAL	Negative number, positive number, or 0	0	Specifies the travel distance from the command current position.
		ARRAY [03] OF LREAL	Negative number, positive number, or 0	0	Specifies the target position for linear interpolation.*6
Position	Target Position	LREAL	Negative number, positive number, or 0	0	Specifies the absolute target position.*6
		ARRAY [03] OF LREAL	Negative number, positive number, or 0	0	Specifies the target position for linear interpolation.*6
VelFactor	Velocity Override Factor	LREAL	0 to 500	100	Specifies the velocity over- ride factor. The valid range of the over- ride factors is between 0.01 and 500.00. Values above 500.00 are treated as 500 and values less then 0.01 (including negative values) are treated as 0.01. The override factor will be 0 only when 0 is specified. The unit is %.

Name	Meaning	Data type	Valid range	Default	Description
AccFactor (Reserved)	Acceleration/ Deceleration Override Factor	LREAL	0 to 500	100	(Reserved)
JerkFactor (Reserved)	Jerk Override Factor	LREAL	0 to 500	100	(Reserved)
ReferenceType*7	Position Type Selection	_eMC_REFERENCE_ TYPE	0: _mcCommand 1: _mcFeedback 2: _mcLatestCommand	0*1	Specifies the master axis input information.  0: Command position (value calculated in the previous primary period)  1: Actual position (value obtained in the same primary period)  2: Command position (value calculated in the same primary period)
FeedDistance	Feed Dis- tance	LREAL	Negative number, positive number, or 0	0	Specifies the travel distance after the interrupt feed input.
FeedVelocity	Feed Velocity	LREAL	Positive number	0	Specifies the travel target velocity after the interrupt feed input.
ErrorDetect	Error Detection Selection	BOOL	TRUE or FALSE	FALSE	Specifies whether to detect an error when there is no interrupt feed input. TRUE: Detect errors. FALSE: Do not detect errors.
ExecutionMode	Execution Mode	BOOL	TRUE or FALSE	FALSE	Specifies whether to execute the specified cam table periodically or only once.  TRUE: Periodic FALSE: Non-periodic
StartMode	Start Mode	_eMC_STARTMODE	0: _mcAbsolutePosition 1: _mcRelativePosition	0*1	Specifies the coordinates used by <i>MasterStartDistance</i> (master following distance).  0: Absolute position  1: Relative position
StartPosition	Cam Table Start Position	LREAL	Negative number, positive number, or 0	0	Specifies the starting point of the cam table (0 phase) as an absolute position of the master axis.
MasterStartDistance	Master Following Distance	LREAL	Negative number, positive number, or 0	0	Specifies the position of the master axis when the following axis starts the cam motion. If you specify absolute positioning for <i>Start-Mode</i> , specify the absolute position of the master axis. If you specify relative positioning for <i>StartMode</i> , specify the relative position of the master axis from <i>Start-Position</i> (Cam Table Start Position).
MasterScaling	Master Coefficient	LREAL	Positive value (>0.0)	1.0	The master axis phase is extended or contracted using the specified scale.

Name	Meaning	Data type	Valid range	Default	Description
SlaveScaling	Slave Axis Coefficient	LREAL	Positive value (>0.0)	1.0	The slave axis displacement is extended or contracted using the specified scale.
MasterOffset	Master Offset	LREAL	Negative number, positive number, or 0	0	The phase of the master axis is shifted using the specified offset value.
SlaveOffset	Slave Offset	LREAL	Negative number, positive number, or 0	0	The displacement of the slave axis is shifted using the specified offset value.
CamTransition	Cam Transi-	_eMC_CAM_	0: _mcCTNone	0*1	(Reserved)
(Reserved)	tion Selec- tion	TRANSITION			
OutMode (Reserved)	Sync End Mode Selec- tion	_eMC_OUT_MODE	0: _mcStop	0*1	(Reserved)
Direction	Direction	_eMC_DIRECTION	0: _mcPositiveDirection 1: _mcShortestWay 2: _mcNegativeDirection 3: _mcCurrentDirection 4: _mcNoDirection	4/0*1	Specifies the travel direction.  0: Positive direction  1: Shortest way  2: Negative direction  3: Current direction  4: No direction specified
Continuous(Res erved)	Continuation Mode Selec- tion	BOOL	TRUE or FALSE		(Reserved)
RatioNumerator	Gear Ratio Numerator	UINT	Positive number	10,000	Specifies the electronic gear ratio numerator between the master and slave axes.
Ratio Denominator	Gear Ratio Denominator	UINT	Positive number	10,000	Specifies the electronic gear ratio denominator between the master and slave axes.
MasterSync Position	Master Sync Position	LREAL	Negative number, positive number, or 0	0	Specifies the absolute master sync position.
SlaveSyncPosi- tion	Slave Sync Position	LREAL	Negative number, positive number, or 0	0	Specifies the absolute slave sync position.
SlaveDistance	Slave Axis Travel Distance	LREAL	Negative number, positive number, or 0	0	Specifies the travel distance for the slave axis.
MasterDistance	Master Distance	LREAL	Non-negative number	0	Specifies the travel distance of the master axis.
MasterDistance- InACC	Master Distance in Acceleration	LREAL	Non-negative number	0	Specifies the travel distance of the master axis while the slave axis is accelerating.
MasterDistance- InDEC	Master Distance in Deceleration	LREAL	Non-negative number	0	Specifies the travel distance of the master axis while the slave axis is decelerating.
LinkOption	Synchroniza- tion Start Condition	_eMC_LINKOPTION	0: _mcCommandExecution 1: _mcTriggerDetection 2: _mcMasterReach	0*1	Specifies the condition for the slave axis to synchronize with the master axis.  O: When instruction execution starts  1: When trigger is detected  2: When the master axis reaches the master following distance.
CombineMode	Combine Mode	_eMC_COMBINE_MO DE	0: _mcAddAxes 1: _mcSubAxes	0*1	Specifies the combining method.  0: Addition 1: Subtraction

Name	Meaning	Data type	Valid range	Default	Description
Ratio Numerator Master (Reserved)	Master Axis Gear Ratio Numerator	UINT	Positive number	10000	Specifies the electronic gear ratio numerator between the master and slave axes.
Ratio Denominator Master (Reserved)	Master Axis Gear Ratio Denominator	UINT	Positive number	10000	Specifies the denominator of the electronic gear ratio between the master and slave axes.
Ratio Numerator Auxiliary (Reserved)	Auxiliary Axis Gear Ratio Numerator	UINT	Positive number	10000	Specifies the numerator of the electronic gear ratio between the auxiliary and slave axes.
Ratio Denominator Auxiliary (Reserved)	Auxiliary Axis Gear Ratio Denominator	UINT	Positive number	10000	Specifies the denominator of the electronic gear ratio between the auxiliary and slave axes.
ReferenceType Master	Master Axis Position Type	_eMC_ REFERENCE_TYPE	1: _mcFeedback 2: _mcLatestCommand	2*1	Specifies the position type of the master axis.  1: Actual position (value obtained in the same primary period)  2: Command position (value calculated in the same primary period)
ReferenceType Auxiliary	Auxiliary Axis Position Type	_eMC_ REFERENCE_TYPE	1: _mcFeedback 2: _mcLatestCommand	2*1	Specifies the position type of the auxiliary axis.  1: Actual position (value obtained in the same primary period)  2: Command position (value calculated in the same primary period)
PhaseShift	Phase Shift Amount	LREAL	Negative number, positive number, or 0	0	Specifies the master phase shift amount.*6
Torque	Target Torque	LREAL	0 to 1000.0	300.0	Specify the target torque to output to the Servo Drive in increments of 0.1%. The target torque is specified as a percentage of the rated torque. The unit is %.
TorqueRamp	Torque Ramp	LREAL	Non-negative number	0	Specifies the rate of change in the torque from the current value to the target torque. The unit is %/s.
PositiveValue	Positive Torque Limit	LREAL	0.1 to 1000.0 or 0.0	300.0	Specifies the torque limit in the positive direction in increments of 0.1%. If a value that exceeds the Maximum Positive Torque Limit axis parameter, the positive torque will be the Maximum Positive Torque Limit.  The value will be 0 if 0 or a negative value is specified.

Name	Meaning	Data type	Valid range	Default	Description
NegativeValue	Negative Torque Limit	LREAL	0.1 to 1000.0 or 0.0	300.0	Specifies the torque limit in the negative direction in increments of 0.1%. If a value that exceeds the Maximum Negative Torque Limit axis parameter, the negative torque will be the Maximum Negative Torque Limit.  The value will be 0 if 0 or a negative value is specified.
WindowOnly	Window Only	BOOL	TRUE or FALSE	FALSE	Specify whether to enable or disable the window mask.
FirstPosition	First Position	LREAL	Negative number, positive number, or 0	0	Specify the first position.
LastPosition	Last Position	LREAL	Negative number, positive number, or 0	0	Specify the last position.
StopMode	Stop Mode	_eMC_STOP_MODE	1: _mcImmediateStop 2: _mcImmediateStopFEReset 3: _mcFreeRunStop 4: _mcNonStop	4*1	Specifies the stopping method.  1: Perform an immediate stop.  2: Perform an immediate stop and reset the following error counter  3: Perform an immediate stop and turn OFF the Servo  4: Do not stop.
Relative (Reserved)	Relative Position Selection	BOOL	TRUE or FALSE		(Reserved)
Execution Mode (Reserved)	Execution Mode	_eMC_EXECUTION_ MODE	0: _mcImmediately	0*1	(Reserved)
Permitted Deviation	Permitted Following Error	LREAL	Non-negative number	0	Specifies the permitted maximum value for the following error between the master and slave axes.
CmdPos Mode	Command Current Position Count Selection	_eMC_CMDPOS_ MODE	0: _mcCount	0*1	O: Use the actual current position and update the command current position.  Home remains defined.
CoordSystem	Coordinate System	_eMC_COORD_SYST EM	0: _mcACS	0*1	Specifies the coordinate system.  0: Axis coordinate system (ACS)
TransitionMode	Transition Mode	_eMC_TRANSITION_ MODE	0: _mcTMNone 10: _mcTMCornerSuperimposed	0*1	Specifies the path of motion.  0: Transition disabled 10:Superimpose corners
MoveMode	Travel Mode	_eMC_MOVE_MODE	0: _mcAbsolute 1: _mcRelative	0*1	Selects the travel method.  0: Absolute positioning  1: Relative positioning
CircAxes	Circular Axes	ARRAY [0,1] OF UINT	0 to 3	0	Specifies the axes for circular interpolation.  0: Axis A0  1: Axis A1  2: Axis A2  3: Axis A3

Name	Meaning	Data type	Valid range	Default	Description
CircMode	Circular Interpolation Mode	_eMC_CIRC_MODE	0: _mcBorder 1: _mcCenter 2: _mcRadius	0*1	Specifies the method for circular interpolation.  0: Border point  1: Center  2: Radius
AuxPoint	Auxiliary Point	ARRAY [0,1] OF LREAL	Negative number, positive number, or 0	0	Specifies the border point, center, or radius.
EndPoint	End Point	ARRAY [0,1] OF LREAL	Negative number, positive number, or 0	0	Specifies the target position.
PathChoice	Path Choice	_eMC_CIRC_PATHCH OICE	0: _mcCW 1: _mcCCW	0*1	Specifies the path direction.  0: CW  1: CCW
Parameter Number	Parameter Number	_eMC_PARAMETER_ NUMBER	0: _mcChkVel 1: _mcChkAcc 2: _mcChkDec 3: _mcPosiChkTrq 4: _mcNegaChkTrq 5: _mcFELmt 6: _mcChkFELmt 7: _mcSwLmtMode 8: _mcPosiSwLmt 9: _mcNegaSwLmt 10: _mcInPosTime	0*1	Specifies the parameter to write.  0: Velocity Warning Value 1: Acceleration Warning Value 2: Deceleration Warning Value 3: Positive Torque Warning Value 4: Negative Torque Warning Value 5: Following Error Over Limit Value 6: Following Error Warning Value 7: Software Limits 8: Positive Software Limit 9: Negative Software Limit 10:In-position Check Time

- \*1 The default value for an enumeration variable is actually not the number, but the enumerator.
- \*2 You can use instructions, such as the MC\_MoveJog or MC\_MoveVelocity instruction, to set the velocity to 0.
- \*3 The command unit is millimeters, micrometers, nanometers, degrees, inches, or pulses.
- \*4 The unit is command units/s<sup>2</sup>.
- \*5 The unit is command units/s3.
- \*6 This unit is command units.
- \*7 When you use \_mcLatestCommand, the axis number set for the master axis in the system-defined variable for motion control must be lower than the axis number set for the slave axis in the system-defined variable for motion control.

# **Valid Range of Input Variables**

This section gives the valid ranges of input variables to motion control instructions. Refer to individual instruction descriptions for the valid ranges for each instruction.

## BOOL Input Variables


Any value other than FALSE is treated as TRUE. For this reason, out-of-range errors do not occur.

# • Enumerated (ENUM) Input Variables

Values that are outside of the valid range will result in an error.

# Input Variables Given as Full Range, Positive Number, or Negative Number

Operation when an input variable is set inside or outside the valid range is described in the following table.



Name	Meaning	Valid range	Outside the maximum value range	Outside the minimum value range (excluding 0)
Velocity	Velocity	0, $(-1 \le \text{and} \le -\text{Maximum}$ velocity), or $(1 \le \text{and} \le \text{Maximum}$ mum velocity)*1	Set to the maximum velocity for a positive number, and to the -maximum velocity for a negative number.*2	Set to 1 pulse/s when positive number, and –1 pulse/s when negative number.*2
Acceleration	Acceleration Rate	0 or (0.004 ≤ and ≤ Maximum acceleration)*3	Set to the maximum acceleration.  If the acceleration time*4 is less than 125 μs, it will always be 125 μs.	Set to 0.004 pulses/s <sup>2</sup> when positive number. If the acceleration time <sup>*4</sup> is greater than 250 s, it will always be 250 s.  Error when negative number.
Deceleration	Deceleration Rate	0 or (0.004 ≤ and ≤ Maximum deceleration)*5	Set to the maximum deceleration.  If the deceleration time*4 is less than 125 μs, it will always be 125 μs.	Set to 0.004 pulses/s <sup>2</sup> when positive number. If the deceleration time* <sup>4</sup> is greater than 250 s, it will always be 250 s.  Error when negative number.
Jerk	Jerk	0 or (0.000016 ≤ and 25,600,000,000,000,000 pulses/s³)	Set to $25,600,000,000,000,000$ pulses/s <sup>3</sup> . If the acceleration jerk application time <sup>*6</sup> or the deceleration jerk application time <sup>*6</sup> is less than $125~\mu s$ , it will always be $125~\mu s$ .	Set to 0.000016 pulses/s <sup>3</sup> . If the acceleration jerk application time <sup>*6</sup> or the deceleration jerk application time <sup>*6</sup> is greater than 250 s, it will always be 250 s.  Error when negative number.
Distance	Travel Distance	(0xFFFFFF0000000001) ≤ and ≤ (0x000000FFFFFFFFF)	Error	Values outside of the minimum value range do not occur.
Position	Command Position	(0xFFFFFF8000000000) ≤ and < (0x0000007FFFFFFFF+ 1)*7	Error	Values outside of the minimum value range do not occur.
VelFactor	Velocity Override Factor	0 or 0.01 ≤ and ≤ 500.00*8	Set to 500.00% if higher than 500.00%.	Set to 0.01% if less than 0.01%.

Name	Meaning	Valid range	Outside the maximum value range	Outside the minimum value range (excluding 0)
Velocity	Interpolation Velocity	$ \begin{array}{l} 0.000\ 000\ 000\ 000\ 01 \leq and \leq \\ \text{Maximum interpolation velocity}^*9 \end{array} $	Set to the maximum interpolation velocity.	Set to 0.000 000 000 1 pulses/s.
Acceleration	Interpolation Acceleration	0 or (0.000 000 000 000 4 ≤ and ≤ Maximum interpolation acceleration)*10	Set to the maximum interpolation acceleration. If the interpolation acceleration time $^{*11}$ is less than 125 $\mu$ s, it will always be 125 $\mu$ s.	Set to 0.000 000 000 000 4 pulses/s <sup>2</sup> when positive number. If the interpolation acceleration time*11 is greater than 250 s, it will always be 250 s.
				Error when negative number.
Deceleration	Interpolation Deceleration	0 or (0.000 000 000 000 000 000 04 ≤ and ≤ Maximum interpolation deceleration)*12	Set to the maximum interpolation deceleration. If the interpolation deceleration time*11 is less than 125 µs, it will always be 125 µs.	Set to 0.000 000 000 000 4 pulses/s² when positive number. If the interpolation deceleration time*11 is greater than 250 s, it will always be 250 s.
				Error when negative number.
Jerk	Interpolation Jerk	0 or (0.000 000 000 000 001 6 ≤ and ≤ 51,200,000,000,000,000 pulses/s³)	Set to $51,200,000,000,000,000$ pulses/s <sup>3</sup> . If the interpolation acceleration jerk application time* <sup>13</sup> or the interpolation deceleration jerk application time* <sup>13</sup> is less than $125 \mu s$ , it will always be $125 \mu s$ .	Set to 0.000 000 000 000 001 6 pulses/s³. If the interpolation acceleration jerk application time*1³ or the interpolation deceleration jerk application time*1³ is greater than 250 s, it will always be 250 s.  Error when negative num-
				Error when negative num ber.

- \*1 The upper limit of the Maximum Velocity in the axis parameters is 400,000,000 pulses/s.
- \*2 If a negative number or 0 is specified when negative numbers and 0 are not included in the effective range, an error occurs.
- \*3 The upper limit of the Maximum Acceleration in the axis parameters is 3,200,000,000,000 pulses/s<sup>2</sup>.
- \*4 Calculated as follows: Acceleration time = Velocity/Acceleration rate, Deceleration time = Velocity/Deceleration rate, and Acceleration/deceleration time = Acceleration time + Deceleration time.
- \*5 The upper limit of the Maximum Deceleration in the axis parameters is 3,200,000,000,000 pulses/s<sup>2</sup>.
- \*6 The acceleration jerk application time and the deceleration jerk application time are the times that jerk is applied. Calculated as follows: Acceleration jerk application time = Acceleration rate/Jerk and Deceleration jerk application time = Deceleration rate/Jerk.
- \*7 Position must be an absolute value in pulses and must be no more than 40 bits signed.
- \*8 The unit is %.
- \*9 The upper limit of the Maximum Interpolation Velocity in the axis parameters is 800,000,000 pulses/s.
- \*10 The upper limit of the Maximum Interpolation Acceleration in the axis parameters is 6,400,000,000,000 pulses/s<sup>2</sup>.
- \*11 Calculated as follows: Interpolation acceleration time = Interpolation velocity/Interpolation acceleration rate, Interpolation deceleration time = Interpolation velocity/Interpolation deceleration rate, and Acceleration/deceleration time = Acceleration time + Deceleration time.
- \*12 The upper limit of the Maximum Interpolation Deceleration in the axis parameters is 6,400,000,000,000 pulses/s<sup>2</sup>.
- \*13 The interpolation acceleration jerk application time and the interpolation deceleration jerk application time are the times that interpolation jerk is applied.
  - Calculated as follows: Interpolation acceleration jerk application time = Interpolation acceleration rate/Jerk and Interpolation deceleration jerk application time = Interpolation deceleration rate/Jerk.

# **Enumerations**

This ENUM data is used by input variables to motion control instructions. An enumeration input variable is not actually set to the number, but to the enumerator.

Data type	Valid range	Description	Corresponding variable name
_eMC_BUFFER_ MODE	0: _mcAborting 1: _mcBuffered 2: _mcBlendingLow 3: _mcBlendingPrevious 4: _mcBlendingNext 5: _mcBlendingHigh	Specifies the operation for multi-execution of motion control instructions.  0: Aborting 1: Buffered 2: Blend with low 3: Blend with previous 4: Blend with next 5: Blend with high	BufferMode (Buffer Mode Selection)
_eMC_CIRC_ MODE	0: _mcBorder 1: _mcCenter 2: _mcRadius	Specifies the method for circular interpolation.  0: Border point  1: Center  2: Radius	CircMode (Circular Interpolation Mode)
_eMC_CAM_ TRANSITION	0: _mcCTNone	Specifies the slave axis command value output method when the cam is restarted.  0: No limit or correction	CamTransition (Cam Transition Selection)
_eMC_CIRC_ PATHCHOICE	0: _mcCW 1: _mcCCW	Specifies the path direction.  0: CW  1: CCW	PathChoice
_eMC_COMBINE_ MODE	0: _mcAddAxes 1: _mcSubAxes	Specifies the combining method.  0: Add  1: Subtraction	CombineMode
_eMC_COORD_ SYSTEM	0: _mcACS	Specifies the coordinate system.  0: Axis coordinate system (ACS)	CoordSystem (Coordinate System)
_eMC_DIRECTION	0: _mcPositiveDirection 1: _mcShortestWay 2: _mcNegativeDirection 3: _mcCurrentDirection 4: _mcNoDirection	Specifies the direction of motion.  0: Positive direction  1: Shortest way  2: Negative direction  3: Current direction  4: No direction specified.	Direction
_eMC_ EXECUTION_MODE	0: _mcImmediately	(Reserved)	ExecutionMode (Execution Mode)
_eMC_LINKOPTION	0: _mcCommandExecution 1: _mcTriggerDetection 2: _mcMasterReach	Specifies the condition for the slave axis to synchronize with the master axis.  0: Start of instruction  1: When trigger is detected  2: When the master axis reaches the master following distance.	LinkOption (Synchronization Start Condition)
_eMC_MOVE_MODE	0: _mcAbsolute 1: _mcRelative 2: _mcVelocity	Selects the travel method.  0: Absolute positioning  1: Relative positioning  2: Velocity control	MoveMode (Travel Mode)
_eMC _OUT_MODE	0: _mcStop	Specifies the mode to disable the synchronization instruction.  0: Deceleration stop	OutMode (Sync End Mode Selection)
		U. Deceleration stop	(Reserved)

Data type	Valid range	Description	Corresponding variable name
_eMC_ PARAMETER_ NUMBER	0: _mcChkVel 1: _mcChkAcc 2: _mcChkDec 3: _mcPosiChkTrq 4: _mcNegaChkTrq 5: _mcFELmt 6: _mcChkFELmt 7: _mcSwLmtMode 8: _mcPosiSwLmt 9: _mcInPosTime	Specifies the parameter to write.  0: Velocity Warning Value 1: Acceleration Warning Value 2: Deceleration Warning Value 3: Positive Torque Warning Value 4: Negative Torque Warning Value 5: Following Error Over Limit Value 6: Following Error Warning Value 7: Software Limits 8: Positive Software Limit 9: Negative Software Limit 10: In-position Check Time	ParameterNumber
_eMC_ SWLMT_MODE	0: _mcNonSwLmt 1: _mcCmdDecelerationStop 2: _mcCmdImmediateStop 3: _mcActDecelerationStop 4: _mcActImmediateStop	<ul> <li>Enables and disables the software limits and specifies the Stop Mode.</li> <li>0: Disable software limits.</li> <li>1: Deceleration stopping enabled for command position.</li> <li>2: Enable software limits and perform immediate stop for command position.</li> <li>3: Enable software limits and decelerate to stop for actual position.</li> <li>4: Enable software limits and perform immediate stop for actual position.</li> </ul>	SettingValue (Setting Value)
_eMC_ REFERENCE_ TYPE *	0: _mcCommand 1: _mcFeedback 2: _mcLatestCommand	Specifies the position type.  0: Command position (value calculated in the previous primary period)  1: Actual position (value obtained in the same primary period)  2: Command position (value calculated in the same primary period)	ReferenceType (Position Type Selection) ReferenceTypeMaster (Master Axis Position Type Selection) ReferenceTypeAuxiliary (Auxiliary Axis Position Type Selection)
_eMC_ STARTMODE	0: _mcAbsolutePosition 1: _mcRelativePosition	Specifies the coordinate system used by MasterStartDistance (master following distance).  0: Absolute position  1: Relative position	StartMode
_eMC_STOP_ MODE	1: _mcImmediateStop 2: _mcImmediateStopFEReset 3: _mcFreeRunStop 4: _mcNonStop	Specifies the stopping method.  1: Perform an immediate stop.  2: Perform an immediate stop and reset the following error counter  3: Turn OFF the Servo.  4: Do not stop.	StopMode
_eMC_TRIGGER_ LATCH_ID	0: _mcLatch1 1: _mcLatch2	Specifies which of the two latch functions to use.  0: Latch 1  1: Latch 2	LatchID
_eMC_ CMDPOS_MODE	0: _mcCount	Use the actual current position and update the command current position. Home remains defined.	CmdPosMode
_eMC_ TRANSITION_ MODE	0: _mcTMNone 10: _mcTMCornerSuperimposed	Specifies the path of motion.  0: Transition disabled  10:Superimpose corners	TransitionMode
_eMC_TRIGGER_ MODE	0: _mcDrive 1: _mcController	Specifies the trigger mode.  0: Drive Mode  1: Controller Mode	Mode
_eMC_TRIGGER_ INPUT_DRIVE	0: _mcEncoderMark 1: _mcEXT	Specifies the trigger signal in Drive Mode.  0: Z-phase signal  1: External input	InputDrive (Trigger Input Signal)

<sup>\*</sup> When you use mcLatestCommand, the axis number set for the master axis in the system-defined variable for motion control must be lower than the axis number set for the slave axis in the system-defined variable for motion control .

# **Output Variables for Motion Control Instructions**

The following table lists the output variables for motion control instructions.

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed. At this time, output variables Active, Error, and CommandAborted are FALSE. Done will be TRUE for at least one period if the input variable Execute is FALSE when the instruction is completed. If Execute is TRUE, Done remains TRUE until Execute changes to FALSE.
Busy	Executing	BOOL	TRUE or FALSE	Changes to TRUE when an instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE	Changes to TRUE when the instruction is executed. <i>Active</i> (Controlling) is TRUE while the instruction is actually controlling an axis or axes group. At this time, output variables <i>Done</i> , <i>Error</i> , and <i>Command-Aborted</i> are FALSE.
Enabled	Enabled	BOOL	TRUE or FALSE	Changes to TRUE when busy.
CommandAborted	Instruction Aborted	BOOL	TRUE or FALSE	TRUE when an instruction could not be executed or when it was aborted during execution. The instruction is not executed if there is an error with the target axis or axes group, or while the axis or axes group is decelerating to a stop. The instruction is aborted when another instruction is executed, or if an error other than for this instruction occurs. At this time, output variables <i>Done</i> , <i>Active</i> , and <i>Error</i> change to FALSE. If the instruction is aborted while the input variable <i>Execute</i> is FALSE, <i>CommandAborted</i> will be TRUE for at least one period. If <i>Execute</i> or <i>Enable</i> is TRUE, <i>CommandAborted</i> remains TRUE until <i>Execute</i> or <i>Enable</i> is TRUE, <i>CommandAborted</i> remains TRUE until <i>Execute</i> or <i>Enable</i> is TRUE, <i>CommandAborted</i> remains TRUE until <i>Execute</i> or <i>Enable</i> is TRUE, <i>CommandAborted</i> remains TRUE until <i>Execute</i> or <i>Enable</i> is TRUE, <i>CommandAborted</i> remains TRUE until <i>Execute</i> or <i>Enable</i> is TRUE, <i>CommandAborted</i> remains TRUE until <i>Execute</i> or <i>Enable</i> is TRUE, <i>CommandAborted</i> remains TRUE until <i>Execute</i> or <i>Enable</i> is TRUE, <i>CommandAborted</i> remains TRUE until <i>Execute</i> or <i>Enable</i> is TRUE, <i>CommandAborted</i> remains TRUE until <i>Execute</i> or <i>Enable</i> is TRUE, <i>CommandAborted</i> remains TRUE until <i>Execute</i> or <i>Enable</i> is TRUE, <i>CommandAborted</i> remains TRUE until <i>Execute</i> or <i>Enable</i> is <i>Execute</i> or <i>Ena</i>
Error	Error	BOOL	TRUE or FALSE	cute or Enable changes to FALSE.  TRUE when there is an error caused by a mistake in an input variable or instruction processing.*1
ErrorID	Error Code	WORD	*2	Contains the error code when an error occurs. 16#0000 indicates normal operation.
Failure	Failure End	BOOL	TRUE or FALSE	TRUE when the instruction was not executed correctly.
Status	Power Servo	BOOL	TRUE or FALSE	TRUE when the device is ready for operation.
EndOfProfile	End of Cam Cycle	BOOL	TRUE or FALSE	Changes to TRUE when the cam table end point is executed.
Index	Index	UINT	Non-negative num- ber	Contains the cam data index number.
StartSync	Following	BOOL	TRUE or FALSE	TRUE when acceleration/deceleration is started for synchronization and the device is ready for operation.
RecordedPosition	Latched Position	LREAL	Negative number, positive number, or 0	Contains the latched position. *3

Name	Meaning	Data type	Valid range	Description
Invalid	Excessive Following Error between Axes	BOOL	TRUE or FALSE	TRUE when the permitted following error between axes is exceeded.
DeviatedValue	Following Error between Axes	LREAL	Negative number, positive number, or 0	Contains the difference between the specified master and slave axes.*3
EndPointIndex	End Point Index	UINT	Non-negative num- ber	Contains the cam table end point index.
MaxDataNumber	Maximum Number of Cam Data	UINT	Positive number	Contains the maximum cam data number.
InVelocity	Target Velocity Reached	BOOL	TRUE or FALSE	TRUE when the target velocity is reached.
InSync	In Sync	BOOL	TRUE or FALSE	TRUE when slave axis is synchronized to the master axis, or when the slave axis reaches the slave axis sync position.
InGear	Gear Ratio Achieved	BOOL	TRUE or FALSE	TRUE when the slave axis reaches the target velocity.
InCombination	Axes Combined	BOOL	TRUE or FALSE	TRUE when axes are combined.
InCam	Cam Motion	BOOL	TRUE or FALSE	TRUE when the cam table start point is executed.
InTorque	Target Torque Reached	BOOL	TRUE or FALSE	TRUE when the target torque is reached.
InFeed	Feeding	BOOL	TRUE or FALSE	TRUE while feeding after receiving a latch input.
InZone	In Zone	BOOL	TRUE or FALSE	TRUE when the axes position is within the zone range.

Error is not reset to FALSE until you execute one of the following instructions: MC\_Reset, MC\_GroupReset, or ResetM-CError. This behavior is different from the PLCopen specifications. With PLCopen specifications, it changes to FALSE when Execute changes to FALSE. When Error is TRUE, the motion control instruction is not executed. Instructions are not executed after an error is cleared even if Execute is TRUE. Execute must change from FALSE to TRUE to execute the instruction. Enable-type motion control instructions are executed whenever their Enable variable is TRUE.

- \*2 The upper four digits of the event code have the same value. Refer to A-1 Error Codes for details.
- \*3 This unit is command units. The command unit is millimeters, micrometers, nanometers, degrees, inches, or pulses.



#### **Additional Information**

To enable accessing output variables for motion control instructions even after the operating mode is changed, assign variables that have output parameters with a retain attribute. By accessing the assigned output parameter, you can access the output variable immediately before the operating mode changed.

## **In-Out Variables for Motion Control Instructions**

The following table lists the in-out variables for motion control instructions.

Name	Meaning	Data type	Valid range	Description
Axis	Axis	_sAXIS_REF		Specifies the axis.
AxesGroup	Axes Group	_sGROUP_REF		Specifies the axes group.
Auxiliary	Auxiliary Axis	_sAXIS_REF		Specifies the auxiliary axis.
Master	Master Axis	_sAXIS_REF		Specifies the master axis.
Slave	Slave Axis	_sAXIS_REF		Specifies the slave axis.
CamTable	Cam Table	ARRAY[0N] OF _sMC_CAM_REF		Specifies the cam data structure _sMC_CAM_REF array variable as the cam table.*1
TriggerInput	Trigger Input Condition	_sTRIGGER_REF		Sets the trigger condition.
TriggerVariable	Trigger Variable	BOOL	TRUE or FALSE	Specifies a trigger input variable when the controller mode is specified with a trigger condition.
Target	Write Target	_sAXIS_REF or _sGROUP_REF		Specifies the axis or axes group for which to write a parameter.
SettingValue	Setting Value	Depends on the variable that is specified.		Specifies the value to write. The valid range follows the motion control parameter that is specified by Parameter-Number.*2 The default value is 0.

<sup>\*1</sup> N in the array variable is set automatically by the Sysmac Studio. Specify a cam data variable that was created on the Sysmac Studio.

<sup>\*2</sup> For details on the data types of variables, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### Instructions 2-2

There are three types of motion instructions. They are given in the following table.

Туре	Outline
Common commands	Common instructions for the MC Function Module
Axis commands	Instructions for MC Function Module to perform single-axis control
Axes group commands	Instructions for MC Function Module to perform multi-axis coordinated control

For details on common commands, refer to Section 5 Common Command Instructions. For axes commands, refer to SECTION 3 Axis Command Instructions. For axes groups, refer to Section 4 Axes Group Instructions.

### **Common Commands**

This section describes the common instructions for the MC Function Module. The Classification Column gives "Administration" for non-motion instructions and "Motion" for motion instructions.

- P: Instructions defined in PLCopen technical specifications.
- O: Instructions defined for the MC Function Module.

Instruction	Instruction name	Outline	Classificatio	n
MC_SetCamTableProperty	Set Cam Table Properties	op- The end point index of the cam table that is specified in the input parameter is changed.		0
MC_SaveCamTable	Save Cam Table	Saves the cam table specified with the input parameter.	Administration	0
MC_Write	Write MC Setting	Writes part of the parameter settings for motion control.	Administration	0

For details on the axis states due to instruction execution, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

## **Axis Commands**

This section describes the instructions that are used to perform single-axis control for the MC Function Module. The *Classification* column gives "Administration" for non-motion instructions and "Motion" for motion instructions.

- P: Instructions defined in PLCopen technical specifications.
- O: Instructions defined for the MC Function Module.

Instruction	Instruction name	Outline	Classification		
MC_Power	Power Servo	Makes the Servo Drive ready to operate.	Administration	Р	
MC_MoveJog	Jog	Performs jogging according to the specified target velocity.	Motion	0	
MC_Home	Home	Operates the motor to determine home using the limit signals, home proximity signal, and home signal.	Motion	Р	
MC_Move	Positioning	Performs absolute positioning or relative positioning.	Motion	0	
MC_MoveAbsolute	Absolute Positioning	Performs positioning for the specified absolute target position.	Motion	Р	
MC_MoveRelative	Relative Positioning	Performs positioning for the specified travel distance from the command current position.	Motion	Р	
MC_MoveVelocity	Velocity Control	Performs velocity control with the Position Control Mode of the Servo Drive.	Motion	Р	
MC_MoveZeroPosition	High-speed Home	Performs positioning with an absolute position of 0 as the target position to return to home.	Motion	0	
MC_MoveFeed	Interrupt Feeding	Positioning is performed for the specified travel distance from the position where an external device triggers an interrupt input.	s- Motion (		
MC_Stop	Stop	Decelerates an axis to a stop.	Motion	Р	
MC_ImmediateStopt	Immediate Stop	Stops an axis according to the stopping mode that is set with the StopMode (Stopping Mode Selection) input variable regardless of the status of the axis.	Motion	0	
MC_SetPosition	Set Position	Changes the command current position or the actual current position as required for an axis.	Administration	Р	
MC_SetOverride	Set Override Factors	Changes the target velocity for an axis.	Administration	Р	
MC_ResetFollowingError	Reset Following Error Counter	Resets the following error between the command position and the actual position.	Motion	0	
MC_CamIn	Start Cam Operation	Starts cam operation with a specified cam table.	Motion	Р	
MC_CamOut	End Cam Operation	Ends cam operation for the axis specified with the input parameter.	Motion	Р	
MC_GearIn	Start Gear Operation	Specifies the gear ratio between the master axis and the slave axis and starts gear operation.	Motion	Р	
MC_GearInPos	Positioning Gear Operation	Specifies the gear ratio between the master axis and the slave axis and starts electronic gear operation. Specifies the positions of the master axis and slave axis to start synchronization.	Motion	Р	
MC_GearOut	End Gear Operation	Cancels MC_GearIn and MC_GearInPos instructions.	Motion	Р	
MC_MoveLink	Synchronous Positioning	Performs positioning in sync with the specified master axis.	Motion	0	
MC_CombineAxes	Combine Axes	Outputs the sum or difference of the command positions of two axes as the command position.	Motion	0	
MC_Phasing	Shift Master Axis Phase	Shifts the phase of the master axis currently in synchronized control.	Motion	Р	
MC_TorqueControl	Torque Control	Uses the Torque Control Mode of the Servo Drive to control the torque.	Motion	Р	
MC_SetTorqueLimit	Set Torque Limit	Limits the torque output from the Servo Drive through the torque limit function of the Servo Drive.	Administration	0	

Instruction	Instruction Instruction name Outline		Classification	
MC_ZoneSwitch	Zone Monitor	Determines if the command position or actual current position of an axis is within a specified zone.	Administration	0
MC_TouchProbe	Enable External Latch	Records the position of an axis when a trigger signal occurs.	Administration	Р
MC_AbortTrigger	Disable External Latch	Disables the current latch.	Administration	Р
MC_AxesObserve	Monitor Axis Follow- ing Error	Monitors the deviation between the command positions or feedback positions for the specified two axes to see if it exceeds the allowed value.	Administration	0
MC_SyncMoveVelocity	Cyclic Synchronous Velocity Control	Outputs the value set for the target velocity every primary period to the Servo Drive in Cyclic Synchronous Velocity Mode.	Motion	0
MC_Reset	Reset Axis Error	Clears an axis error.	Administration	Р

For details on the axis states due to instruction execution, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

Refer to the compliance list for items that conform to PLCopen technical specifications. The compliance list can be accessed on the PLCopen website.

# **Axes Group Commands**

This section describes the instructions to perform multi-axis coordinated control for the MC Function Module. The Instruction Type Column gives "Group administration" for non-motion instructions and "Group motion" for motion instructions.

P: Instructions defined in PLCopen technical specifications.

O	Instructions	defined for	or the MC	Function	Module
<b>U</b> .	11 13 11 4 5 11 5 13	acili ica i		i uncuon	module.

Instruction	Instruction name	Outline	Classification	on
MC_GroupEnable	Enable Axes Group Enables an axes group.		Group administration	Р
MC_GroupDisable	Disable Axes Group	Disables an axes group.	Group administration	Р
MC_MoveLinear	Linear Interpolation	Performs linear interpolation.	Group motion	0
MC_MoveLinearAbsolute	Absolute Linear Interpolation	Performs linear interpolation for the specified absolute position.	Group motion	Р
MC_MoveLInearRelative	Relative Linear Interpolation	Performs linear interpolation for the specified relative position.	Group motion	Р
MC_MoveCircular2D	Circular 2D Interpola- tion	Performs circular interpolation for two axes.	Group motion	0
MC_GroupStop	Group Stop	Decelerates all axes in an interpolated motion to a stop.	Group motion	Р
MC_GroupImmediateStop	Axes Group Immediate Stop	Immediately stops all axes that are currently in interpolated motion with the method that is specified in the axis parameters.	Group motion	0
MC_GroupSetOverride	Set Group Overrides	Changes the blended target velocity during an interpolated motion.	Group administration	Р
MC_GroupReset	Group Reset	Clears axes group errors and axis errors.	Group administration	Р

For details on the axes group states due to instruction execution, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

Refer to the compliance list for items that conform to PLCopen technical specifications. The compliance list can be accessed on the PLCopen website.

# 2-3 PDO Mapping

You must map the objects that are required for the motion control functions that you will use to process data communications. The PDO map lists all of the objects that are registered in advance.

The default PDO map in the Sysmac Studio is given below.

RxPDO (1704 hex)	Controlword (6040 hex), Target Position (607A hex), Target Velocity (60FF hex), Target Torque (6071 hex), Modes of Operation (6060 hex), Touch Probe Function (60B8 hex), Max Profile Velocity (607F hex), Positive Torque Limit Value (60E0 hex), and Negative Torque Limit Value (60E1 hex)
TxPDO (1B02 hex)	Error Code(603F hex), Status Word (6041 hex), Position Actual Value (6064 hex), Torque Actual Value (6077 hex), Modes of Operation Display (6061 hex), Touch Probe Status (60B9 hex), Touch Probe Pos1 Pos Value (60BA hex), Touch Probe Pos2 Pos Value (60BC hex), and Digital Inputs (60FD hex)



#### **Additional Information**

If you use an OMRON G-series R88-KN ——-ECT Servo Drive (version 2.1 or higher), then it is not necessary to change the default PDO map on the Sysmac Studio.

For details on setting the PDO map, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

# **Required Objects**

There are objects that are required for Servo axes and an object that is required for encoder axes. If even one of the required objects is not set, a Required Process Data Object Not Set error (error code 3460 hex) occurs.

# **Servo Axes**

The following objects must be set to use motion control instructions for a Servo axis.

Input/output	Function	Process data
Output	Control word	6040 hex
	Target position	607A hex
Input	Status word	6041 hex
	Position actual value	6064 hex

# **Encoder Axes**

The following object must be set to use motion control instructions for an encoder axis.

Input/output	Function	Process data	
Input	Position actual value	4010 hex	

# **Objects Required for Specific Instructions**

There are objects that you must set to use specific instructions. There are settings required for both Servo axes and encoder axes. If an object that is required for an instruction is not set, a Process Data Object Setting Missing error (error code 3461 hex) occurs.

# **Servo Axes**

There are objects that you must set to use specific instructions for Servo axes. Refer to the following tables and set the required objects. There are no additional object settings required for Servo axis operation for any instructions that are not listed in the following table.

## Output Settings

	Function						
Instruction	Target velocity (60FF hex)	Target torque (6071 hex)	Modes of operation (6060 hex)	Touch probe function (60B8 hex)	Max. profile velocity (607F hex)	Positive torque limit value (60E0 hex)	Negative torque limit value (60E1 hex)
MC_Home				Conditionally required*1			
MC_MoveFeed				Conditionally required*2			
MC_MoveLink				Conditionally required*3			
MC_TorqueControl		Required	Required		Conditionally required*4		
MC_SetTorqueLimit						Required	Required
MC_TouchProbe				Conditionally required*2			
MC_SyncMoveVelocity	Required		Required				

<sup>\*1</sup> Setting is not required for Homing Operation Modes 11, 12, and 14.

#### Input Settings

	Function						
Instruction	Torque actual value (6077 hex)	Modes of opera- tion display (6061 hex)	Touch probe sta- tus (60B9 hex)	Touch probe pos1 pos value (60BA hex)	Touch probe pos2 pos value (60BC hex)		
MC_Home			Conditionally required*1	Conditionally required*1			
MC_MoveFeed			Conditionally required*2	Conditionally required*3	Conditionally required*4		
MC_MoveLink			Conditionally required*5	Conditionally required*6	Conditionally required*7		
MC_TorqueControl	Required	Required					
MC_TouchProbe			Conditionally required*2	Conditionally required*3	Conditionally required*4		
MC_SyncMoveVelocity		Required					

<sup>\*2</sup> Setting is required when *Mode* is set to Drive Mode.

Setting is required when LinkOption (Synchronization Start Condition) is set to\_mcTriggerDetection and Mode is set to Drive Mode.

<sup>\*4</sup> This setting is checked only when using an OMRON G5-series Servo Drive.

- \*1 Setting is not required for Homing Operation Modes 11, 12, and 14.
- \*2 Setting is required when *Mode* is set to Drive Mode.
- \*3 Setting is required when Mode is set to Drive Mode and LatchID is set to \_mcLatch1 (Latch 1).
- \*4 Setting is required when Mode is set to Drive Mode and LatchID is set to \_mcLatch2 (Latch 2).
- \*5 Setting is required when LinkOption (Synchronization Start Condition) is set to\_mcTriggerDetection and Mode is set to Drive Mode.
- \*6 Setting is required when *LinkOption* (Synchronization Start Condition) is set to \_*mcTriggerDetection*, Mode is set to Drive Mode, and LatchID is set to \_*mcLatch1* (Latch 1).
- \*7 Setting is required when *LinkOption* (Synchronization Start Condition) is set to \_*mcTriggerDetection*, Mode is set to Drive Mode, and LatchID is set to \_*mcLatch2* (Latch 2).

## **Encoder Axes**

There are objects that you must set to use specific instructions for encoder axes. Refer to the following tables and set the required objects. There are no additional object settings required for encoder axis operation for any instructions that are not listed in the following table.

## Output Settings

	Function				
Instruction	Touch probe function (4020 hex)	Software Switch of Encoder's Input Slave (4020 hex)			
MC_TouchProbe	Conditionally required*1	Conditionally required*2			

<sup>\*1</sup> Setting is required when *Mode* is set to Drive Mode.

## Input Settings

	Function					
Instruction	Touch probe sta- tus (4030 hex)	Touch probe pos1 pos value (4012 hex)	Touch probe pos2 pos value (4013 hex)	Status of Encoder's Input Slave (4030 hex)		
MC_TouchProbe	Conditionally required*1	Conditionally required*2	Conditionally required*3	Conditionally required*4		

<sup>\*1</sup> Setting is required when *Mode* is set to Drive Mode.

<sup>\*2</sup> Setting is required when an OMRON encoder slave is used and *Mode* is set to Drive Mode.

<sup>\*2</sup> Setting is required when Mode is set to Drive Mode and LatchID is set to \_mcLatch1 (Latch 1).

<sup>\*3</sup> Setting is required when *Mode* is set to Drive Mode and *LatchID* is set to \_mcLatch2 (Latch 2).

<sup>\*4</sup> Setting is required when an OMRON encoder slave is used and *Mode* is set to Drive Mode.



# **Axis Command Instructions**

This section describes the instructions that are used to perform single-axis control for the MC Function Module.

MC_Power	-3
MC_MoveJog 3-	-8
MC_Home 3-1	6
MC_Move 3-3	36
MC_MoveAbsolute	1
MC_MoveRelative	8
MC_MoveVelocity	'5
MC_MoveZeroPosition	0
MC_MoveFeed 3-9	7
MC_Stop 3-12	25
MC_ImmediateStop 3-13	34
MC_SetPosition 3-13	39
MC_SetOverride 3-14	ŀ5
MC_ResetFollowingError 3-15	<b>6</b> 0
MC_CamIn	6
MC_CamOut 3-20	)2
MC_GearIn 3-20	)7
MC_GearInPos 3-22	25
MC_GearOut 3-24	ŀ5
MC_MoveLink	0
MC_CombineAxes 3-27	'2
MC_Phasing 3-28	3
MC_TorqueControl	0
MC_SetTorqueLimit 3-30	)1
MC_ZoneSwitch 3-30	)7
MC_TouchProbe	3
MC_AbortTrigger 3-33	3

MC_AxesObserve	3-338
MC_SyncMoveVelocity	3-344
MC Reset	3-352

# **MC\_Power**

The MC\_Power instruction makes a Servo Drive ready to operate.

Instruction	Name	FB/FUN	Graphic expression	ST expression
MC_Power	Power Servo	FB	MC_Power_instance  MC_Power Axis Axis Enable Status Busy Error ErrorID	MC_Power_instance ( Axis :=parameter, Enable :=parameter, Status =>parameter, Busy =>parameter, Error =>parameter, ErrorID =>parameter );

# **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Enable	Enable	BOOL	TRUE or FALSE	FALSE	The device is ready for operation when Enable is TRUE, and not ready when it is FALSE.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Status	Servo ON	BOOL	TRUE or FALSE	TRUE when the device is ready for operation.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

# Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Status	When the specified axis becomes ready for operation.	When operation ready status for the specified axis is cleared.
		When Error changes to TRUE.
Busy	When Enable changes to TRUE.	When Enable changes to FALSE.
		When Error changes to TRUE.
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# In-Out Variables

Name	Meaning	Data type	Valid range	Description
Axis	Axis	_sAXIS_REF		Specify the axis.*

Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are MC\_Axis\*\*\*.)

## **Function**

- When Enable changes to TRUE, the axis specified by Axis is made ready to operate. You can control the axis when it is ready to operate.
- When Enable changes to FALSE, the ready status is cleared for the axis specified by Axis. You cannot control the axis after the ready status is cleared because it will not acknowledge operation commands. Also, an error occurs if a motion command is executed for an axis for which the ready status is cleared. You can execute the MC\_Power (Power Servo) and MC\_Reset (Reset Axis Error) instructions even for axes that are not ready.
- You can use this instruction to disable the operation of axes while they are in motion. In this case, CommandAborted will change to TRUE. Output of the operation command will stop and the axis will not longer be ready for operation.
- If home is not defined for a Servomotor with an absolute encoder, compensation is performed using the absolute encoder home offset to define home when the axis is ready to operate. For details on the absolute encoder home offset, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).



#### **Precautions for Correct Use**


- You can use this instruction for servo axes and virtual servo axes. If the instruction is used for encoder axes or virtual encoder axes, an error will occur.
- Executing this Instruction for the Master Axis of Synchronized Control When master axis operation is disabled for a vertical axis, the position of the master axis may change rapidly. This may cause the motion of the slave axis to change rapidly. Take suitable measures to prevent the slave axis from moving rapidly, such as applying a brake to the master axis or leaving master axis operation enabled until after synchronized control is completed.




#### **Additional Information**

We recommend that you use the master control instructions for the MC\_Power (Power Servo) instruction as shown below. This ensures that the Servo is turned OFF when the master control is turned OFF.

Master control started.





## Relation to CPU Unit Operating Modes


If an axis is placed in ready status during RUN mode, ready status will continue even if the operating mode changes to PROGRAM mode.

## Deleting Instruction with Online Editing

If an axis is placed in ready status, ready status will continue even if the instruction is deleted during online editing.

# **Timing Charts**

- When *Enable* changes to TRUE, *Busy* (Executing) changes to TRUE to indicate that the instruction was acknowledged.
- After the axis becomes ready for operation, Status (Servo ON) changes to TRUE.
- When Enable changes to FALSE, Busy (Executing) changes to FALSE. Status (Servo ON) changes
  to FALSE when ready status is cleared. Status (Servo ON) outputs the axis ready status regardless
  of whether Enable is TRUE or FALSE.





#### **Precautions for Correct Use**

Status (Servo ON) will not change to TRUE until Enable changes to TRUE and the processing is finished at the axis. Make sure that Status (Servo ON) changes to TRUE before moving the axis.



#### **Precautions for Safe Use**

Write the user program to confirm that EtherCAT communications are established before you execute motion control instructions. This is particularly important when starting axis operation immediately after you turn ON the power supply to the CPU Unit.

Also, include interlocks in the user program that detect errors in EtherCAT communications during operation.

# Re-execution of Motion Control Instructions

You cannot re-execute motion instructions with enable-type inputs.

## **Multi-execution of Motion Control Instructions**

For details on multi-execution of motion control instructions, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).


#### Multi-execution of MC Power Instructions




#### **Precautions for Correct Use**

Do not execute the MC\_Power (Power Servo) instruction for an axis that is already enabled for another instance of the MC\_Power (Power Servo) instruction. Normally, use only one MC\_Power (Power Servo) instruction for each axis.

If another MC\_Power instruction is executed for the same axis, the last instruction takes priority.





# **Error Codes**

Refer to A-1 Error Codes for instruction errors.

# MC\_MoveJog

The MC\_MoveJog instruction jogs an axis according to the specified target velocity.

Instruction	Name	FB/FUN	Graphic expression	ST expression
MC_MoveJog	Jog	FB	MC_MoveJog_instance  MC_MoveJog Axis — Axis PositiveEnable Busy NegativeEnable CommandAborted Velocity Error Acceleration ErrorID Deceleration	MC_MoveJog_instance ( Axis :=parameter, PositiveEnable :=parameter, NegativeEnable :=parameter, Velocity :=parameter, Acceleration :=parameter, Deceleration :=parameter, Busy =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorlD =>parameter );

# **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
PositiveEnable	Positive Direction Enable	BOOL	TRUE or FALSE	FALSE	When this variable changes to TRUE, the axis starts moving in the positive direction. When it changes to FALSE, the axis stops moving.
NegativeEnable	Negative Direction Enable	BOOL	TRUE or FALSE	FALSE	When this variable changes to TRUE, the axis starts moving in the negative direction. When it changes to FALSE, the axis stops moving.
Velocity	Target Velocity	LREAL	Non-negative number	0	Specify the target velocity. The unit is command units/s.*
Acceleration	Acceleration Rate	LREAL	Non-negative number	0	Specify the acceleration rate. The unit is command units/s <sup>2</sup> .*
Deceleration	Deceleration Rate	LREAL	Non-negative number	0	Specify the deceleration rate. The unit is command units/s <sup>2</sup> .*

<sup>\*</sup> Refer to Unit Conversion Settings in the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507) for information on command units.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

## Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Busy	When PositiveEnable or NegativeEnable changes to TRUE.	<ul> <li>When the axis stops.</li> <li>When <i>Error</i> changes to TRUE.</li> <li>When <i>CommandAborted</i> changes to TRUE.</li> </ul>
CommandAborted	<ul> <li>When this instruction is aborted because another motion control instruction was executed with the Buffer Mode set to <i>Aborting</i>.</li> <li>When this instruction is canceled due to an error.</li> <li>When this instruction is executed while there is an error.</li> <li>When you start this instruction during MC_Stop instruction execution.</li> </ul>	<ul> <li>When PositiveEnable changes to FALSE.</li> <li>When NegativeEnable changes to FALSE.</li> <li>After one period when PositiveEnable and NegativeEnable are FALSE.</li> </ul>
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# **In-Out Variables**

Name	Meaning	Data type	Valid range	Description
Axis	Axis	_sAXIS_REF		Specify the axis.*

<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are *MC\_Axis*\*\*\*.)


### **Function**

- The MC\_MoveJog instruction performs jogging according to the specified Velocity (Target Velocity).
- To jog in the positive direction, change *PositiveEnable* (Positive Direction Enable) to TRUE. To jog in the negative direction, change *NegativeEnable* (Negative Direction Enable) to TRUE.
- If *PositiveEnable* (Positive Direction Enable) and *NegativeEnable* (Negative Direction Enable) are changed to TRUE at the same time, *PositiveEnable* (Positive Direction Enable) takes priority. As a result, the axis will jog in the positive direction.
- If the command velocity of the MC\_MoveJog (Jog) instruction exceeds the maximum jog velocity that is set in the axis parameters, the maximum jog velocity is used.




#### **Precautions for Correct Use**

• When creating a ladder diagram, you must connect the PositiveEnable (Positive Direction Enable) input variable to the left bus bar and specify a variable for the NegativeEnable (Negative Direction Enable) input variable as shown below.




To use the master control instructions (MC and MCR) for the MC MoveJog (Jog) instruction, do not program the instructions as shown below. If you do, master control is applied only to PositiveEnable (Positive Direction Enabled), i.e., it is not applied to NegativeEnable (Negative Direction Enabled).


Master control started.








Master control ended.




Always use the master control instructions for the MC\_Power instruction.



# **Timing Charts**

- Busy (Executing) changes to TRUE as soon as PositiveEnable (Positive Direction Enable) or NegativeEnable (Negative Direction Enable) changes to TRUE.
- The axis starts deceleration as soon as PositiveEnable (Positive Direction Enable) or NegativeEnable (Negative Direction Enable) changes to FALSE. Busy (Executing) changes to FALSE when the axis stops completely.
- If another instruction aborts this instruction, CommandAborted changes to TRUE and Busy (Executing) changes to FALSE.




You can specify the Velocity (Target Velocity), Acceleration (Acceleration Rate), and Deceleration (Deceleration Rate) as input variables. Input variables Velocity (Target Velocity), Acceleration (Acceleration Rate), and Deceleration (Deceleration Rate) are updated in the motion only when PositiveEnable (Positive Direction Enable) or NegativeEnable (Negative Direction Enable) changes to TRUE. Therefore, the axis velocity will not change even if Velocity (Target Velocity) changes while PositiveEnable (Positive Direction Enable) or NegativeEnable (Negative Direction Enable) remains TRUE.

## • Timing Chart When Target Velocity Is 0


When the *Velocity* (Target Velocity) is 0 and you start jogging the axis, the axis will enter continuous operation without motion.

The following timing chart shows an example when the *Velocity* (Target Velocity) is 0 and you start jogging the axis.



## • Timing Chart When Acceleration/Deceleration Rate Is 0

When the *Acceleration* (Acceleration Rate) or *Deceleration* (Deceleration Rate) is 0 and you start jogging the axis, the axis will reach the target velocity without accelerating or decelerating. The timing chart below shows an example when the *Acceleration* (Acceleration Rate) and *Deceleration* (Deceleration Rate) are 0.




## **Re-execution of Motion Control Instructions**

## Restarting with Enable in the Same Direction

If you change PositiveEnable (Positive Direction Enable) or NegativeEnable (Negative Direction Enable) to TRUE when it is FALSE and the axis is decelerating, the axis will begin to accelerate towards the target velocity. If you change the Velocity (Target Velocity), Acceleration (Acceleration Rate), or *Deceleration* (Deceleration Rate) at this time, the new value of the input parameter is used in operation.

The axis is not stopped, and Busy (Executing) does not change to FALSE.

The following example shows operation when PositiveEnable (Positive Direction Enable) changes to TRUE during deceleration.




#### Restarting with Enable in the Opposite Direction

If you change NegativeEnable (Negative Direction Enable) to TRUE when PositiveEnable (Positive Direction Enable) is TRUE and the axis is jogging in the positive direction, the axis will reverse its direction and start jogging in the negative direction. When this happens, you can jog the axis with the input variables for when NegativeEnable (Negative Direction Enable) changes to TRUE. The input variables are Velocity (Target Velocity), Acceleration (Acceleration Rate), and Deceleration (Deceleration Rate).

The deceleration rate before the axis direction is reversed and the acceleration rate after it is reversed follow the input variables for when Negative Enable (Negative Direction Enabled) changes to TRUE, regardless of the Operation at Reversing axis parameter. When NegativeEnable (Negative Direction Enable) is TRUE and the axis is jogging in the negative direction, the same operation occurs when PositiveEnable (Positive Direction Enable) changes to TRUE.

If NegativeEnable (Negative Direction Enable) changes to TRUE while PositiveEnable (Positive Direction Enable) is TRUE, the axis starts jogging in the negative direction. In this case, the axis will not jog in the positive direction even if NegativeEnable (Negative Direction Enable) changes to FALSE. To jog the axis in the positive direction, change PositiveEnable (Positive Direction Enable) to FALSE, and then back to TRUE again. The same operation applies to the opposite case.

The following example shows an operation example when NegativeEnable (Negative Direction Enabled) changes to TRUE after Positive Enable (Positive Direction Enabled) changes to TRUE.




# **Multi-execution of Motion Control Instructions**

For details on multi-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

## **Errors**

If an error occurs during instruction execution, *Error* will change to TRUE and the axes will stop. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).

## • Timing Chart When Error Occurs



## Error Codes

Refer to A-1 Error Codes for instruction errors.

# MC\_Home

The MC\_Home instruction operates the motor to determine home. It uses the limit signals, home proximity signal, and home signal.

Instruction	Name	FB/FUN	Graphic expression	ST expression
MC_Home	Home	FB	MC_Home_instance  MC_Home Axis Execute  Done Busy CommandAborted Error ErrorID	MC_Home_instance ( Axis :=parameter, Execute :=parameter, Done =>parameter, Busy =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorID =>parameter );

# **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Execute</i> changes to TRUE.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description	
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.	
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.	
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.	
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.	
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.	

<sup>\*</sup> Refer to A-1 Error Codes.

## Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When the instruction is completed.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
CommandAborted	<ul> <li>When this instruction is aborted because another motion control instruction was executed with the Buffer Mode set to <i>Aborting</i>.</li> <li>When this instruction is canceled due to an error.</li> <li>When this instruction is executed while there is an error.</li> <li>When you start this instruction during MC_Stop instruction execution.</li> </ul>	When Execute is TRUE and changes to FALSE.     After one period when Execute is FALSE.
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# In-Out Variables

Name	Meaning	Data type	Valid range	Description
Axis	Axis	_sAXIS_REF		Specify the axis.*

<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are *MC\_Axis*\*\*\*.)

### **Function**

- Homing starts when Execute changes to TRUE for the axis specified in Axis.
- Set the parameters used by the home instruction in the axis parameters.
- There are 10 Homing Operation Modes for the home instruction.
   Set the desired method in axis parameter Homing Method in the Sysmac Studio.



### **Precautions for Correct Use**

Refer to *Precautions for Master and Auxiliary Axes in Synchronized Control* on page 1-7 for precautions on the master axis.

#### Mapping Data Objects

To use the MC\_Home instruction, map the following object data in the Detailed Settings Area of the Axis Basic Settings Display of the Sysmac Studio. However, setting is not required for Homing Operation Modes 11, 12, and 14.

- Touch probe function (60B8 hex)
- Touch probe status (60B9 hex)
- Touch probe pos1 pos value (60BA hex)

If even one of the required objects is not set, a Process Data Object Setting Missing error (error code 3461 hex) occurs.

For details on mapping data objects, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

# Settings for OMRON G5-series Servo Drives

Set the input signals, such as the home proximity signal, that are used by the home instruction in the OMRON G5-series Servo Drive.

Refer to the information on connecting to the Servo Drive in the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507) and information on sequence I/O signals in the G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications User's Manual (Cat. No. 1576) for details on how to set the input signals.


Name	Meaning	Data type	Valid range	Unit	Default	Description
ProximitySignal Reference	Proximity Sig- nal Selection	Input_REF				Select the input to use for the home proximity input signal.
HomeSignal Reference	Home Signal Selection	Input_REF				Select the input to use for the home input signal.

# **Homing Operation Modes**


You can select any of the ten operations to define home. For details on the operations, refer to Function on page 3-17.

# **Operation at Positive Limit Input and at Negative Limit Input**

- Select the operation when the axis reaches a limit input in the operating direction during homing: reverse the axis and continue with homing, or do not reverse the axis, create an error, and stop the axis. To reverse the axis, also select the stopping method.
- An error occurs and the axis stops if the axis is set to reverse direction, and the limit signal in the
  home input detection direction turns ON when traveling at the homing approach velocity. However, if
  the operating mode is 13 (no home proximity input/holding home input), which does not use proximity
  signals, no error will occur and the axis will not stop.



 An error occurs and the axis stops if the axis is set to reverse direction or the limit input operation in both directions and home cannot be detected after moving from the limit input opposite to the home input detection direction to the other limit input.



# **Homing Start Direction**

Select the direction in which the axis starts moving when homing is started. If homing starts while the home proximity signal is ON in a Homing Operation Mode that includes reversal operation, the axis starts motion in the direction opposite to the home input detection direction (regardless of the setting of the homing start direction).

There are four Homing Operation Modes that include reversal operation for a reverse turn. These are listed below.

- 0: Proximity reverse turn/home proximity input OFF
- 1: Proximity reverse turn/home proximity input ON
- 9: Proximity reverse turn/home input mask distance
- 12: Proximity reverse turn/holding time

Homing start direction: Positive Home input detection direction: Positive Home proximity input signal (3)Operation command Start Positive direction Negative direction Start Start (2)

- The home proximity signal is OFF, so the axis starts moving in the homing start direction. (1), (3):
- (2): The home proximity signal is ON, so the axis starts moving in the direction opposite to the home input detection direction.

Homing start direction: Negative Home input detection direction: Negative ON Home proximity input signal OFF Operation command Start Start Negative direction Positive direction


- The home proximity signal is OFF, so the axis starts moving in the homing start direction. (1), (3):
- (2): The home proximity signal is ON, so the axis starts moving in the direction opposite to the home input detection direction.

# **Home Input Detection Direction**

Select the direction when home input is detected.


The following timing chart shows the operation when the home input detection direction is FALSE (positive direction).

Operation Example: Proximity Reverse Turn/Home Proximity Input OFF



The following timing chart shows the operation when the home input detection direction is TRUE (negative direction).

Operation Example: Proximity Reverse Turn/Home Proximity Input OFF



# **Home Input Mask Distance**

Set the feed distance when you set the Homing Operation Mode to 9 (proximity reverse turn/home input mask distance). For details on operation, refer to *Function* on page 3-17.

# **Homing Compensation Value**

Set the homing compensation value that is applied after the home is detected. Set the travel velocity in the Homing Compensation Velocity. For details on operation, refer to *Function* on page 3-17.

## **Home Position Offset**

The Home Position Offset is used to preset the actual position after homing is completed. The current value is the value set for the Home Position Offset.

# **Homing Velocity**

This is the high velocity during homing.

# **Homing Approach Velocity**

This is the proximity velocity during homing.

# **Homing Compensation Velocity**

This is the velocity when you set a homing compensation value. For details on operation, refer to *Function* on page 3-17.


# **Instruction Details**

## Homing Definition Operation

This section describes the 10 Homing Operation Modes.

## 0: Proximity Reverse Turn/Home Proximity Input OFF Operation

- The axis starts at the homing velocity. When the home proximity input signal turns ON, the axis starts decelerating to the homing approach velocity.
- **2** After the axis reaches the homing approach velocity, the axis stops at the first home input signal after the home proximity input signal turns OFF. This defines home.




- If you start homing while the home proximity input signal is ON, the operation will start at the homing velocity in the direction opposite to the home input detection direction. After the home proximity input turns OFF, the homing operation will start at the homing velocity in the home input detection direction.
- Homing is started and home is defined when the home input signal turns ON after the home proximity input signal turns ON and OFF while the velocity is below the homing approach velocity.

#### 1: Proximity Reverse Turn/Home Proximity Input ON Operation

- 1 The axis starts at the homing velocity. When the home proximity input signal turns ON, the axis starts decelerating to the homing approach velocity.
- **2** After the axis reaches the homing approach velocity, the axis stops at the first home input signal. This defines home.


After the home proximity input signal turns ON, its status does not affect operation.



- If you start homing while the home proximity input signal is ON, the operation will start at the homing velocity in the direction opposite to the home input detection direction. After the home proximity input turns OFF, the homing operation will start at the homing velocity in the home input detection direction.
- Homing is started and home is defined when the home input signal turns ON after the home proximity input signal turns ON while the velocity is below the homing approach velocity.

## 4: Operation for Home Proximity Input OFF

- **1** When the home proximity input signal turns ON, the axis starts decelerating to the homing approach velocity.
- **2** After the axis reaches the homing approach velocity, the axis stops at the first home input signal after the home proximity input signal turns OFF. This defines home.



• If you start homing while the home proximity input signal is ON, the axis performs the following operation depending on the setting of the homing start direction.

#### **Homing Start Direction Same as Home Input Detection Direction**

The axis does not perform a reverse turn operation and homing starts in the home input detection direction at the homing approach velocity.

#### Homing Start Direction Different from Home Input Detection Direction


Operation starts in the homing start direction at the homing velocity, regardless of the status of the home proximity input signal. If you set the operation at the limit input in the homing start direction to reverse direction, the axis reverses direction when limit input is detected and performs a homing operation in the home input detection direction.

 Homing is started and home is defined when the home input signal turns ON after the home proximity input signal turns ON and OFF while the velocity is below the homing approach velocity.

### 5: Home Proximity Input ON Operation

- When the home proximity input signal turns ON, the axis starts decelerating to the homing approach velocity.
- After the axis reaches the homing approach velocity, the axis stops at the first home input signal. This defines home.

After the home proximity input signal turns ON, its status does not affect operation.



· If you start homing while the home proximity input signal is ON, the axis performs the following operation depending on the setting of the homing start direction.

#### **Homing Start Direction Same as Home Input Detection Direction**

The axis does not perform a reverse turn operation and homing starts in the home input detection direction at the homing approach velocity.


#### Homing Start Direction Different from Home Input Detection Direction

Operation starts in the homing start direction at the homing velocity, regardless of the status of the home proximity input signal. If you set the operation at the limit input in the homing start direction to reverse direction, the axis reverses direction when limit input is detected and performs a homing operation in the home input detection direction.

 Homing is started and home is defined when the home input signal turns ON after the home proximity input signal turns ON while the velocity is below the homing approach velocity.

## 8: Operation for Limit input OFF

- The axis starts at the homing velocity. When the limit signal in the direction opposite to the home input detection direction turns ON, the axis starts decelerating to the homing approach velocity.
- **2** After the axis reaches the homing approach velocity, the axis stops at the first home input signal after the limit signal turns OFF. This defines home.




- If you perform homing while the limit input on the opposite side of the home input detection direction is ON, the homing operation starts at the home approach velocity in the home input detection direction.
- Homing is started and home is defined when the home input signal turns ON after the limit signal
  in the direction opposite to the home input detection direction turns ON and OFF again while the
  velocity is below the homing approach velocity.

# 9: Proximity Reverse Turn/Home Input Mask Distance Operation

- 1 The axis starts at the homing velocity. When the home proximity input signal turns ON, the axis starts decelerating to the homing approach velocity.
- The axis moves by the home input mask distance after the home proximity input signal turns ON and stops at the first home input signal. This defines home.

After the home proximity input signal turns ON, its status does not affect operation. If the specified travel distance is too short and travel would be completed before the axis decelerates to the homing approach velocity, an Invalid Home Input Mask Distance error (error code: 742B hex) occurs when you start homing.




• If you start homing while the home proximity input signal is ON, the operation will start at the homing velocity in the direction opposite to the home input detection direction. After the home proximity input signal turns OFF, the homing operation will start at the homing approach velocity in the home input detection direction.

Homing is started and home is defined when the home input signal turns ON after the axis travels
the home input mask distance after the home proximity input signal turns ON while the velocity is
below the homing approach velocity.

## 11: Operation for Limit Inputs Only

- The axis starts at the homing velocity. When the limit signal in the direction opposite to the home input detection direction turns OFF, the axis decelerates to a stop.
- **2** After the axis stops, the axis moves in the other direction at the homing velocity and decelerates to a stop when the limit signal turns ON.
- After the axis stops, the axis moves in the other direction at the homing approach velocity. The position where the limit signal turns OFF is defined as home and an immediate stop is performed (i.e., a stop using remaining pulses). The axis does not return to the home position.



- If you use only the limit signals to perform homing, the point at which the limit signal turns OFF during operation in the home input detection direction is set as the home detection position.
- If you start homing while the limit signal in the home input detection direction is ON, the operation will start at the homing velocity in the direction opposite to the home input detection direction. When the limit signal in the direction opposite to the home input detection direction turns ON, the axis decelerates to a stop.
- Even if the limit signal turns OFF before the axis decelerates to a stop after the limit signal is detected, home is not defined and the axis continues to decelerate. In this case, no error will occur.
- Home is defined if the limit signal turns OFF before the homing approach velocity is reached after the axis reverses or after starting while the limit signal is input.


#### Differences between Homing Mode 11 and Other Homing Modes

For Homing Mode 11, the MC Function Module detects when the limit signal turns OFF to define home. It differs from a Homing Mode that uses the home input as an external latch signal in the following ways.

Make sure that you understand these differences before you use Homing Mode 11.

The MC Function Module detects the limit input without an external latch function, such as one
provided by a Servo Drive. The processing for the MC Function Module is performed in the primary period. Therefore, the precision of the home definition will depend on the homing approach
velocity and the control period of the primary periodic task.

- The axis does not return to the home position. If the homing compensation value is 0, processing for homing will end with the axis at a different position (i.e., not at home).
- Homing compensation is not performed if the homing compensation value is set to 0. If the homing compensation value is 0, processing for homing will end with the axis at a different position (i.e., not at home), as explained above. If the homing compensation value is not 0, then homing compensation is performed with the homing compensation value as a relative position from home in the same way as for other modes.
- The home offset is used to change the position of home. If the stop position is offset from home by distance D, as shown in the following figure, the position after the completion of processing for homing will be L + D if the home offset is L and the homing compensation value is 0.






#### **Precautions for Correct Use**

- After the OFF limit signal is detected, the limit signal in the opposite direction from the home input detection direction is ignored while stopping for the remaining pulses until homing compensation is started.
- If the homing compensation value is 0 and the limit input signal in the home input detection direction turns ON immediately after home is defined, set a homing compensation value to return past the limit signal input position.

## **Application Example for Homing Mode 11**

If, as shown below, there is not sufficient space to install both a negative limit signal and home signal, you can use the negative limit signal to perform the functions of both the limit signal and home signal.



## 12: Proximity Reverse Turn/Holding Time Operation

The axis starts at the homing velocity. When the home proximity input signal turns ON, the axis starts decelerating to the homing approach velocity.

Decelerating the axis and monitoring time are started at the same time. The torque limit at the start of holding differs between OMRON G5-series Servo Drives and other Servo Drives as shown below.


G5 Servo Drives: Automatically applies torque limits.

Other Servo Drives: Apply torque limits according to a setting.

Refer to *Holding Operation for OMRON G5-series Servo Drives* on page 3-31 for information on the holding operation.

**2** Home is defined when the set time elapses.

After the home proximity input signal turns ON, its status does not affect operation.



- If you start homing while the home proximity input signal is ON, the operation will start at the homing velocity in the direction opposite to the home input detection direction. After the home proximity input signal turns OFF, the homing operation will start at the homing approach velocity in the home input detection direction.
- Releasing the torque limit also differs between OMRON G5-series Servo Drives and other Servo Drives.

G5 Servo Drives: Automatically released when the axis moves in the direction oppo-

site to home definition direction for the first time after homing.

Other Servo Drives: If a torque limit is used, release the torque limit when the axis

moves in the direction opposite to home definition direction for the first time after homing. Use the ECAT\_CoEWriteSdo command to

change the torque limit.

- An error will not occur and home is defined even if the holding time elapses after the home proximity input signal is detected and before velocity reaches the homing approach velocity.
- Home is also defined if the holding time elapses after the home proximity input signal turns ON before the homing approach velocity is reached.

# 13: No Home Proximity Input/Holding Home Input Operation

**1** The axis starts at the homing approach velocity.


The torque limit at the start of holding differs between OMRON G5-series Servo Drives and other Servo Drives as shown below.

G5 Servo Drives: Automatically applies torque limits.

Other Servo Drives: A torque limit imposed as required.

Refer to *Holding Operation for OMRON G5-series Servo Drives* on page 3-31 for information on the holding operation.

**2** Home is defined when the home input turns ON.



Command torque from previous operation

 Releasing the torque limit also differs between OMRON G5-series Servo Drives and other Servo Drives.

G5 Servo Drives: Automatically released when the axis moves in the direction oppo-

site to home definition direction for the first time after homing.

Other Servo Drives: If a torque limit is used, release the torque limit when the axis


moves in the direction opposite to home definition direction for the first time after homing. Use the ECAT\_WriteSDO command to

change the torque limit.

• Home is also defined if the home input signal turns ON before the homing approach velocity is reached after homing starts.

#### 14: Zero Position Preset Operation


The command current position and the actual current position are set to the home position offset to define home. The following timing chart shows the operation when home position offset is set to 0.



### Axis Stopping Method and In-position Check When Homing

The axis is stopped with the following procedure when homing.

- The actual position where the home input signal was detected is latched and the axis stops immediately.
- After the immediate stop, the axis moves with absolute travel in the reverse direction to the position that was latched in step 1.




• Waiting for the in-position state is always performed for this instruction regardless of the setting of the In-position Check Time axis parameter.

Be particularly careful when performing absolute travel to the home input signal detection position if the In-position Check Time is set to 0 because the instruction will continue waiting for the inposition status. Make sure that the signal is received within the in-position range. In-position waiting is not performed for the homing compensation value operation even if the in-position check time is set to 0. The status of in-position waiting can be checked with the InPosWaiting (In-position Waiting) system-defined variable for motion control.

### Homing Compensation

When you set a homing compensation value, the axis will move by the homing compensation value after the home input is detected to define home. Adjusting the workpiece is sometimes difficult after home has been defined in the mechanical system. You can use the homing compensation to fine-tune the position of home after it is defined. The travel velocity at this time is the homing compensation velocity. The axis starts moving 500 ms after it stopped when the home input was detected.

The sign of the homing compensation value indicates the direction relative to the coordinate axis. If it is negative, the axis moves in the negative direction.



#### Override Factors

Overrides are disabled for this instruction.

### Automatic Control of Torque Limit

If you are using an OMRON G5-series Servo Drive, and you select either Proximity Reverse Turn/Holding Time Operation (12) or No Home Proximity Input/Holding Home Input Operation (13) for the homing operation, the torque limit will be automatically started in the holding direction. Automatic control of the torque limit when homing maintains the torque limit even after homing is completed. The torque limit is released when the axis moves in the direction opposite to the home input detection direction.

The torque limit is automatically released at the following times.

- When the Servo is turned OFF (Servo Unlock)
- When the Cyclic Synchronous Positioning Control (CSP) Mode is changed to another control mode.

During the homing operation, torque limits are released for operation in the direction opposite to the home input detection direction. For example, if the reversal operation direction at a limit input is in the direction opposite to the home input detection direction, the torque limit is released when the reversal operation is completed. If the operation direction reverses again and becomes the home input detection direction, the torque limit will be enabled again.

### Holding Operation for OMRON G5-series Servo Drives

Torque limits that are set in the Servo Drive in advance are used for the Proximity Reverse Turn/Holding Time (12) or No Home Proximity Input/Holding Home Input (13) Homing Operation Modes to automatically start torque control in the home input detection direction.



#### **Precautions for Correct Use**

The automatic torque limit function of the MC\_Home instruction is not used for servo drives from other manufacturers. Use the MC\_SetTorqueLimit instruction, SDO communications, or support software to set suitable values.



#### **Additional Information**

- The torque limits are continued even after a normal completion of homing.
- · The torque limits are automatically released when an instruction that moves the axis in the opposite direction is executed.

#### Settings for OMRON G5-series Servo Drives

To use the holding operation, you must use the support software of the Servo Drive to set the Torque Limit Selection (3521 hex) in the G5-series Servo Drive.

- Set the Torque Limit Selection to 6 to apply a torque limit in the home input detection direction during the holding operation for homing and to use the torque limit directions and values that are set with the MC\_SetTorqueLimit instruction for other operation. In that case, the values of the input variables to the MC\_SetTorqueLimit instruction are ignored during the holding operation for homing.
- If the Torque Limit Selection is set to 4, the values of the input variables to the MC\_SetTorqueLimit instruction are always used. You must set torque limits that are suitable for both for the holding operation during homing and for other operations.

		Torque Limit Selection (3521 hex)			
		6 (recommended)	4		
Positive Torque	Homing	Torque Limit 3 (3525 hex) is used.	The smaller of the PositiveValue		
Limit	Operations other than Homing	The smaller of the PositiveValue (Positive Torque Limit) for the MC_SetTorqueLimit instruction and Torque Limit 1 (3013 hex) is used.	(Positive Torque Limit) for the MC_SetTorqueLimit instruction and Torque Limit 1 (3013 hex) is used.		
Negative Torque	Homing	Torque Limit 4 (3526 hex) is used.	The smaller of the NegativeValue		
Limit	Operations other than Homing	The smaller of the NegativeValue (Negative Torque Limit) for the MC_SetTorqueLimit instruction and Torque Limit 2 (3522 hex) is used.	(Negative Torque Limit) for the MC_SetTorqueLimit instruction an Torque Limit 2 (3522 hex) is used.		

For details on torque limits, refer to MC\_SetTorqueLimit on page 3-301. Refer to the G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications User's Manual (Cat. No. 1576) for information on the settings in the OMRON G5-series Servo Drive.

#### Monitoring Following Error during Holding Operation


The following error is not monitored during the holding operation for homing.

For details on monitoring the following error, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).


# **Timing Charts**

The following charts show the timing of homing.


### No Homing Compensation




### With Homing Compensation



#### • Execution When Home Is Defined



### • Execution with Incorrect Parameters or When Motion Control Instructions Are **Disabled**



# **Re-execution of Motion Control Instructions**

This instruction cannot be re-executed.

A Motion Control Instruction Re-execution Disabled error (error code: 543B hex) occurs if re-execution is attempted.

# **Multi-execution of Motion Control Instructions**

For details on multi-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

# **Error Codes**

Refer to A-1 Error Codes for instruction errors.

# MC\_Move

The MC\_Move instruction performs absolute positioning or relative positioning.

Instruction	Name	FB/FUN	Graphic expression	ST expression
MC_Move	Positioning	FB	MC_Move_instance  MC_Move Axis	MC_Move_instance ( Axis :=parameter, Execute :=parameter, Position :=parameter, Velocity :=parameter, Acceleration :=parameter, Deceleration :=parameter, Jerk :=parameter, Direction :=parameter, BufferMode :=parameter, MoveMode :=parameter, Done =>parameter, Busy =>parameter, Active =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorID =>parameter);

# **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Execute</i> changes to TRUE.
Position	Target Position	LREAL	Negative number, positive number, or 0	0	Specify the target position in absolute coordinates when you specify absolute positioning as the Travel Mode. Specify the relative position when you specify relative positioning as the Travel Mode. The unit is command units.*1
Velocity	Target Velocity	LREAL	Positive number	0	Specify the target velocity.*2 The unit is command units/s.*1
Acceleration	Acceleration Rate	LREAL	Non-negative number	0	Specify the acceleration rate. The unit is command units/s <sup>2</sup> .* <sup>1</sup>
Deceleration	Decelera- tion Rate	LREAL	Non-negative number	0	Specify the deceleration rate. The unit is command units/s <sup>2</sup> .* <sup>1</sup>
Jerk	Jerk	LREAL	Non-negative number	0	Specify the jerk. The unit is command units/s <sup>3</sup> .* <sup>1</sup>

Name	Meaning	Data type	Valid range	Default	Description
Direction	Direction	_eMC_DIRECTION	0: _mcPositiveDirection 1: _mcShortestWay 2: _mcNegativeDirection 3: _mcCurrentDirection 4: _mcNoDirection	0*3	Specify the direction of rotation when MoveMode is set to absolute positioning*4 and when the Count Mode is Rotary Mode.
					O: Positive direction 1: Shortest way 2: Negative direction 3: Current direction 4: No direction specified
BufferMode	Buffer Mode Selection	_eMC_BUFFER _ MODE	0: _mcAborting 1: _mcBuffered 2: _mcBlendingLow 3: _mcBlendingPrevious 4: _mcBlendingNext 5: _mcBlendingHigh	0*3	Specifies the operation when executing more than one motion instruction.  0: Aborting 1: Buffered 2: Blend with low 3: Blend with previous 4: Blend with next 5: Blend with high
MoveMode	Travel Mode	_eMC_MOVE_ MODE	0: _mcAbsolute 1: _mcRelative	0*3	Select the travel method.  0: Absolute positioning  1: Relative positioning

<sup>\*1</sup> Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE	TRUE when the axis is being controlled.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

<sup>\*2</sup> Always set the target velocity. A Target Velocity Setting Out of Range error (error code: 5422 hex) occurs when the instruction is executed if the target velocity is not set.

<sup>\*3</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

<sup>\*4</sup> When MoveMode is set to relative positioning, the travel direction is determined by the sign of the position.

#### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When the axis decelerates to a stop and the velocity reaches 0.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
Active	When the instruction is started.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
CommandAborted	When this instruction is aborted because another motion control instruction was	When Execute is TRUE and changes to FALSE.
	executed with the Buffer Mode set to Aborting.	After one period when Execute is FALSE.
	When this instruction is canceled due to an error.	
	When this instruction is executed while there is an error.	
	When you start this instruction during MC_Stop instruction execution.	
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# **In-Out Variables**

Name	Meaning	Data type	Valid range	Description
Axis	Axis	_sAXIS_REF		Specify the axis.*

<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are MC\_Axis\*\*\*.)

### **Function**

- You can use the MC\_Move instruction to perform absolute positioning or relative positioning.
- If you specify absolute positioning for MoveMode (Travel Mode), the operation is the same as for the MC\_MoveAbsolute (Absolute Positioning) instruction. If you specify relative positioning for Move-Mode (Travel Mode), the operation is the same as the MC\_MoveRelative (Relative Positioning) instruction.
- If relative positioning is used, Direction is not used.
- For details, refer to MC\_MoveAbsolute on page 3-41 or MC\_MoveRelative on page 3-68.

# **Instruction Details**

This section describes the instruction in detail.



#### **Precautions for Correct Use**

When you perform absolute positioning, set the target position so that the settings of the Modulo Maximum Position Setting Value and Modulo Minimum Position Setting Value axis parameters are not exceeded. If the target position is set outside of the settings of the Modulo Maximum Position Setting Value and Modulo Minimum Position Setting Value axis parameters, a Target Position Setting Out of Range error (error code 5478 hex) will occur.

#### In-position Check

An in-position check is performed for this instruction according to the settings in In-position Range and In-position Check Time axis parameters.

### **Re-execution of Motion Control Instructions**

You can change the operation of the instruction if you change an input variable during positioning and change *Execute* to TRUE again. Input variables *Position* (Target Position), *Velocity* (Target Velocity), *Acceleration* (Acceleration Rate), and *Deceleration* (Deceleration Rate) can be changed by re-executing the motion control instruction. For details on re-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

# **Multi-execution of Motion Control Instructions**

For details on multi-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

### Execution during Execution of Other Instructions

You can switch to this instruction or buffer this instruction if you execute it during execution of another instruction. You can buffer one instruction per axis. Specify the operation of this instruction with *BufferMode* (Buffer Mode Selection) for multi-execution of instructions.

Bu	ffer Mode Selection	Description		
Abo	orting	Aborts the instruction being executed and switches to this instruction.  If the direction of axis motion is reversed by switching instructions, the motion will be reversed according to the Operation at Reversing axis parameter.		
Buff	fered	Buffers this instruction and executes it automatically after the current instruction is completed.		
Bler	nding	Starts the buffered instruction at the velocity (transit velocity) at which the current instruction reaches the target position. The operation of the current instruction is changed so that the axes reach the target position at the transit velocity. There are four methods to specify the transit velocity. These are described below.		
	Blend with low	The lower of the target velocities of the current instruction and the buffered instruction is used as the transit velocity.		
	Blend with previous	The target velocity of the current instruction is used as the transit velocity.		
	Blend with next	The target velocity of the buffered instruction is used as the transit velocity.		
	Blend with high	The higher of the target velocities of the current instruction and the buffered instruction is used as the transit velocity.		

For details on *BufferMode* (Buffer Mode Selection), refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).


## • Execution of Other Instructions during Instruction Execution

If you execute another instruction during execution of this instruction, you can specify aborting, buffering, or blending.

# **Errors**

# • Timing Chart When Error Occurs

If an error occurs during instruction execution, Error will change to TRUE and the axis will stop. You can find out the cause of the error by referring to the value output by ErrorID (Error Code).



#### Error Codes

Refer to A-1 Error Codes for instruction errors.

# **MC\_MoveAbsolute**

The MC\_MoveAbsolute instruction moves the axis to a specified absolute target position.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_MoveAbsolute	Absolute Positioning	FB	MC_MoveAbsolute_instance  MC_MoveAbsolute Axis	MC_MoveAbsolute_instance ( Axis :=parameter, Execute :=parameter, Position :=parameter, Velocity :=parameter, Acceleration :=parameter, Deceleration :=parameter, Jerk :=parameter, Direction :=parameter, BufferMode :=parameter, Busy =>parameter, Busy =>parameter, Active =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorlD =>parameter);

# **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when Execute changes to TRUE.
Position	Target Position	LREAL	Negative number, positive number, or 0	0	Specify the absolute target position. The unit is command units.*1
Velocity	Target Velocity	LREAL	Positive number	0	Specify the target velocity.*2 The unit is command units/s.*1
Acceleration	Accelera- tion Rate	LREAL	Non-negative number	0	Specify the acceleration rate. The unit is command units/s <sup>2</sup> .* <sup>1</sup>
Deceleration	Decelera- tion Rate	LREAL	Non-negative number	0	Specify the deceleration rate. The unit is command units/s <sup>2</sup> .* <sup>1</sup>
Jerk	Jerk	LREAL	Non-negative number	0	Specify the jerk. The unit is command units/s <sup>3</sup> .* <sup>1</sup>

Name	Meaning	Data type	Valid range	Default	Description
Direction	Direction	_eMC_ DIRECTION	0: _mcPositiveDirection 1: _mcShortestWay 2: _mcNegativeDirection 3: _mcCurrentDirection 4: _mcNoDirection	0*3	Specify the direction of rotation when the Count Mode is Rotary Mode.  0: Positive direction 1: Shortest way 2: Negative direction 3: Current direction 4: No direction specified
BufferMode	Buffer Mode Selection	_eMC_BUFFER_ MODE	0: _mcAborting 1: _mcBuffered 2: _mcBlendingLow 3: _mcBlendingPrevious 4: _mcBlendingNext 5: _mcBlendingHigh	0*3	Specify the operation when executing more than one motion instruction.  0: Aborting 1: Buffered 2: Blend with low 3: Blend with previous 4: Blend with next 5: Blend with high

<sup>\*1</sup> Refer to Unit Conversion Settings in the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507) for information on command units.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE	TRUE when the axis is being controlled.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

# Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When positioning is completed.	<ul> <li>When Execute is TRUE and changes to FALSE.</li> <li>After one period when Execute is FALSE.</li> </ul>
Busy	When Execute changes to TRUE.	<ul> <li>When Done changes to TRUE.</li> <li>When Error changes to TRUE.</li> <li>When CommandAborted changes to TRUE.</li> </ul>
Active	When the instruction is started.	<ul> <li>When Done changes to TRUE.</li> <li>When Error changes to TRUE.</li> <li>When CommandAborted changes to TRUE.</li> </ul>

<sup>\*2</sup> Always set the target velocity. If the axis is moved without setting a target velocity, an error will occur.

<sup>\*3</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

Name	Timing for changing to TRUE	Timing for changing to FALSE
CommandAborted	<ul> <li>When this instruction is aborted because another motion control instruction was executed with the Buffer Mode set to Aborting.</li> <li>When this instruction is canceled due to an error.</li> <li>When this instruction is executed while there is an error.</li> <li>When you start this instruction during MC_Stop instruction execution.</li> </ul>	<ul> <li>When Execute is TRUE and changes to FALSE.</li> <li>After one period when Execute is FALSE.</li> </ul>
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# **In-Out Variables**


Name	Meaning	Data type	Valid range	Description
Axis	Axis	_sAXIS_REF		Specify the axis.*

<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are *MC\_Axis*\*\*\*.)


### **Function**

- The absolute target position is specified to perform positioning.
- Absolute positioning starts when Execute changes to TRUE.
- You can execute this instruction even if home is not defined.
- You can specify the Velocity (Target Velocity), Acceleration (Acceleration Rate), Deceleration (Deceleration Rate), and Jerk as input variables.


The following chart shows an operation example of absolute positioning.



When the *Acceleration* (Acceleration Rate) or *Deceleration* (Deceleration Rate) is 0 and the instruction is executed, the axis will reach the target velocity without accelerating or decelerating. The following chart shows an operation example of when the acceleration rate is 0.



Specify Jerk when you want to accelerate or decelerate smoothly. The following chart shows an operation example when Jerk is specified.



For details on Jerk, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).


When the positioning is started with Position (Target Position) set to the command current position, the axis will not move but Done will change to TRUE. Done will change to TRUE in the cycle after Busy changes to TRUE. Therefore, Active (Controlling) will not change to TRUE.

# **Instruction Details**


This section describes the instruction in detail.

#### Direction

*Direction* specifies the direction for starting positioning when the Count Mode is Rotary Mode. *Direction* is not used if the Count Mode is Linear Mode. Positioning starts in the positive direction towards the target position when the positive direction is specified for *Direction*. The following chart shows an operation example when positioning starts with a command position of 50 and moves toward –20.




Positioning starts in the negative direction towards the target position when the negative direction is specified for *Direction*. The following chart shows an operation example when positioning starts with a command position of 50 and moves toward –20.




Positioning starts towards the target position within the ring counter range when No direction is specified for Direction. Therefore, the size relationship between the command current position and the target position determines the direction of travel.


The following chart shows an operation example when positioning starts with a command position of 50 and moves toward -20.



When No direction is specified for Direction, you can specify a Position (Target Position) outside the range specified by the upper and lower limits of the ring counter. When Position (Target Position) is outside the range specified by the upper and lower limits of the ring counter, positioning is performed using the travel distance exceeding the upper limit as a relative distance. This allows positioning of multiple ring rotations. Positioning is the same when Position (Target Position) is below the lower limit of the ring counter as well. The following chart shows an operation example for when the command current position is -20 and *Position* (Target Position) is 290.



When the shortest way is specified for *Direction*, positioning starts in the direction with the shortest distance between the command current position and the target position. The following chart shows an operation example when positioning starts with a command position of 50 and moves toward –20.



Movement is in the same direction as the current direction if the travel distance is the same in the positive and the negative direction.



#### **Precautions for Correct Use**


- When you perform absolute positioning, set the target position so that the settings of the Modulo Maximum Position Setting Value and Modulo Minimum Position Setting Value axis parameters are not exceeded. If the target position is set outside of the settings of the Modulo Maximum Position Setting Value and Modulo Minimum Position Setting Value axis parameters, a Target Position Setting Out of Range error (error code 5478 hex) will occur. However, when No direction is specified for Direction, you can specify a Position (Target Position) outside the range specified by the upper and lower limits of the ring counter.
- If the current direction is specified for *Direction*, operation is in the same command direction as the previous motion. Therefore, depending on the instructions that are used together, the direction may not be the same as the direction that was specified with the input to the motion control instruction for the previous motion. When you specify the current direction, check the current direction with *Dir.Posi* (Positive Direction) and *Dir.Nega* (Negative Direction) in the Axis Variable.

### In-position Check

An in-position check is performed for this instruction according to the settings in In-position Range and In-position Check Time axis parameters.

# **Timing Charts**

- . Busy (Executing) changes to TRUE at the same time as Execute changes to TRUE. Active (Controlling) changes to TRUE in the next period.
- Done changes to TRUE when Position (Target Position) is reached and positioning is completed.
- If another instruction aborts this instruction, CommandAborted changes to TRUE and Busy (Executing) and Active (Controlling) change to FALSE.



# **Re-execution of Motion Control Instructions**

You can change the operation of the instruction if you change an input variable during positioning and change Execute to TRUE again. Input variables Position (Target Position), Velocity (Target Velocity), Acceleration (Acceleration Rate), and Deceleration (Deceleration Rate) can be changed by re-executing the motion control instruction. For details on re-execution of motion control instructions, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

# **Multi-execution of Motion Control Instructions**

For details on multi-execution of motion control instructions, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

# Execution during Execution of Other Instructions

You can switch to this instruction or buffer this instruction if you execute it during execution of another instruction. You can buffer one instruction per axis. Specify the operation of this instruction using *BufferMode* (Buffer Mode Selection) for multi-execution of instructions.

Buff	fer Mode Selection	Description	
Aborting		Aborts the instruction being executed and switches to this instruction. If the direction of axis motion is reversed by switching instructions, the motion will be reversed according to the Operation at Reversing axis parameter.	
Buffered		Buffers this instruction and executes it automatically after the current instruction is completed.	
Blending		Starts the buffered instruction at the velocity (transit velocity) at which the current instruction reaches the target position. The operation of the current instruction is changed so that the axes reach the target position at the transit velocity. There are four methods to specify the transit velocity. These are described below.	
	Blend with low	The lower of the target velocities of the current instruction and the buffered instruction is used as the transit velocity.	
	Blend with previous	The target velocity of the current instruction is used as the transit velocity.	
Blend with next		The target velocity of the buffered instruction is used as the transit velocity.	
	Blend with high	The higher of the target velocities of the current instruction and the buffered instruction is used as the transit velocity.	

For details on *BufferMode* (Buffer Mode Selection), refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).


## • Execution of Other Instructions during Instruction Execution

If you execute another instruction during execution of this instruction, you can specify aborting, buffering, or blending.

# **Errors**

If an error occurs during instruction execution, Error will change to TRUE and the axis will stop. You can find out the cause of the error by referring to the value output by ErrorID (Error Code).

# • Timing Chart When Error Occurs



#### Error Codes

Refer to A-1 Error Codes for instruction errors.

# **Sample Programming 1**

This section shows sample programming for positioning by periodic multi-execution of instructions.

# **Parameter Settings**

The minimum settings required for this sample programming are given below.

#### Setting Axis Parameters

## **Axis Type**

Axis	Axis Type
Axis 1	Servo axis

### **Count Mode**

Axis	Count Mode
Axis 1	Linear Mode

#### **Unit of Display**

Axis	Unit of Display
Axis 1	mm


# **Operation Example**

In this sample, *BufferMode* (Buffer Mode Selection) is set to *Buffered* for MC\_MoveAbsolute (Absolute Positioning) instructions and the axis is moved to the final target position by executing multiple instructions.

When the axis reaches the final target position, it is returned to home with the MC\_ZeroPosition (Highspeed Home) instruction.

Multi-execution of instructions is performed when the *Active* (Controlling) output variable from the previous instruction is TRUE. For single-axis operation, multi-execution is possible for only one instruction.

#### Operation Pattern




- Turning ON the Operation Start Switch
  - When you turn ON the operation start switch at home, axis 1 is positioned to 50.00 mm in the positive direction.
- Turning ON the Operation Start Switch Again Thereafter, axis 1 is positioned to 100.00 mm and 200.00 mm, and then returns to home and stops. The operation start switch must be turned ON once for each of these motions.

# Ladder Diagram

#### Main Variables

Name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		Axis Variable for axis 1.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for
			axis 1.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
StartPg	BOOL	FALSE	The Servo is turned ON if this variable is TRUE and EtherCAT process data communications are established.

### Timing Chart




### Sample Programming

If StartPq is TRUE, EtherCAT communications are checked to see if process data communications are normal.

```
StartPg _EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress] _EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress] Lock1
```


If process data communications are active, the Servo is turned ON.




If there is a minor fault level error for axis 1, the error handler for the device (FaultHandler) is executed. Design FaultHandler separately.

```
MC_Axis000.MFaultLvl.Active
FaultHandler
EN FaultHandler
```


If the Servo is ON and home is not defined, the Home instruction is executed.




After home is defined, absolute positioning 1 is started.




After absolute positioning 1 is started, absolute positioning 2 is started with multi-execution of instructions.





After absolute positioning 2 is started, absolute positioning 3 is started with multi-execution of instructions.

After absolute positioning 3 is started, the High-speed Home instruction is executed.




# **Structured Text (ST)**

#### Main Variables

Name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		Axis Variable for axis 1.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 1.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
StartPg	BOOL	FALSE	The Servo is turned ON if this variable is TRUE and EtherCAT process data communications are established.
Hm_Ex	BOOL	FALSE	The HM instance of MC_Home is executed when this variable changes to TRUE.
Mv_Abs1_Ex	BOOL	FALSE	The MV_ABS1 instance of MC_MoveAbsolute is executed when this variable changes to TRUE.
Mv_Abs2_Ex	BOOL	FALSE	The MV_ABS2 instance of MC_MoveAbsolute is executed when this variable changes to TRUE.
Mv_Abs3_Ex	BOOL	FALSE	The MV_ABS3 instance of MC_MoveAbsolute is executed when this variable changes to TRUE.
Mv_Zero_Ex	BOOL	FALSE	The MV_ZERO instance of MC_MoveZeroPosition is executed when this variable changes to TRUE.
InitFlag	BOOL	FALSE	This variable indicates if it is necessary to set the input parameters. Input parameters are set when this variable is FALSE. When setting the input parameters is completed, this variable changes to TRUE.

## Timing Chart



### Sample Programming

```
// Processing when input parameters are not set IF InitFlag = FALSE THEN
```

```
// MV_ABS1 parameters
Mv Abs1 Pos := LREAL#50.0;
Mv Abs1 Vel := LREAL#10.0;
Mv_Abs1_Acc := LREAL#1000.0;
Mv\_Abs1\_Dec := LREAL#1000.0;
Mv_Abs1_Dir
             := _eMC_DIRECTION#_mcNoDirection;
// MV_ABS2 parameters
Mv_Abs2_Pos := LREAL#100.0;
Mv_Abs2_Vel := LREAL#20.0;
Mv\_Abs2\_Acc := LREAL#1000.0;
Mv\_Abs2\_Dec \quad := LREAL\#1000.0;
Mv\_Abs2\_Dir := \_eMC\_DIRECTION\#\_mcNoDirection;
Mv_Abs2_Bm
             := _eMC_BUFFER_MODE#_mcBuffered;
// MV_ABS3 parameters
Mv\_Abs3\_Pos := LREAL#200.0;
Mv_Abs3_Vel := LREAL#30.0;
Mv_Abs3_Acc := LREAL#1000.0;
Mv_Abs3_Dec := LREAL#1000.0;
Mv_Abs3_Dir
               := _eMC_DIRECTION#_mcNoDirection;
Mv_Abs3_Bm
             := _eMC_BUFFER_MODE#_mcBuffered;
// MV_ZERO parameters
Mv_Zero_Vel
             := LREAL#250;
Mv_Zero_Acc
             := LREAL#1000.0;
```

```
Mv_Zero_Dec := LREAL#1000.0;
   Mv_Zero_Bm
                 := _eMC_BUFFER_MODE#_mcBuffered;
   // Change InitFlag to TRUE after setting the input parameters.
   InitFlag:=TRUE;
END_IF;
// If StartPg is TRUE and EtherCAT communications are normal, the Servo is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
   Pwr_En:=TRUE;
ELSE
   Pwr_En:=FALSE;
END_IF;
// Processing for a minor fault level error
// Implement FaultHandler separately.
IF MC_Axis000.MFaultLvl.Active=TRUE THEN
   FaultHandler();
END_IF;
// If the Servo is ON and home is not defined, the Home instruction is executed.
IF (Pwr_Status=TRUE) AND (MC_Axis000.Details.Homed=FALSE) THEN
   Hm Ex:=TRUE:
END IF;
// After home is defined, MV_ABS1 is executed.
IF Hm_D=TRUE THEN
   Mv_Abs1_Ex:=TRUE;
END_IF;
// After MV_ABS1 is started, MV_ABS2 is executed with multi-execution of instructions.
IF Mv_Abs1_Act=TRUE THEN
   Mv_Abs2_Ex:=TRUE;
END IF;
// After MV_ABS2 is started, MV_ABS3 is executed with multi-execution of instructions.
IF Mv Abs2 Act=TRUE THEN
   Mv_Abs3_Ex:=TRUE;
END_IF;
// After MV_ABS3 is started, MV_ZERO is executed with multi-execution of instructions.
IF Mv_Abs3_Act=TRUE THEN
   Mv_Zero_Ex:=TRUE;
END_IF;
```

```
//MC_Power
PWR(
   Axis
            := MC_Axis000,
   Enable
            := Pwr_En,
   Status
            => Pwr_Status,
   Busy
            => Pwr_Bsy,
   Error
            => Pwr_Err,
   ErrorID
            => Pwr_ErrID
);
//MC_Home
HM(
   Axis
                      := MC_Axis000,
   Execute
                      := Hm Ex,
   Done
                      => Hm_D,
   Busy
                      => Hm_Bsy,
   CommandAborted
                      => Hm Ca,
   Error
                      => Hm_Err,
                      => Hm_ErrID
   ErrorID
);
//MC_MoveAbsolute
MV_ABS1(
   Axis
                      := MC Axis000.
                      := Mv Abs1 Ex,
   Execute
   Position
                      := Mv Abs1 Pos.
   Velocity
                      := Mv Abs1 Vel,
   Acceleration
                      := Mv Abs1 Acc,
   Deceleration
                      := Mv_Abs1_Dec,
   Direction
                      := Mv_Abs1_Dir,
   Done
                      => Mv_Abs1_D,
                      => Mv_Abs1_Bsy,
   Busy
                      => Mv_Abs1_Act,
   Active
                      => Mv_Abs1_Ca,
   CommandAborted
   Error
                      => Mv_Abs1_Err,
   ErrorID
                      => Mv_Abs1_ErrID
);
MV ABS2(
                      := MC_Axis000,
   Axis
   Execute
                      := Mv_Abs2_Ex,
                      := Mv_Abs2_Pos,
   Position
   Velocity
                      := Mv_Abs2_Vel,
   Acceleration
                      := Mv_Abs2_Acc,
                      := Mv_Abs2_Dec,
   Deceleration
   Direction
                      := Mv_Abs2_Dir,
   BufferMode
                      := Mv_Abs2_Bm,
   Done
                      => Mv Abs2 D,
   Busy
                      => Mv_Abs2_Bsy,
   Active
                      => Mv_Abs2_Act,
   CommandAborted
                      => Mv Abs2 Ca.
   Error
                      => Mv_Abs2_Err,
   ErrorID
                      => Mv_Abs2_ErrID
);
MV_ABS3(
   Axis
                      := MC_Axis000,
   Execute
                      := Mv_Abs3_Ex,
   Position
                      := Mv_Abs3_Pos,
                      := Mv_Abs3_Vel,
   Velocity
                      := Mv_Abs3_Acc,
   Acceleration
```

```
:= Mv_Abs3_Dec,
   Deceleration
   Direction
                    := Mv_Abs3_Dir,
   BufferMode
                    := Mv_Abs3_Bm,
   Done
                    => Mv_Abs3_D,
   Busy
                    => Mv_Abs3_Bsy,
   Active
                    => Mv_Abs3_Act,
   CommandAborted => Mv_Abs3_Ca,
                    => Mv_Abs3_Err,
   Error
   ErrorID
                     => Mv_Abs3_ErrID
);
//MC_MoveZeroPosition
MV_ZERO(
   Axis
                     := MC_Axis000,
   Execute
                     := Mv_Zero_Ex,
   Velocity
                    := Mv_Zero_Vel,
   Acceleration
                    := Mv_Zero_Acc,
  Deceleration
BufferMode
                     := Mv Zero Dec.
                     := Mv_Zero_Bm,
   BufferMode
                     => Mv_Zero_D,
   Done
                     => Mv_Zero_Bsy,
   Busy
                     => Mv_Zero_Act,
   Active
   CommandAborted => Mv_Zero_Ca,
                     => Mv_Zero_Err,
   Error
                     => Mv_Zero_ErrID
   ErrorID
);
```

# **Sample Programming 2**

In this sample, when the Count Mode is set to Rotary Mode and positioning is performed toward the target position, the shortest direction, clockwise or counterclockwise, is automatically determined and positioning is performed.

This section shows sample programming for shortest-way control of the rotation direction of a tool changer.

# **Parameter Settings**

The minimum settings required for this sample programming are given below.

### Setting Axis Parameters

#### **Axis Type**

Axis	Axis Type
Axis 1	Servo axis

#### **Count Mode**

Axis	Count Mode
Axis 1	Rotary Mode

#### **Ring Counter**

Axis	Modulo maximum position	Modulo minimum position
Axis 1	360	0


#### **Unit of Display**

Axis	Unit of Display	
Axis 1	degree	

# **Operation Example**

In this sample, multi-execution of absolute positioning instructions is used to position in a range of  $0^{\circ}$  to  $360^{\circ}$ . The actual position returns to  $0^{\circ}$  once it exceeds the range of  $0^{\circ}$  to  $360^{\circ}$ .

Multi-execution of instructions is performed when the *Active* (Controlling) output variable from the previous instruction is TRUE. For single-axis operation, multi-execution is possible for only one instruction. In this sample, multi-execution of instructions is executed with *BufferMode* (Buffer Mode Selection) set to *Buffered*.



Shortest-way positioning is performed.

If you specify 0° (home), 90°, 120°, or 290°, the axis will move to that position. The rotation direction in this instance is in the shorter rotation direction. The travel velocity is 250°/s.


The sample programming performs positioning with a shortest way specification from 290° to 90° to 120° and then to home (0°).

# Ladder Diagram

#### Main Variables

Name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		Axis Variable for axis 1.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 1.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
StartPg	BOOL	FALSE	The Servo is turned ON if this variable is TRUE and EtherCAT process data communications are established.

### Timing Chart




# Sample Programming

If StartPg is TRUE, EtherCAT communications are checked to see if process data communications are normal.

```
StartPg _EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress] _EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress] Lock1
```


If process data communications are active, the Servo is turned ON.




If there is a minor fault level error for axis 1, the error handler for the device (FaultHandler) is executed. Design FaultHandler separately.

```
MC_Axis000.MFaultLvl.Active FaultHandler EN FaultHandler
```


If the Servo is ON and home is not defined, the Home instruction is executed.




After home is defined, absolute positioning 1 is executed to move to 290.0°. The shortest way is specified for the motion direction.




Absolute positioning 2 is executed with multi-execution of instructions to move from 290.0° to 90.0°. The shortest way is used for the motion direction.



Absolute positioning 3 is executed with multi-execution of instructions to move from 90.0° to 120.0°. The shortest way is used for the motion direction.



Absolute positioning 4 is executed with multi-execution of instructions to move from  $120.0^{\circ}$  to  $0.0^{\circ}$ . The shortest way is used for the motion direction.




# Structured Text (ST)

#### Main Variables

Name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		Axis Variable for axis 1.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 1.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
StartPg	BOOL	FALSE	The Servo is turned ON if this variable is TRUE and EtherCAT process data communications are established.
Hm_Ex	BOOL	FALSE	The HM instance of MC_Home is executed when this variable changes to TRUE.
Mv_Abs1_Ex	BOOL	FALSE	The MV_ABS1 instance of MC_MoveAbsolute is executed when this variable changes to TRUE.
Mv_Abs2_Ex	BOOL	FALSE	The MV_ABS2 instance of MC_MoveAbsolute is executed when this variable changes to TRUE.
Mv_Abs3_Ex	BOOL	FALSE	The MV_ABS3 instance of MC_MoveAbsolute is executed when this variable changes to TRUE.
Mv_Abs4_Ex	BOOL	FALSE	The MV_ABS4 instance of MC_MoveAbsolute is executed when this variable changes to TRUE.
InitFlag	BOOL	FALSE	This variable indicates if it is necessary to set the input parameters. Input parameters are set when this variable is FALSE. When setting the input parameters is completed, this variable changes to TRUE.

3-63

### Timing Chart



#### Sample Programming

```
// Processing when input parameters are not set
IF InitFlag = FALSE THEN
```

```
// MV_ABS1 parameters
Mv\_Abs1\_Pos := LREAL#290.0;
Mv_Abs1_Vel := LREAL#250.0;
Mv_Abs1_Acc := LREAL#1000.0;
Mv_Abs1_Dec := LREAL#1000.0;
Mv_Abs1_Dir := _eMC_DIRECTION#_mcShortestWay;
// MV_ABS2 parameters
Mv\_Abs2\_Pos := LREAL#90.0;
Mv_Abs2_Vel := LREAL#250.0;
Mv\_Abs2\_Acc := LREAL#1000.0;
\label{eq:mv_Abs2_Dec} \mathsf{Mv\_Abs2\_Dec} \quad := \mathsf{LREAL\#1000.0};
Mv_Abs2_Dir := _eMC_DIRECTION#_mcShortestWay;
Mv_Abs2_Bm := _eMC_BUFFER_MODE#_mcBuffered;
```

```
Mv_Abs3_Pos
                  := LREAL#120.0;
   Mv Abs3 Vel
                  := LREAL#250.0;
   Mv_Abs3_Acc
                 := LREAL#1000.0;
   Mv_Abs3_Dec := LREAL#1000.0;
                  := _eMC_DIRECTION#_mcShortestWay;
   Mv_Abs3_Dir
   Mv_Abs3_Bm
                 := _eMC_BUFFER_MODE#_mcBuffered;
   // MV_ABS4 parameters
   Mv_Abs4_Pos
                 := LREAL#0.0;
   Mv_Abs4_Vel
                 := LREAL#250.0;
   Mv_Abs4_Acc := LREAL#1000.0;
   Mv_Abs4_Dec := LREAL#1000.0;
   Mv_Abs4_Dir
                  := _eMC_DIRECTION#_mcShortestWay;
   Mv_Abs4_Bm
                 := _eMC_BUFFER_MODE#_mcBuffered;
   // Change InitFlag to TRUE after setting the input parameters.
   InitFlag := TRUE;
END_IF;
// If StartPg is TRUE and EtherCAT communications are normal, the Servo is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
   Pwr En:=TRUE;
ELSE
   Pwr En:=FALSE;
END IF:
// Processing for a minor fault level error
// Implement FaultHandler separately.
IF MC_Axis000.MFaultLvl.Active=TRUE THEN
   FaultHandler():
END_IF;
// If the Servo is ON and home is not defined, the Home instruction is executed.
IF (Pwr_Status=TRUE) AND (MC_Axis000.Details.Homed=FALSE) THEN
   Hm Ex:=TRUE:
END_IF;
// After home is defined, MV_ABS1 is executed.
IF Hm_D=TRUE THEN
   Mv_Abs1_Ex:=TRUE;
END_IF;
// After MV_ABS1 is started, MV_ABS2 is executed with multi-execution of instructions.
IF Mv_Abs1_Act=TRUE THEN
   Mv_Abs2_Ex:=TRUE;
END_IF;
// After MV_ABS2 is started, MV_ABS3 is executed with multi-execution of instructions.
IF Mv Abs2 Act=TRUE THEN
   Mv_Abs3_Ex:=TRUE;
END_IF;
// After MV_ABS3 is started, MV_ABS4 is executed with multi-execution of instructions.
IF Mv_Abs3_Act=TRUE THEN
   Mv_Abs4_Ex:=TRUE;
END_IF;
// MC_Power
PWR(
   Axis
            := MC_Axis000,
```

```
:= Pwr_En,
   Enable
   Status
            => Pwr_Status,
            => Pwr_Bsy,
   Busy
   Error
            => Pwr_Err,
   ErrorID
            => Pwr_ErrID
);
// MC_Home
HM(
                      := MC_Axis000,
   Axis
   Execute
                      := Hm_Ex,
                      => Hm_D,
   Done
   Busy
                      => Hm_Bsy,
   CommandAborted => Hm_Ca,
   Error
                      => Hm Err,
   ErrorID
                      => Hm_ErrID
);
// Absolute positioning (1)
MV_ABS1(
                      := MC_Axis000,
   Axis
   Execute
                      := Mv_Abs1_Ex,
                      := Mv_Abs1_Pos,
   Position
                      := Mv_Abs1_Vel,
   Velocity
                      := Mv_Abs1_Acc,
   Acceleration
                      := Mv_Abs1_Dec,
   Deceleration
                      := Mv Abs1 Dir,
   Direction
                      => Mv_Abs1_D,
   Done
   Busy
                      => Mv Abs1 Bsv.
   Active
                      => Mv Abs1 Act,
   CommandAborted => Mv_Abs1_Ca,
   Error
                      => Mv_Abs1_Err,
   ErrorID
                      => Mv_Abs1_ErrID
);
// Absolute positioning (2)
MV_ABS2(
   Axis
                      := MC_Axis000,
   Execute
                      := Mv_Abs2_Ex,
                      := Mv_Abs2_Pos,
   Position
                      := Mv_Abs2_Vel,
   Velocity
   Acceleration
                      := Mv_Abs2_Acc,
   Deceleration
                      := Mv_Abs2_Dec,
                      := Mv_Abs2_Dir,
   Direction
   BufferMode
                      := Mv_Abs2_Bm,
   Done
                      => Mv_Abs2_D,
                      => Mv_Abs2_Bsy,
   Busy
                      => Mv_Abs2_Act,
   Active
   CommandAborted => Mv_Abs2_Ca,
   Error
                      => Mv_Abs2_Err,
   ErrorID
                      => Mv_Abs2_ErrID
);
// Absolute positioning (3)
MV_ABS3(
                      := MC_Axis000,
   Axis
   Execute
                      := Mv_Abs3_Ex,
                      := Mv_Abs3_Pos,
   Position
   Velocity
                      := Mv_Abs3_Vel,
   Acceleration
                      := Mv_Abs3_Acc,
   Deceleration
                      := Mv_Abs3_Dec,
                      := Mv_Abs3_Dir,
   Direction
   BufferMode
                      := Mv_Abs3_Bm,
```

```
=> Mv_Abs3_D,
   Done
   Busy
                      => Mv_Abs3_Bsy,
   Active
                      => Mv_Abs3_Act,
   CommandAborted
                    => Mv_Abs3_Ca,
   Error
                      => Mv_Abs3_Err,
   ErrorID
                      => Mv_Abs3_ErrID
);
// Absolute positioning (4)
MV_ABS4(
                      := MC_Axis000,
   Axis
   Execute
                      := Mv_Abs4_Ex,
   Position
                     := Mv_Abs4_Pos,
   Velocity
                     := Mv Abs4 Vel,
   Acceleration
                      := Mv_Abs4_Acc,
   Deceleration
                      := Mv_Abs4_Dec,
   Direction
                      := Mv Abs4 Dir,
                      := Mv_Abs4_Bm,
   BufferMode
                      => Mv_Abs4_D,
   Done
                      => Mv_Abs4_Bsy,
   Busy
                      => Mv_Abs4_Act,
   Active
   CommandAborted => Mv_Abs4_Ca,
                      => Mv_Abs4_Err,
   Error
                     => Mv_Abs4_ErrID
   ErrorID
);
```

# MC\_MoveRelative

The MC\_MoveRelative instruction moves the axis the specified travel distance from the command current position.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_MoveRelative	Relative Positioning	FB	MC_MoveRelative_instance  MC_MoveRelative Axis Axis Done Distance Busy Velocity Active Acceleration CommandAborted Deceleration Error Jerk ErrorID BufferMode	MC_MoveRelative_instance ( Axis := parameter, Execute := parameter, Distance := parameter, Velocity := parameter, Acceleration := parameter, Deceleration := parameter, Jerk := parameter, BufferMode := parameter, Done => parameter, Busy => parameter, Active => parameter, Active => parameter, CommandAborted => parameter, Error => parameter, Error => parameter); ErrorID => parameter);

# **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Execute</i> changes to TRUE.
Distance	Travel Distance	LREAL	Negative number, positive number, or 0	0	Specify the travel distance from the command current position. The unit is command units.*1
Velocity	Target Velocity	LREAL	Positive number	0	Specify the target velocity.*2 The unit is command units/s.*1
Acceleration	Acceleration Rate	LREAL	Non-negative number	0	Specify the acceleration rate. The unit is command units/s <sup>2</sup> .* <sup>1</sup>
Deceleration	Deceleration Rate	LREAL	Non-negative number	0	Specify the deceleration rate. The unit is command units/s <sup>2</sup> .* <sup>1</sup>
Jerk	Jerk	LREAL	Non-negative number	0	Specify the jerk. The unit is command units/s <sup>3</sup> .* <sup>1</sup>

Name	Meaning	Data type	Valid range	Default	Description
BufferMode	Buffer Mode Selection	_eMC_BUFFER_ MODE	0: _mcAborting 1: _mcBuffered 2: _mcBlendingLow 3: _mcBlendingPrevious 4: _mcBlendingNext 5: _mcBlendingHigh	0*3	Specify the operation when executing more than one motion instruction.  0: Aborting 1: Buffered 2: Blend with low 3: Blend with previous 4: Blend with next 5: Blend with high

<sup>\*1</sup> Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE	TRUE when the axis is being controlled.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When positioning is completed.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
Active	When the instruction is started.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
CommandAborted	When this instruction is aborted because another motion control instruction was exe-	When Execute is TRUE and changes to FALSE.
	cuted with the Buffer Mode set to Aborting.	After one period when Execute is FALSE.
	When this instruction is canceled due to an error.	
	When this instruction is executed while there is an error.	
	When you start this instruction during MC_Stop instruction execution.	
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

<sup>\*2</sup> Always set the target velocity. If the axis is moved without setting a target velocity, an error will occur.

<sup>\*3</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

## In-Out Variables


Name	Meaning	Data type	Valid Ranges	Description
Axis	Axis	_sAXIS_REF		Specify the axis.*

Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are MC\_Axis\*\*\*.)

#### **Function**


- The travel distance from the command current position is specified to perform positioning.
- Relative positioning starts when Execute changes to TRUE.
- You can specify the Velocity (Target Velocity), Acceleration (Acceleration Rate), Deceleration (Deceleration Rate), and Jerk as input variables.

The following chart shows an operation example of relative positioning.




When the acceleration rate or deceleration rate is 0 and the instruction is executed, it will reach the target velocity without accelerating or decelerating.

The following chart shows an operation example of when the acceleration rate is 0.




Specify Jerk when you want to accelerate or decelerate smoothly. The following chart shows an operation example when Jerk is specified.



For details on Jerk, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

#### **Instruction Details**

When the Count Mode is Rotary Mode, you can specify a Distance (Travel Distance) that exceeds the relative distance range from the ring counter modulo minimum position setting value to the ring counter modulo maximum position setting value of the ring counter in the axis parameters so that you can perform multiple ring rotation positioning. The following chart shows an operation example when the command current position is –20 and *Distance* (Travel Distance) is 300.




When *Distance* (Travel Distance) is 0 and the instruction is executed, the axis will not move, but *Done* will change to TRUE.



#### **Precautions for Correct Use**

Observe the following precautions if you re-execute relative positioning just before the completion of positioning. If positioning is completed before the MC Function Module re-executes the instruction, normal instruction execution is performed.

- For normal instruction execution, positioning is performed to the relative value that is based on the position of the axis when the instruction is executed.
- For re-execution of an instruction, positioning is performed to the relative value that is based on the position of the axis when original instruction was executed.




#### In-position Check

An in-position check is performed for this instruction according to the settings in In-position Range and In-position Check Time axis parameters.

## **Timing Charts**


- Busy (Executing) changes to TRUE at the same time as Execute changes to TRUE. Active (Controlling) changes to TRUE in the next period.
- Done changes to TRUE when Distance (Target Distance) is reached and positioning is completed.
- If another instruction aborts this instruction, *CommandAborted* changes to TRUE and *Busy* (Executing) and *Active* (Controlling) change to FALSE.



#### **Re-execution of Motion Control Instructions**

You can change the operation of the instruction if you change an input variable during positioning and change *Execute* to TRUE again.


Input variables *Distance* (Travel Distance), *Velocity* (Target Velocity), *Acceleration* (Acceleration Rate), and *Deceleration* (Deceleration Rate) can be changed by re-executing the motion control instruction. The starting point for *Distance* (Travel Distance) when the instruction is re-executed is not the command current position for the first execution, but rather it is the command current position when the instruction was first executed. The following chart shows an operation example when a motion control instruction is re-executed twice with different values for *Distance* (Travel Distance) and *Velocity* (Target Velocity).





#### **Precautions for Correct Use**

To change any input parameter other than *Distance* (Travel Distance), re-execute the instruction with *Distance* (Travel Distance) assigned to the same value as the original instruction. If *Distance* (Travel Distance) is omitted when the instruction is re-executed, the re-executed instruction will use a *Distance* (Travel Distance) of 0. This will cause the axis to return to the original first position, as shown below.



For details on re-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### **Multi-execution of Motion Control Instructions**

For details on multi-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### Execution during Execution of Other Instructions

You can switch to this instruction or buffer this instruction if you execute it during execution of another instruction. You can buffer one instruction per axis.

The starting point for *Distance* (Travel Distance) for multi-execution of the motion instruction is the command current position when *Active* (Controlling) changes to TRUE after the start of instruction execution.

Specify the operation of this instruction using *BufferMode* (Buffer Mode Selection) for multi-execution of instructions.

В	uffer Mode Selection	Description
Aborting		Aborts the instruction being executed and switches to this instruction. If the direction of axis motion is reversed by switching instructions, the motion will be reversed according to the Operation at Reversing axis parameter.
Buffere	d	Buffers this instruction and executes it automatically after the current instruction is completed.
Blendin	g	Starts the buffered instruction at the velocity (transit velocity) at which the current instruction reaches the target position. The operation of the current instruction is changed so that the axes reach the target position at the transit velocity. There are four methods to specify the transit velocity. These are described below.
	Blend with low	The lower of the target velocities of the current instruction and the buffered instruction is used as the transit velocity.
	Blend with previous	The target velocity of the current instruction is used as the transit velocity.
	Blend with next	The target velocity of the buffered instruction is used as the transit velocity.
	Blend with high	The higher of the target velocities of the current instruction and the buffered instruction is used as the transit velocity.

For details on *BufferMode* (Buffer Mode Selection), refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).


#### • Execution of Other Instructions during Instruction Execution

If you execute another instruction during execution of this instruction, you can specify aborting, buffering, or blending.

### **Errors**

If an error occurs during instruction execution, Error will change to TRUE and the axis will stop. You can find out the cause of the error by referring to the value output by ErrorID (Error Code).

#### Timing Chart When Error Occurs



#### Error code

Refer to A-1 Error Codes for instruction errors.

# **MC\_MoveVelocity**

The MC\_MoveVelocity instruction performs velocity control with the Position Control Mode of the Servo Drive

Instruction	Name	FB/FUN	Graphic expression	ST expression
MC_MoveVelocity	Velocity Control	FB	MC_MoveVelocity_instance  MC_MoveVelocity Axis — Axis — Execute InVelocity — Velocity Busy — Acceleration Active — Deceleration CommandAborted — Jerk Error — Direction ErrorID — Continuous — BufferMode	MC_MoveVelocity_instance ( Axis :=parameter, Execute :=parameter, Velocity :=parameter, Acceleration :=parameter, Deceleration :=parameter, Jerk :=parameter, Direction :=parameter, Continuous :=parameter, BufferMode :=parameter, InVelocity =>parameter, Busy =>parameter, Active =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorID =>parameter);

### **Variables**

# **Input Variables**

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Execute</i> changes to TRUE.
Velocity	Target Veloc- ity	LREAL	Non-negative number	0	Specify the target velocity.*1 The unit is command units/s.*2
Acceleration	Acceleration Rate	LREAL	Non-negative number	0	Specify the acceleration rate. The unit is command units/s <sup>2</sup> .* <sup>2</sup>
Deceleration	Deceleration Rate	LREAL	Non-negative number	0	Specify the deceleration rate. The unit is command units/s <sup>2</sup> .* <sup>2</sup>
Jerk	Jerk	LREAL	Non-negative number	0	Specify the jerk. The unit is command units/s <sup>3</sup> .* <sup>2</sup>
Direction	Direction	_eMC_ DIRECTION	0: _mcPositiveDirection 2: _mcNegativeDirection 3: _mcCurrentDirection	0*3	Specify the rotation direction.  0: Positive direction  2: Negative direction  3: Current direction
BufferMode	Buffer Mode Selection	e_MC_BUFFER_ MODE	0: _mcAborting 1: _mcBuffered	0*3	Specify the operation when executing more than one motion instruction.
					0: Aborting 1: Buffered

Name	Meaning	Data type	Valid range	Default	Description
Continuous (Reserved)	Continuation Mode Selec- tion	BOOL	TRUE or FALSE		Reserved

<sup>\*1</sup> Always set the target velocity. If the axis is moved without setting a target velocity, an error will occur.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
InVelocity	Target Velocity Reached	BOOL	TRUE or FALSE	TRUE when the target velocity is reached.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE	TRUE when the axis is being controlled.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
InVelocity	When the target velocity is reached.	<ul> <li>When <i>Error</i> changes to TRUE.</li> <li>When <i>CommandAborted</i> changes to TRUE.</li> <li>When the instruction is re-executed and the target velocity is changed.</li> </ul>
Busy	When Execute changes to TRUE.	When Error changes to TRUE.     When CommandAborted changes to TRUE.
Active	When the instruction is started.	When Error changes to TRUE.     When CommandAborted changes to TRUE.
CommandAborted	<ul> <li>When this instruction is aborted because another motion control instruction was executed with the Buffer Mode set to Aborting or Buffered.</li> <li>When this instruction is canceled due to an error.</li> <li>When this instruction is executed while there is an error.</li> <li>When you start this instruction during MC_Stop instruction execution.</li> </ul>	<ul> <li>When Execute is TRUE and changes to FALSE.</li> <li>After one period when Execute is FALSE.</li> </ul>
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

<sup>\*2</sup> Refer to Unit Conversion Settings in the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507) for information on command units.

<sup>\*3</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

### In-Out Variables

Name	Meaning	Data type	Valid range	Description
Axis	Axis	_sAXIS_REF		Specify the axis.*

Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are MC\_Axis\*\*\*.)

#### **Function**

- · Pseudo velocity control is performed with position control.
- The velocity control operation starts when Execute changes to TRUE.

#### **Instruction Details**

This section describes the instruction in detail.

#### Direction

Specify the travel direction with *Direction*. When *Direction* specifies the positive direction, the axis moves in the positive direction. When it specifies the negative direction, the axis moves in the negative direction. When it specifies the current direction, the axis motion depends on whether the axis is stopped or not. If the axis is stopped, it will move in the direction in which it was traveling previously. If the power was turned ON or after restarting, the axis moves in the positive direction. If you execute this instruction during multi-execution of motion control instructions for the axis, the axis will move in the direction that it is currently traveling.




#### **Precautions for Correct Use**

If the current direction is specified for *Direction*, operation is in the same command direction as the previous motion. Therefore, depending on the instructions that are used together, the direction may not be the same as the direction that was specified with the input to the motion control instruction for the previous motion. When you specify the current direction, check the current direction with *Dir.Posi* (Positive Direction) and *Dir.Nega* (Negative Direction) in the Axis Variable.

## **Timing Charts**


- Busy (Executing) changes to TRUE at the same time as Execute changes to TRUE. Active (Controlling) changes to TRUE in the next period.
- InVelocity (Target Velocity Reached) changes to TRUE when Velocity (Target Velocity) is reached.
- If another instruction aborts this instruction, CommandAborted changes to TRUE and Busy (Executing), Active (Controlling), and InVelocity (Target Velocity Reached) change to FALSE.



The InVelocity (Target Velocity Reached) output variable indicates when the velocity has reached the same velocity for this instruction and the re-executed motion control instruction. Therefore, after InVelocity (Target Velocity Reached) changes to TRUE, even if the velocity is changed by the override factor, InVelocity (Target Velocity Reached) will not change to FALSE. If the override factor changes before InVelocity (Target Velocity Reached) changes to TRUE, InVelocity (Target Velocity Reached) will change to TRUE when the new target velocity is reached.


You can specify Acceleration (Acceleration Rate), Deceleration (Deceleration Rate) and Jerk as input variables. When the Velocity (Target Velocity) is 0 and the instruction is executed, the axis will enter continuous operation without motion.

The following chart shows an operation example of when Velocity (Target Velocity) is 0.




When the *Acceleration* (Acceleration Rate) or *Deceleration* (Deceleration Rate) is 0 and the instruction is executed, the axis will reach the target velocity without accelerating or decelerating.

The following chart shows an operation example of when the acceleration rate is 0.



Specify *Jerk* when you want to accelerate or decelerate smoothly. The following chart shows an operation example when *Jerk* is specified.



For details on Jerk, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

#### Re-execution of Motion Control Instructions

You can change the operation of the instruction if you change an input parameter during continuous operation and then change Execute to TRUE again. Input variables Velocity (Target Velocity), Acceleration (Acceleration Rate), and Deceleration (Deceleration Rate) can be changed by re-executing the motion control instruction. When changing the Velocity (Target Velocity) by re-executing a motion control instruction, InVelocity (Target Velocity Reached) changes to FALSE when Execute changes to FALSE.

When the motion control instruction is re-executed to change Velocity (Target Velocity), InVelocity (Target Velocity Reached) operates for the new target velocity that was set at re-execution.

For details on re-execution of motion control instructions, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

#### Multi-execution of Motion Control Instructions

For details on multi-execution of motion control instructions, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

#### Execution during Execution of Other Instructions

You can switch to this instruction or buffer this instruction if you execute it during execution of another instruction. You can buffer one instruction per axis. Specify the operation of this instruction using BufferMode (Buffer Mode Selection) for multi-execution of instructions.

Buffer Mode Selection	Description
Aborting	Aborts the instruction being executed and switches to this instruction.  If the direction of axis motion is reversed by switching instructions, the motion will be reversed according to the Operation at Reversing axis parameter.
Buffered	Buffers this instruction and executes it automatically after the current instruction is completed.

For details on BufferMode (Buffer Mode Selection), refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

#### Execution of Other Instructions during Instruction Execution


If another instruction is executed during execution of this instruction, the BufferMode input variable to the other instruction must be set to Aborting or *Buffered*.

If you specify Buffered, the buffered instruction is executed when the InVelocity (Target Velocity Reached) output variable from this instruction changes to TRUE.

### **Error**

If an error occurs during instruction execution, *Error* will change to TRUE and the axis will stop. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).

#### Timing Chart When Error Occurs



#### Error Codes

Refer to A-1 Error Codes for instruction errors.

### **Sample Programming**

This section shows sample programming for velocity control, such as for a spinner or centrifuge.

## **Parameter Settings**


The minimum settings required for this sample programming are given below.

#### Setting Axis Parameters


#### **Axis Type**

Axis	Axis Type
Axis 1	Servo axis

### **Operation Example**



#### **Operation Pattern**



- Starting Velocity Control Sensor 1 detects the insertion of liquid chemical. When it turns ON, velocity control starts for axis 1.
- Changing to the Second Velocity

When the *Sensor2* bit changes to TRUE, the override factor is set to 500% and the velocity is changed.

3 Changing to the Third Velocity

When the *Sensor3* bit changes to TRUE, the override factor is set to 200% and the velocity is changed. If both Sensor2 and Sensor3 are TRUE at the same time, the override factor is 200%.


**4** Stopping Velocity Control
When the stop command (*StopTrig*) changes to TRUE, the axis decelerates to a stop.

# Ladder Diagram

#### Main Variables

Name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		Axis Variable for axis 1.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 1.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
StartPg	BOOL	FALSE	The Servo is turned ON if this variable is TRUE and EtherCAT process data communications are established.
Vel_Act	BOOL	FALSE	This variable is assigned to the <i>Active</i> output variable from the VEL instance of the MC_MoveVelocity instruction. It is TRUE during velocity control by the VEL instance.
Set_Ov_Velfct	LREAL	0	This is the velocity override factor.
StopTrig	BOOL	FALSE	When this variable is TRUE, MC_Stop is executed.
Sensor1	BOOL	FALSE	TRUE when chemical solution supply is detected.  If the Servo is ON for axis 1, the  MC_MoveVelocity (Velocity Control) instruction is executed.
Sensor2	BOOL	FALSE	If this variable is TRUE, the override factor is set to 500%. After this variable changes to TRUE, it remains TRUE until <i>Sensor3</i> changes to TRUE, at which time it changes to FALSE.
Sensor3	BOOL	FALSE	If this variable is TRUE, the override factor is set to 200%. After this variable changes to TRUE, it remains TRUE.

#### Timing Chart




#### Sample Programming

If StartPg is TRUE, EtherCAT communications are checked to see if process data communications are normal.

```
_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress] _EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]
\dashv \vdash
```


If process data communications are active, the Servo is turned ON.




If there is a minor fault level error for axis 1, the error handler for the device (FaultHandler) is executed. Design FaultHandler separately.

```
MC_Axis000.MFaultLvl.Active
                                                                   FaultHandler
                                                                      FaultHandler
```


When Sensor1 changes to TRUE, the MC\_MoveVelocity (Velocity Control) instruction is executed.




During execution of the MC\_MoveVelocity (Velocity Control) instruction, the override factor is changed according to the status of the Sensor2 and Sensor3 bits.



The MC\_SetOverride (Set Override Factors) instruction is executed during execution of the MC\_MoveVelocity (Velocity Control) instruction.



When the stop command (StopTrig) changes to TRUE, the MC\_Stop instruction is executed.



#### Contents of Inline ST

```
IF (Sensor2=FALSE) AND (Sensor3=FALSE) THEN
Set_Ov_Velfct := LREAL#100.0;
ELSIF (Sensor2=TRUE) AND (Sensor3=FALSE) THEN
Set_Ov_Velfct := LREAL#500.0;
ELSIF (Sensor2=FALSE) AND (Sensor3=TRUE) THEN
Set_Ov_Velfct := LREAL#200.0;
ELSE
Set_Ov_Velfct := LREAL#200.0;
END_IF;
```


# Structured Text (ST)

#### Main Variables

Name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		Axis Variable for axis 1.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 1.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.

Name	Data type	Default	Comment
StartPg	BOOL	FALSE	The Servo is turned ON if this variable is TRUE and EtherCAT process data communications are established.
Vel_Act	BOOL	This variable is assigned to the <i>Active</i> output able from the VEL instance of the MC_MoveVelocity instruction. It is TRUE du velocity control by the VEL instance.	
Set_Ov_Velfct	LREAL	0	This is the velocity override factor.
StopTrig	BOOL	FALSE	When this variable is TRUE, MC_Stop is executed.
Sensor1	BOOL	FALSE	TRUE when chemical solution supply is detected.  If the Servo is ON for axis 1, the  MC_MoveVelocity (Velocity Control) instruction is executed.
Sensor2	BOOL	FALSE	If this variable is TRUE, the override factor is set to 500%. After this variable changes to TRUE, it remains TRUE until <i>Sensor3</i> changes to TRUE, at which time it changes to FALSE.
Sensor3	BOOL	FALSE	If this variable is TRUE, the override factor is set to 200%. After this variable changes to TRUE, it remains TRUE.
Vel_Ex	BOOL	FALSE	The VEL instance of MC_MoveVelocity is executed when this variable changes to TRUE.
Set_Ov_En	BOOL	FALSE	The SET_OV instance of MC_SetOverride is executed while this variable is TRUE.
Stp_Ex	BOOL	FALSE	The STP instance of MC_Stop is executed when this variable changes to TRUE.
InitFlag	BOOL	FALSE	This variable indicates if it is necessary to set the input parameters. Input parameters are set when this variable is FALSE. When setting the input parameters is completed, this variable changes to TRUE.

#### Timing Chart



#### Sample Programming

```
// Processing when input parameters are not set
IF InitFlag = FALSE THEN
   // MC_MoveVelocity parameters
   Vel Vel := LREAL#1048576.0;
   Vel Acc := LREAL#1048576.0:
   Vel Dec := LREAL#1048576.0;
   Vel_Dir := _eMC_DIRECTION#_mcPositiveDirection;
   // MC_SetOverride parameters
   Set_Ov_Velfct := LREAL#100.0;
   // MC_Stop parameters
   Stp_Dec := LREAL#524288.0;
   // Change InitFlag to TRUE after setting the input parameters.
   InitFlag:=TRUE;
END_IF;
// If StartPg is TRUE and EtherCAT communications are normal, the Servo for axis 1 is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
   Pwr_En:=TRUE;
ELSE
   Pwr_En:=FALSE;
END_IF;
// If a minor fault level error occurs for axis 1, the error handler for the device (FaultHandler) is executed.
// Implement FaultHandler separately.
IF MC_Axis000.MFaultLvl.Active=TRUE THEN
   FaultHandler();
```

```
END_IF;
// If the Servo is ON for axis 1 and the Sensor1 bit is TRUE, the MC_MoveVelocity instruction is executed.
IF (Pwr_Status=TRUE) AND (Sensor1=TRUE) THEN
   Vel_Ex := TRUE;
END_IF;
// During execution of the MC_MoveVelocity instruction, the override factor is changed according to the status of
the Sensor2 and Sensor3 bits.
IF Vel_Act=TRUE THEN
   IF (Sensor2=FALSE) AND (Sensor3=FALSE) THEN
      Set_Ov_Velfct := LREAL#100.0;
   ELSIF (Sensor2=TRUE) AND (Sensor3=FALSE) THEN
      Set Ov Velfct := LREAL#500.0;
   ELSIF (Sensor2=FALSE) AND (Sensor3=TRUE) THEN
      Set_Ov_Velfct := LREAL#200.0;
      Set_Ov_Velfct := LREAL#200.0;
   END_IF;
END_IF;
// The MC_SetOverride instruction is executed during velocity control for the MC_MoveVelocity instruction.
IF Vel Act=TRUE THEN
   Set_Ov_En := TRUE;
END_IF;
// The MC Stop instruction is executed when StopTrig is TRUE.
IF StopTrig=TRUE THEN
   Stp_Ex := TRUE;
END_IF;
//MC Power
PWR(
   Axis
            := MC_Axis000,
   Enable
            := Pwr_En,
   Status
            => Pwr_Status,
            => Pwr_Bsy,
   Busv
   Error
            => Pwr Err,
   ErrorID => Pwr_ErrID
);
//MC_MoveVelocity
VEL(
                      := MC_Axis000,
   Axis
                      := Vel_Ex,
   Execute
   Velocity
                      := Vel_Vel,
                      := Vel_Acc,
   Acceleration
   Deceleration
                      := Vel_Dec,
                      := Vel Dir.
   Direction
   InVelocity
                      => Vel Invel,
   Busy
                      => Vel_Bsy,
   Active
                      => Vel_Act,
   CommandAborted => Vel_Ca,
   Error
                      => Vel_Err,
   ErrorID
                      => Vel_ErrID
);
```

```
//MC_SetOverride
SET_OV(
   Axis
                   := MC_Axis000,
   Enable
                  := Set_Ov_En,
   VelFactor
                  := Set_Ov_Velfct,
   AccFactor
                 := Set_Ov_Accfct,
   JerkFactor
                  := Set_Ov_Jfct,
   Busy
                   => Set_Ov_Bsy,
   Enabled
                   => Set_Ov_End,
   Error
                  => Set_Ov_Err,
   ErrorID
                   => Set_Ov_ErrID
);
//MC_Stop
STP(
                      := MC_Axis000,
   Axis
   Execute
                      := Stp_Ex,
   Deceleration
                      := Stp_Dec,
                      => Stp_D,
   Done
   Busy
                      => Stp_Bsy,
   Active
                      => Stp_Act,
   CommandAborted => Stp_Ca,
   Error
                      => Stp_Err,
   ErrorID
                      => Stp_ErrID
);
```

# MC\_MoveZeroPosition

The MC\_MoveZeroPosition instruction performs positioning with an absolute position of 0 as the target position to return to home.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_MoveZeroPosition	High- speed Home	FB	MC_MoveZeroPosition_instance  MC_MoveZeroPosition Axis — Axis — Execute Done — Velocity Busy — Acceleration Active — Deceleration CommandAborted — Jerk Error — BufferMode ErrorID	MC_MoveZeroPosition_instance ( Axis :=parameter, Execute :=parameter, Velocity :=parameter, Acceleration :=parameter, Deceleration :=parameter, Jerk :=parameter, BufferMode :=parameter, Done =>parameter, Busy =>parameter, Rative =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorID =>parameter);

#### **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Execute</i> changes to TRUE.
Velocity	Target Variable	LREAL	Positive number	0	Specify the target velocity.*1 The unit is command units/s.*2
Acceleration	Acceleration Rate	LREAL	Non-negative number	0	Specify the acceleration rate. The unit is command units/s <sup>2</sup> .* <sup>2</sup>
Deceleration	Deceleration Rate	LREAL	Non-negative number	0	Specify the deceleration rate. The unit is command units/s <sup>2</sup> .* <sup>2</sup>
Jerk	Jerk	LREAL	Non-negative number	0	Specify the jerk. The unit is command units/s <sup>3</sup> .* <sup>2</sup>
BufferMode	Buffer Mode Selection	_eMC_BUFFER_ MODE	0: _mcAborting 1: _mcBuffered	0*3	Specify the behavior for multi- execution of instructions.
					0: Aborting 1: Buffered

<sup>\*1</sup> Always set the target velocity. If the axis is moved without setting a target velocity, an error will occur.

<sup>\*2</sup> Refer to Unit Conversion Settings in the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507) for information on command units.

<sup>\*3</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

3-91

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE	TRUE when the axis is being controlled.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When positioning is completed.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
Active	When the axis starts moving.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
CommandAborted	When this instruction is aborted because another motion control instruction was	When Execute is TRUE and changes to FALSE.
	executed with the Buffer Mode set to Aborting.	After one period when Execute is FALSE.
	When this instruction is canceled due to an error.	
	When this instruction is executed while there is an error.	
	<ul> <li>When you start this instruction during MC_Stop instruction execution.</li> </ul>	
Error	When there is an error in the execution conditions or input parameters for the instruc-	When the error is cleared.
	tion.	

# In-Out Variables

Name	Meaning	Data type	Valid range	Description
Axis	Axis	_sAXIS_REF		Specify the axis.*

<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are MC\_Axis\*\*\*.)

#### **Function**

- · The axis moves to home.
- You can specify the Velocity (Target Velocity), Acceleration (Acceleration Rate), Deceleration (Deceleration) eration Rate), and Jerk as input variables.



#### **Precautions for Correct Use**


Execute the MC MoveZeroPosition (High-speed Home) instruction only after defining home. If home is not defined, an Instruction Execution Error with Undefined Home (error code: 5466 hex) occurs.

#### Instruction Details

This section describes the instruction in detail.

#### Direction Designation

When the Count Mode is set to Rotary Mode, positioning is performed in the direction with the shortest distance to home (shortest-way positioning). The following chart shows an operation example of this instruction according to the command current position.





#### **Precautions for Correct Use**

If this instruction is executed when home is outside of the settings of the Modulo Maximum Position Setting Value and Modulo Minimum Position Setting Value axis parameters, a Target Position Ring Counter Out of Range error (error code: 549C hex) will occur.


#### Override Factors

Override factors are enabled for this instruction.

#### In-position Check


An in-position check is performed for this instruction according to the settings in In-position Range and In-position Check Time axis parameters.

#### Operation Example




When the acceleration rate or deceleration rate is 0 and the instruction is executed, it will reach the target velocity without accelerating or decelerating.

The following chart shows an operation example of when the acceleration rate is 0.




Specify *Jerk* when you want to accelerate or decelerate smoothly. The following chart shows an operation example when *Jerk* is specified.



For details on Jerk, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

## **Timing Charts**

A timing chart for execution of the MC\_MoveZeroPosition (High-speed Home) instruction is shown below.



# **Aborting the Instruction**

Home will not become undefined even if this instruction is aborted and CommandAborted changes to TRUE.

# **Re-execution of Motion Control Instructions**

You can change the operation of the instruction if you change an input variable during positioning and change Execute to TRUE again. Input variables Velocity (Target Velocity), Acceleration (Acceleration Rate), and Deceleration (Deceleration Rate) can be changed by re-executing the motion control instruction. For details on re-execution of motion control instructions, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

### **Multi-execution of Motion Control Instructions**

For details on multi-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### Execution during Execution of Other Instructions

You can switch to this instruction or buffer this instruction if you execute it during execution of another instruction. You can buffer one instruction per axis. Specify the operation of this instruction using *BufferMode* (Buffer Mode Selection) for multi-execution of instructions.

<b>Buffer Mode Selection</b>	Description
Aborting	Aborts the instruction being executed and switches to this instruction. a If the direction of axis motion is reversed by switching instructions, the motion will be reversed according to the Operation at Reversing axis parameter.
Buffered	Buffers this instruction and executes it automatically after the current instruction is completed.


For details on *BufferMode* (Buffer Mode Selection), refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### • Execution of Other Instructions during Instruction Execution

If you execute another instruction during execution of this instruction, you can specify either aborting or buffering. You cannot specify blending.

#### MC\_SetPosition Execution during Instruction Execution


Home becomes undefined for the MC\_SetPosition instruction. Therefore an error will occur if you attempt to execute it during execution of this instruction, and it will not be executed. If attempting to execute the MC\_SetPosition instruction causes an error, the current instruction decelerates the axis to a stop and *CommandAborted* changes to TRUE. In this case, the output variable *Error* changes to TRUE for the MC\_SetPosition instruction.



# **Errors**

If an error occurs during instruction execution, Error will change to TRUE and the axis will stop. You can find out the cause of the error by referring to the value output by ErrorID (Error Code).

### • Timing Chart When Error Occurs



#### Error Codes

Refer to A-1 Error Codes for instruction errors.

# MC\_MoveFeed

The MC\_MoveFeed instruction performs positioning for the specified travel distance from the position where an external device triggers an interrupt input. Interrupt feeding is possible for absolute positioning, relative positioning, and velocity control.

Instruction	Name	FB/FUN	Graphic expression	ST expression
MC_MoveFeed	Interrupt Feeding	FB	MC_MoveFeed instance  MC_MoveFeed Axis	MC_MoveFeed_instance ( Axis :=parameter, TriggerInput :=parameter, TriggerVariable :=parameter, Execute :=parameter, WindowOnly :=parameter, FirstPosition :=parameter, LastPosition :=parameter, LastPosition :=parameter, ReferenceType :=parameter, Position :=parameter, Velocity :=parameter, Acceleration :=parameter, Deceleration :=parameter, Derection :=parameter, Direction :=parameter, FeedDistance :=parameter, FeedVelocity :=parameter, FeedVelocity :=parameter, FerorDetect :=parameter, ErrorDetect :=parameter, UnFeed =>parameter, Busy =>parameter, Active =>parameter, CommandAborted =>parameter, ErrorID =>parameter) ErrorID =>parameter) );

# **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Execute</i> changes to TRUE.
WindowOnly	Window Only	BOOL	TRUE or FALSE	FALSE	Specify whether to enable or disable the window.
FirstPosition	First Position	LREAL	Negative number, positive number, or 0	0	Specify the position where latching is enabled. The unit is command units.*1
LastPosition	Last Position	LREAL	Negative number, positive number, or 0	0	Specify the position where latching is disabled. The unit is command units.*1
ReferenceType	Position Type	_eMC_	1: _mcFeedback	1*2	Specify the position type.
	Selection	REFERENCE_ TYPE			Actual position (value obtained in the same primary period)
Position	Target Position	LREAL	Negative number, positive number, or 0	0	Specify the absolute target position. The unit is command units.*1
Velocity	Target Velocity	LREAL	Positive number*3	0	Specify the target velocity. The unit is command units/s.*1
Acceleration	Acceleration Rate	LREAL	Non-negative number	0	Specify the acceleration rate. The unit is command units/s <sup>2</sup> .* <sup>1</sup>
Deceleration	Deceleration Rate	LREAL	Non-negative number	0	Specify the deceleration rate. The unit is command units/s <sup>2</sup> .* <sup>1</sup>
Jerk	Jerk	LREAL	Non-negative number	0	Specify the jerk. The unit is command units/s <sup>3</sup> .* <sup>1</sup>
Direction	Direction	_eMC_ DIRECTION	0: _mcPositiveDirection 1: _mcShortestWay 2: _mcNegativeDirection 3: _mcCurrentDirection 4: _mcNoDirection	0*2	Specify the direction of rotation when MoveMode is set to absolute positioning*4 and when the Count Mode is Rotary Mode.  0: Positive direction
					1: Shortest way 2: Negative direction 3: Current direction 4: No direction specified
MoveMode	Travel Mode	_eMC_MOVE_	0: _mcAbsolute	0*2	Select the travel method.
		MODE	1: _mcRelative 2: _mcVelocity		O: Absolute positioning     1: Relative positioning     2: Velocity control

Name	Meaning	Data type	Valid range	Default	Description
FeedDistance	Feed Distance	LREAL	Negative number, positive number, or 0	0	Specify the travel distance after the interrupt feed input. Specify a positive value to feed in the same direction as the axis was moving before the interrupt input and specify a negative value to feed in the opposite direction. The unit is command units.*1
FeedVelocity	Feed Velocity	LREAL	Positive number	0	Specify the target travel velocity after the interrupt feed input. The unit is command units/s.*1
BufferMode	Buffer Mode Selection	_eMC_BUFFER_ MODE	0: _mcAborting 1: _mcBuffered	0*2	Specify the behavior for multi- execution of instructions.  0: Aborting 1: Buffered
ErrorDetect	Error Detection Selection	BOOL	TRUE or FALSE	FALSE	Specify whether to detect an error when there is no interrupt feed input.  TRUE: Detect errors.  FALSE: Do not detect errors.

<sup>\*1</sup> Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.

- \*2 The default value for an enumeration variable is actually not the number, but the enumerator.
- \*3 A value of 0 can be set if MoveMode is set to velocity control.
- \*4 The axis moves to the specified position when *MoveMode* is set to absolute positioning and when the Count Mode is Linear Mode.

When MoveMode is set to relative positioning, the travel direction is determined by the sign of the position.

\_mcShortestWay and \_mcNoDirection cannot be selected when MoveMode is set to velocity control, regardless of the Counter Mode.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
InFeed	Feeding	BOOL	TRUE or FALSE	TRUE while feeding after receiving a latch input.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE	TRUE when the axis is being controlled.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When the instruction is completed.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
Active	When the instruction is started.	When Done changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
InFeed	When feeding is started by the interrupt	When <i>Done</i> changes to TRUE.
	input.*	When Error changes to TRUE.
		When CommandAborted changes to TRUE.
CommandAborted	When this instruction is aborted because	When Execute is TRUE and changes to
	another motion control instruction was executed with the Buffer Mode set to	FALSE.  • After one period when <i>Execute</i> is FALSE.
	Aborting.	After one period when Execute is FALSE.
	When this instruction is canceled due to an error.	
	When this instruction is executed while there is an error.	
	When you start this instruction during MC_Stop instruction execution.	
Error	When there is an error in the execution con-	When the error is cleared.
	ditions or input parameters for the instruction.	

<sup>\*</sup> There may be a delay of up to several primary periods from when the interrupt input turns ON until InFeed changes to TRUE.

# **In-Out Variables**

Name	Meaning	Data type	Valid range	Description
Axis	Axis	_sAXIS_REF		Specify the axis.*1
TriggerInput	Trigger Input Condition	_sTRIGGER_REF		Set the trigger condition.*2
TriggerVariable	Trigger Variable	BOOL	TRUE or FALSE	Specify a trigger input variable when the Controller Mode is specified for the trigger mode.

Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are MC\_Axis\*\*\*.)

<sup>\*2</sup> Define a user-defined variable with a data type of \_sTRIGGER\_REF.

#### • strigger ref

Name	Meaning	Data type	Valid range	Function
Mode	Mode	_eMC_TRIGGER	0: _mcDrive	Specify the trigger mode.
		_ MODE	1: _mcController	0: Drive Mode
				1: Controller Mode
LatchID	Latch ID	_eMC_TRIGGER	0: _mcLatch1	Specify which of the two latch functions
	Selection	_ LATCHID	1: _mcLatch2	to use.
				0: Latch 1
				1: Latch 2
InputDrive	Trigger Input	_eMC_TRIGGER	0: _mcEncoderMark	Specify the Servo Drive trigger signal
	Signal	_ INPUT_DRIVE	1: _mcEXT	to use in Drive Mode.
				0: Z-phase signal
				1: External input

# **Function**

- When Execute changes to TRUE, the axis travels with absolute travel, relative travel, or velocity control depending on the MoveMode setting.
- The target position is set in *Position* (Target Position) for absolute travel. The target distance is set in *Position* (Target Distance) for relative travel.
   Both modes use *Velocity* (Target Velocity) for travel operation.
- Relative positioning is performed with *FeedVelocity* from the actual position where the external input turned ON during travel for the feed distance that is specified with *FeedDistance*.
- If no interrupt signal is input before the axis reaches the default target position during interrupt feeding in absolute or relative travel mode, the axis stops at the target position. You can specify whether there is an error output when the axis stops for *ErrorDetect* (i.e., when there is no interrupt input.) If you specify an error output, *CommandAborted* changes to TRUE, and Busy (Executing) and *Active* (Controlling) change to FALSE.
- To use interrupt masks, change WindowOnly to TRUE, then specify FirstPosition and LastPosition.
   Interrupt feeding is performed for the first interrupt signal generated by the actual position between the FirstPosition and the LastPosition.



#### **Precautions for Correct Use**

- Feeding after the interrupt is performed as a relative movement for the distance that is specified with FeedDistance. If a positive value is specified for FeedDistance, feeding is performed in the same direction as before the interrupt input, and if a negative value is specified, feeding is performed in the opposite direction.
- The setting of the Operation Selection at Reversing axis parameter is used for the acceleration and deceleration rates when reversing to feed.
- If an underflow or overflow would occur for the position after interrupt feeding, an error occurs
  when the interrupt input is received. If an interrupt input is received after there is an overflow or
  underflow, an axis error will still occur.



#### **Additional Information**

Refer to *MC\_MoveAbsolute* on page 3-41 for absolute travel, *MC\_MoveRelative* on page 3-68 for relative travel, *MC\_MoveVelocity* on page 3-75 for velocity control, and *WindowOnly* on page 3-104 for WindowOnly.

### Mapping Data Objects

You must map the following object data when the MC\_MoveFeed (Interrupt Feeding) instruction is executed with Mode set to Drive Mode. Mapping is performed in the Detailed Setting Area of the Axis Basic Settings Display of the Sysmac Studio.

- Touch probe function (60B8 hex)
- Touch probe status (60B9 hex)
- Touch probe pos1 pos value (60BA hex)
- Touch probe pos2 pos value (60BC hex)

If even one of the required objects is not set, a Process Data Object Setting Missing error (error code 3461 hex) occurs.

For details on mapping data objects, refer to 2-3 PDO Mapping and to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

# **Instruction Details**

This section describes the instruction in detail.

#### Specifying Axis

• Axis specifies the axis for which to latch the position.

### Trigger Input Condition


Select the trigger conditions with Mode, LatchID, and InputDrive of the TriggerInput (Trigger Input Conditions) variable.

#### Mode

- The mode can be set to Drive Mode to specify a signal from the Servo Drive as the trigger, or to Controller Mode to specify a trigger with *TriggerVariable*.
- The trigger occurs on the rising edge of the trigger signal. The axis position is latched on the first trigger (FALSE to TRUE) after the MC\_TouchProbe instruction is executed.
- While this instruction is Busy (Executing), a change in TriggerVariable is taken as a trigger even if Execute is FALSE.

#### **Drive Mode**

For trigger detection and latching of the actual position, the latched actual position is more precise in Drive Mode (which is a Servo Drive function) than it is in Controller Mode.





#### **Precautions for Correct Use**


- When using Drive Mode, make sure that you connect the latch signal to the LatchID that you
  are going to use.
- The width of the latch signal depends on the performance of the Servo drive and other factors.
- You must map the following object data when the MC\_MoveFeed (Interrupt Feeding) instruction is executed with *InputDrive* set to Drive Mode.

Touch probe function (60B8 hex), Touch probe status (60B9 hex), Touch probe pos1 pos value (60BA hex), and Touch probe pos2 pos value (60BC hex)

If even one of the required objects is not set, a Process Data Object Setting Missing error (error code 3461 hex) occurs. For details on mapping object data, refer to *2-3 PDO Mapping* and to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### **Controller Mode**

- You can specify a BOOL variable in the Controller Mode.
- Use TriggerVariable to specify the BOOL variable that you want to use as a trigger.
- The Controller Mode causes a longer delay compared to the Drive Mode. This is due to the I/O refresh delay that occurs when the trigger input signal is updated in the BOOL variable.





### **Precautions for Correct Use**

If you use Controller Mode, the latch is performed each primary period. Therefore, the trigger variable must remain TRUE for at least one primary period.

Also, one primary period is required between when the trigger variable changes to TRUE and the MC Function Module processes the latch.

#### LatchID

- Specify which of the two to use with *LatchID*. You can use only one of the latches with any one axis
- LatchIDs indicate latch circuit 1 and latch circuit 2 in the Servo Drive.

For information on latch IDs, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### InputDrive

- You can select \_mcEncoderMark (Z Phase) or \_mcEXT (External Input) as triggers.
- Select \_mcEncoderMark (Z Phase) to use the Z phase of the Servo Drive as the trigger.
   An external trigger signal that is input to the Servo Drive is used as the trigger for \_mcEXT (External Input).
- For an OMRON G5-series Servo Drive, there are three options for \_mcEXT: Ext1, Ext2, and Ext3.
   Use Sysmac Studio to make the setting. Make the settings from the Sysmac Studio.
   The two triggers set in the Servo Drive can have the same setting.


### WindowOnly

- WindowOnly specifies whether the window is enabled or disabled.
- If you specify *Disable*, triggers are detected for all axis positions.
- If you specify Enable, triggers are detected only when the axis position is within the range specified by FirstPosition and LastPosition.

The following timing chart shows the difference in operation depending on the WindowOnly setting.


### WindowOnly Set to Disable

The axis position when the first trigger occurs after Execute changes to TRUE is used as the reference position for the feed distance.



### WindowOnly Set to Enable

Only trigger inputs within the window are detected to latch the axis position.





#### **Precautions for Correct Use**


- Latching is not possible at the moment that WindowOnly changes to TRUE and until the latch function is activated.
- Time is needed until the latch function is activated. If the effective range for *WindowOnly* is too small, latching is not possible. The range in which latching is possible depends on the Servo Drive or Encoder Input Terminal performance, and on EtherCAT communications.

The range that is defined by FirstPosition and LastPosition depends on the Count Mode, as given below.

#### **Linear Mode**

- FirstPosition must be less than or equal to the window range and the window range must be less than or equal to LastPosition.
- An error will occur if the FirstPosition is greater than the LastPosition.
- An error will also occur if a position beyond the position range of Linear Mode is specified.
- FirstPosition and LastPosition are LREAL variables. Do not set them to the same values. Refer to Treatment of REAL and LREAL Data on page 1-13 for information on LREAL data.

The window only range in Linear Mode is shown below.




Note The window only range can include the FirstPosition and LastPosition.


### **Rotary Mode**

- The FirstPosition can be less than, equal to, or greater than the LastPosition.
- If the FirstPosition is greater than the LastPosition, the setting range includes the maximum/minimum position of the ring counter.
- An error will occur if you specify a value beyond the upper and lower limits of the ring counter.

#### FirstPosition ≤ LastPosition



#### FirstPosition > LastPosition



# ReferenceType (Position Type Selection)

The position type is as follows:

\_mcFeedback: Value obtained in the same primary period The actual position of the master axis that was obtained in the same primary period is used.

#### FeedDistance


Specify a positive value for FeedDistance to perform feed in the same direction as the motion before the interrupt input. Specify a negative value for FeedDistance to perform feed in the opposite direction as the motion before the interrupt input.

For example, if you specify a positive value for FeedDistance when the motion was in the negative direction before the interrupt input, feeding is performed in the negative direction. If you specify a negative value for *FeedDistance*, feeding is performed in the positive direction.

# **Timing Charts**

- Busy (Executing) changes to TRUE at the same time as Execute changes to TRUE. Active (Controlling) changes to TRUE in the next period.
- After an interrupt input, InFeed changes to TRUE and when FeedDistance is reached and positioning is completed, Done changes to TRUE.
- If another instruction aborts this instruction, *CommandAborted* changes to TRUE and *Busy* (Executing) and *Active* (Controlling) change to FALSE.

# When MoveMode (Travel Mode) is \_mcAbsolute or \_mcRelative




\* There may be a delay of up to several control periods from when the interrupt input turns ON until *InFeed* changes to TRUE.



#### **Additional Information**

Acceleration or deceleration to interrupt feeding is performed according to the *Acceleration* (Acceleration Rate) or *Deceleration* (Deceleration Rate) input variable.


# ● When *MoveMode* (Travel Mode) is \_mcVelocity



# Operation at Reversing Axis Parameter

When feeding reverses its direction after the interrupt input, operation follows the Operation at Reversing axis parameter

# When Motion Variable Is 0 (Decelerate to a Stop After Reversing)






#### **Additional Information**


The deceleration rate when the axis reverses after an interrupt input follows the *Deceleration* (Deceleration Rate) input variable.

# When Motion Variable Is 1 (Stop Immediately After Reversing)




# • When MoveMode (Travel Mode) is \_mcAbsolute and an Interrupt Input Is Not Received


# When ErrorDetect (Error Detection Selection) Is Set to Not Detect Errors



### When ErrorDetect (Error Detection Selection) Is Set to Detect Errors



# • When WindowOnly Is Enabled



# **Re-execution of Motion Control Instructions**

This instruction cannot be re-executed.

A Motion Control Instruction Re-execution Disabled error (error code: 543B hex) occurs if re-execution is attempted.

# **Multi-execution of Motion Control Instructions**

For details on multi-execution of motion control instructions, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

#### Execution during Execution of Other Instructions

You can switch to this instruction or buffer this instruction if you execute it during execution of another instruction. You can buffer one instruction per axis. Specify the operation of this instruction using BufferMode (Buffer Mode Selection) for multi-execution of instructions.

<b>Buffer Mode Selection</b>	Description
Aborting	Aborts the instruction being executed and switches to this instruction.  If the direction of axis motion is reversed by switching instructions, the motion will be reversed according to the Operation at Reversing axis parameter.
Buffered	Buffers this instruction and executes it automatically after the current instruction is completed.

For details on BufferMode (Buffer Mode Selection), refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

### Execution of Other Instructions during Instruction Execution

You can execute another instruction with the Buffer Mode set to Aborting during execution of this instruction.

The following will occur if another instruction with the Buffer Mode set to Buffered or a blending mode is executed.


- Error changes to TRUE in the other instruction. A Motion Control Instruction Multi-execution Disabled error (error code: 543C hex) is output to ErrorID (Error Code).
- The MC\_MoveFeed instruction is aborted and CommandAborted changes to TRUE.

# **Errors**

If an error occurs during instruction execution, *Error* will change to TRUE and the axis will stop. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).

# Timing Chart When Error Occurs

When there is an error, the latch used for the interrupt input for this instruction is disabled.



#### Error Codes

Refer to A-1 Error Codes for instruction errors.

# **Sample Programming**

This section shows sample programming where control changes from velocity control to interrupt feed-

# **Parameter Settings**

The minimum settings required for this sample programming are given below.

# Setting Axis Parameters

# **Axis Types**

Axis	Axis Type
Axis 1	Servo axis
Axis 2	Servo axis

#### **Count Modes**

Axis	Count Mode			
Axis 1	Rotary Mode			
Axis 2	Linear Mode			


### **Ring Counters**

Axis	Modulo maximum position	Modulo mini- mum position
Axis 1	360	0


# **Units of Display**

Axis	Unit of Display
Axis 1	degree
Axis 2	mm

# **Operation Example**



# Operation Pattern



# **1** Conveyor Operation

Axis 1, which moves the conveyer belt, performs velocity control before interrupt feeding.

# **2** Feeding

Sensor 1 is connected to latch 1.

When Sensor1 turns ON, operation changes to feeding and the axis stops at the specified position.

# **3** Pressing the Stamp

When positioning is finished, axis 2 of the stamp moves perpendicularly down at the position determined by absolute positioning to press the stamp.

After stamping is performed, axis 2 returns to home.

When the absolute positioning is completed, the axis is immediately returned to home. To enable this, *BufferMode* (Buffer Mode Selection) of the MC\_MoveZeroPosition (High-speed Home) instruction is set to Buffered. Multi-execution of instructions is performed if the Active output from the previous instruction is TRUE.


# **Ladder Diagram**

#### Main Variables

Name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		Axis Variable for axis 1.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 1.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
MC_Axis001	_sAXIS_REF		Axis Variable for axis 2.
MC_Axis001.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 2.
MC_Axis001.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 2.
TrigRef	_sTRIGGER _REF		This is the specified variable for the interrupt input. Latch 1 of the Servo Drive is used in this sample. When the rising edge of the external input for sensor 1 is detected, interrupt feeding is executed.
StartPg	BOOL	FALSE	The Servo is turned ON if this variable is TRUE and EtherCAT process data communications are established.


Name	Data type	Default	Comment
InitFlag	BOOL	FALSE	This variable indicates if it is necessary to set the input parameters. Input parameters are set when this variable is FALSE. When setting the input parameters is completed, this variable changes to TRUE.

# Timing Chart





# Sample Programming

If StartPg is TRUE, EtherCAT communications for the axes are checked to see if process data communications are normal.



If process data communications are active, the Servo is turned ON.







If there is a minor fault level error for a composition axis, the error handler for the device (FaultHandler) is executed. Design FaultHandler separately.

```
MC_Axis000.MFaultLvl.Active
                                                                FaultHandler
                                                                   FaultHandler
MC_Axis001.MFaultLvl.Active
```


If the Servo is ON for axis 1 and home is not defined, the Home instruction is executed.




If the Servo is ON for axis 2 and home is not defined, the Home instruction is executed.




The parameters are set for interrupt feeding, absolute positioning, and high-speed homing.




If home is defined for axis 1, interrupt feeding is executed for axis 1.



If home is defined for axis 2 and interrupt feeding is completed for axis 1, absolute positioning is performed for axis 2.



After absolute positioning is completed, the High-speed Home instruction is executed to move to home.



#### **Contents of Inline ST**

// MV\_FEED parameters Mv\_Feed\_TrigRef.Mode := \_eMC\_TRIGGER\_MODE#\_mcDrive; Mv\_Feed\_TrigRef.LatchID := \_eMC\_TRIGGER\_LATCH\_ID#\_mcLatch1; Mv\_Feed\_TrigRef.InputDrive := \_eMC\_TRIGGER\_INPUT\_DRIVE#\_mcEXT; Mv\_Feed\_TrigVar := FALSE: Mv Feed Pos := LREAL#2000.0; Mv Feed Vel := LREAL#1000.0; Mv\_Feed\_Acc := LREAL#10000.0; Mv\_Feed\_Dec := LREAL#10000.0; Mv Feed Mm := \_eMC\_MOVE\_MODE#\_mcVelocity; Mv\_Feed\_FeedDis := LREAL#500.0;


```
Mv_Feed_FeedVel
                             := LREAL#500.0;
// MV_ABS parameters
Mv\_Abs\_Pos := LREAL#1000.0;
Mv_Abs_Vel := LREAL#500.0;
Mv_Abs_Acc := LREAL#10000.0;
Mv_Abs_Dec := LREAL#10000.0;
Mv\_Abs\_Jrk := LREAL#10000.0;
// MV_ZERO parameters
Mv\_Zero\_Vel := LREAL#500.0;
Mv_Zero_Acc := LREAL#10000.0;
Mv_Zero_Dec := LREAL#10000.0;
Mv_Zero_Jrk := LREAL#10000.0;
Mv_Zero_Bm := _eMC_BUFFER_MODE#_mcBuffered;
// Change InitFlag to TRUE after setting the input parameters.
InitFlag := TRUE;
```

# Structured Text (ST)

#### Main Variables

Name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		Axis Variable for axis 1.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 1.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
MC_Axis001	_sAXIS_REF		Axis Variable for axis 2.
MC_Axis001.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 2.
MC_Axis001.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 2.
TrigRef	_sTRIGGER _REF		This is the specified variable for the interrupt input. Latch 1 of the Servo Drive is used in this sample. When the rising edge of the external input for sensor 1 is detected, interrupt feeding is executed.
StartPg	BOOL	FALSE	The Servo is turned ON if this variable is TRUE and EtherCAT process data communications are established.
InitFlag	BOOL	FALSE	This variable indicates if it is necessary to set the input parameters. Input parameters are set when this variable is FALSE. When setting the input parameters is completed, this variable changes to TRUE.
Hm1_Ex	BOOL	FALSE	The HM1 instance of MC_Home is executed when this variable changes to TRUE.
Hm2_Ex	BOOL	FALSE	The HM2 instance of MC_Home is executed when this variable changes to TRUE.
Mv_Feed_Ex	BOOL	FALSE	The MV_FEED instance of MC_MoveFeed is executed when this variable changes to TRUE.
Mv_Abs_Ex	BOOL	FALSE	The MV_ABS instance of MC_MoveAbsolute is executed when this variable changes to TRUE.
Mv_Zero_Ex	BOOL	FALSE	The MV_ZERO instance of MC_MoveZeroPosition is executed when this variable changes to TRUE.

# Timing Chart



### Sample Programming

 $/\!/$  Processing when input parameters are not set IF InitFlag=FALSE THEN

// MV\_FEED parameters Mv\_Feed\_TrigRef.Mode := \_eMC\_TRIGGER\_MODE#\_mcDrive; Mv\_Feed\_TrigRef.LatchID := \_eMC\_TRIGGER\_LATCH\_ID#\_mcLatch1; Mv\_Feed\_TrigRef.InputDrive := \_eMC\_TRIGGER\_INPUT\_DRIVE#\_mcEXT; Mv\_Feed\_TrigVar := FALSE; Mv\_Feed\_Pos := LREAL#2000.0; Mv\_Feed\_Vel := LREAL#1000.0; Mv\_Feed\_Acc := LREAL#10000.0; Mv\_Feed\_Dec := LREAL#10000.0; Mv\_Feed\_Mm := \_eMC\_MOVE\_MODE#\_mcVelocity; Mv\_Feed\_FeedDis := LREAL#500.0; Mv\_Feed\_FeedVel := LREAL#500.0;

```
// MV_ABS parameters
   Mv\_Abs\_Pos := LREAL#1000.0;
   Mv_Abs_Vel
                := LREAL#500.0;
   Mv_Abs_Acc := LREAL#10000.0;
   Mv_Abs_Dec := LREAL#10000.0;
   Mv\_Abs\_Jrk := LREAL#10000.0;
   // MV_ZERO parameters
   Mv_Zero_Vel := LREAL#500.0;
   Mv_Zero_Acc := LREAL#10000.0;
   Mv_Zero_Dec := LREAL#10000.0;
   Mv_Zero_Jrk := LREAL#10000.0;
   Mv_Zero_Bm := _eMC_BUFFER_MODE#_mcBuffered;
   // Change InitFlag to TRUE after setting the input parameters.
   InitFlag := TRUE;
END IF;
// If StartPg is TRUE and EtherCAT communications are normal, the Servo for axis 1 is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
                        // Turn ON the Servo.
   Pwr1 En:=TRUE;
ELSE
                         // Turn OFF the Servo.
   Pwr1_En:=FALSE;
END IF;
// If StartPq is TRUE and EtherCAT communications are normal, the Servo for axis 2 is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis001.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis001.Cfg.NodeAddress]=FALSE) THEN
                         // Turn ON the Servo for axis 2.
   Pwr2 En:=TRUE;
ELSE
   Pwr2_En:=FALSE;
                         // Turn OFF the Servo for axis 2.
END IF;
// Processing for a minor fault level error
// Implement FaultHandler separately.
IF (MC_Axis000.MFaultLvl.Active=TRUE) OR (MC_Axis001.MFaultLvl.Active=TRUE) THEN
   FaultHandler();
END IF;
// If the Servo is ON for axis 1 and home is not defined, the Home instruction is executed for axis 1.
IF (Pwr1_Status=TRUE) AND (MC_Axis000.Details.Homed=FALSE) THEN
   Hm1_Ex:=TRUE;
END IF;
// If the Servo is ON for axis 2 and home is not defined, the Home instruction is executed for axis 2.
IF (Pwr2_Status=TRUE) AND (MC_Axis001.Details.Homed=FALSE) THEN
   Hm2_Ex:=TRUE;
END_IF;
// After home is defined for axis 1, MC_MoveFeed is executed.
IF MC_Axis000.Details.Homed=TRUE THEN
   Mv_Feed_Ex:=TRUE;
END_IF;
```

```
// If home is defined for axis 2 and interrupt feeding is completed for axis 1, absolute positioning is performed for
axis 2.
IF (MC_Axis001.Details.Homed=TRUE) AND (Mv_Feed_D=TRUE) THEN
   Mv_Abs_Ex := TRUE;
END_IF;
// After MC_MoveAbsolute is started, MC_MoveZeroPosition is executed with multi-execution of instructions.
IF Mv_Abs_Act=TRUE THEN
   Mv_Zero_Ex := TRUE;
END_IF;
// MC_Power for axis 1
PWR1(
   Axis
             := MC_Axis000,
   Enable
             := Pwr1_En,
   Status
             => Pwr1 Status,
             => Pwr1_Bsy,
   Busy
             => Pwr1_Err,
   Error
            => Pwr1_ErrID
   ErrorID
);
// MC_Power for axis 2
PWR2(
   Axis
             := MC Axis001,
   Enable
             := Pwr2 En.
   Status
             => Pwr2 Status,
   Busy
             => Pwr2 Bsv.
   Error
             => Pwr2_Err,
   ErrorID
            => Pwr2_ErrID
);
// MC_Home for axis 1
HM1(
   Axis
                      := MC_Axis000,
   Execute
                      := Hm1_Ex,
   Done
                      => Hm1 D.
   Busv
                      => Hm1_Bsy,
   CommandAborted
                      => Hm1 Ca,
   Error
                      => Hm1_Err,
                      => Hm1_ErrID
   ErrorID
);
// MC_Home for axis 2
HM2(
   Axis
                      := MC_Axis001,
   Execute
                      := Hm2 Ex,
   Done
                      => Hm2_D,
                      => Hm2_Bsy,
   Busv
   CommandAborted
                      => Hm2 Ca,
   Error
                      => Hm2_Err,
   ErrorID
                      => Hm2_ErrID
);
// MC_MoveFeed
MV_FEED(
   Axis
                      := MC_Axis000,
   TriggerInput
                      := Mv_Feed_TrigRef,
   TriggerVariable
                      := Mv_Feed_TrigVar,
   Execute
                       := Mv_Feed_Ex,
   Position
                      := Mv_Feed_Pos,
```

```
Velocity
                     := Mv_Feed_Vel,
                     := Mv_Feed_Acc,
   Acceleration
   Deceleration
                     := Mv_Feed_Dec,
   MoveMode
                     := Mv_Feed_Mm,
   FeedDistance
                     := Mv_Feed_FeedDis,
   FeedVelocity
                     := Mv_Feed_FeedVel,
   Done
                     => Mv_Feed_D,
                     => Mv_Feed_InFeed,
   InFeed
                     => Mv_Feed_Bsy,
   Busy
                     => Mv_Feed_Act,
   Active
   CommandAborted => Mv_Feed_Ca,
                     => Mv_Feed_Err,
   Error
   ErrorID
                     => Mv_Feed_ErrID
);
// MC_MoveAbsolute
MV_ABS(
                     := MC_Axis001,
   Axis
   Execute
                     := Mv_Abs_Ex,
                     := Mv_Abs_Pos,
   Position
                     := Mv_Abs_Vel,
   Velocity
                     := Mv_Abs_Acc,
   Acceleration
                     := Mv_Abs_Dec,
   Deceleration
                     := Mv_Abs_Jrk,
   Jerk
                     => Mv_Abs_D,
   Done
                     => Mv_Abs_Bsy,
   Busy
                     => Mv_Abs_Act,
   Active
   CommandAborted => Mv Abs Ca,
   Error
                     => Mv Abs Err,
   ErrorID
                     => Mv_Abs_ErrID
);
// MC_MoveZeroPosition
MV_ZERO(
   Axis
                     := MC_Axis001,
   Execute
                     := Mv_Zero_Ex,
   Velocity
                     := Mv_Zero_Vel,
                     := Mv_Zero_Acc,
   Acceleration
   Deceleration
                     := Mv_Zero_Dec,
   Jerk
                     := Mv_Zero_Jrk,
   BufferMode
                     := Mv Zero Bm,
   Done
                     => Mv_Zero_D,
   Busy
                     => Mv_Zero_Bsy,
                     => Mv_Zero_Act,
   Active
   CommandAborted => Mv_Zero_Ca,
                     => Mv_Zero_Err,
   Error
                     => Mv_Zero_ErrID
   ErrorID
);
```

# MC\_Stop

The MC\_Stop instruction decelerates an axis to a stop.

Instruction	Name	FB/FUN	Graphic expression	ST expression
MC_Stop	Stop	FB	MC_Stop_instance  MC_Stop  Axis	MC_Stop_instance ( Axis :=parameter, Execute :=parameter, Deceleration :=parameter, Jerk :=parameter, BufferMode :=parameter, Done =>parameter, Busy =>parameter, Active =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorID =>parameter );

# **Variables**

# **Input Variables**

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when Execute changes to TRUE.
Deceleration	Deceleration Rate	LREAL	Non-negative number	0	Specify the deceleration rate. The unit is command units/s <sup>2</sup> .* <sup>1</sup>
Jerk	Jerk	LREAL	Non-negative number	0	Specify the jerk. The unit is command units/s <sup>3</sup> .* <sup>1</sup>
BufferMode	Buffer Mode Selection	_eMC_BUFFER_ MODE	0: _mcAborting	0*2	Specify the operation when executing more than one motion instruction.
					0: Aborting

<sup>\*1</sup> Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE	TRUE when the axis is being controlled.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

<sup>\*2</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

# Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When the axis decelerates to a stop and the velocity reaches 0.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	When Done changes to TRUE.  When Error changes to TRUE.  When CommandAborted changes to TRUE.
Active	When the instruction is started.	When Done changes to TRUE.  When Error changes to TRUE.  When CommandAborted changes to TRUE.
CommandAborted	<ul> <li>When this instruction is aborted because another MC_Stop instruction was executed with the Buffer Mode set to <i>Aborting</i>.</li> <li>When this instruction is canceled due to an error.</li> <li>When this instruction is executed while there is an error.</li> </ul>	<ul> <li>When Execute is TRUE and changes to FALSE.</li> <li>After one period when Execute is FALSE.</li> </ul>
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# **In-Out Variables**

Name	Meaning	Data type	Valid range	Description
Axis	Axis	_sAXIS_REF		Specify the axis.*

<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are MC\_Axis\*\*\*.)

# **Function**

- The MC\_Stop instruction decelerates an axis from the current velocity to a velocity of 0.
- The deceleration stop operation starts when Execute changes to TRUE.
- CommandAborted for the instruction that is currently in operation will change to TRUE when MC\_Stop is executed.



#### **Precautions for Correct Use**

You cannot execute this instruction if the *Status.ErrorStop* (Error Deceleration Stopping) variable that gives the status of this axis is TRUE.

Use the MC\_ImmediateStop instruction to stop the motion of an axis that is decelerating to a stop for an error.

# **Instruction Details**

This section describes the instruction in detail.


# • Specifying Deceleration and Jerk

Set the input variables *Deceleration* and *Jerk* to set the deceleration rate and jerk when decelerating to a stop.

The relationship between the deceleration and velocity when *Jerk* is set to 0 and when it is set to any other value is shown below.

#### Jerk Set to 0


The command value for the velocity is created with deceleration rate Dt.



Vt: Velocity when deceleration starts, Dt: Specified deceleration rate, Jt: Specified jerk

### Jerk Set to Any Value Other Than 0

The command value for the velocity is created based on the current velocity with Dt as the upper limit to the deceleration rate.



Vt: Velocity when deceleration starts, Dt: Specified deceleration rate, Jt: Specified jerk



# **Additional Information**

If you set the deceleration to 0, an Immediate Stop instruction is executed. This will stop the axis immediately without decelerating. An immediate stop occurs regardless of the setting of the Acceleration/Deceleration Over Limit Selection only when the deceleration rate is set to 0.

# • Specifying *BufferMode* (Buffer Mode Selection)

*BufferMode* specifies how to join the axis motions for this instruction and the previous instruction. *BufferMode* (Buffer Mode Selection) of this instruction is a reserved parameter for future expansion. There is currently only the following setting.

Buffer Mode Selection	Description
Aborting	Aborts the instruction being executed and executes this instruction.

For details on *BufferMode* (Buffer Mode Selection), refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).


### In-position Check

An in-position check is not performed when stopping for this instruction.

# **Timing Charts**

- Busy (Executing) changes to TRUE at the same time as Execute changes to TRUE. Active (Controlling) changes to TRUE in the next period.
- Done changes to TRUE when a velocity of 0 is reached.
- If another instruction aborts this instruction, *CommandAborted* changes to TRUE and *Busy* (Executing) and *Active* (Controlling) change to FALSE.

Executing an Axis Instruction




# **Re-execution of Motion Instructions**

Deceleration (Deceleration Rate) changes if *Execute* is changed to TRUE again while this instruction is in execution. The *Jerk* setting is not changed when a motion control instruction is re-executed.

### Jerk Set to Any Value Other Than 0

The command value for the velocity is created based on the current velocity and deceleration rate, with Dt2 as the upper limit to the deceleration rate after it is changed.



Vt: Velocity when deceleration starts, Dt: Specified deceleration rate, Jt: Specified jerk

### **Multi-execution of Motion Instructions**

For details on multi-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### Execution during Execution of Other Instructions

#### **Axes Group Moving**

If the MC-Stop instruction is executed for an axis that is in an axes group motion, an error will occur for the axis. An error will occur also for the axes group, and the axes group motion will stop.

#### When the Status. Error Stop (Error Deceleration Stop) Axis Variable Is TRUE

Status. Error Stop (Error Deceleration Stopping) in the Axis Variable is TRUE while there is an error for the axis. If the MC\_Stop instruction is not executed normally for an axis that is decelerating to a stop for an error. CommandAborted changes to TRUE. Use the MC\_ImmediateStop instruction to stop the motion of an axis for which an error occurred.

# During Execution of the MC\_ResetFollowingError (Reset Following Error Counter) Instruction

If the MC\_Stop instruction is executed during the MC\_ResetFollowingError (Reset Following Error Counter) instruction, *CommandAborted* from the MC\_ResetFollowingError instruction changes to TRUE. The MC\_Stop instruction is executed. However, *Deceleration* (Deceleration Rate) to the MC\_Stop instruction is not used and an immediate stop is performed.

# Execution of Other Instructions during Instruction Execution

- If any of the following is executed while the axis is not decelerating to a stop for an MC\_Stop instruction, Status.Stopping in the Axis Variable changes to TRUE.
   MC\_ResetFollowingError (Reset Following Error Counter) instruction
   An immediate stop for the MC\_TouchProbe (Enable External Latch) instruction
   When Execute is TRUE for any other MC\_Stop instruction
- Operation is as follows for an axis for which Status. Stopping (Deceleration Stopping) is TRUE.
  - If single-axis positioning, continuous positioning, synchronized operation, or manual operation is performed, *CommandAborted* from the instruction changes to TRUE.
  - If the MC\_ResetFollowingError (Reset Following Error Counter) instruction is executed during MC\_Stop instruction execution, *Done* from the MC\_Stop instruction changes to TRUE and the MC\_ResetFollowingError instruction is executed.
  - Multi-execution of more than one MC\_Stop Instruction is possible. *Done* from the first MC\_Stop instruction changes to TRUE.
- Done of the MC\_Stop instruction changes to TRUE when one of the following conditions is met after the MC\_Stop instruction is executed.
  - When the *Enable* input variable for the MC\_Power instruction changes to FALSE (when the Servo is turned OFF)
  - When \_mcImmediateStop is selected for the StopMode input variable to the MC\_TouchProbe (Enable External Latch) instruction, the trigger condition is met, and the OMRON G5-series Servo Drive stops immediately

# **Errors**


Operation will stop if an error (e.g., axis error) occurs during instruction execution. Specify the stopping method in the axis parameters. The stopping method can be immediate stop, deceleration stop, or Servo OFF. If you specify a deceleration stop, the axis will continue decelerating until it stops.

For details on setting the Stop Mode in the axis parameters, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### Timing Chart When Error Occurs

If an error occurs during instruction execution, *Error* will change to TRUE and the axis will stop. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).


#### MC\_MoveVelocity



# Operation When Error Is Cleared

If an error occurs for this instruction and the error is reset while *Execute* is TRUE, *Error* changes to FALSE and *Done* changes to TRUE. *Status.Stopping* (Deceleration Stopping) in the Axis Variable changes to TRUE in the same way as for normal execution of the deceleration stop. Reset errors after the axis has stopped. Do not reset errors during axis motion.

#### MC\_Stop



### Error Codes

Refer to A-1 Error Codes for instruction errors.

# MC\_ImmediateStop

The MC\_ImmediateStop instruction stops an axis according to the stopping mode that is set with the *StopMode* (Stopping Mode Selection) input variable regardless of the status of the axis.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_ImmediateStop	Immediate Stop	FB	MC_ImmediateStop_instance  MC_ImmediateStop Axis Axis Done StopMode Busy CommandAborted Error ErrorID	MC_ImmediateStop_instance ( Axis :=parameter, Execute :=parameter, StopMode :=parameter, Done =>parameter, Busy =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorID =>parameter );

# **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when Execute changes to TRUE.
StopMode	Stopping Mode Selection	_eMC_ STOP_M ODE	1: _mcImmediateStop 2: _mcImmediateStopFEReset 3: _mcFreeRunStop	1*	Select the stopping mode.  1: Perform an immediate stop.  2: Perform an immediate stop and reset the following error counter.  3: Perform an immediate stop and turn OFF the Servo.

<sup>\*</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When the axis has decelerated to a stop.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	<ul> <li>When <i>Done</i> changes to TRUE.</li> <li>When <i>Error</i> changes to TRUE.</li> <li>When <i>CommandAborted</i> changes to</li> </ul>
		TRUE.
CommandAborted	When this instruction is aborted because another deceleration stop instruction was executed with	When Execute is TRUE and changes to FALSE.
	<ul><li>the Buffer Mode set to <i>Aborting</i>.</li><li>When this instruction is canceled due to an error.</li></ul>	After one period when <i>Execute</i> is FALSE.
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# **In-Out Variables**

Name	Meaning	Data type	Valid range	Description
Axis	Axis	_sAXIS_REF		Specify the axis.*

<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are *MC\_Axis*\*\*\*.)

### **Function**

- You can execute the MC\_ImmediateStop instruction under any conditions.
   For example, you can use this instruction to stop an axis immediately even if it is defined.
  - For example, you can use this instruction to stop an axis immediately even if it is decelerating to a stop for an error.
  - You cannot execute the MC\_Stop while *Status.ErrorStop* (Error Deceleration Stopping) is TRUE, but you can execute the MC\_ImmediateStop.
- When this instruction is executed, the axis stops immediately according to StopMode (Stopping Mode Selection). CommandAborted changes to TRUE for the instruction that is currently in operation.
- Status. Error Stop (Error Deceleration Stopping) in the axis status changes to TRUE when this instruction is executed and an Immediate Stop Instruction Executed error (error code: 5485 hex) occurs.




#### **Precautions for Correct Use**

Refer to *Precautions for Master and Auxiliary Axes in Synchronized Control* on page 1-7 for precautions on the master axis.

# **Timing Charts**

- Busy (Executing) changes to TRUE when Execute changes to TRUE.
- Done changes to TRUE when processing of the Immediate Stop instruction is completed.

MC\_Move Instruction



# **Re-execution of Motion Instructions**

This instruction cannot be re-executed.

A Motion Control Instruction Re-execution Disabled error (error code: 543B hex) occurs if re-execution is attempted.

## **Multi-execution of Motion Instructions**

For details on multi-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### Execution during Execution of Other Instructions

#### **Axes Group Moving**

If the instruction is executed for an axis that is in an axes group motion, an error will occur for the axis and an immediate stop is performed. An error will also occur for the axis group, and the axis group motion will stop.

## When the Status. Stopping (Deceleration Stopping) Axis Variable Is TRUE

Status. Stopping (Deceleration Stopping) in the Axis Variable changes to TRUE in the following cases.

- While the axis is decelerating for the MC\_Stop Instruction
- During execution of the MC\_ResetFollowingError (Reset Following Error Counter) instruction
- During an immediate stop for the MC\_TouchProbe (Enable External Latch) instruction
- While Execute is TRUE for one or more MC\_Stop instructions

You can execute this instruction for an axis for which *Status.Stopping* (Deceleration Stopping) is TRUE.

When this instruction is executed, *CommandAborted* from the following instructions changes to TRUE.

- MC\_Stop instruction
- MC\_ResetFollowingError (Reset Following Error Counter) instruction
- MC\_TouchProbe (Enable External Latch) instruction (during the immediate stop)

#### When the Status. Error Stop (Error Deceleration Stop) Axis Variable Is TRUE

Status. ErrorStop (Error Deceleration Stopping) in the axis status is TRUE while there is an error for the axis.

You can execute this instruction even for an axis that is decelerating to a stop for an error.


## **Error**

The axis will stop immediately even if an error (e.g., axis error) occurs during instruction execution.

For details on setting the Stop Mode in the axis parameters, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### Timing Chart When Error Occurs

If an error occurs during instruction execution, *Error* will change to TRUE and the axis will stop. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).



#### Error Codes

Refer to A-1 Error Codes for instruction errors.

# **MC\_SetPosition**

The MC\_SetPosition instruction changes the command current position or the actual current position of an axis as required.

Instruction	Name	FB/FUN	Graphic expression	ST expression
MC_SetPosition	Set Position	FB	MC_SetPosition_instance  MC_SetPosition Axis — Axis — Axis — Execute Done — Position Busy — ReferenceType CommandAborted — Relative Error — ExecutionMode ErrorID	MC_SetPosition_instance ( Axis :=parameter, Execute :=parameter, Position :=parameter, ReferenceType :=parameter, Relative :=parameter, ExcutionMode :=parameter, Done =>parameter, Busy =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorID =>parameter );

## **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Execute</i> changes to TRUE.
Position	Target Position	LREAL	Negative number, positive number, or 0	0	Specify the absolute target position. The unit is command units.*1
ReferecneType	Position Type Selection	_eMC_REFERENCE_ TYPE	0: _mcCommand 1: _mcFeedback	0*2	Specifies the position type.  0: Command position (servo axis or virtual servo axis)  1: Actual position (encoder axis or virtual encoder axis)
Relative (Reserved)	Relative Position Selection	BOOL	TRUE or FALSE		(Reserved)
MC_Execution Mode (Reserved)	Execution Mode	_eMC_EXECUTION_ MODE	0: _mcImmediately	0*2	(Reserved)

<sup>\*1</sup> Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.

<sup>\*2</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

## **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

## Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When changing the command current position and the actual current position are completed.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
CommandAborted	<ul> <li>When this instruction is canceled due to an error.</li> <li>When this instruction is executed while there is an</li> </ul>	When Execute is TRUE and changes to FALSE.
	error.	After one period when <i>Execute</i> is FALSE.
	When you start this instruction during MC_Stop instruction execution.	
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

## **In-Out Variables**

Name	Meaning	Data type	Valid range	Description
Axis	Axis	_sAXIS_REF		Specify the axis.*

<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are MC\_Axis\*\*\*.)

## **Function**

- This instruction changes the command current position of the Servo axis to the specified target position. If you execute this instruction on an encoder axis, the actual current position will change to the specified target position.
- Specify the target position in absolute coordinates.
- The actual current position changes at the same time as the command current position changes. The following error is kept the same before and after the change. If you execute this instruction on a command servo axis, the difference between the actual position and the actual current position will remain the same before and after the change. Because of this, after you execute this instruction, the actual current position of the axis takes the value calculated by the following equation.

Actual current position after change = Target position - Following error before change

If you specify the actual position for a servo axis or the command position for an encoder axis, a position type error will occur.

- When the Count Mode is set to Rotary Mode, set the target position to a value between the lower limit
  and upper limit of the ring counter. A ring counter error will occur if the target position is outside this
  range.
- When the Count Mode is set to Linear Mode, you can set the target position to a value outside the range defined by the software limits.
- You can use this instruction for an axis that is stopped or in motion.



#### **Precautions for Correct Use**

Home is undefined for the specified axis after this instruction ends. Because of this, you cannot execute following functions or instructions after this instruction ends.

- · Software limits
- MC\_MoveZeroPosition (High-speed Home) instruction
- Multi-axes coordinated control instructions (linear or circular interpolation)

## • ReferenceType (Position Type Selection)

- Set ReferenceType to the command position to use a servo axis or virtual servo axis.
- Set ReferenceType to the actual position to use an encoder axis or virtual encoder axis.

## Relationship between Axis Types and Position Types

The relationship between the axis types that you can monitor and position types that is monitored is shown below.


Axis Type	ReferenceType			
Axis Type	_mcCommand	_mcFeedback		
Servo axis	OK	No		
Encoder axis	No*	OK		
Virtual servo axis	OK	OK		
Virtual encoder axis	No*	OK		

<sup>\*</sup> A Position Type Selection Out of Range error (error code 5430 hex) occurs when the instruction is executed.

# **Timing Charts**

#### Execution While Axis Is Stopped

The actual position starts changing when *Execute* changes to TRUE. *Busy* (Executing) changes to TRUE when *Execute* changes to TRUE. *Done* changes to TRUE after the actual position is changed.




#### Execution While Axis Is in Motion

If you execute this instruction while positioning to an absolute position, the target value will change according to the change in position.

As an example, the axis operation and timing chart are shown below for a situation where the actual position is changed from 200 mm to 800 mm while the axis is moved to 400 mm for an MC\_MoveAbsolute (Absolute Positioning) instruction. The axis will move in the negative direction because the actual value is 800 mm and the target value is 400 mm. As shown in the following figure, even if the actual position is changed, the MC\_MoveAbsolute (Absolute Positioning) instruction will move the axis from the new actual position to the specified target position. When the specified target position is reached, *Done* changes to TRUE.

Previous Instruction (Example MC\_MoveAbsolute)





#### **Additional Information**

- If you execute this instruction while the MC\_MoveRelative (Relative Positioning) or MC\_MoveVelocity (Velocity Control) instruction is in execution, the actual position will change. However, if you execute this instruction while the MC\_MoveRelative (Relative Positioning) or MC\_MoveVelocity (Velocity Control) instruction is in execution, the positioning operation is not affected.
- If there is a buffered instruction, positioning is performed for the position after the change when the buffer is switched.

## **Re-execution of Motion Instructions**

This instruction cannot be re-executed.

A Motion Control Instruction Re-execution Disabled error (error code: 543B hex) occurs if re-execution is attempted.

## **Multi-execution of Motion Instructions**

For details on multi-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

### Execution during Execution of Other Instructions

You cannot use the MC\_SetPosition instruction on an axis for which any of the following instructions is being executed. A multi-execution of instructions error will occur if it is executed.

MC_Home (Home) instruction	MC_CombineAxes (Combine Axes) instruction
MC_CamIn (Start Cam Operation) Instruction	MC_MoveZeroPosition (High-speed Home) instruction
MC_GearIn (Start Gear Operation) Instruction	MC_TorqueControl (Torque Control) Instruction
MC_GearInPos (Positioning Gear Operation) instruction	MC_SyncMoveVelocity (Cyclic Synchronous Velocity Control) instruction
MC_MoveLink (Synchronous Positioning) instruction	



#### **Precautions for Correct Use**

Do not use the MC\_SetPosition instruction for *Master* (Master Axis) that is in synchronized operation for instructions such as MC\_Gearln (Start Gear Operation). If it is used for a *Master* (Master Axis), as soon as the command current position and the actual current position of the *Master* (Master Axis) are changed, the *Slave* (Slave Axis) will detect that the *Master* (Master Axis) has moved. It will then begin moving corresponding to the *Master* (Master Axis) travel distance. For this reason, the *Slave* (Slave Axis) may change suddenly or the cam motion may end suddenly. If you want to use the MC\_SetPosition instruction for the *Master* (Master Axis), disable the relationship between the *Master* (Master Axis) and slave axes before executing the instruction. Execute an instruction such as the MC\_GearOut (End Gear Operation) instruction to disable the relationship between the *Master* (Master Axis) and *Slave* (Slave Axis).

Refer to *Precautions for Master and Auxiliary Axes in Synchronized Control* on page 1-7 for precautions on the master axis.

#### Execution of Other Instructions during Instruction Execution

If another MC\_SetPosition instruction is executed while there is one already in execution, the last instruction takes priority.

In this case, *Done* for the first MC\_SetPosition instruction will change to TRUE, but the change to the set position for the first instruction is not completed.

## **Errors**


If an error occurs during instruction execution, *Error* will change to TRUE and the axis will stop. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).



#### **Additional Information**

If you execute this instruction while the axis is in motion, the instruction of the axis currently in motion will be restarted and the data required for positioning will be recalculated. If an error occurs, it will be for the instruction of the axis currently in motion rather than for this instruction.

## Timing Chart When Error Occurs



### Error Codes

Refer to A-1 Error Codes for instruction errors.

# MC\_SetOverride

The MC\_SetOverride instruction changes the target velocity for an axis.

Instruction	Name	FB/FUN	Graphic expression	ST expression
MC_SetOverride	Set Override Factors	FB	MC_SetOverride_instance  MC_SetOverride Axis Axis Enable VelFactor AccFactor JerkFactor ErrorID	MC_SetOverride_instance ( Axis :=parameter, Enable :=parameter, VelFactor :=parameter, AccFactor :=parameter, JerkFactor :=parameter, Enabled =>parameter, Busy =>parameter, Error =>parameter, ErrorlD =>parameter );

## **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Enable	Enable	BOOL	TRUE or FALSE	FALSE	The override factors are enabled when Enable is TRUE. The override factors return to 100% when Enable changes to FALSE.
VelFactor	Velocity Over- ride Factor	LREAL	0 to 500	100	Specify the velocity override factor. The valid range of the override factors is between 0.01and 500.00. Values above 500.00 are treated as 500 and values less then 0.01 (including negative values) are treated as 0.01. The override factor will be 0 only when 0 is specified. The unit is %.
AccFactor (Reserved)	Accelera- tion/Decelera- tion Override Factor	LREAL	0 to 500	100	(Reserved)
JerkFactor (Reserved)	Jerk Override Factor	LREAL	0 to 500	100	(Reserved)

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Enabled	Enable	BOOL	TRUE or FALSE	TRUE when the axis is being controlled.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

## Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Enabled	When this instruction is started.	<ul><li>After one period when <i>Enable</i> is FALSE.</li><li>When <i>Error</i> changes to TRUE.</li></ul>
Busy	When Enable changes to TRUE.	<ul><li>When Enable changes to FALSE.</li><li>When Error changes to TRUE.</li></ul>
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

## In-Out Variables

Name	Meaning	Data type	Valid range	Description
Axis	Axis	_sAXIS_REF		Specify the axis.*

<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are MC Axis\*\*\*.)

### **Function**

- The MC\_SetOverride instruction changes override factors related to the target velocity of the axis. Changes the target velocity of the axes in operation by changing the override.
- The override factors apply only to the following instructions.

MC_Move (Positioning) instruction	MC_MoveJog (Jog) instruction
MC_MoveAbsolute (Absolute Positioning) instruction	MC_MoveFeed (Interrupt Feeding) instruction
MC_MoveRelative (Relative Positioning) instruction	MC_MoveZeroPosition (High-speed Home) instruction
MC_MoveVelocity (Velocity Control) instruction	

- The new target velocity is found with the following equation.
   The target velocity after the change = Target velocity of the current instruction × Override factor
- The unit for override factors is %. A setting of 100 indicates 100%.
- If the target velocity that results from the override exceeds the maximum velocity set in the axis parameters, the maximum velocity is used.
- The axis will accelerate or decelerate to the target velocity that results from the override.
- If the velocity override factor is set to 0, the target velocity will be 0. Axis operation will decelerate to a
  velocity of 0, and operation will continue. If you want to pause the axis motion while maintaining the
  operation status, set the override factor to 0.
  - Status. Discrete and Status. Continuous in the Axis Variable do not change at this time.
- The override factors are always updated when the instruction is executed as long as Enable remains TRUE.
- The override factors apply to operation commands for new target velocities, e.g., when you start a stopped axis, re-execute a motion instruction, or perform multi-execution of motion control instructions.
- The override factors will return to 100% when Enable changes to FALSE.
- If an axis error occurs during MC\_SetOverride instruction execution, the value of Enable for the MC\_SetOverride instruction remains TRUE.



#### **Precautions for Correct Use**

When *Enable* to this instruction changes to FALSE, *Enabled* and *Busy* from this instruction change to FALSE.

The axis will accelerate or decelerate to a velocity with a 100% override factor.



#### **Additional Information**

#### Influence on Other Instructions


Use this instruction to temporarily change the target velocities of other instructions.

This instruction has no affect on instructions to which a target velocity is not input or instructions for which the target velocity is updated every period, such the Cyclic Synchronous Velocity Control instruction.

## **Timing Charts**

## Overriding the MC\_MoveAbsolute Instruction


An example of a time chart for using the Set Override Factors instruction for the MC\_MoveAbsolute (Absolute Positioning) instruction is given below.



If the MC\_SetOverride instruction is disabled, the target velocity returns to an override factor of 100%.

### Overrides for the MC\_MoveVelocity (Velocity Control) Instruction

An example of a time chart for using the Set Override Factors instruction for the MC\_MoveVelocity (Velocity Control) instruction is given below. After *InVelocity* (Target Velocity Reached) changes to TRUE, it will stay TRUE even if the velocity changes.



## **Re-execution of Motion Instructions**

You cannot re-execute enable-type motion control instructions.

## **Multi-execution of Motion Instructions**

For details on multi-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

### Multi-execution of MC\_SetOverride Instructions


If another instance of MC\_SetOverride is executed during MC\_SetOverride instruction execution, the last MC\_SetOverride instance that is executed takes priority. *Enable* will be TRUE for both instructions.

## **Errors**

If an error occurs during instruction execution, *Error* will change to TRUE. If a minor fault occurs, the axis will stop.

You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code). If you remove the cause of error, *Error* will change to FALSE.

## Timing Chart When Error Occurs



#### Error Codes

Refer to A-1 Error Codes for instruction errors.

# MC\_ResetFollowingError

The MC\_ResetFollowingError instruction resets the following error between the command current position and the actual current position.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_ResetFollowingError	Reset Following Error Counter	FB	MC_ResetFollowingError_instance  MC_ResetFollowingError Axis Axis Execute Done BufferMode Busy Active CommandAborted Error ErrorID	MC_ResetFollowingError_ instance ( Axis := parameter, Execute := parameter, BufferMode := parameter, Done => parameter, Busy => parameter, Active => parameter, CommandAborted => parameter, Error => parameter, ErrorID => parameter );

## **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Execute</i> changes to TRUE.
BufferMode	Buffer Mode Selection	_eMC_ BUFFER_ MODE	0: _mcAborting	0*	Specify the operation when executing more than one motion instruction.  0: Aborting

<sup>\*</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE	TRUE when the axis is being controlled.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

## Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When resetting the following error counter is completed.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
Active	When the instruction is started.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
CommandAborted	When the MC_ResetFollowingError instruction is aborted because another motion control instruc-	When Execute is TRUE and changes to FALSE.
	tion was executed with the Buffer Mode set to Aborting.	After one period when <i>Execute</i> is FALSE.
	When this instruction is canceled due to an error.	
	When this instruction is executed while there is an error.	
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

## **In-Out Variables**


Name	Meaning	Data type	Valid range	Description
Axis	Axis	_sAXIS_REF		Specify the axis.*

<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are *MC\_Axis*\*\*\*.)

## **Function**

- The MC\_ResetFollowingError instruction resets the following error between the command current position and the actual current position in the MC Function Module to 0 in Cyclic Synchronous Positioning Mode.
- When *Execute* changes to TRUE, the actual current position at that point is used as the command position (i.e., the target position).
  - For example, when a following error occurs in the holding operation shown below, you can execute this instruction to implement a position command in the reverse direction and therefore set the following error to 0.

CommandAborted for the instruction for which the following error occurred changes to TRUE and instruction execution is aborted.



- When the following error is set to 0, the maximum velocity that is set in the axis parameters is used to implement a position command. The maximum acceleration and deceleration rates are not used.
- When the command to the new target position is completed, the *Done* output variable changed to TRUE.
- This instruction implements a command position in the reverse direction to the direction in which the following error occurred, but the Operation at Reversing axis parameter is not used.



#### **Precautions for Correct Use**

- Execute this instruction only when the axis velocity is low.

  This instruction implements a command value in the opposite direction to the previous instruction (e.g., in the opposite direction to the holding direction). If the axis speed is too high when this instruction is executed, the controlled system may be subjected to shock.
- Before you execute this instruction for a vertical axis, for which constant torque is required, make sure that the torque will not become insufficient.
- Executing this Instruction for the Master Axis of Synchronized Control

If this instruction is executed for the master axis of synchronous control when the command position is used as the synchronization data for the master axis, the slave axis will move in the reverse direction according to the gear ratio or cam data variable.

Refer to *Precautions for Master and Auxiliary Axes in Synchronized Control* on page 1-7 for precautions on the master axis.

## Instruction Details

This section describes the instruction in detail.

#### Applicable Axes and Execution Condition

- You can use this instruction for servo and virtual servo axes in the following cases.
   During single-axis position control
   During the MC\_MoveVelocity (Velocity Control) instruction
   During synchronized control
- An error occurs if the instruction is executed for an encoder or virtual encoder axis.


#### Axis Variable Status

Status. Stopping (Deceleration Stopping) in the Axis Variable status changes to TRUE.

# **Timing Charts**

Timing charts for when this instruction is executed during holding status for the MC\_MoveAbsolute (Absolute Positioning) instruction are given below.





## **Re-execution of Motion Control Instructions**

This instruction cannot be re-executed.

A Motion Control Instruction Re-execution Disabled error (error code: 543B hex) occurs if re-execution is attempted.

## **Multi-execution of Motion Control Instructions**

For details on multi-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

### Execution during Execution of Other Instructions

You can switch to this instruction or buffer this instruction if you execute it during execution of another instruction.

You can buffer one instruction per axis.

Specify the operation of this instruction by using *BufferMode* (Buffer Mode Selection) for multi-execution of instructions.

Buffer Mode Selection	Description
Aborting	Cancels the instruction being executed and switches to this instruction.

For details on *BufferMode* (Buffer Mode Selection), refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### Relation to MC\_Stop Instruction

If the MC\_ResetFollowingError (Reset Following Error Counter) instruction is executed during MC\_Stop instruction execution, *Done* from the MC\_Stop instruction changes to TRUE and the MC\_ResetFollowingError instruction is executed.

#### Execution of Other Instructions during Instruction Execution

The axis decelerates to a stop when this instruction is executed.

Execute an instruction for which multi-execution is supported while the axis is decelerating. If an instruction for which multi-execution is not supported is executed, *CommandAborted* for the instruction changes to TRUE.

#### Relation to MC\_Stop Instruction


If the MC\_Stop instruction is executed during the MC\_ResetFollowingError (Reset Following Error Counter) instruction, *CommandAborted* from the MC\_ResetFollowingError instruction changes to TRUE. The MC\_Stop instruction is executed. However, *Deceleration* (Deceleration Rate) to the MC\_Stop instruction is not used and an immediate stop is performed.

## **Errors**

If an error occurs during instruction execution, an immediate stop is performed and *CommandAborted* changes to TRUE. Also, if an error occurs when this instruction is executed, *Error* will change to TRUE. You can find out the cause of the error by referring to the value output to *ErrorID* (Error Code).

Timing charts for when the MC\_MoveAbsolute (Absolute Positioning) instruction is executed and an error occurs when the MC\_ResetFollowing Error is executed during holding status are given below.





#### Error Codes

Refer to A-1 Error Codes for instruction errors.

# MC\_CamIn

The MC\_CamIn instruction starts a cam operation by using a specified cam table.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_CamIn	Start Cam Operation	FB	MC_CamIn_instance    MC_CamIn	MC_CamIn_instance ( Master :=parameter, Slave :=parameter, CamTable :=parameter, Execute :=parameter, Periodic :=parameter, StartMode :=parameter, StartPosition :=parameter, MasterStartDistance :=parameter, MasterScaling :=parameter, SlaveScaling :=parameter, MasterOffset :=parameter, SlaveOffset :=parameter, SlaveOffset :=parameter, Direction :=parameter, CamTransition :=parameter, BufferMode :=parameter, InCam =>parameter, InCam =>parameter, InGam =>parameter, Index =>parameter, EndOfProfile =>parameter, Active =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorID =>parameter);

# **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Execute</i> changes to TRUE.
Periodic	Periodic Mode	BOOL	TRUE or FALSE	FALSE	Specify whether to execute the specified cam table peri- odically or only once. FALSE: Non-periodic TRUE: Periodic
StartMode	Start Mode	_eMC_ START_MODE	0: _mcAbsolutePosition 1: _mcRelativePosition	0*1	Specify the coordinates used by MasterStartDistance. 0: Absolute position 1: Relative position

Name	Meaning	Data type	Valid range	Default	Description
StartPosition	Cam Table Start Posi- tion	LREAL	Negative number, positive number, or 0	0	Specify the starting point of the cam table (0 phase) as an absolute position of the master axis. The unit is command units.*2
MasterStart Distance	Master Following Distance	LREAL	Negative number, positive number, or 0	0	Specify the position of the master axis when the following axis starts the cam motion. When absolute positioning is specified with <i>StartMode</i> , specify the absolute position of the master axis. When relative positioning is specified, specify a relative distance from the StartPosition (Cam Table Start Position). The unit is command units.*2
Master Scaling	Master Coefficient	LREAL	Positive value (>0.0)	1.0	The phase of the master axis is extended or contracted by using the specified scale.
SlaveScaling	Slave Axis Coefficient	LREAL	Positive value (>0.0)	1.0	The displacement of the slave axis is extended or contracted by using the specified scale.
MasterOffset	Master Off- set	LREAL	Negative number, positive number, or 0	0	The phase of the master axis is shifted by using the specified offset value.
SlaveOffset	Slave Off- set	LREAL	Negative number, positive number, or 0	0	The displacement of the slave axis is shifted by using the specified offset value.
Reference Type	Position Type Selection	_eMC_REFERENCE _ TYPE	0: _mcCommand 1: _mcFeedback 2: _mcLatestCommand	0*1	Specify the position type of the master axis.  0: Command position (value calculated in the previous primary period)  1: Actual position (value obtained in the same primary period)  2: Command position (value calculated in the same primary period)
Direction	Direction	_eMC_DIRECTION	0: _mcPositiveDirection 2: _mcNegativeDirection 4: _mcNoDirection	4*1	The slave axis cam moves when the master axis moves in the specified direction only. If the master axis is moving opposite to the direction specified, the slave axis cam is stopped.  0: Positive direction  2: Negative direction  4: No direction specified
CamTransition (Reserved)	Cam Transition Selection	_eMC_CAM_ TRANSITION	0: _mcCTNone	0*1	(Reserved)

Name	Meaning	Data type	Valid range	Default	Description
BufferMode	Buffer Mode Selection	_eMC_ BUFFER_MODE	0: _mcAborting 1: _mcBuffered	0*1	Specify the operation when executing more than one motion instruction.  0: Aborting 1: Buffered

<sup>\*1</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

# **Output Variables**

Name	Meaning	Data type	Valid range	Unit	Description
InCam	Cam Motion	BOOL	TRUE or FALSE		TRUE when the cam table start point is executed.
InSync	In Sync	BOOL	TRUE or FALSE		TRUE when the cam is in operation.
EndOfProfile	End of Cam Cycle	BOOL	TRUE or FALSE		TRUE when the cam table end point is executed.
Index	Index	UNIT	Nonnega- tive value		Contains the cam data index number.
Busy	Executing	BOOL	TRUE or FALSE		TRUE when the instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE		TRUE when the axis is being controlled.
Command Aborted	Command Aborted	BOOL	TRUE or FALSE		TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE		TRUE while there is an error.
ErrorID	Error Code	WORD	*2		Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*1</sup> FALSE while InCam (Cam In Motion) is FALSE.

## Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
InSync	When the slave axis starts cam operation.	<ul> <li>When Periodic is FALSE and EndOfProfile changes to TRUE.</li> <li>When Error changes to TRUE.</li> <li>When CommandAborted changes to TRUE.</li> </ul>
EndOfProfile	The period where the phase and displacement of the end point of the cam table are output as the command position.	One period after <i>EndofProfile</i> changes to TRUE.
Busy	When Execute changes to TRUE.	When Periodic is FALSE and EndOfProfile changes to TRUE.  When Error changes to TRUE.  When CommandAborted changes to TRUE.
InCam	When the master axis passes the StartPosition (Cam Table Start Position).	<ul> <li>When Periodic is FALSE and EndOfProfile changes to TRUE.</li> <li>When Error changes to TRUE.</li> <li>When CommandAborted changes to TRUE.</li> </ul>

<sup>\*2</sup> Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.

<sup>\*2</sup> Refer to A-1 Error Codes.

Name	Timing for changing to TRUE	Timing for changing to FALSE
Active	When the instruction is started.	When Periodic is FALSE and EndOfProfile changes to TRUE.  When Error changes to TRUE.  When CommandAborted changes to TRUE.
CommandAborted	When this instruction is aborted because another motion control instruction was executed with the Buffer Mode set to Aborting. When this instruction is canceled due to an error. When this instruction is executed while there is an error. When you start this instruction during MC_Stop instruction execution. When the MC_CamOut instruction is executed.	When Execute is TRUE and changes to FALSE.     After one period when Execute is FALSE.
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

**Note** The update timing of the output variables may change depending on the mode that is set for cam switching. The default timing is given above.

## **In-Out Variables**

Name	Meaning	Data type	Valid range	Description
Master	Master Axis	_sAXIS_REF		Specify the master axis.*1
Slave	Slave Axis	_sAXIS_REF		Specify the slave axis.*1
CamTable	Cam Table	ARRAY[0N]OF _sMC_CAM_ REF		Specify the cam data structure _sMC_CAM_REF array variable as the cam table.*2

<sup>\*1</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are *MC\_Axis*\*\*\*.)

<sup>\*2</sup> N in the array variable is set automatically by the Sysmac Studio. Specify a cam data variable that was created on Cam Editor of the Sysmac Studio.



#### **Precautions for Correct Use**

If you specify the same axis for the master axis and slave axis, a Master and Slave Defined as Same Axis minor fault (error code 5436 hex) will occur.

## **Function**

- The MC\_CamIn instruction executes a cam motion that synchronizes the master axis phase and slave axis displacement according to a cam table.
- You must create the cam table specified for this instruction by using the Cam Editor and download it to the Controller in advance.
- This instruction is executed when Execute changes to TRUE.



#### **Precautions for Correct Use**

For the cam table, you must use a cam data variable that was created on the Cam Editor of the Sysmac Studio.




#### **Additional Information**

Use the Synchronize Menu of the Sysmac Studio to download the project.

For details on cam tables, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

Specify the phases and displacements in the cam table as relative quantities from a start point of 0.0. The command positions for the master and slave axes are linear interpolations between two cam data where the slave axis displacement corresponding to the master axis phase is calculated.

If there are only a few cam data, the intervals between phases are large and cam operation will not be very precise. If there are many cam data, the intervals between phases are small and cam operation will be very precise.



Linearly interpolate between cam data (black dots on the line).



#### **Precautions for Correct Use**

- When executed, this instruction checks if the phases are in ascending order. If they are not in ascending order, an error occurs.
  - When you change cam data, execute the MC\_SetCamTableProperty (Set Cam Table Properties) instruction to make sure that the phases are in ascending order.
  - Make sure that the phases will be in ascending order before you change the phases during a cam motion. The cam motion may stop if the phases are not in ascending order.
- Cam data variables are global variables. You can therefore access or change the values of cam data variables from more than one task. If you change the values of cam data variables from more than one task, program the changes so that there is no competition in writing the value from more than one task.
- If you use exclusive control of global variables between tasks for a cam data variable, do not
  use the cam data variable for motion control instructions while exclusive control is in effect for
  the cam data variable. An Incorrect Cam Table Specification error (error code: 5439 hex) will
  occur.



#### **Precautions for Safe Use**

Do not execute the MC\_SetPosition instruction on the *Master* (Master Axis) if you use this instruction.

If the MC\_SetPosition instruction is executed for the *Master* (Master Axis), the *Slave* (Slave Axis) may follow the master axis quickly.

If you want to use the MC\_SetPosition instruction for the *Master* (Master Axis), disable the relationship between the *Master* (Master Axis) and slave axes before executing the instruction. Refer to *Precautions for Master and Auxiliary Axes in Synchronized Control* on page 1-7 for precautions on the master axis.

## **Instruction Details**

This section describes the instruction in detail.

#### Instruction Execution Condition

You can execute this instruction while the master axis is stopped, during position control, velocity control, or synchronized control. For details on the slave axis, refer to *Re-execution of Motion Instructions* on page 3-173 and *Multi-execution of Motion Instructions* on page 3-174.

#### Software Limits

If the slave axis exceeds the software limit during cam operation, an error occurs.

#### Cam Data Variables

A cam data variable is declared as an array of cam data structures. The type declaration for the cam data structure is shown below.

```
TYPE

(*Cam data structure*)

_sMC_CAM_REF:

STRUCT

Phase : REAL; (*Phase*)

Distance : REAL; (*Displacement*)

END_STRUCT;

END_TYPE
```

Create the cam data variables on the Sysmac Studio.


You can specify a name for the cam table name (i.e., the name of the cam data variable).

For example, if you make a cam table called MyCam1 with 1,000 points use the following variable declaration is automatically made by the Sysmac Studio.

```
VAR
(*Cam table*)

MyCam1 : ARRAY [0..999] OF _sMC_CAM_REF;
END_VAR
```

The following notation is used to specify *MyCam1* for this instruction. In this example, the master axis is *Axis1* and the slave axis is *Axis2*.



An error will occur if the specified cam table does not exist in the Controller. You can also specify the same cam table for more than one axis.

The values in cam data variables can be written from the user program or other means. However, any changes to the values are lost when the power supply to the Controller is turned OFF or the cam data variables are downloaded from the Sysmac Studio.

The values that are downloaded from the Sysmac Studio are always used when the power supply to the Controller is turned ON or after the cam data variables are downloaded.

To save any changes, execute the MC\_SaveCamTable instruction.

Changes to the cam data variables are retained when the operating mode of the CPU Unit is changed.



#### **Additional Information**

- The cam data variables are not published to the network.
   For example, you can monitor the values of MyCam1[10].Phase or MyCam1[10].Distance from the Sysmac Studio, but you cannot access from another Controller via EtherNet/IP.
- Use the Synchronize Menu of the Sysmac Studio to download the project.


## Starting Cam Operation

After the instruction starts, the master axis has to reach the *StartPosition* (Cam Table Start Position). When the master axis moves the *MasterStartDistance* after it reaches the *StartPosition* (Cam Table Start Position), slave axis cam operation starts.


*MasterStartDistance* is specified as an absolute position or as a relative distance from *StartPosition* (Cam Table Start Position).

Set whether to specify using an absolute position or relative position with StartMode.

The following chart shows the operation when the cam table start position is 20°, master start distance is 40°, Start Mode is set to relative coordinates, and the Execution Mode is set to Periodic.



To specify the same operation in absolute coordinates, set the cam table start position to 20°, master start distance to 60°, Start Mode to absolute coordinates, and Execution Mode to Periodic.



## **Precautions for Correct Use**

To perform a cam motion, use the Cam Editor in the Sysmac Studio to create a cam profile and then download the cam profile to the CPU Unit. Use the Synchronize Menu of the Sysmac Studio to download the project.


## Periodic (Periodic Mode)

If you specify TRUE (periodic) for *Periodic*, the cam motion will be repeated from the start to the end point of the cam table.


If you specify FALSE (non-periodic), the cam operation ends when the last point in the cam table is executed.

If the stroke position of the slave axis is the same at the start and end points of the cam table when TRUE (periodic) is set, the cam operates as a reciprocal cam. (Refer to *Reciprocal Cam Operation*.) If the stroke position of the slave axis differs at the start point and end point, the cam operates as a feeding cam. (Refer to *Feeding Cam Operation*.) In the following chart, the horizontal axis indicates the master axis and the vertical axis indicates the slave axis.

## **Reciprocal Cam Operation**



## **Feeding Cam Operation**



## EndOfProfile (End of Cam Cycle)


EndOfProfile (End of Cam Cycle) is TRUE for one period when the command value of the cam motion for the phase and displacement defined by the end point in the cam table is output. Set the absolute position of the master axis as the *StartPosition* (Cam Table Start Position) and the cam table becomes relative to that position. *EndOfProfile* (End of Cam Cycle) functions as an output indicating the end of the cam table.

## Ending Cam Operation

Use the MC\_CamOut (End Cam Operation) instruction or MC\_Stop instruction to stop cam operation before it is completed.

## Scaling Factor


You can specify a scaling factor to scale up or scale down the master axis phase and slave axis displacement of a specified cam table. You can apply separate factors to the master and slave axes.




#### Offset

You can shift the phase and displacement by an offset from the specified cam table. You can specify separate offsets for the master axis phase and slave axis displacement.


#### MasterOffset > 0




## MasterOffset < 0



### SlaveOffset > 0



## SlaveOffset < 0



#### ReferenceType (Position Type Selection)

Any of the following position types can be selected for the master axis to which the slave axis is synchronized.

\_mcCommand: Command position (value calculated in the previous primary period)
 The master axis command position that was calculated in the previous primary period is used for the current period.

The command value that was calculated for the master axis in the last primary period is used to calculate the command position of the slave axis in the current period.

- \_mcFeedback: Value obtained in the same primary period
  The actual position of the master axis that was obtained in the same primary period is used.
- \_mcLatestCommand: Command position (value calculated in the same primary period)
   The command position of the master axis that was calculated in the same primary period is used.
   This enables the use of information that is more recent than for \_mcCommand. However, the axis number of the master axis must be set lower than the axis number of the slave axis. If the axis number of the slave axis is lower than the axis number of the master axis, Error will change to TRUE. A Master/Slave Axis Numbers Not in Ascending Order error (error code: 5438 hex) will be output to ErrorID.



#### **Additional Information**

The command position that is calculated in the same primary period enables greater precision in synchronization than the command position that was calculated in the previous primary period. However, the axis number set for the master axis in the system-defined variable for motion control must be lower than the axis number set for the slave axis in the system-defined variable for motion control.

## Relationship between Axis Types and Position Types

The relationship between the axis types that you can monitor and position types that is monitored is shown below.

Axis Type	ReferenceType		
Axis Type	_mcCommand or _mcLatestCommand	_mcFeedback	
Servo axis	OK	OK	
Encoder axis	No*	OK	
Virtual servo axis	OK	OK	
Virtual encoder axis	No*	OK	


<sup>\*</sup> A Position Type Selection Out of Range error (error code: 5430 hex) occurs when the instruction is executed.

#### Direction

You can start cam operation for the slave axis only if the travel direction of the master axis matches the setting in *Direction*. *Direction* is valid only while *InSync* is TRUE.


#### \_mcNoDirection (No Direction Specified)

Cam operation starts regardless of whether the master axis is traveling in the positive or negative direction.




### \_mcPositiveDirection

Cam operation starts when the master axis is moving in the positive direction.



## \_mcNegativeDirection

Cam operation starts when the master axis is moving in the negative direction.



#### Index

Of the two cam data used to find the command positions of the master and slave axes, the one with the smaller cam data index number is output to the Index output variable. Use this value for fine-tuning the cam data with the Cam Editor or with the user program.

### In-position Check

An in-position check is not performed for this instruction.


#### Override Factors

You cannot set override factors with the MC\_SetOverride (Set Override Factors) instruction for this instruction.

# **Timing Charts**

## Non-periodic Operation

The following timing chart shows the operation when *Periodic* (Periodic Mode) is FALSE (non-periodic) for the MC\_CamIn (Start Cam Operation) instruction.




## Periodic Operation

The cam motion is repeatedly executed.

The slave axis decelerates to 0 when the cam operation is ended with the MC\_CamOut (End Cam Operation) instruction. The operation of the master axis is not affected.


The following timing chart shows the operation when *Periodic* (Periodic Mode) is TRUE (periodic) for the MC\_CamIn (Start Cam Operation) instruction and then the MC\_CamOut (End Cam Operation) instruction is executed.



## MC\_Stop Instruction


If the MC\_Stop instruction is executed for the master axis during cam operation, the sync between the master axis and slave axis is maintained. If the MC\_Stop instruction is executed for the slave axis during cam operation, the sync between the master axis and slave axis ends.

The following timing chart displays the operation when *Periodic* (Periodic Mode) is TRUE (periodic) for the MC\_CamIn (Start Cam Operation) instruction and then the MC\_Stop instruction is executed for the slave axis.



# **Aborting the Instruction**

If an axis error occurs for the slave axis during execution of this instruction or if the MC\_Stop instruction is executed for the slave axis, *CommandAborted* changes to TRUE and the slave axis decelerates to a stop at the maximum deceleration rate. Refer to *A-1 Error Codes* for information on isolating the causes of axis errors. If an axis error occurs on the master axis, cam operation will continue.



## Re-execution of Motion Instructions

You can re-execute this instruction to change the cam table during operation. When re-executing the instruction, *InCam* and *InSync* retain the status that they had prior to the re-execution. If the instruction is re-executed when InSync is TRUE, the cam operation starts from the current phase.



#### **Precautions for Correct Use**

If a cam table is switched by re-executing the instruction during a cam motion, the velocity or acceleration of the slave axis may change rapidly after re-execution. Be careful when re-executing the instruction because the mechanical composition may be affected.

For details on re-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### Re-execution Procedure

For the procedure to re-execute this instruction, refer to *Sample Programming 1* on page 3-175 and *Sample Programming 2* on page 3-186.

## **Multi-execution of Motion Instructions**

For details on re-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### Execution of Other Instructions during Instruction Execution


To use multi-execution of motion instruction for this instruction, specify the slave axis. When multi-execution of another instruction is performed while this instruction is in execution, the following limits apply depending on the Buffer Mode.

- When another instruction is executed by using multi-execution with *BufferMode* set to *Aborting*, the cam motion is aborted and the next operation is started.
- When another instruction is executed with BufferMode set to *Buffered*, the command position of the next operation is output when *EndOfProfile* (End of Cam Cycle) changes to TRUE.

#### **Errors**

If an error occurs during instruction execution, *Error* will change to TRUE. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).

## Timing Chart When Error Occurs



#### Error Codes

Refer to A-1 Error Codes for instruction errors.

# **Sample Programming 1**

This sample programming shows cam operation when periodic operation is specified. In this example, the master axis is *axis 1* and the slave axis is *axis 2*.



#### **Additional Information**

You can specify only the initial values for input variables that are reserved. In this sample, variables with initial values are defined for the instructions, but you do not need to assign variables and parameters when you program them.

# **Parameter Settings**

The minimum settings required for this sample programming are given below.

## Setting Axis Parameters

#### **Axis Types**

Axis	Axis Type
Axis 1	Servo axis (master axis)
Axis 2	Servo axis (slave axis)

#### **Count Modes**

Axis	Count Mode
Axis 1	Rotary Mode
Axis 2	Linear Mode

## **Ring Counter**


Axis	Modulo maxi- mum position	Modulo mini- mum position
Axis 1	360	0

#### **Units of Display**

Axis	Unit of Display
Axis 1	degree
Axis 2	mm

# Operation Example

#### Operation Pattern



# 1 Starting Cam Operation

If the cam table start point position (zero phase position) is  $20^{\circ}$ , the slave axis starts operation when the master axis reaches a position where the relative angle from that point is  $40^{\circ}$ . Cam operation operates in a periodic motion. If *Periodic* is TRUE, periodic operation is performed.

# **2** Ending Cam Operation

When the actual position of the slave axis *MC\_Axis001.Act.Pos* exceeds 1000.0, cam operation is ended and the slave axis is stopped at deceleration rate *DecRate2*.


# Ladder Diagram

#### Main Variables

Name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		Axis Variable for the master axis, axis 1.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 1.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
MC_Axis001	_sAXIS_REF		Axis Variable for the slave axis, axis 2.
MC_Axis001.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 2.
MC_Axis001.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 2.
Pwr1_S	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.

Name	Data type	Default	Comment
Pwr2_S	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR2 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
CamProfile0	ARRAY[0360] OF _sMC_CAM_REF		This is the cam data variable. The array elements ARRAY[0N] are set with the Cam Editor. In this sample, 0 to 360 are used, but the number of array elements depends on the settings that you make with the Cam Editor.
DecRate2	LREAL	10000.0	This variable sets the deceleration rate for execution of MC_CamOut.
Vel_InVel	BOOL	FALSE	This variable is assigned to the <i>InVelocity</i> output variable from the VEL instance of the MC_MoveVelocity instruction. It is TRUE when the target velocity is reached.
Camin_InCam0	BOOL	FALSE	This variable is assigned to the <i>InCam</i> output variable from the CAMIN instance of the MC_CamIn instruction. It is TRUE during cam operation.
Camout_Ex	BOOL	FALSE	The CAMOUT instance of MC_CamOut is executed while this variable is TRUE.
StartPg	BOOL	FALSE	The Servo is turned ON if this variable is TRUE and EtherCAT process data communications are established.





## Sample Programming


If StartPg is TRUE, EtherCAT communications for axis 1 are checked to see if process data communications are normal.

```
StartPg _EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress] _EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress] Lock1
```


If StartPg is TRUE, EtherCAT communications for axis 2 are checked to see if process data communications are normal.

```
StartPg _EC_PDSlavTbl[MC_Axis001.Cfg.NodeAddress] _EC_CommErrTbl[MC_Axis001.Cfg.NodeAddress] Lock2
```

If process data communications are active for axis 1, the Servo is turned ON.



If process data communications are active for axis 2, the Servo is turned ON.




If there is a minor fault level error for a composition axis, the error handler for the device (FaultHandler) is executed. Design FaultHandler separately.

```
MC_Axis000.MFaultLvl.Active

FaultHandler
EN FaultHandler
```


If the Servo is ON for axis 1 and home is not defined, the Home instruction is executed to define home.




If the Servo is ON for axis 2 and home is not defined, the Home instruction is executed to define home.

```
HM2
                                                             MC_Home
                                                                                                   Hm2_D
                                     MC_Axis001 -
                                                    Axis
                                                                            Axis
Pwr2 S MC Axis001.Details.Homed
                                                    Execute
                                                                           Done
                                                                                  - Hm2_Bsy
                                                                           Busy
                                                                CommandAborted
                                                                                  - Hm2_Ca
                                                                                  - Hm2_Err
                                                                           Error
                                                                         ErrorID
                                                                                  - Hm2_ErrID
```


The MC\_MoveVelocity (Velocity Control) instruction is executed after homing is completed for axis 1.




The MC\_CamIn (Start Cam Operation) instruction is executed if *Vel\_InVel* is TRUE for the MC\_MoveVelocity (Velocity Control) instruction.



CamOut\_Ex changes to TRUE if Camin\_InCam0 is TRUE and MC\_Axis001.Act.Pos exceeds 1000.



The MC\_CamOut (End Cam Operation) instruction is executed when *Camout\_Ex* changes to TRUE. The deceleration rate is specified by *DecRate2*.



#### **Contents of Inline ST**

IF MC\_Axis001.Act.Pos>LREAL#1000.0 THEN
 Camout\_Ex := TRUE;
END\_IF;


# Structured Text (ST)

#### Main Variables

Name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		Axis Variable for the master axis, axis 1.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 1.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
MC_Axis001	_sAXIS_REF		Axis Variable for the slave axis, axis 2.
MC_Axis001.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 2.

N	D. 1. 1	D. (. 11	
Name	Data type	Default	Comment
MC_Axis001.Details.Homed Pwr1_S	BOOL BOOL	FALSE FALSE	TRUE when home is defined for axis 2.  This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
Pwr2_S	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR2 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
CamProfile0	ARRAY[0360] OF _sMC_CAM_REF		This is the cam data variable. The array elements ARRAY[0N] are set with the Cam Editor. In this sample, 0 to 360 are used, but the number of array elements depends on the settings that you make with the Cam Editor.
DecRate2	LREAL	10000.0	This variable sets the deceleration rate for execution of MC_CamOut.
Vel_InVel	BOOL	FALSE	This variable is assigned to the <i>InVelocity</i> output variable from the VEL instance of the MC_MoveVelocity instruction. It is TRUE when the target velocity is reached.
Camin_InCam0	BOOL	FALSE	This variable is assigned to the <i>InCam</i> output variable from the CAMIN instance of the MC_CamIn instruction. It is TRUE during cam operation.
Camout_Ex	BOOL	FALSE	The CAMOUT instance of MC_CamOut is executed while this variable is TRUE.
StartPg	BOOL	FALSE	The Servo is turned ON if this variable is TRUE and EtherCAT process data communications are established.
Camin_Ex	BOOL	FALSE	This variable is changed to TRUE when Vel_InVel changes to TRUE to change Execute for the CAMIN instance of MC_CamIn to TRUE.
InitFlag	BOOL	FALSE	This variable indicates if it is necessary to set the input parameters. Input parameters are set when this variable is FALSE. When setting the input parameters is completed, this variable changes to TRUE.

## Timing Chart



#### Sample Programming

// Processing when input parameters are not set IF InitFlag=FALSE THEN

```
// MC_CamIn parameters
Camin_EM := TRUE;
                                       // Periodic Mode
Camin_StMode := _eMC_START_MODE#_mcRelativePosition;
Camin_StPos := LREAL#20.0;
                                       // Master axis absolute position for start point
Camin_MStDis := LREAL#40.0;
                                       // Master axis position to start cam operation
Camin_MSc
              := LREAL#1.0;
                                       // Master axis scaling
Camin_SSc
              := LREAL#1.0;
                                       // Slave axis scaling
                                       // Master offset
Camin_MO
               := LREAL#0.0;
                                       // Slave offset
Camin_SO
              := LREAL#0.0;
               := _eMC_REFERENCE_TYPE#_mcCommand;
                                                              // Position type selection
Camin_RT
Camin_Dir
              := _eMC_DIRECTION#_mcNoDirection;
                                                               // Direction
// MC_MoveVelocity parameters
Vel_Vel := LREAL#1000.0;
Vel_Acc := LREAL#100000.0;
Vel_Dec := LREAL#100000.0;
Vel_Dir := _eMC_DIRECTION#_mcPositiveDirection;
```

```
// MC_CamOut parameters
   Camout_Dec := DecRate2;
   // Change InitFlag to TRUE after setting the input parameters.
   InitFlag := TRUE;
END_IF;
// If StartPq is TRUE and EtherCAT communications are normal, the Servo for axis 1 is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
   Pwr1 En:=TRUE;
ELSE
   Pwr1_En:=FALSE;
END IF:
// If StartPg is TRUE and EtherCAT communications are normal, the Servo for axis 2 is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis001.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis001.Cfg.NodeAddress]=FALSE) THEN
   Pwr2_En:=TRUE;
ELSE
   Pwr2 En:=FALSE;
END_IF;
// If a minor fault level error occurs for axis 1 or axis 2, the error handler for the device is executed.
// Implement FaultHandler separately.
IF (MC_Axis000.MFaultLvl.Active=TRUE) OR (MC_Axis001.MFaultLvl.Active=TRUE) THEN
   FaultHandler();
END_IF;
// If the Servo is ON for axis 1 and home is not defined, the Home instruction is executed for axis 1.
IF (Pwr1_S=TRUE) AND (MC_Axis000.Details.Homed=FALSE) THEN
   Hm1_Ex:=TRUE;
END IF:
// If the Servo is ON for axis 2 and home is not defined, the Home instruction is executed for axis 2.
IF (Pwr2 S=TRUE) AND (MC Axis001.Details.Homed=FALSE) THEN
   Hm2_Ex:=TRUE;
END_IF;
// After homing is completed for axis 1, MC_MoveVelocity is executed.
IF Hm1_D=TRUE THEN
   Vel_Ex := TRUE;
END_IF;
// CamIn is executed when InVel of MC_MoveVelocity is TRUE.
IF Vel InVel=TRUE THEN
   Camin_Ex := TRUE;
END IF:
// CamOut is executed when Camin InCamO is TRUE and MC_Axis001.Act.Pos is greater than 1000.
IF (Camin_InCam0=TRUE) AND (MC_Axis001.Act.Pos>LREAL#1000.0) THEN
   Camout_Ex := TRUE;
END_IF;
// MC_Power for axis 1
PWR1(
   Axis
             := MC_Axis000,
   Enable
             := Pwr1_En,
```

```
=> Pwr1_S,
   Status
            => Pwr1_Bsy,
   Busy
   Error
            => Pwr1_Err,
   ErrorID => Pwr1_ErrID
);
// MC_Power for axis 2
PWR2(
   Axis
            := MC_Axis001,
            := Pwr2_En,
   Enable
   Status
            => Pwr2_S,
   Busy
            => Pwr2_Bsy,
   Error
            => Pwr2_Err,
   ErrorID => Pwr2 ErrID
);
// MC_Home for axis 1
HM1(
   Axis
                     := MC_Axis000,
   Execute
                     := Hm1_Ex,
                     => Hm1_D,
   Done
                     => Hm1_Bsy,
   Busy
   CommandAborted => Hm1_Ca,
                     => Hm1_Err,
   Error
                     => Hm1_ErrID
   ErrorID
);
// MC_Home for axis 2
HM2(
   Axis
                     := MC_Axis001,
   Execute
                     := Hm2_Ex,
   Done
                     => Hm2_D,
                     => Hm2_Bsy,
   Busy
   CommandAborted => Hm2_Ca,
                     => Hm2_Err,
   Error
                     => Hm2_ErrID
   ErrorID
);
//MC_MoveVelocity
VEL(
                     := MC_Axis000,
   Axis
   Execute
                     := Vel_Ex,
   Velocity
                     := Vel_Vel,
   Acceleration
                     := Vel_Acc,
   Deceleration
                     := Vel_Dec,
   Direction
                     := Vel_Dir,
   InVelocity
                     => Vel InVel,
                     => Vel_Bsy,
   Busy
                     => Vel_Act,
   Active
   CommandAborted => Vel_Ca,
   Error
                     => Vel_Err,
   ErrorID
                     => Vel_ErrID
);
//MC_CamIn
CAMIN(
   Master
                         := MC_Axis000,
   Slave
                         := MC_Axis001,
                         := CamProfile0,
   CamTable
   Execute
                         := Camin_Ex,
   Periodic
                         := Camin_EM,
```

```
StartMode
                         := Camin_StMode,
   StartPosition
                         := Camin_StPos,
   MasterStartDistance
                         := Camin_MStDis,
   MasterScaling
                         := Camin_MSc,
   SlaveScaling
                         := Camin_SSc,
   MasterOffset
                         := Camin_MO,
   SlaveOffset
                         := Camin_SO,
   ReferenceType
                         := Camin_RT,
                         := Camin_Dir,
   Direction
                         := Camin\_CT,
   CamTransition
   BufferMode
                         := Camin_BM,
   InCam
                         => Camin_InCam0,
   InSync
                         => Camin_InSync,
   EndOfProfile
                         => Camin_EOP,
   Index
                         => Camin Index,
   Busy
                         => Camin_Bsy,
   Active
                         => Camin_Act,
   CommandAborted
                         => Camin Ca,
                         => Camin_Err,
   Error
   ErrorID
                         => Camin_ErrID
//MC_CamOut
CAMOUT(
   Slave
                      := MC_Axis001,
   Execute
                      := Camout_Ex,
                      := Camout Dec.
   Deceleration
                      => Camout D,
   Done
   Busy
                      => Camout_Bsy,
   CommandAborted
                     => Camout_Ca,
   Error
                      => Camout Err,
   ErrorID
                      => Camout_ErrID
);
```

# **Sample Programming 2**

This sample programming shows cam operation for a liquid filler.



## **Additional Information**

You can specify only the initial values for input variables that are reserved. Parameters are not specified in this sample.

# **Parameter Settings**

The minimum settings required for this sample programming are given below.

## Setting Axis Parameters

## **Axis Types**

Axis	Axis Type
Axis 1	Servo axis (master axis)
Axis 2	Servo axis (slave axis)
Axis 3	Servo axis (slave axis)
Axis 4	Servo axis (slave axis)
Axis 5	Servo axis (slave axis)

#### **Count Modes**

Axis	Count Mode
Axis 1	Rotary Mode
Axis 2	Rotary Mode
Axis 3	Rotary Mode
Axis 4	Rotary Mode
Axis 5	Rotary Mode


## **Ring Counters**

Axis	Modulo maxi- mum position	Modulo mini- mum position
Axis 1	360	0
Axis 2	360	0
Axis 3	360	0
Axis 4	360	0
Axis 5	360	0


## **Units of Display**

Axis	Unit of Display
Axis 1	degree
Axis 2	degree
Axis 3	degree
Axis 4	degree
Axis 5	degree

# Operation Example



## Operation Pattern



# **1** Start Cam Operation

The slave axes, axes 2 to 5, perform cam operation in synchronization with the master axis, axis 1. Each axis shifts its phase by  $50^{\circ}$  and starts cam operation.

# **2** Periodic Operation


Each axis periodically executes the specified cam operation.

# Ladder Diagram

#### Main Variables

Name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		Axis Variable for the master axis, axis 1.
MC_Axis001	_sAXIS_REF		Axis Variable for the slave axis, axis 2.
MC_Axis002	_sAXIS_REF		Axis Variable for the slave axis, axis 3.
MC_Axis003	_sAXIS_REF		Axis Variable for the slave axis, axis 4.
MC_Axis004	_sAXIS_REF		Axis Variable for the slave axis, axis 5.
StartPg	BOOL	FALSE	The Servo is turned ON if this variable is TRUE and EtherCAT process data communications are established.
Vel_InVel	BOOL	FALSE	This variable is assigned to the <i>InVelocity</i> output variable from the VEL instance of the MC_MoveVelocity instruction. It is TRUE when the target velocity is reached.
CamProfile0	ARRAY[0360] OF _sMC_CAM_REF		This is the cam data variable. This variable is assigned to the <i>CamTable</i> input variables from the CAMIN1 to CAMIN4 instances of the MC_CamIn instruction. The array elements ARRAY[0N] are set with the Cam Editor.


## Timing Chart




- \*1 The timing is the same for the following: Camin1\_InCam, Camin2\_InCam, Camin3\_InCam, and Camin4\_InCam.
- \*2 The timing is the same for the following: Camin1\_InSync, Camin2\_InSync, Camin3\_InSync, and Camin4\_InSync. In this sample, MasterStartDistance is 0, so InSync changes to TRUE from when the master axis is 0°.
- \*3 The timing is the same for the following: Camin1\_Bsy, Camin2\_Bsy, Camin3\_Bsy, and Camin4\_Bsy.
- \*4 The timing is the same for the following: Camin1\_Act, Camin2\_Act, Camin3\_Act, and Camin4\_Act.


## Sample Programming

If StartPg is TRUE, EtherCAT communications for the axes are checked to see if process data communications are normal.




If process data communications are active, the Servo is turned ON for the axes.







If there is a minor fault level error for a composition axis, the error handler for the device (FaultHandler) is executed. Design FaultHandler separately.




If the Servo is ON for axis 1 to axis 5 and the Home instruction is executed for each axis if home is not defined.







The MC\_MoveVelocity (Velocity Control) instruction is executed after homing is completed for axis 1.




The MC\_CamIn (Start Cam Operation) instruction is executed for axis 2 (slave axis) if *Vel\_InVel* is TRUE for the MC\_MoveVelocity (Velocity Control) instruction and homing is completed for axis 2.




The MC\_CamIn (Start Cam Operation) instruction is executed for axis 3 (slave axis) if *Vel\_InVel* is TRUE for the MC\_MoveVelocity (Velocity Control) instruction and homing is completed for axis 3.



The MC\_CamIn (Start Cam Operation) instruction is executed for axis 4 (slave axis) if *Vel\_InVel* is TRUE for the MC\_MoveVelocity (Velocity Control) instruction and homing is completed for axis 4.






The MC\_CamIn (Start Cam Operation) instruction is executed for axis 5 (slave axis) if *Vel\_InVel* is TRUE for the MC\_MoveVelocity (Velocity Control) instruction and homing is completed for axis 5.

# **Structured Text (ST)**

#### Main Variables

Name	Data type	Default	Comment	
MC_Axis000	_sAXIS_REF		Axis Variable for the master axis, axis 1.	
MC_Axis001	_sAXIS_REF		Axis Variable for the slave axis, axis 2.	
MC_Axis002	_sAXIS_REF		Axis Variable for the slave axis, axis 3.	
MC_Axis003	_sAXIS_REF		Axis Variable for the slave axis, axis 4.	
MC_Axis004	_sAXIS_REF		Axis Variable for the slave axis, axis 5.	
StartPg	BOOL	FALSE	The Servo is turned ON if this variable is TRUE and EtherCAT process data communications are established.	
Vel_InVel	BOOL	FALSE	This variable is assigned to the <i>InVelocity</i> output variable from the VEL instance of the MC_MoveVelocity instruction. It is TRUE when the target velocity is reached.	
CamProfile0	ARRAY[0360] OF _sMC_CAM_REF		This is the cam data variable. This variable is assigned to the <i>CamTable</i> input variables from the CAMIN1 to CAMIN4 instances of the MC_CamIn instruction. The array elements ARRAY[0N] are set with the Cam Editor.	
Camin1_Ex	BOOL	FALSE	The CAMIN1 to CAMIN4 instances of MC_CamIn are	
Camin2_Ex	BOOL	FALSE	executed when this variable changes to TRUE.	
Camin3_Ex	BOOL	FALSE		
Camin4_Ex	BOOL	FALSE		
InitFlag	BOOL	FALSE	This variable indicates if it is necessary to set the input parameters. Input parameters are set when this variable is FALSE. When setting the input parameters is completed, this variable changes to TRUE.	

## Timing Chart



- \*1 The timing is the same for the following: Camin1\_InCam, Camin2\_InCam, Camin3\_InCam, and Camin4\_InCam.
- \*2 The timing is the same for the following: Camin1\_InSync, Camin2\_InSync, Camin3\_InSync, and Camin4\_InSync. In this sample, MasterStartDistance is 0, so InSync changes to TRUE from when the master axis is 0°.
- \*3 The timing is the same for the following: Camin1\_Bsy, Camin2\_Bsy, Camin3\_Bsy, and Camin4\_Bsy.
- \*4 The timing is the same for the following: Camin1\_Act, Camin2\_Act, Camin3\_Act, and Camin4\_Act.

#### Sample Programming

// Processing when input parameters are not set IF InitFlag=FALSE THEN

//MC\_MoveVelocity Input Parameter
Vel\_Vel := LREAL#1000.0;
Vel\_Acc := LREAL#0.0;
Vel\_Dec := LREAL#0.0;
Vel\_Dir := \_eMC\_DIRECTION#\_mcPositiveDirection;

//MC\_CamIn Input Parameter

Camin1\_Em := TRUE;

Camin1\_Sm := \_eMC\_START\_MODE#\_mcAbsolutePosition;

 $\begin{tabular}{llll} Camin1\_Sp & := LREAL\#0.0; \\ Camin1\_Msd & := LREAL\#0.0; \\ Camin1\_Ms & := LREAL\#1.0; \\ \end{tabular}$ 

```
Camin1_Ss
                := LREAL#1.0;
  Camin1 Mo
              := LREAL#30.0;
  Camin1_So
               := LREAL#0.0;
               := _eMC_REFERENCE_TYPE#_mcCommand;
  Camin1_Rt
  Camin1_Dir := _eMC_DIRECTION#_mcNoDirection;
  Camin2_Em := TRUE;
  Camin2_Sm := _eMC_START_MODE#_mcAbsolutePosition;
  Camin2_Sp
                := LREAL#0.0;
  Camin2_Msd := LREAL#0.0;
  Camin2_Ms := LREAL#1.0;
  Camin2_Ss
               := LREAL#1.0;
  Camin2_Mo := LREAL#80.0;
  Camin2\_So \qquad := LREAL\#0.0;
  Camin2_Rt
               := _eMC_REFERENCE_TYPE#_mcCommand;
  Camin2 Dir
                := _eMC_DIRECTION#_mcNoDirection;
  Camin3_Em
                 := TRUE;
  Camin3 Sm
                 := eMC START MODE# mcAbsolutePosition;
  Camin3_Sp
                 := LREAL#0.0;
  Camin3_Msd := LREAL#0.0;
  Camin3_Ms
                 := LREAL#1.0;
  Camin3_Ss
                 := LREAL#1.0;
  Camin3_Mo
                 := LREAL#130.0;
  Camin3 So
                := LREAL#0.0;
                := _eMC_REFERENCE_TYPE#_mcCommand;
  Camin3 Rt
  Camin3 Dir
               := _eMC_DIRECTION#_mcNoDirection;
  Camin4 Em
  Camin4 Sm
              := _eMC_START_MODE#_mcAbsolutePosition;
  Camin4 Sp
                := LREAL#0.0;
  Camin4_Msd := LREAL#0.0;
  Camin4_Ms := LREAL#1.0;
  Camin4 Ss := LREAL#1.0;
  Camin4\_Mo := LREAL#180.0;
  Camin4_So := LREAL#0.0;
  Camin4_Rt
               := _eMC_REFERENCE_TYPE#_mcCommand;
  Camin4_Dir
               := _eMC_DIRECTION#_mcNoDirection;
  // Change InitFlag to TRUE after setting the input parameters.
  InitFlag := TRUE;
END_IF;
// If StartPg is TRUE and EtherCAT communications are normal, the Servo for axis 1 is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
  Pwr1_En:=TRUE;
ELSE
  Pwr1_En:=FALSE;
END_IF;
// If StartPq is TRUE and EtherCAT communications are normal, the Servo for axis 2 is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis001.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis001.Cfg.NodeAddress]=FALSE) THEN
  Pwr2_En:=TRUE;
FLSE
  Pwr2_En:=FALSE;
END_IF;
// If StartPq is TRUE and EtherCAT communications are normal, the Servo for axis 3 is turned ON.
```

```
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis002.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis002.Cfg.NodeAddress]=FALSE) THEN
   Pwr3_En:=TRUE;
   Pwr3_En:=FALSE;
END_IF;
// If StartPq is TRUE and EtherCAT communications are normal, the Servo for axis 4 is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis003.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis003.Cfg.NodeAddress]=FALSE) THEN
   Pwr4 En:=TRUE;
ELSE
   Pwr4_En:=FALSE;
END IF:
// If StartPg is TRUE and EtherCAT communications are normal, the Servo for axis 5 is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis004.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis004.Cfg.NodeAddress]=FALSE) THEN
   Pwr5_En:=TRUE;
ELSE
   Pwr5 En:=FALSE;
END_IF;
// If a minor fault level error occurs for axis 1 to axis 5, the error handler for the device (FaultHandler) is
executed.
// Implement FaultHandler separately.
IF (MC_Axis000.MFaultLvl.Active=TRUE)
OR (MC_Axis001.MFaultLvl.Active=TRUE)
OR (MC_Axis002.MFaultLvl.Active=TRUE)
OR (MC_Axis003.MFaultLvl.Active=TRUE)
OR (MC_Axis004.MFaultLvl.Active=TRUE) THEN
   FaultHandler();
END IF;
// If the Servo is ON for axis 1 and home is not defined, the Home instruction is executed for axis 1.
IF (Pwr1 Status=TRUE) AND (MC Axis000.Details.Homed=FALSE) THEN
   Hm1_Ex:=TRUE;
END_IF;
// If the Servo is ON for axis 2 and home is not defined, the Home instruction is executed for axis 2.
IF (Pwr2_Status=TRUE) AND (MC_Axis001.Details.Homed=FALSE) THEN
   Hm2_Ex:=TRUE;
END_IF;
// If the Servo is ON for axis 3 and home is not defined, the Home instruction is executed for axis 3.
IF (Pwr3_Status=TRUE) AND (MC_Axis002.Details.Homed=FALSE) THEN
   Hm3_Ex:=TRUE;
END IF:
// If the Servo is ON for axis 4 and home is not defined, the Home instruction is executed for axis 4.
IF (Pwr4_Status=TRUE) AND (MC_Axis003.Details.Homed=FALSE) THEN
   Hm4_Ex:=TRUE;
END_IF;
// If the Servo is ON for axis 5 and home is not defined, the Home instruction is executed for axis 5.
IF (Pwr5_Status=TRUE) AND (MC_Axis004.Details.Homed=FALSE) THEN
   Hm5_Ex:=TRUE;
END_IF;
```

```
// After homing is completed for axis 1, MC_MoveVelocity is executed.
IF Hm1_D=TRUE THEN
   Vel_Ex:=TRUE;
END_IF;
// If home is defined for axis 2 and Vel_InVel of MC_MoveVelocity is TRUE,
// the MC_CamIn instruction for axis 2 (slave axis) is executed.
IF (Vel_InVel=TRUE) AND (MC_Axis001.Details.Homed=TRUE) THEN
   Camin1_Ex := TRUE;
END_IF;
// If home is defined for axis 3 and Vel_InVel of MC_MoveVelocity is TRUE,
// the MC_CamIn instruction for axis 3 (slave axis) is executed.
IF (Vel_InVel=TRUE) AND (MC_Axis002.Details.Homed=TRUE) THEN
   Camin2_Ex := TRUE;
END_IF;
// If home is defined for axis 4 and Vel_InVel of MC_MoveVelocity is TRUE,
// the MC_CamIn instruction for axis 4 (slave axis) is executed.
IF (Vel_InVel=TRUE) AND (MC_Axis003.Details.Homed=TRUE) THEN
   Camin3_Ex := TRUE;
END_IF;
// If home is defined for axis 5 and Vel_InVel of MC_MoveVelocity is TRUE,
// the MC CamIn instruction for axis 5 (slave axis) is executed.
IF (Vel_InVel=TRUE) AND (MC_Axis004.Details.Homed=TRUE) THEN
   Camin4 Ex := TRUE:
END IF;
// MC_Power for axis 1
PWR1(
   Axis
            := MC_Axis000,
   Enable
            := Pwr1_En,
   Status
            => Pwr1_Status,
   Busy
            => Pwr1_Bsy,
            => Pwr1_Err,
   Error
   ErrorID => Pwr1_ErrID
);
// MC Power for axis 2
PWR2(
   Axis
            := MC_Axis001,
   Enable
            := Pwr2_En,
             => Pwr2_Status,
   Status
            => Pwr2_Bsy,
   Busy
   Error
            => Pwr2_Err,
   ErrorID => Pwr2_ErrID
);
// MC_Power for axis 3
PWR3(
            := MC Axis002.
   Axis
            := Pwr3 En,
   Enable
   Status
            => Pwr3_Status,
   Busy
            => Pwr3_Bsy,
   Error
            => Pwr3_Err,
   ErrorID => Pwr3_ErrID
);
// MC_Power for axis 4
PWR4(
   Axis
            := MC_Axis003,
   Enable
            := Pwr4_En,
```

Status

=> Pwr4\_Status,

```
=> Pwr4_Bsy,
   Busy
            => Pwr4_Err,
   Error
   ErrorID
            => Pwr4_ErrID
);
// MC_Power for axis 5
PWR5(
            := MC_Axis004,
   Axis
   Enable
            := Pwr5_En,
            => Pwr5_Status,
   Status
            => Pwr5_Bsy,
   Busy
            => Pwr5_Err,
   Error
   ErrorID
           => Pwr5_ErrID
);
// MC_Home for axis 1
HM1(
   Axis
                     := MC Axis000.
   Execute
                     := Hm1_Ex,
                     => Hm1_D,
   Done
                     => Hm1_Bsy,
   Busy
                    => Hm1_Ca,
   CommandAborted
                     => Hm1_Err,
   Error
                     => Hm1_ErrID
   ErrorID
);
// MC_Home for axis 2
HM2(
   Axis
                     := MC Axis001,
   Execute
                     := Hm2 Ex,
   Done
                     => Hm2_D,
   Busy
                     => Hm2_Bsy,
   CommandAborted => Hm2_Ca,
   Error
                     => Hm2_Err,
                     => Hm2_ErrID
   ErrorID
);
// MC_Home for axis 3
HM3(
                     := MC_Axis002,
   Axis
   Execute
                     := Hm3_Ex,
   Done
                     => Hm3 D,
   Busy
                     => Hm3_Bsy,
                     => Hm3_Ca,
   CommandAborted
   Error
                     => Hm3_Err,
                     => Hm3_ErrID
   ErrorID
);
// MC_Home for axis 4
HM4(
                     := MC Axis003,
   Axis
                     := Hm4_Ex,
   Execute
   Done
                     => Hm4 D.
                     => Hm4_Bsy,
   Busy
   CommandAborted
                     => Hm4_Ca,
   Error
                     => Hm4_Err,
   ErrorID
                     => Hm4_ErrID
);
// MC_Home for axis 5
HM5(
   Axis
                     := MC_Axis004,
   Execute
                     := Hm5_Ex,
                     => Hm5_D,
   Done
                     => Hm5_Bsy,
   Busy
```

```
CommandAborted => Hm5_Ca,
   Error
                      => Hm5 Err,
   ErrorID
                      => Hm5_ErrID
);
//MC_MoveVelocity
VEL(
                      := MC_Axis000,
   Axis
   Execute
                      := Vel_Ex,
   Velocity
                      := Vel_Vel,
   Acceleration
                      := Vel_Acc,
   Deceleration
                      := Vel_Dec,
   Direction
                      := Vel_Dir,
   InVelocity
                      => Vel_InVel,
   Busy
                      => Vel Bsv.
   Active
                      => Vel_Act,
   CommandAborted
                     => Vel_Ca,
   Error
                      => Vel Err,
   ErrorID
                      => Vel_ErrID
);
//MC_CamIn
CAMIN1(
   Master
                         := MC_Axis000,
                         := MC Axis001,
   Slave
                         := CamProfile0.
   CamTable
                         := Camin1 Ex.
   Execute
   Periodic
                         := Camin1 Em,
   StartMode
                         := Camin1 Sm,
   StartPosition
                         := Camin1_Sp,
   MasterStartDistance
                         := Camin1_Msd,
   MasterScaling
                         := Camin1_Ms,
   SlaveScaling
                         := Camin1_Ss,
   MasterOffset
                         := Camin1_Mo,
   SlaveOffset
                         := Camin1_So,
                         := Camin1_Rt,
   ReferenceType
   Direction
                         := Camin1_Dir,
   InCam
                         => Camin1_InCam,
   InSvnc
                         => Camin1_InSync,
                         => Camin1_Eop,
   EndOfProfile
   Index
                         => Camin1 Index,
   Busy
                         => Camin1_Bsy,
   Active
                         => Camin1_Act,
   CommandAborted
                         => Camin1_Ca,
   Error
                         => Camin1_Err,
   ErrorID
                         => Camin1_ErrID
);
CAMIN2(
   Master
                         := MC Axis000,
   Slave
                         := MC_Axis002,
   CamTable
                         := CamProfile0.
   Execute
                         := Camin2 Ex,
   Periodic
                         := Camin2_Em,
   StartMode
                         := Camin2_Sm,
   StartPosition
                         := Camin2_Sp,
   MasterStartDistance
                         := Camin2_Msd,
   MasterScaling
                         := Camin2_Ms,
   SlaveScaling
                         := Camin2_Ss,
                         := Camin2_Mo,
   MasterOffset
                         := Camin2_So,
   SlaveOffset
   ReferenceType
                         := Camin2_Rt,
   Direction
                         := Camin2_Dir,
   InCam
                         => Camin2_InCam,
```

```
InSync
                          => Camin2_InSync,
   EndOfProfile
                          => Camin2_Eop,
                          => Camin2_Index,
   Index
                          => Camin2_Bsy,
   Busy
   Active
                          => Camin2_Act,
   CommandAborted
                          => Camin2_Ca,
   Error
                          => Camin2_Err,
   ErrorID
                          => Camin2_ErrID
);
CAMIN3(
                          := MC_Axis000,
   Master
   Slave
                          := MC_Axis003,
   CamTable
                          := CamProfile0,
   Execute
                          := Camin3 Ex,
   Periodic
                          := Camin3_Em,
   StartMode
                          := Camin3_Sm,
   StartPosition
                          := Camin3 Sp.
   MasterStartDistance
                          := Camin3_Msd,
   MasterScaling
                          := Camin3_Ms,
                          := Camin3_Ss,
   SlaveScaling
   MasterOffset
                          := Camin3_Mo,
   SlaveOffset
                          := Camin3_So,
   ReferenceType
                          := Camin3_Rt,
                          := Camin3_Dir,
   Direction
   InCam
                          => Camin3 InCam,
   InSync
                          => Camin3 InSync,
   EndOfProfile
                          => Camin3 Eop.
                          => Camin3 Index,
   Index
                          => Camin3 Bsy.
   Busy
   Active
                          => Camin3_Act,
   CommandAborted
                          => Camin3_Ca,
   Error
                          => Camin3_Err,
   ErrorID
                          => Camin3_ErrID
);
CAMIN4(
   Master
                          := MC_Axis000,
                          := MC_Axis004,
   Slave
   CamTable
                          := CamProfile0.
   Execute
                          := Camin4 Ex.
   Periodic
                          := Camin4 Em,
   StartMode
                          := Camin4_Sm,
   StartPosition
                          := Camin4_Sp,
   MasterStartDistance
                          := Camin4_Msd,
                          := Camin4_Ms,
   MasterScaling
   SlaveScaling
                          := Camin4_Ss,
                          := Camin4_Mo,
   MasterOffset
   SlaveOffset
                          := Camin4_So,
   ReferenceType
                          := Camin4_Rt,
   Direction
                          := Camin4 Dir,
                          => Camin4 InCam.
   InCam
                          => Camin4_InSync,
   InSvnc
   EndOfProfile
                          => Camin4 Eop.
   Index
                          => Camin4_Index,
   Busy
                          => Camin4_Bsy,
   Active
                          => Camin4_Act,
   CommandAborted
                          => Camin4_Ca,
   Error
                          => Camin4_Err,
   ErrorID
                          => Camin4_ErrID
);
```

# MC\_CamOut

Cam operation is ended for the axis specified with the input parameter.

Instruction	Name	FB/FUN	Graphic expression	ST expression
MC_CamOut	End Cam Operation	FB	MC_CamOut_instance  MC_CamOut Slave Slave Execute Done Deceleration Busy Jerk CommandAborted OutMode Error ErrorID	MC_CamOut_instance ( Slave :=parameter, Execute :=parameter, Deceleration :=parameter, Jerk :=parameter, OutMode :=parameter, Done =>parameter, Busy =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorlD =>parameter );

## **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Execute</i> changes to TRUE.
Deceleration	Deceleration Rate	LREAL	Non-negative number	0	Specify the deceleration rate. The unit is command units/s <sup>2</sup> .* <sup>1</sup>
Jerk (Reserved)	Jerk	LREAL	0	0	(Reserved)
OutMode (Reserved)	Sync End Mode Selec- tion	_eMC_ OUT_ MODE	0: _mcStop	0*2	(Reserved)

<sup>\*1</sup> Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

<sup>\*2</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

#### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When the velocity reaches 0.	When Execute is TRUE and changes to FALSE.  After any poried when Execute is FALSE.
		After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
CommandAborted	<ul> <li>When this instruction is aborted because another motion control instruction was executed with the Buffer Mode set to <i>Aborting</i>.</li> <li>When this instruction is canceled due to an error.</li> <li>When this instruction is executed while</li> </ul>	<ul> <li>When <i>Execute</i> is TRUE and changes to FALSE.</li> <li>After one period when <i>Execute</i> is FALSE.</li> </ul>
	there is an error.	
	<ul> <li>When you start this instruction during MC_Stop instruction execution.</li> </ul>	
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# In-Out Variables

Name	Meaning	Data type	Valid range	Description
Slave	Slave Axis	_sAXIS_REF		Specify the slave axis.*

<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are MC\_Axis\*\*\*.)

#### **Function**


- The MC\_CamOut instruction disables cam operation of the slave axis.
- When *Execute* changes to TRUE, the axis starts decelerating towards 0 velocity at the deceleration rate specified with *Deceleration* (Deceleration Rate).
- When the command velocity reaches 0, the instruction is completed.
- If you execute this instruction on an axis that is not in cam operation, an error will occur.



#### **Precautions for Correct Use**

- Cam data variables are global variables. You can therefore access or change the values of cam data variables from more than one task. If you change the values of cam data variables from more than one task, program the changes so that there is no competition in writing the value from more than one task.
- If you use exclusive control of global variables between tasks for a cam data variable, do not
  use the cam data variable for motion control instructions in a task that does not control the
  variable. An Incorrect Cam Table Specification error (error code: 5439 hex) will occur.


# **Timing Charts**



# **Aborting the Instruction**

If an axis error occurs for the slave axis during execution of this instruction, *CommandAborted* changes to TRUE and *Busy* (Executing) changes to FALSE. The axis will decelerate at the rate specified with *Deceleration* (Deceleration Rate) for this instruction.

Refer to A-1 Error Codes for information on axis errors.



#### **Re-execution of Motion Instructions**

This instruction cannot be re-executed.

A Motion Control Instruction Re-execution Disabled error (error code: 543B hex) occurs if re-execution is attempted.

## **Multi-execution of Motion Instructions**

#### Execution during Execution of Other Instructions

If you execute this instruction while the MC\_CamIn (Start Cam Operation) instruction is in execution, *CommandAborted* for the MC\_CamIn instruction will change to TRUE and *Busy* for this instruction will change to TRUE. If this instruction is executed when the MC\_CamIn (Start Cam Operation) instruction is not in execution, and an error will occur.


#### Execution of Other Instructions during Instruction Execution

To use multi-execution of motion instructions for this instruction, specify the slave axis. If you execute another instruction during execution of this instruction, you can specify either aborting or buffering.

## **Errors**

If an error occurs during instruction execution, *Error* will change to TRUE. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).

## • Timing Chart When Error Occurs



#### Error Codes

Refer to A-1 Error Codes for instruction errors.

# MC\_GearIn

Specifies the gear ratio between the master axis and the slave axis and starts gear operation.

Instruction	Name	FB/FUN	Graphic expression	ST expression
MC_GearIn	Start Gear Operation	FB	MC_GearIn_instance  MC_GearIn  Master — Master — Slave — Slave — Slave — InGear — RatioNumerator — RatioDenominator — Active — ReferenceType — CommandAborted — Acceleration — Error — Deceleration — Error — Jerk — BufferMode	MC_GearIn_instance ( Master :=parameter, Slave :=parameter, Execute :=parameter, RatioNumerator :=parameter, RatioDenominator :=parameter, ReferenceType :=parameter, Acceleration :=parameter, Deceleration :=parameter, Jerk :=parameter, BufferMode :=parameter, InGear =>parameter, Busy =>parameter, Active =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorID =>parameter);

# **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when Execute changes to TRUE.
Ratio Numerator	Gear Ratio Numerator	UNIT	Positive number	10,000	Specify the numerator of the electronic gear ratio between the master and slave axes.
Ratio Denominator	Gear Ratio Denominator	UNIT	Positive number	10,000	Specify the denominator of the electronic gear ratio between the master and slave axes.
Reference Type*1	Position Type Selection	_eMC_ REFERENCE_ TYPE	0: _mcCommand 1: _mcFeedback 2: _mcLatestCommand	0*2	Specify the position type.  0: Command position (value calculated in the previous primary period)  1: Actual position (value obtained in the same primary period)  2: Command position (value calculated in the same primary period)
Acceleration	Acceleration Rate	LREAL	Non-negative number	0	Specify the acceleration rate. The unit is command units/s <sup>2</sup> .* <sup>3</sup>

Name	Meaning	Data type	Valid range	Default	Description
Deceleration	Deceleration Rate	LREAL	Non-negative number	0	Specify the deceleration rate. The unit is command units/s <sup>2</sup> .* <sup>3</sup>
Jerk (Reserved)	Jerk	LREAL	0	0	(Reserved)
BufferMode	Buffer Mode Selection	_eMC_ BUFFER_ MODE	0: _mcAborting 1: _mcBuffered	0*2	Specify the operation when executing more than one motion instruction.  0: Aborting 1: Buffered

<sup>\*1</sup> When you use \_mcLatestCommand, the axis number set for the Master (Master Axis) in the system-defined variable for motion control must be lower than the axis number set for the Slave (Slave Axis) in the system-defined variable for motion control.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
InGear	Gear Ratio Achieved	BOOL	TRUE or FALSE	TRUE when the slave axis reaches the target velocity.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE	TRUE when the axis is being controlled.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

# Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
InGear	When the following relationship is established.	When Error changes to TRUE.
	Accelerating: Velocity of slave axis ≥ Velocity of master axis × Gear ratio	When CommandAborted changes to TRUE.
	Decelerating: Velocity of slave axis ≤ Velocity of master axis × Gear ratio	
Busy	When Execute changes to TRUE.	When Error changes to TRUE.
		When CommandAborted changes to TRUE.
Active	When the instruction is started.	When Error changes to TRUE.
		When CommandAborted changes to TRUE.

<sup>\*2</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

<sup>\*3</sup> Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.

Name	Timing for changing to TRUE	Timing for changing to FALSE
CommandAborted	<ul> <li>When this instruction is aborted because another motion control instruction was executed with the Buffer Mode set to <i>Aborting</i>.</li> <li>When this instruction is canceled due to an error.</li> <li>When this instruction is executed while there is an error.</li> <li>When you start this instruction during MC_Stop instruction execution.</li> <li>When the MC_GearOut instruction is executed.</li> </ul>	<ul> <li>When Execute is TRUE and changes to FALSE.</li> <li>After one period when Execute is FALSE.</li> </ul>
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# **In-Out Variables**

Name	Meaning	Data type	Valid range	Description	
Master	Master Axis	_sAXIS_REF		Specify the master axis.*	
Slave	Slave Axis	_sAXIS_REF		Specify the slave axis.*	

<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are *MC\_Axis*\*\*\*.)




### **Precautions for Correct Use**


If you specify the same axis for the master axis and slave axis, a Master and Slave Defined as Same Axis minor fault (error code 5436 hex) will occur.

### **Function**

- The MC\_GearIn instruction performs gear operation for the slave axis specified with Slave. The following parameters are also specified: RatioNumerator (Gear Ratio Numerator), RatioDenominator (Gear Ratio Denominator), ReferenceType (Position Type), Acceleration (Acceleration Rate), and Deceleration (Deceleration Rate).
- For the master axis, you can specify the command position, actual position, or most recent command position.



- After operation starts, the slave axis uses the velocity of the master axis multiplied by the gear ratio for its target velocity, and accelerates/decelerates accordingly.
- The catching phase exists until the target velocity is reached. The InGear phase exists after that.



• Electronic gear operation starts when Execute changes to TRUE.



### **Precautions for Safe Use**

Do not execute the MC\_SetPosition instruction for the *Master* (Master Axis) if you use this instruction. If the MC\_SetPosition instruction is executed for the *Master* (Master Axis), the *Slave* (Slave Axis) may follow the master axis guickly.

If you want to use the MC\_SetPosition instruction for the *Master* (Master Axis), disable the relationship between the *Master* (Master Axis) and *Slave* (Slave Axis) before executing the instruction.

Refer to *Precautions for Master and Auxiliary Axes in Synchronized Control* on page 1-7 for precautions on the master axis.

### ReferenceType (Position Type Selection)

You can select one of the following position types.

\_mcCommand: Command position (value calculated in the previous primary period)
 The master axis command position that was calculated in the previous primary period is used for the current period.

The command value that was calculated for the master axis in the last primary period is used to calculate the command position of the slave axis in the current period.

- \_mcFeedback: Value obtained in the same primary period
   The actual position of the master axis that was obtained in the same primary period is used.
- \_mcLatestCommand: Command position (value calculated in the same primary period)
  The command position of the master axis that was calculated in the same primary period is used.
  This enables the use of information that is more recent than for \_mcCommand. However, the axis number of the master axis must be set lower than the axis number of the slave axis.
  If the axis number of the slave axis is lower than the axis number of the master axis, Error will change to TRUE. A Master/Slave Axis Numbers Not in Ascending Order error (error code: 5438 hex) will be output to ErrorID.



#### **Additional Information**

The command position that is calculated in the same primary period enables greater precision in synchronization than the command position that was calculated in the previous primary period. However, the axis number set for the *Master* (Master Axis) in the system-defined variable for motion control must be lower than the axis number set for the *Slave* (Slave Axis) in the system-defined variable for motion control.

### Relationship between Axis Types and Position Types


The relationship between the axis types that you can monitor and position types that is monitored is shown below.

Axis Type	ReferenceType					
Axis Type	_mcCommand or _mcLatestCommand	_mcFeedback				
Servo axis	OK	OK				
Encoder axis	No*	OK				
Virtual servo axis	OK	OK				
Virtual encoder axis	No*	OK				


<sup>\*</sup> A Position Type Selection Out of Range error (error code: 5430 hex) occurs when the instruction is executed.

# **Timing Charts**


- Busy (Executing) changes to TRUE at the same time as Execute changes to TRUE. Active (Controlling) changes to TRUE in the next period.
- InGear (Gear Ratio Reached) changes to TRUE when the target velocity is reached.
- If another instruction aborts this instruction, *CommandAborted* changes to TRUE and *Busy* (Executing), *Active* (Controlling), and *InGear* (Gear Ratio Reached) change to FALSE.
- Use the MC\_GearOut (End Gear Operation) or MC\_Stop instruction to stop electronic gear operation before it is completed.



You can specify the *Acceleration* (Acceleration Rate) and *Deceleration* (Deceleration Rate) as input variables.




When the *Acceleration* (Acceleration Rate) or *Deceleration* (Deceleration Rate) is 0 and you execute this instruction, the axis will reach the target velocity without accelerating or decelerating.




## **Re-execution of Motion Instructions**

You can change the operation of the instruction if you change an input variable during positioning and change *Execute* to TRUE again. Input variables *RatioNumerator* (Gear Ratio Numerator), *RatioDenominator* (Gear Ratio Denominator), *Acceleration* (Acceleration Rate), and *Deceleration* (Deceleration Rate) can be changed by re-executing the motion control instruction. For details on re-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

The following timing chart shows when the instruction is re-executed during the Catching phase to change the *Acceleration* (Acceleration Rate).



The following timing chart shows when the instruction is re-executed during the InGear phase to change the *RatioNumerator* (Gear Ratio Numerator) and *RatioDenominator* (Gear Ratio Denominator). The motion is the same as when *Acceleration* (Acceleration Rate) and *Deceleration* (Deceleration Rate) are both set to 0.



### **Multi-execution of Motion Instructions**

For details on re-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

### Execution during Execution of Other Instructions

You can switch to this instruction or buffer this instruction if you execute it during execution of another instruction. You can buffer one instruction per axis.

Specify the operation of this instruction by using *BufferMode* (Buffer Mode Selection) for multi-execution of instructions.

Buffer Mode Selection	Description
Aborting	Aborts the instruction being executed and switches to this instruction. If the direction of axis motion is reversed by switching instructions, the motion will be reversed according to the Operation at Reversing axis parameter.
Buffered	Automatically executes the buffered instruction after the current instruction is completed.


For details on *BufferMode* (Buffer Mode Selection), refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

### • Execution of Other Instructions during Instruction Execution

Another instruction with the Buffer Mode set to *Aborting* can be executed during execution of this instruction. In that case, the gear operation is stopped and the operation of the aborting instruction is started. You cannot specify any Buffer Mode with other than *Aborting*.

# **Errors**

If an error occurs during instruction execution, *Error* will change to TRUE and the axis will stop. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).





### **Additional Information**

- The slave axis is not affected by the error status of the master axis during synchronized control. The error status of the master axis is cleared and the slave axis continues electronic gear operation after the master axis operates normally.
- The master axis is not affected if an error occurs for the slave axis during startup or execution of this instruction.

### Error Codes

Refer to A-1 Error Codes for instruction errors.

# **Sample Programming**

This section shows sample programming for operation proportional to a gear ratio.



### **Additional Information**

You can specify only the initial values for input variables that are reserved. Parameters are not specified in this sample.

# **Parameter Settings**

The minimum settings required for this sample programming are given below.

### Setting Axis Parameters

### **Axis Types**

Axis	Axis Type		
Axis 1	Servo axis (master axis)		
Axis 2	Servo axis (slave axis)		
Axis 3	Servo axis (slave axis)		

### **Count Modes**

Axis	Count Mode
Axis 1	Rotary Mode
Axis 2	Rotary Mode
Axis 3	Rotary Mode


### **Ring Counter**

Axis	Modulo maxi- mum position	Modulo mini- mum position
Axis 1	360	0
Axis 2	360	0
Axis 3	360	0

### **Units of Display**

Axis	Unit of Display
Axis 1	mm
Axis 2	mm
Axis 3	mm

# **Operation Example**



1 Starting the Master Axis

The master axis (axis 1) is an actual servo axis and it is operated with velocity control.

**2** Executing the Slave Axes

When the actual velocity for the master axis reaches the target velocity, gear operation is performed so that the gear ratio of axis 2 (slave axis) is 1:2 and axis 3 (slave axis) is 2:3 against the actual position of the master axis.

**3** Stopping the Slave Axes


When the actual position of the master axis *MC\_Axis000.Act.Pos* exceeds 1000.0, gear operation of axis 2 is ended and axis 2 decelerates to a stop with deceleration rate *DecRate*. Axis 3 continues gear operation.

# Ladder Diagram

### Main Variables


Name	Data type	Default	Comment	
MC_Axis000	_sAXIS_REF		Axis Variable for the master axis, axis 1.	
MC_Axis000.Act.Pos	LREAL		This variable gives the actual current position of axis 1.	
MC_Axis001	_sAXIS_REF		Axis Variable for the slave axis, axis 2.	
MC_Axis002	_sAXIS_REF		Axis Variable for the slave axis, axis 3.	
Pwr1_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.	
Pwr2_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR2 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.	
Pwr3_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR3 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.	
StartPg	BOOL	FALSE	The Servo is turned ON if this variable is TRUE and Ether-CAT process data communications are established.	
Vel_InVel	BOOL	FALSE	This variable is assigned to the <i>InVelocity</i> output variable from the VEL instance of the MC_MoveVelocity instruction. It is TRUE when the target velocity is reached.	
Gearin1_Act	BOOL	FALSE	This variable is assigned to the <i>Active</i> output variable from the GEARIN1 instance of the MC_GearIn instruction. It is TRUE during control operations for GEARIN1.	
Gearout_Ex	BOOL	FALSE	The GEAROUT instance of MC_GearOut is executed when this variable changes to TRUE.	

# Timing Chart




### Sample Programming


If StartPg is TRUE, EtherCAT communications for the axes are checked to see if process data communications are normal.




If process data communications are active, the Servo is turned ON for the axes.




If there is a minor fault level error for a composition axis, the error handler for the device (FaultHandler) is executed. Design FaultHandler separately.



The MC\_MoveVelocity (Velocity Control) instruction is executed after the Servo is turned ON for the master axis (axis 1).



When the actual velocity for the master axis (axis 1) reaches the target velocity, gear operation is performed so that the gear ratio of axis 2 (slave axis) is 1:2 and axis 3 (slave axis) is 2:3.




When the actual position of the master axis is 1000.0 or higher during gear operation of axis 2 (slave axis), Gearout\_Ex changes to TRUE.

Note: The contents of the inline ST are given below.

When *Gearout\_Ex* changes to TRUE, gear operation is stopped for the axis 2 (slave axis). The axis decelerates to a stop.

GEAROUT



### **Contents of Inline ST**


IF (Gearin1\_Act=TRUE) AND (MC\_Axis000.Act.Pos>=LREAL#1000.0) THEN
 Gearout\_Ex := TRUE;
END IF:

# Structured Text (ST)

### Main Variables

Name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		Axis Variable for the master axis, axis 1.
MC_Axis000.Act.Pos	LREAL		This variable gives the actual current position of axis 1.
MC_Axis001	_sAXIS_REF		Axis Variable for the slave axis, axis 2.
MC_Axis002	_sAXIS_REF		Axis Variable for the slave axis, axis 3.
Pwr1_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
Pwr2_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR2 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
Pwr3_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR3 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
StartPg	BOOL	FALSE	The Servo is turned ON if this variable is TRUE and EtherCAT process data communications are established.
Vel_InVel	BOOL	FALSE	This variable is assigned to the <i>InVelocity</i> output variable from the VEL instance of the MC_MoveVelocity instruction. It is TRUE when the target velocity is reached.
Gearin1_Act	BOOL	FALSE	This variable is assigned to the <i>Active</i> output variable from the GEARIN1 instance of the MC_GearIn instruction. It is TRUE during control operations for GEARIN1.
Gearout_Ex	BOOL	FALSE	The GEAROUT instance of MC_GearOut is executed when this variable changes to TRUE.
Vel_Ex	BOOL	FALSE	The VEL instance of MC_MoveVelocity is executed when this variable changes to TRUE.
Gearin1_Ex	BOOL	FALSE	The GEARIN1 instance of MC_GearIn is executed when this variable changes to TRUE.
Gearin2_Ex	BOOL	FALSE	The GEARIN2 instance of MC_GearIn is executed when this variable changes to TRUE.
InitFlag	BOOL	FALSE	This variable indicates if it is necessary to set the input parameters. Input parameters are set when this variable is FALSE. When setting the input parameters is completed, this variable changes to TRUE.

# Timing Chart



### Sample Programming

```
// Processing when input parameters are not set
IF InitFlag = FALSE THEN
  // MC_MoveVelocity parameters
   Vel_Vel := LREAL#2000.0;
  Vel_Acc := LREAL#2000.0;
   Vel_Dec := LREAL#2000.0;
   Vel_Dir := _eMC_DIRECTION#_mcPositiveDirection;
  // MC_GearIn1 parameters
  Gearin1_Rn := UINT#10#1;
  Gearin1_Rd
                 := UINT#10#2;
  Gearin1_Rt := _eMC_REFERENCE_TYPE#_mcFeedback;
  Gearin1 Acc := LREAL#4000.0;
  Gearin1_Dec := LREAL#4000.0;
  // MC_GearIn2 parameters
  Gearin2_Rn := UINT#10#2;
  Gearin2_Rd := UINT#10#3;
  Gearin2_Rt := _eMC_REFERENCE_TYPE#_mcFeedback;
  Gearin2_Acc := LREAL#4000.0;
  Gearin2_Dec := LREAL#4000.0;
  // MC_GearOut parameters
                := LREAL#200.0;
  DecRate
  Gearout_Dec := DecRate;
  // Change InitFlag to TRUE after setting the input parameters.
  InitFlag:=TRUE;
END_IF;
// If StartPg is TRUE and EtherCAT communications are normal, the Servo for axis 1 is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
  Pwr1 En:=TRUE;
  Pwr1_En:=FALSE;
END_IF;
// If StartPg is TRUE and EtherCAT communications are normal, the Servo for axis 2 is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis001.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis001.Cfg.NodeAddress]=FALSE) THEN
  Pwr2_En:=TRUE;
FLSE
  Pwr2_En:=FALSE;
END_IF;
// If StartPg is TRUE and EtherCAT communications are normal, the Servo for axis 3 is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis002.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis002.Cfg.NodeAddress]=FALSE) THEN
  Pwr3_En:=TRUE;
ELSE
  Pwr3_En:=FALSE;
END_IF;
```

```
// If a minor fault level error occurs for axis 1 to axis 3, the error handler for the device (FaultHandler) is
executed.
// Implement FaultHandler separately.
IF (MC_Axis000.MFaultLvI.Active=TRUE) OR (MC_Axis001.MFaultLvI.Active=TRUE) OR
(MC_Axis002.MFaultLvl.Active=TRUE) THEN
   FaultHandler();
END_IF;
// If the Servo is ON for axis 1, the MC_MoveVelocity instruction is executed.
IF Pwr1_Status=TRUE THEN
   Vel_Ex := TRUE;
END_IF;
// If InVelocity of MC_MoveVelocity is TRUE and the Servo for axis 2 is ON, MC_Gearln is executed with axis 1
as the master axis and axis 2 as the slave axis.
IF (Vel_InVel=TRUE) AND (Pwr2_Status=TRUE) THEN
   Gearin1 Ex := TRUE;
END_IF;
// If InVelocity of MC_MoveVelocity is TRUE and the Servo for axis 3 is ON, MC_Gearln is executed with axis 1
as the master axis and axis 3 as the slave axis.
IF (Vel_InVel=TRUE) AND (Pwr3_Status=TRUE) THEN
   Gearin2_Ex := TRUE;
END_IF;
// If the actual position of axis 1 is 1000.0 or higher during gear operation for axis 2,
// the GearOut instruction for axis 2 (slave axis) is executed.
IF (Gearin1 Act=TRUE) AND (MC Axis000.Act.Pos>=LREAL#1000.0) THEN
   Gearout_Ex := TRUE;
END IF:
// MC Power for axis 1
PWR1(
   Axis
             := MC_Axis000,
   Enable
             := Pwr1_En,
   Status
             => Pwr1_Status,
   Busv
             => Pwr1_Bsy,
   Error
             => Pwr1 Err.
             => Pwr1 ErrID
   ErrorID
);
// MC_Power for axis 2
PWR2(
             := MC_Axis001,
   Axis
             := Pwr2_En,
   Enable
             => Pwr2_Status,
   Status
             => Pwr2_Bsy,
   Busy
             => Pwr2 Err.
   Error
   ErrorID
             => Pwr2 ErrID
);
// MC_Power for axis 3
PWR3(
             := MC_Axis002,
   Axis
   Enable
             := Pwr3_En,
   Status
             => Pwr3_Status,
   Busy
             => Pwr3_Bsy,
   Frror
             => Pwr3 Err,
   ErrorID
             => Pwr3_ErrID
```

);

```
//MC_MoveVelocity
VEL(
   Axis
                      := MC_Axis000,
   Execute
                      := Vel_Ex,
   Velocity
                      := Vel_Vel,
   Acceleration
                      := Vel_Acc,
   Deceleration
                      := Vel_Dec,
   Direction
                      := Vel_Dir,
   InVelocity
                      => Vel_InVel,
                      => Vel_Bsy,
   Busy
                      => Vel_Act,
   Active
   CommandAborted => Vel_Ca,
   Error
                      => Vel_Err,
   ErrorID
                      => Vel ErrID
);
// MC Gearln with axis 1 as master axis and axis 2 as slave axis
GEARIN1(
                      := MC_Axis000,
   Master
                      := MC_Axis001,
   Slave
   Execute
                      := Gearin1_Ex,
   RatioNumerator
                      := Gearin1_Rn,
   RatioDenominator := Gearin1_Rd,
                      := Gearin1_Rt,
   ReferenceType
                      := Gearin1_Acc,
   Acceleration
   Deceleration
                      := Gearin1 Dec.
   InGear
                      => Gearin1_InGear,
                      => Gearin1_Bsy,
   Busy
   Active
                      => Gearin1 Act,
   CommandAborted => Gearin1_CA,
   Error
                      => Gearin1_Err,
   ErrorID
                       => Gearin1_ErrID
);
// MC_GearIn with axis 1 as master axis and axis 3 as slave axis
GEARIN2(
   Master
                      := MC_Axis000,
   Slave
                      := MC_Axis002,
   Execute
                      := Gearin2 Ex.
   RatioNumerator
                      := Gearin2 Rn,
   RatioDenominator
                      := Gearin2_Rd,
   ReferenceType
                      := Gearin2_Rt,
   Acceleration
                       := Gearin2_Acc,
   Deceleration
                      := Gearin2_Dec,
   InGear
                       => Gearin2_InGear,
   Busy
                       => Gearin2_Bsy,
   Active
                      => Gearin2_Act,
   CommandAborted => Gearin2_CA,
                       => Gearin2_Err,
   Error
                       => Gearin2_ErrID
   ErrorID
);
//MC_GearOut
GEAROUT(
                       := MC_Axis001,
   Slave
   Execute
                       := Gearout_Ex,
                       := Gearout_Dec,
   Deceleration
                       => Gearout_D,
   Done
                       => Gearout_Bsy,
   Busy
   CommandAborted
                      => Gearout_CA,
                       => Gearout_Err,
   Error
   ErrorID
                       => Gearout_ErrID
);
```

# MC\_GearInPos

The MC\_GearInPos instruction performs electronic gear operation for the specified gear ratio between the master axis and the slave axis. The positions at which to start synchronizing the master axis and slave axis are specified.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_GearInPOS	Positioning Gear Operation	FB	MC_GearInPos_instance  MC_GearInPos Master — Master Slave — Slave — Execute StartSync — RatioNumerator InSync — RatioDenominator Busy — ReferenceType Active — MasterSyncPosition CommandAborted — SlaveSyncPosition Error — Velocity ErrorID — Acceleration — Deceleration — Jerk — BufferMode	MC_GearInPos_instance ( Master :=parameter, Slave :=parameter, Execute :=parameter, RatioNumerator :=parameter, RatioDenominator :=parameter, ReferenceType :=parameter, MasterSyncPosition :=parameter, SlaveSyncPosition :=parameter, Velocity :=parameter, Acceleration :=parameter, Deceleration :=parameter, Jerk :=parameter, BufferMode :=parameter, StartSync =>parameter, InSync =>parameter, Busy =>parameter, Active =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorID =>parameter) );

# **Variables**

# **Input Variables**

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when Execute changes to TRUE.
Ratio Numerator	Gear Ratio Numerator	UNIT	Positive number	10,000	Specify the numerator of the electronic gear ratio between the master and slave axes.
Ratio Denominator	Gear Ratio Denominator	UNIT	Positive number	10,000	Specify the denominator of the electronic gear ratio between the master and slave axes.
Reference Type*1	Position Type Selection	_eMC_ REFERENCE_ TYPE	0: _mcCommand 1: _mcFeedback 2: _mcLatestCommand	0*2	Specify the position type.  0: Command position (value calculated in the previous primary period)  1: Actual position (value obtained in the same primary period)  2: Command position (value calculated in the same primary period)
MasterSync Position	Master Sync Start Position	LREAL	Negative number, positive number, or 0	0	Specify the absolute master sync position. The unit is command units.*3

Name	Meaning	Data type	Valid range	Default	Description
SlaveSync Position	Slave Sync Start Position	LREAL	Negative number, positive number, or 0	0	Specify the absolute slave sync position. The unit is command units.*3
Velocity	Target Velocity	LREAL	Positive number	0	Specify the target velocity. Always set the target velocity. If the axis is moved without setting a target velocity, an error will occur. The unit is command units/s.*3
Acceleration	Acceleration Rate	LREAL	Non-negative number	0	Specify the acceleration rate. The unit is command units/s <sup>2</sup> .* <sup>3</sup>
Deceleration	Deceleration Rate	LREAL	Non-negative number	0	Specify the deceleration rate. The unit is command units/s <sup>2</sup> .* <sup>3</sup>
Jerk (Reserved)	Jerk	LREAL	0	0	(Reserved)
BufferMode (Reserved)	Buffer Mode Selection	_eMC_ BUFFER_ MODE	0: _mcAborting	0*2	(Reserved)

<sup>\*1</sup> When you use \_mcLatestCommand, the axis number set for the Master (Master Axis) in the system-defined variable for motion control must be lower than the axis number set for the Slave (Slave Axis) in the system-defined variable for motion control

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
StartSync	Following	BOOL	TRUE or FALSE	TRUE when acceleration/deceleration is started for synchronization.
InSync	In Sync	BOOL	TRUE or FALSE	TRUE when the slave axis reaches the slave sync position.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE	TRUE when the axis is being controlled.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

<sup>\*2</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

<sup>\*3</sup> Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.

### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
StartSync	When the axis starts moving.	When Error changes to TRUE.
		When CommandAborted changes to TRUE.
InSync	When the slave axis reaches SlaveSyncPosition.	When Error changes to TRUE.
		When CommandAborted changes to TRUE.
Busy	When Execute changes to TRUE.	When Error changes to TRUE.
		When CommandAborted changes to TRUE.
Active	When an instruction is received.	When Error changes to TRUE.
		When CommandAborted changes to TRUE.
CommandAborted	When this instruction is aborted because another	When Execute is TRUE and changes to
	motion control instruction was executed with the Buffer Mode set to <i>Aborting</i> .	FALSE.  • After one period when <i>Execute</i> is FALSE.
	When this instruction is canceled due to an error.	After one period when Execute is TALSE.
	When this instruction is executed while there is an error.	
	When you start this instruction during MC_Stop instruction execution.	
	When the MC_GearOut instruction is executed.	
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# **In-Out Variables**

Name	Meaning	Data type	Valid range	Description
Master	Master Axis	_sAXIS_REF		Specify the master axis.*
Slave	Slave Axis	_sAXIS_REF		Specify the slave axis.*

<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are *MC\_Axis*\*\*\*.)




### **Precautions for Correct Use**


If you specify the same axis for the master axis and slave axis, a Master and Slave Defined as Same Axis minor fault (error code 5436 hex) will occur.

### **Function**

- The MC\_GearInPos instruction performs gear operation for the slave axis specified with *Slave*. The following parameters are also specified: *RatioNumerator* (Gear Ratio Numerator), *RatioDenominator* (Gear Ratio Denominator), *ReferenceType* (Position Type), *Acceleration* (Acceleration Rate), and *Deceleration* (Deceleration Rate).
- For the master axis, you can specify the command position, actual position, or most recent command position.



- After operation starts, the Slave (Slave Axis) accelerates and decelerates in sync with the Master (Master Axis) in the catching operation.
- Catching phase exists until the slave axis reaches the slave sync position. For either, the position is synchronized with the master axis.
- The Velocity (Target Velocity) input variable is the target velocity for the catching phase.
- The slave axis moves in the same direction as the master axis when operation is started. An error occurs if the master axis velocity is 0 when started. If the master axis is moving in the positive direction and SlaveSyncPosition (Slave Sync Start Position) is smaller than the position of the slave axis when the instruction was executed, the slave axis will reverse direction. If the master axis is moving in the negative direction and *SlaveSyncPosition* (Slave Sync Start Position) is larger than the position of the slave axis when the instruction was executed, the slave axis will also reverse direction. For either, the position is synchronized with the master axis.
- If the master axis velocity changes significantly between periods, the slave axis velocity will not be constant.






#### **Precautions for Safe Use**

Do not execute the MC\_SetPosition instruction on the *Master* (Master Axis) if you use this instruction.

If the MC\_SetPosition instruction is executed for the *Master* (Master Axis), the *Slave* (Slave Axis) may follow the *Master* (Master Axis) quickly.

If you want to use the MC\_SetPosition instruction for the *Master* (Master Axis), disable the relationship between the *Master* (Master Axis) and *Slave* (Slave Axis) before executing the instruction.

- The MC Function Module calculates the velocity profile for linear acceleration and deceleration with the following three velocities using the *Acceleration* (Acceleration Rate) and *Deceleration* (Deceleration Rate).
  - The velocity of the Slave (Slave Axis) when catching operation starts is the initial velocity.
  - The velocity of the *Master* (Master Axis) when catching operation starts multiplied by the gear ratio is the final velocity.
  - The Velocity (Target Velocity) is the maximum velocity.



For the *Slave* (Slave Axis) to catch up with the *Master* (Master Axis) for the *MasterSyncPosition* (Master Sync Start Position) and *SlaveSyncPosition* (Slave Sync Start Position), the following condition must be met for the *Velocity* (Target Velocity)

Velocity >

Master axis velocity when MC\_GearInPos is executed × Gear ratio numerator

Gear ratio denominator

The information that is used as the mater axis velocity depends on the setting of ReferenceType (Position Type Selection).

When \_mcCommand or \_mcLatestCommand is set: Use the command current velocity. When \_mcFeedback is set: Use the actual current position.

If the *Slave* (Slave Axis) cannot catch up with the *Master* (Master Axis) for the *MasterSyncPosition* (Master Sync Start Position) and *SlaveSyncPosition* (Slave Sync Start Position), a Positioning Gear Operation Insufficient Target Velocity error (error code 5447 hex) will occur. Also, if you set the Count Mode to Rotary Mode, make sure that the synchronous operation starts within one cycle of the ring counter.



### **Precautions for Correct Use**

Refer to *Precautions for Master and Auxiliary Axes in Synchronized Control* on page 1-7 for precautions on the master axis.

### ReferenceType (Position Type Selection)

You can select one of the following position types.

- \_mcCommand: Command position (value calculated in the previous primary period)
   The master axis command position that was calculated in the previous primary period is used for the current period.
  - The command value that was calculated for the master axis in the last primary period is used to calculate the command position of the slave axis in the current period.
- \_mcFeedback: Value obtained in the same primary period

  The actual position of the master axis that was obtained in the same primary period is used.
- \_mcLatestCommand: Command position (value calculated in the same primary period)
   The command position of the master axis that was calculated in the same primary period is used.
   This enables the use of information that is more recent than for \_mcCommand. However, the axis number of the master axis must be set lower than the axis number of the slave axis.
   If the axis number of the slave axis is lower than the axis number of the master axis, Error will change to TRUE. A Master/Slave Axis Numbers Not in Ascending Order error (error code: 5438 hex) will be output to ErrorID.



### **Additional Information**

The command position that is calculated in the same primary period enables greater precision in synchronization than the command position that was calculated in the previous primary period. However, the axis number set for the *Master* (Master Axis) in the system-defined variable for motion control must be lower than the axis number set for the *Slave* (Slave Axis) in the system-defined variable for motion control.

### Relationship between Axis Types and Position Types


The relationship between the axis types that you can monitor and position types that is monitored is shown below.

Axis Type	ReferenceType			
Axis Type	_mcCommand or _mcLatestCommand	_mcFeedback		
Servo axis	OK	OK		
Encoder axis	No*	OK		
Virtual servo axis	OK	OK		
Virtual encoder axis	No*	OK		


<sup>\*</sup> A Position Type Selection Out of Range error (error code 5430 hex) occurs when the instruction is executed.

# **Timing Charts**


- Electronic gear operation starts when Execute changes to TRUE.
- Busy (Executing) changes to TRUE when Execute changes to TRUE. After the operation is started, Active (Controlling) and StartSync (Following) change to TRUE and the Slave (Slave Axis) starts the gear operation.
- When the *MasterSyncPosition* (Master Sync Start Position) and *SlaveSyncPosition* (Slave Sync Start Position) are reached, *InSync* changes to TRUE.
- If another instruction aborts this instruction, *CommandAborted* changes to TRUE and *Busy* (Executing), *Active* (Controlling), *StartSync* (Following), and *InSync* change to FALSE.




The operation when this instruction is aborted by another instruction is shown below.




Depending on setting of the *SlaveSyncPosition*, the axis may not reach the target velocity. An example of this is shown below.



The slave axis follows the master axis position before the InSync phase as well. An example of this is shown below.



You can specify the *Acceleration* (Acceleration Rate) and *Deceleration* (Deceleration Rate) as input variables. The following figures show operation examples of the electronic gear.



# **Re-execution of Motion Instructions**

This instruction cannot be re-executed.

A Motion Control Instruction Re-execution Disabled error (error code: 543B hex) occurs if re-execution is attempted.

# **Multi-execution of Motion Instructions**

The axis command status of the master axis, including whether it is stopped due to an error or it is decelerating to a stop, does not affect the execution of this instruction.

For details on re-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

### Execution of Other Instructions during Instruction Execution

Specify the operation of this instruction by using *BufferMode* (Buffer Mode Selection) for multi-execution of instructions.

Buffer Mode Selection	Description			
Aborting	Aborts the instruction being executed and switches to this instruction.  If the direction of axis motion is reversed by switching instructions, the motion will be reversed according to the Operation at Reversing axis parameter.			

For details on *BufferMode* (Buffer Mode Selection), refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).




#### **Precautions for Correct Use**

If another instruction is executed with BufferMode set to anything other than *Aborting*, an error will occur in the other instruction.

### **Errors**

If an error occurs during instruction execution, *Error* will change to TRUE. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).

### Timing Chart When Error Occurs



The slave axis is not affected by the error status of the master axis during synchronized control. After the error status of the master axis is cleared, the slave axis continues electronic gear operation when the master axis operates.

The master axis is not affected if an error occurs for the slave axis during startup or execution of this instruction.

### Error Codes

Refer to A-1 Error Codes for instruction errors.

# **Sample Programming**

This section describes sample programming where the sync position for the master axis is *Pos1* and the sync position for the slave axis *Pos2*.

# **Parameter Settings**

The minimum settings required for this sample programming are given below.

### Setting Axis Parameters

## **Axis Types**

Axis	Axis Types
Axis 1	Servo axis (master axis)
Axis 2	Servo axis (slave axis)

### **Count Modes**

Axis	Count Mode		
Axis 1	Rotary Mode		
Axis 2	Rotary Mode		


### **Ring Counters**

Axis	Modulo maxi- mum position	Modulo mini- mum position
Axis 1	360	0
Axis 2	360	0


# **Units of Display**

Axis	Unit of Display
Axis 1	degree
Axis 2	degree

# **Operation Example**



### Operation Pattern



**1** Starting the Master Axis

The master axis (axis 1) is an actual servo axis and it is operated with velocity control.

**2** Reaching Target Velocity for Main Axis

When the command velocity of the master axis reaches the target velocity, *InVelocity* (Target Velocity Reached) of the master axis changes to TRUE.

**3** Executing the Slave Axes

When *InVelocity* of the master axis changes to TRUE, slave axis (axis 2) performs gear operation with a gear ratio of 1:2 against the actual position of the master axis. The synchronized positions are *Pos1* for the master axis and *Pos2* for the slave axis.


# Ladder Diagram

### Main Variables

Name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		Axis Variable for the master axis, axis 1.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 1.
MC_Axis001	_sAXIS_REF		Axis Variable for the slave axis, axis 2.
MC_Axis001.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 2.
MC_Axis001.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 2.
Pwr1_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
Pwr2_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR2 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.


Name	Data type	Default	Comment
Hm1_D	BOOL	FALSE	This variable is assigned to the <i>Done</i> output variable from the HM1 instance of the MC_Home instruction.
Hm2_D	BOOL	FALSE	This variable is assigned to the <i>Done</i> output variable from the HM2 instance of the MC_Home instruction.
Vel_InVel	BOOL	FALSE	This variable is assigned to the <i>InVelocity</i> output variable from the VEL instance of the MC_MoveVelocity instruction. It is TRUE when the target velocity is reached.
Pos1	LREAL		This variable gives the master axis sync position.
Pos2	LREAL		This variable gives the slave axis sync position.
StartPg	BOOL	FALSE	The Servo is turned ON if this variable is TRUE and EtherCAT process data communications are established.

# Timing Chart




### Sample Programming

If StartPg is TRUE, EtherCAT communications for the axes are checked to see if process data communications are normal.



If process data communications are active, the Servo is turned ON for the axes.



If there is a minor fault level error for a composition axis, the error handler for the device (FaultHandler) is executed. Design FaultHandler separately.

```
MC_Axis000.MFaultLvl.Active
                                                                   FaultHandler
                                                                FN
                                                                      FaultHandler
MC Axis001.MFaultLvl.Active
```

If the Servo is ON for the master axis (axis 1) and home is not defined, the Home instruction is executed to define home.

```
HM<sub>1</sub>
                                                                 MC_Home
                                                                                                        Hm1_D
                                        MC_Axis000
                                                       Axis
                                                                                 Axis
Pwr1_Status MC_Axis000.Details.Homed
                                                       Execute
                                                                                Done
                                                                                Busy
                                                                                       Hm1_Bsy
                                                                    CommandAborted
                                                                                      - Hm1_Ca
                                                                                      – Hm1_Err
                                                                                Error
                                                                              ErrorID
                                                                                      – Hm1_ErrID
```


If the Servo is ON for the slave axis (axis 2) and home is not defined, the Home instruction is executed to define home.

```
HM2
                                                              MC_Home
                                                                                                   Hm2_D
                                      MC_Axis001
                                                    Axis
                                                                            Axis
Pwr2_Status MC_Axis001.Details.Homed
                                                    Execute
                                                                           Done
                                                                                  - Hm2_Bsy
                                                                            Busy
                                                                                  - Hm2_Ca
                                                                CommandAborted
                                                                                  - Hm2_Err
                                                                            Error
                                                                                  - Hm2_ErrID
                                                                          ErrorID
```


ErrorID

- Pwr2\_ErrID

The MC\_MoveVelocity (Velocity Control) instruction is executed after homing is completed for the master axis (axis 1).



After homing is completed for axis 2 (slave axis), MC\_GearInPos (Positioning Gear Operation) is executed to start gear operation if *Vel\_InVel* of MC\_MoveVelocity is TRUE.




# Structured Text (ST)

### Main Variables

Name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		Axis Variable for the master axis, axis 1.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for
			axis 1.
MC_Axis001	_sAXIS_REF		Axis Variable for the slave axis, axis 2.
MC_Axis001.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 2.
MC_Axis001.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 2.
Pwr1_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
Pwr2_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR2 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
Hm1_D	BOOL	FALSE	This variable is assigned to the <i>Done</i> output variable from the HM1 instance of the MC_Home instruction.
Hm2_D	BOOL	FALSE	This variable is assigned to the <i>Done</i> output variable from the HM2 instance of the MC_Home instruction.

Name	Data type	Default	Comment
Vel_InVel	BOOL	FALSE	This variable is assigned to the <i>InVelocity</i> output variable from the VEL instance of the MC_MoveVelocity instruction. It is TRUE when the target velocity is reached.
Pos1	LREAL		This variable gives the master axis sync position.
Pos2	LREAL		This variable gives the slave axis sync position.
StartPg	BOOL	FALSE	The Servo is turned ON if this variable is TRUE and EtherCAT process data communications are established.
Gearinpos_Ex	BOOL	FALSE	The GEARIN1 instance of MC_GearInPos is executed when this variable changes to TRUE.
Vel_Ex	BOOL	FALSE	The VEL instance of MC_MoveVelocity is executed when this variable changes to TRUE.
InitFlag	BOOL	FALSE	This variable indicates if it is necessary to set the input parameters. Input parameters are set when this variable is FALSE. When setting the input parameters is completed, this variable changes to TRUE.

### Timing Chart



### Sample Programming

```
Gearinpos_Rd
                     := UINT#10#2;
   Gearinpos_Rt
                     := _eMC_REFERENCE_TYPE#_mcFeedback;
   Gearinpos_Mtpos := Pos1;
   Gearinpos_Svpos := Pos2;
                    := LREAL#180.0;
   Gearinpos_Vel
   Gearinpos_Acc := LREAL#180.0;
   Gearinpos_Dec := LREAL#180.0;
   // Change InitFlag to TRUE after setting the input parameters.
   InitFlag:=TRUE;
END_IF;
// If StartPg is TRUE and EtherCAT communications are normal, the Servo for axis 1 is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
AND ( EC CommErrTbl[MC Axis000.Cfg.NodeAddress]=FALSE) THEN
   Pwr1_En:=TRUE;
ELSE
   Pwr1_En:=FALSE;
END_IF;
// If StartPg is TRUE and EtherCAT communications are normal, the Servo for axis 2 is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND ( EC PDSlavTbl[MC Axis001.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis001.Cfg.NodeAddress]=FALSE) THEN
   Pwr2 En:=TRUE;
ELSE
   Pwr2_En:=FALSE;
END_IF;
// If a minor fault level error occurs for axis 1 or axis 2, the error handler for the device (FaultHandler) is
// Implement FaultHandler separately.
IF (MC_Axis000.MFaultLvl.Active=TRUE) OR (MC_Axis001.MFaultLvl.Active=TRUE) THEN
   FaultHandler():
END_IF;
// If the Servo is ON for axis 1 and home is not defined, the Home instruction is executed.
IF (Pwr1_Status=TRUE) AND (MC_Axis000.Details.Homed=FALSE) THEN
   Hm1_Ex:=TRUE;
END IF;
// If the Servo is ON for axis 2 and home is not defined, the Home instruction is executed.
IF (Pwr2_Status=TRUE) AND (MC_Axis001.Details.Homed=FALSE) THEN
   Hm2_Ex:=TRUE;
END_IF;
// After homing is completed for axis 1, MC_MoveVelocity is executed.
IF Hm1 D=TRUE THEN
   Vel Ex := TRUE;
END_IF;
// After homing is completed for axis 2, MC_GearInPos is executed when Vel_InVel of MC_MoveVelocity is
IF (MC_Axis001.Details.Homed=TRUE) AND (Vel_InVel=TRUE) THEN
   Gearinpos_Ex := TRUE;
END_IF;
// MC Power for axis 1
PWR1(
```

```
:= MC_Axis000,
   Axis
             := Pwr1 En,
   Enable
   Status
             => Pwr1_Status,
   Busy
             => Pwr1_Bsy,
   Error
             => Pwr1_Err,
   ErrorID
            => Pwr1_ErrID
// MC_Power for axis 2
PWR2(
             := MC_Axis001,
   Axis
             := Pwr2_En,
   Enable
             => Pwr2_Status,
   Status
   Busy
             => Pwr2_Bsy,
   Error
             => Pwr2_Err,
   ErrorID
            => Pwr2 ErrID
);
// MC Home for axis 1
HM1(
                      := MC_Axis000,
   Axis
                      := Hm1_Ex,
   Execute
                      => Hm1_D,
   Done
                      => Hm1_Bsy,
   Busy
                      => Hm1_Ca,
   CommandAborted
                      => Hm1_Err,
   Error
                      => Hm1 ErrID
   ErrorID
// MC_Home for axis 2
HM2(
   Axis
                      := MC Axis001,
   Execute
                      := Hm2_Ex,
   Done
                      => Hm2_D,
   Busy
                      => Hm2_Bsy,
   CommandAborted
                      => Hm2_Ca,
                      => Hm2_Err,
   Error
                      => Hm2_ErrID
   ErrorID
);
//MC MoveVelocity
VEL(
                      := MC_Axis000,
   Axis
   Execute
                      := Vel Ex,
                      := Vel_Vel,
   Velocity
                      := Vel_Acc,
   Acceleration
                      := Vel_Dec,
   Deceleration
   Direction
                      := Vel_Dir,
   InVelocity
                      => Vel_InVel,
                      => Vel_Bsy,
   Busy
   Active
                      => Vel_Act,
   CommandAborted
                     => Vel_Ca,
   Error
                      => Vel Err,
   ErrorID
                      => Vel_ErrID
);
//MC_GearInPos
GEARINPOS(
   Master
                          := MC_Axis000,
   Slave
                          := MC_Axis001,
                          := Gearinpos_Ex,
   Execute
   RatioNumerator
                          := Gearinpos_Rn,
   RatioDenominator
                          := Gearinpos_Rd,
   ReferenceType
                          := Gearinpos_Rt,
   MasterSyncPosition
                          := Gearinpos_Mtpos,
                          := Gearinpos_Svpos,
   SlaveSyncPosition
                          := Gearinpos_Vel,
   Velocity
```

```
Acceleration
                         := Gearinpos_Acc,
  Deceleration
StartSync
                         := Gearinpos_Dec,
   StartSync
                         => Gearinpos_StSync,
   InSync
                         => Gearinpos_InSync,
   Busy
                         => Gearinpos_Bsy,
   Active
                         => Gearinpos_Act,
   CommandAborted
                         => Gearinpos_Ca,
                         => Gearinpos_Err,
   Error
                         => Gearinpos_ErrID
   ErrorID
);
```

3-245

# MC\_GearOut

The MC\_GearOut instruction stops operation for the MC\_GearIn (Start Gear Operation) instruction or MC\_GearInPos (Positioning Gear Operation) instruction.

Instruction	Name	FB/FUN	Graphic expression	ST expression
MC_GearOut	End Gear Operation	FB	MC_GearOut_instance  MC_GearOut Slave — Slave Execute Done Deceleration Busy Jerk CommandAborted OutMode Error ErrorID	MC_GearOut_instance ( Slave :=parameter, Execute :=parameter, Deceleration :=parameter, Jerk :=parameter, OutMode :=parameter, Done =>parameter, Busy =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorID =>parameter);

### **Variables**

# **Input Variables**

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when Execute changes to TRUE.
Deceleration	Deceleration Rate	LREAL	Non-negative number	0	Specify the deceleration rate. The unit is command units/s <sup>2</sup> .* <sup>1</sup>
Jerk (Reserved)	Jerk	LREAL	0	0	(Reserved)
OutMode (Reserved)	Sync End Mode Selec- tion	_eMC_OUT_ MODE	0: _mcStop	0*2	(Reserved)

<sup>\*1</sup> Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

<sup>\*2</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

# Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When the instruction is completed.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	<ul> <li>When <i>Done</i> changes to TRUE.</li> <li>When <i>Error</i> changes to TRUE.</li> <li>When <i>CommandAborted</i> changes to TRUE.</li> </ul>
CommandAborted	<ul> <li>When this instruction is aborted because another motion control instruction was executed with the Buffer Mode set to <i>Aborting</i>.</li> <li>When this instruction is canceled due to an error.</li> <li>When this instruction is executed while there is an error.</li> <li>When you start this instruction during MC_Stop instruction execution.</li> </ul>	<ul> <li>When Execute is TRUE and changes to FALSE.</li> <li>After one period when Execute is FALSE.</li> </ul>
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# In-Out Variables

Name	Meaning	Data type	Valid range	Description
Slave	Slave Axis	_sAXIS_REF		Specify the slave axis.*


<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are MC\_Axis\*\*\*.)

### **Function**


- The MC\_GearOut instruction stops the operation of the MC\_GearIn (Start Gear Operation) or MC\_GearInPos (Positioning Gear Operation) instruction for the operation axis specified with *Slave* and at the specified *Deceleration* (Deceleration Rate).
- This instruction does not affect the MC\_Gearln (Start Gear Operation) or MC\_GearlnPos (Positioning Gear Operation) operation of the master axis.

# **Timing Charts**

- Busy (Executing) changes to TRUE when Execute changes to TRUE.
- Done changes to TRUE when the target velocity is reached.
- If another instruction aborts this instruction, CommandAborted changes to TRUE and Busy (Executing) changes to FALSE.




### When This Instruction Is Aborted by Another Instruction



3-247

#### When The Instruction Is Executed with a Deceleration Rate of 0

If deceleration rate is set to 0 and the instruction is executed, the axis will stop without decelerating. The following chart shows an operation example of when the deceleration rate is 0.



## **Re-execution of Motion Instructions**

This instruction cannot be re-executed.

A Motion Control Instruction Re-execution Disabled error (error code: 543B hex) occurs if re-execution is attempted.

### **Multi-execution of Motion Instructions**

For details on re-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

### Execution during Execution of Other Instructions

If you execute this instruction while MC\_GearIn (Start Gear Operation) or MC\_GearInPos (Positioning Gear Operation) instruction is in execution, *CommandAborted* for MC\_GearIn or MC\_GearInPos will change to TRUE and *Busy* (Executing) of this instruction will change to TRUE. If you execute this instruction while instructions other than MC\_GearIn or MC\_GearInPos are in execution, this instruction will result in an error.


#### Execution of Other Instructions during Instruction Execution

To use multi-execution of motion instruction for this instruction, specify the slave axis. If you execute another instruction during execution of this instruction, you can specify either aborting or buffering.

## **Errors**

If an error occurs during instruction execution, *Error* will change to TRUE. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).

### Timing Chart When Error Occurs



### Error Codes

Refer to A-1 Error Codes for instruction errors.

# MC\_MoveLink

Positioning is performed in sync with the specified master axis.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_MoveLink	Synchro- nous Posi- tioning	FB	MC_MoveLink_instance  MC_MoveLink Master — Master Slave — Slave TriggerInput — TriggerInput TriggerVariable — TriggerVariable Execute Done ReferenceType InSync SlaveDistance Busy MasterDistance Active MasterDistanceInACC CommandAborted MasterDistanceInDEC Error LinkOption ErrorID MasterStartDistance BufferMode	MC_MoveLink_instance ( Master :=parameter, Slave :=parameter, TriggerInput :=parameter, TriggerVariable :=parameter, Execute :=parameter, Execute :=parameter, ReferenceType :=parameter, SlaveDistance :=parameter, MasterDistance :=parameter, MasterDistanceInACC :=parameter, MasterDistanceInDEC :=parameter, LinkOption :=parameter, MasterStartDistance :=parameter, BufferMode :=parameter, Done =>parameter, InSync =>parameter, Busy =>parameter, Active =>parameter, CommandAborted =>parameter, Error =>parameter); ErrorID =>parameter);

# **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Execute</i> changes to TRUE.
Reference Type*1	Position Type Selec- tion	_eMC_ REFERENCE _TYPE	0: _mcCommand 1: _mcFeedback 2: _mcLatestCommand	0*2	Specify the position type.  0: Command position   (value calculated in the previous primary period)  1: Actual position (value obtained in the same primary period)  2: Command position   (value calculated in the
SlaveDistance	Slave Axis Travel Dis- tance	LREAL	Negative number, positive number, or 0	0	Specify the travel distance of the slave axis. The unit is command units.*3
MasterDistance	Master Axis Travel Dis- tance	LREAL	Non-negative number	0	Specify the travel distance of the master axis. The unit is command units.*3

Name	Meaning	Data type	Valid range	Default	Description
Master DistanceInACC	Master Distance in Acceleration	LREAL	Non-negative number	0	Specify the travel distance of the master axis while the slave axis is accelerating. The unit is command units.*3
Master DistanceInDEC	Master Distance in Deceleration	LREAL	Non-negative number	0	Specify the travel distance of the master axis while the slave axis is decelerating. The unit is command units.*3
LinkOption	Synchronization Start Condition	_eMC_ LINKOPTION	0: _mcCommandEexecution 1: _mcTriggerDetection 2: _mcMasterReach	0*2	Specify the condition for the slave axis to synchronize with the master axis.  0: When instruction execution starts  1: When trigger is detected  2: When the master axis reaches the master following distance.
MasterStart Distance	Master Following Distance	LREAL	Negative number, positive number, or 0	0	Specify the absolute position of the master axis when the slave axis starts following the master axis. The unit is command units.*3
BufferMode	Buffer Mode Selection	_eMC_ BUFFER_ MODE	0: _mcAborting 1: _mcBuffered	0*2	Specify the operation when executing more than one motion instruction.  0: Aborting 1: Buffered

<sup>\*1</sup> When you use \_mcLatestCommand, the axis number set for the Master (Master Axis) in the system-defined variable for motion control must be lower than the axis number set for the Slave (Slave Axis) in the system-defined variable for motion control.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
InSync	In Sync	BOOL	TRUE or FALSE	TRUE when synchronization is started.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE	TRUE when the axis is being controlled.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

<sup>\*2</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

<sup>\*3</sup> Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.

## Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When the instruction is completed.	When Execute is TRUE and changes to FALSE.
		After one period when <i>Execute</i> is FALSE.
InSync	When synchronization conditions are met.	When Done changes to TRUE.  When Error changes to TRUE.  When Command Aborted changes to
		When CommandAborted changes to TRUE.
Busy	When Execute changes to TRUE.	When <i>Done</i> changes to TRUE.
		When <i>Error</i> changes to TRUE.
		When CommandAborted changes to TRUE.
Active	When an instruction is received.	When <i>Done</i> changes to TRUE.
		When <i>Error</i> changes to TRUE.
		When CommandAborted changes to TRUE.
CommandAborted	When this instruction is aborted because another motion control instruction was executed with the	When Execute is TRUE and changes to FALSE.
	Buffer Mode set to Aborting.	After one period when Execute is
	When this instruction is canceled due to an error.	FALSE.
	<ul> <li>When this instruction is executed while there is an error.</li> </ul>	
	When you start this instruction during MC_Stop instruction execution.	
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# In-Out Variables

Name	Meaning	Data type	Valid range	Description
Master	Master Axis	_sAXIS_REF		Specify the master axis.*1
Slave	Slave Axis	_sAXIS_REF		Specify the slave axis.*1
TriggerInput	Trigger Input Condition	_sTRIGGER_REF		Set the trigger condition.*2
TriggerVariable	Trigger Vari- able	BOOL	TRUE or FALSE	Specify the input variable to function as the trigger to specify the controller mode with a trigger condition.

<sup>\*1</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are *MC\_Axis*\*\*\*.)

<sup>\*2</sup> Define a user-defined variable with a data type of \_sTRIGGER\_REF.

### • sTRIGGER REF

Name	Meaning	Data type	Valid range	Function
Mode	Mode	_eMC_Trigger_ Mode	0: _mcDrive 1: _mcController	Specify the trigger mode. 0: Drive Mode 1: Controller Mode
LatchID	Latch ID Selection	_eMC_Trigger_ Latch_ID	0: _mcLatch1 1: _mcLatch2	Specify which of the two latch functions to use. 0: Latch 1 1: Latch 2
InputDrive	Trigger Input Sig- nal	_eMC_Trigger_ Input _Drive	0: _mcEncoderMark 1: _mcEXT	Specify the Servo Drive trigger signal to use in Drive Mode. 0: Z-phase signal 1: External input

### **Function**

- The MC\_MoveLink instruction moves a slave axis in synchronization with a specified master axis.
- A type of electronic cam operation is performed, but synchronous positioning is performed between the slave axis and the master axis.
- Use MC\_Stop to stop the axis during motion for this instruction.



#### **Precautions for Safe Use**

Do not execute the MC\_SetPosition instruction for the *Master* (Master Axis) if you use this instruction. If the MC\_SetPosition instruction is executed for the *Master* (Master Axis), the *Slave* (Slave Axis) may follow the *Master* (Master Axis) quickly.

If you want to use the MC\_SetPosition instruction for the *Master* (Master Axis), disable the relationship between the *Master* (Master Axis) and *Slave* (Slave Axis) executing the instruction. Refer to *Precautions for Master and Auxiliary Axes in Synchronized Control* on page 1-7 for pre-

cautions on the master axis.

### Mapping Data Objects

You must map the following object data when *LinkOption* (Synchronization Start Condition) is set to \_mcTriggerDetection and the MC\_MoveLink (Synchronous Positioning) instruction executed with Mode set to Drive Mode. Mapping is performed in the Detailed Setting Area of the Axis Basic Settings Display of the Sysmac Studio.

- Touch probe function (60B8 hex)
- Touch probe status (60B9 hex)
- Touch probe pos1 pos value (60BA hex)
- Touch probe pos2 pos value (60BC hex)

If even one of the required objects is not set, a Process Data Object Setting Missing error (error code 3461 hex) occurs.

For details on mapping data objects, refer to 2-3 PDO Mapping and to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

### **Instruction Details**

This section describes the instruction in detail.

#### Master (Master Axis)

Specify the master axis with Master.

### • Slave (Slave Axis)

Specify the slave axis with Slave.

### TriggerInput (Trigger Input Condition) and TriggerVariable

These variables specify the input signal on which to start synchronization when the sync start condition is set to \_mcTriggerDectection. For the input signal selection and information on the timing when a trigger is generated, refer to MC\_TouchProbe on page 3-313. If the Drive Mode is specified for Mode in TriggerInput (Trigger Input Condition), a drive input from the slave axis is used. If the Controller Mode is specified, TriggerVariable is used as the trigger signal.

### ReferenceType (Position Type Selection)

You can select one of the following position types.

- \_mcCommand: Command position (value calculated in the previous primary period)
   The master axis command position that was calculated in the previous primary period is used for the current period.
  - The command value that was calculated for the master axis in the last primary period is used to calculate the command position of the slave axis in the current period.
- \_mcFeedback: Value obtained in the same primary period
  The actual position of the master axis that was obtained in the same primary period is used.
- \_mcLatestCommand: Command position (value calculated in the same primary period)
   The command position of the master axis that was calculated in the same primary period is used.
   This enables the use of information that is more recent than for \_mcCommand. However, the axis number of the master axis must be set lower than the axis number of the slave axis.
   If the axis number of the slave axis is lower than the axis number of the master axis, Error will change to TRUE. A Master/Slave Axis Numbers Not in Ascending Order error (error code: 5438 hex) will be output to ErrorID.



#### **Additional Information**

The command position that is calculated in the same primary period enables greater precision in synchronization than the command position that was calculated in the previous primary period. However, the axis number set for the *Master* (Master Axis) in the system-defined variable for motion control must be lower than the axis number set for the *Slave* (Slave Axis) in the system-defined variable for motion control.

#### Relationship between Axis Types and Position Types


The relationship between the axis types that you can monitor and position types that is monitored is shown below.

Axis Type	ReferenceType					
Axis Type	_mcCommand or _mcLatestCommand	_mcFeedback				
Servo axis	OK	OK				
Encoder axis	No*	OK				
Virtual servo axis	OK	OK				
Virtual encoder axis	No*	OK				

<sup>\*</sup> A Position Type Selection Out of Range error (error code: 5430 hex) occurs when the instruction is executed.

### SlaveDistance (Slave Axis Travel Distance), MasterDistance (Master Axis Travel Distance), MasterDistanceInACC (Master Distance in Acceleration), and MasterDistanceInDEC (Master Distance in Deceleration)

The velocity and position of the slave axis are determined by the ratio of the travel distances of the master axis and the slave axis as shown in the following figure. The master following distance shown in the following figure represents the position where the sync start condition was met.



The relationship between the travel distance of the master axis and the travel distance of the slave axis is shown in the following table.

Section		Relationship between the master axis and slave axis travel distances					
Accelera-	Master axis	Master Distance in Acceleration					
tion	Slave axis	Slave axis Master distance in acceleration 2					
		travel distance    Master distance    Master distance    Master distance    Master distance    Master distance    Acceleration    Master distance    Master distance    Master distance    in deceleration    2					
Constant	Master axis	Master distance – Master distance in acceleration – Master distance in deceleration					
velocity	Slave axis	Slave axis travel distance – Slave axis travel distance at the acceleration rate above – Slave axis travel distance at the deceleration rate below					
Decelera-	Master axis	Master Distance in Deceleration					
tion	Slave axis	Slave axis 2					
		travel distance    Master distance    Master axis travel distance – Master distance in acceleration + master distance in deceleration + in deceleration    2					

When the constant velocity section of the master axis is negative, a constant velocity travel distance error occurs and the axis stops. If you want to feed the slave axis at the same velocity as the master axis, set the following value as the travel distance of the slave axis.

Master axis travel distance – Master distance in acceleration – Master distance in deceleration

Master distance in deceleration 2

### LinkOption (Synchronization Start Condition)

Specify the condition for the slave axis to synchronize with the master axis.

· Start of Instruction

When this instruction is executed, the slave axis performs positioning in synchronization with the master axis from the next period.

· When Trigger Is Detected

When the input signal specified as the input trigger occurs, the slave axis synchronizes with the master axis and performs positioning from the next period.

• When the Master Axis Reaches the Master Following Distance

When the master axis reaches the master following distance during instruction execution, the slave axis starts synchronization and performs positioning from the next period.

Even if the instruction is executed while the master axis is stopped at the master following distance, the slave axis starts synchronization and performs positioning from the next period.



#### **Precautions for Correct Use**

You must map object data when LinkOption (Synchronization Start Condition) is set to\_mcTriggerDetection and Mode is set to Drive Mode. Set the following objects.

- Touch probe function (60B8 hex)
- Touch probe status (60B9 hex)
- Touch probe pos1 pos value (60BA hex)
- Touch probe pos2 pos value (60BC hex)

If even one of the required objects is not set, a Process Data Object Setting Missing error (error code 3461 hex) occurs. For details on mapping object data, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### MasterStartDistance

MasterStartDistance specifies the absolute position where the slave axis starts synchronization with the master axis.

#### BufferMode (Buffer Mode Selection)

*BufferMode* specifies how to join the axis motions for this instruction and the previous instruction. There is currently only the following two settings.

Buffer Mode Selection	on Description		
Aborting	Aborts the instruction being executed and switches to this instruction.		
Buffered	Automatically executes the buffered instruction after the current instruction is completed.		

For details on *BufferMode* (Buffer Mode Selection), refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

### In-position Check


An in-position check is performed when the slave axis ends operation.

An in-position check is performed for this instruction according to the settings in In-position Range and In-position Check Time axis parameters.


# **Timing Charts**

# • Executing MC\_MoveLink


# LinkOption Set to \_mcCommandExecution



## LinkOption Set to \_mcTriggerDetection



# Sync Start Condition Setting = When the Master Axis Reaches the Master Following Distance




### When an Instruction Is Executed with BufferMode Set to Aborting during Previous Operation

This section describes when this instruction is executed with *LinkOption* set to \_mcCommandExecution when the previous operation, MC\_MoveAbsolute (Absolute Positioning), is in execution.



#### **Precautions for Correct Use**

As shown in the following chart, the velocity of the slave axis becomes discontinuous when this instruction is started.




### When an Instruction Is Executed with BufferMode Set to Buffered during Previous Operation

This instruction is executed after the previous instruction is finished.

## **Re-execution of Motion Instructions**

This instruction cannot be re-executed.

A Motion Control Instruction Re-execution Disabled error (error code: 543B hex) occurs if re-execution is attempted, and the axis stops.



### **Multi-execution of Motion Instructions**

For details on multi-execution of instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

### • Execution of Other Instructions during Instruction Execution

If you execute another instruction during execution of this instruction, you can specify either aborting or buffering.

You cannot specify blending.

### **Errors**

If an error occurs during instruction execution, *Error* will change to TRUE and the axis will stop. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code). Refer to *Re-execution of Motion Instructions* on page 3-261 for the timing chart after an error occurs.

#### Error Codes

Refer to A-1 Error Codes for instruction errors.

# **Sample Programming**

This sample programming shows the control of a cutter.

# **Parameter Settings**

The minimum settings required for this sample programming are given below.

### Setting Axis Parameters

### **Axis Types**

Axis	Axis Type		
Axis 1	Servo axis (master axis)		
Axis 2	Servo axis (slave axis)		

### **Count Modes**

Axis	Count Mode
Axis 1	Rotary Mode
Axis 2	Linear Mode


### **Ring Counter**

Axis	Modulo maxi- mum position	Modulo mini- mum position	
Axis 1	360	0	


### **Units of Display**

Axis	Unit of Display		
Axis 1	degree		
Axis 2	mm		

# **Operation Example**



### Operation Patterns



- Starting the Master Axis
  Axis 1 for the belt conveyer is treated as master axis to feed back the position.
- 2 Executing the Slave Axis
  Axis 2 for the ball screw that moves in the horizontal direction moves in synchronization with axis 1.
- 3 Cutting with the Cutter

The pneumatic actuator turns ON when axis 2 is synchronized. The cutter, which is connected to the pneumatic actuator, descends in a vertical direction and cuts the workpiece.


# **Ladder Diagram**

#### Main Variables

Name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		Axis Variable for the master axis, axis 1.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 1.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
MC_Axis001	_sAXIS_REF		Axis Variable for the slave axis, axis 2.
MC_Axis001.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 2.
MC_Axis001.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 2.
Pwr1_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.

Name	Data type	Default	Comment
Pwr2_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR2 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
StartPg	BOOL	FALSE	The Servo is turned ON if this variable is TRUE and EtherCAT process data communications are established.
Actuator	BOOL	FALSE	TRUE when axis 1 and axis 2 are synchronized. While <i>Actuator</i> is TRUE, the cutter moves down vertically.
InitFlag	BOOL	FALSE	This variable indicates if it is necessary to set the input parameters. Input parameters are set when this variable is FALSE. When setting the input parameters is completed, this variable changes to TRUE.

# Timing Chart



### Sample Programming

If StartPq is TRUE, EtherCAT communications for the axes are checked to see if process data communications are normal.

```
StartPg _EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress] _EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress] Lock1

__EC_PDSlavTbl[MC_Axis001.Cfg.NodeAddress] _EC_CommErrTbl[MC_Axis001.Cfg.NodeAddress] Lock2
```

If process data communications are active, the Servo is turned ON for the axes.

```
PWR1
                                                               MC_Power
                                                                                                      Pwr1_Status
                                       MC_Axis000 ·
                                                      Axis
                                                                                Axis
Lock1
 Enable
                                                                              Status
                                                                               Busy
                                                                                       Pwr1_Bsy
                                                                               Error
                                                                                       Pwr1_Err
                                                                                      - Pwr1_ErrID
                                                                             ErrorID
                                                                  PWR2
                                                               MC_Power
                                       MC_Axis001 -
                                                                                                      Pwr2_Status
                                                      Axis
                                                                                Axis
Lock2
                                                      Enable
                                                                              Status
                                                                                       Pwr2_Bsy
                                                                               Busy
                                                                                      - Pwr2_Err
                                                                               Error
                                                                             ErrorID
                                                                                      - Pwr2_ErrID
```

If there is a minor fault level error for a composition axis, the error handler for the device (FaultHandler) is executed. Design FaultHandler separately.

```
MC_Axis000.MFaultLvl.Active

| MC_Axis001.MFaultLvl.Active | FaultHandler | EN Fault
```

If the Servo is ON for axis 1 and home is not defined, the Home instruction is executed to define home.

```
HM1
                                                               MC_Home
                                                                                                      Hm1_D
                                       MC_Axis000
                                                      Axis
                                                                              Axis
Pwr1_Status MC_Axis000.Details.Homed
                                                      Execute
                                                                              Done
                                                                              Busy
                                                                                     - Hm1_Bsy
                                                                  CommandAborted
                                                                                     - Hm1_Ca
                                                                              Error
                                                                                     - Hm1_Err
                                                                            ErrorID
                                                                                     - Hm1_ErrID
```


If the Servo is ON for axis 2 and home is not defined, the Home instruction is executed to define home.

```
HM2
                                                              MC_Home
                                                                                                    Hm2_D
                                       MC_Axis001 -
                                                     Axis
                                                                             Axis
            MC Axis001.Details.Homed
Pwr2 Status
                                                     Execute
                                                                            Done
                                                                             Busy
                                                                                   - Hm2 Bsy
                                                                                   - Hm2_Ca
                                                                  CommandAborted
                                                                                  - Hm2_Err
                                                                             Frror
                                                                           ErrorID - Hm2_ErrID
```


The parameters are set for the MC\_MoveVelocity (Velocity Control) and MC\_MoveLink (Synchronous Positioning) instructions.

```
Note: The contents of the inline ST are given below.
```

The MC\_MoveVelocity (Velocity Control) instruction is executed if home is defined for axis 1.



The MC\_MoveLink (Synchronous Positioning) instruction is executed if home is defined for axis 2 (slave axis).



Actuator is TRUE while the axes are synchronized.

```
Mv_Link_InSync Actuator
```

#### **Contents of Inline ST**

```
// MC_MoveVelocity parameters
Vel_Vel
        := LREAL#1000.0;
Vel Acc := LREAL#0.0;
Vel_Dec := LREAL#0.0;
// MC_MoveLink parameters
Mv_Link_TrigRef.Mode
                           := _eMC_TRIGGER_MODE#_mcDrive;
Mv_Link_TrigRef.LatchID
                           := _eMC_TRIGGER_LATCH_ID#_mcLatch1;
Mv_Link_TrigRef.InputDrive
                           := _eMC_TRIGGER_INPUT_DRIVE#_mcEXT;
Mv_Link_TrigVar
                           := FALSE;
Mv_Link_SlvDis
                           := LREAL#1000.0;
Mv_Link_MasDis
                           := LREAL#1000.0;
Mv_Link_MasDisInAcc
                           := LREAL#100.0;
Mv_Link_MasDisInDec
                           := LREAL#100.0;
```

 $\label{eq:mv_link_lnkOpt} \mathsf{Mv\_Link\_LnkOpt} \qquad \qquad := \_\mathsf{eMC\_LINKOPTION\#\_mcTriggerDetection};$ 


// Change  $\mathit{InitFlag}$  to TRUE after setting the input parameters. InitFlag := TRUE;

# Structured Text (ST)

### Main Variables

Name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		Axis Variable for the master axis, axis 1.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 1.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
MC_Axis001	_sAXIS_REF		Axis Variable for the slave axis, axis 2.
MC_Axis001.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 2.
MC_Axis001.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 2.
Pwr1_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
Pwr2_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR2 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
StartPg	BOOL	FALSE	The Servo is turned ON if this variable is TRUE and EtherCAT process data communications are established.
Actuator	BOOL	FALSE	TRUE when axis 1 and axis 2 are synchronized. While <i>Actuator</i> is TRUE, the cutter moves down vertically.
InitFlag	BOOL	FALSE	This variable indicates if it is necessary to set the input parameters. Input parameters are set when this variable is FALSE. When setting the input parameters is completed, this variable changes to TRUE.

## Timing Chart



### Sample Programming

```
// Processing when input parameters are not set
IF InitFlag=FALSE THEN
   // MC_MoveVelocity parameters
   Vel_Vel := LREAL#1000.0;
   Vel_Acc := LREAL#0.0;
   Vel_Dec := LREAL#0.0;
   // MC_MoveLink parameters
   Mv_Link_TrigRef.Mode
                                := _eMC_TRIGGER_MODE#_mcDrive;
   Mv_Link_TrigRef.LatchID
                                := _eMC_TRIGGER_LATCH_ID#_mcLatch1;
   Mv_Link_TrigRef.InputDrive
                                := _eMC_TRIGGER_INPUT_DRIVE#_mcEXT;
   Mv_Link_TrigVar
                                := FALSE;
   Mv_Link_SlvDis
                                := LREAL#1000.0;
   Mv_Link_MasDis
                                := LREAL#1000.0;
   Mv_Link_MasDisInAcc
                                := LREAL#100.0;
   Mv_Link_MasDisInDec
                                := LREAL#100.0;
   Mv_Link_LnkOpt
                                := _eMC_LINKOPTION#_mcTriggerDetection;
   // Change InitFlag to TRUE after setting the input parameters.
   InitFlag := TRUE;
END_IF;
// If StartPq is TRUE and EtherCAT communications are normal, the Servo for axis 1 is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
                         // Turn ON the Servo for axis 1.
   Pwr1_En:=TRUE;
FLSE
   Pwr1_En:=FALSE;
                         // Turn OFF the Servo for axis 1.
END_IF;
// If StartPg is TRUE and EtherCAT communications are normal, the Servo for axis 2 is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis001.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis001.Cfg.NodeAddress]=FALSE) THEN
   Pwr2_En:=TRUE;
                         // Turn ON the Servo for axis 2.
ELSE
                         // Turn OFF the Servo for axis 2.
   Pwr2_En:=FALSE;
END_IF;
// Processing for a minor fault level error
// Implement FaultHandler separately.
IF (MC_Axis000.MFaultLvl.Active=TRUE) OR (MC_Axis001.MFaultLvl.Active=TRUE) THEN
   FaultHandler();
END_IF;
// If the Servo is ON for axis 1 and home is not defined, the Home instruction is executed.
IF (Pwr1_Status=TRUE) AND (MC_Axis000.Details.Homed=FALSE) THEN
   Hm1_Ex:=TRUE;
END_IF;
// If the Servo is ON for axis 2 and home is not defined, the Home instruction is executed.
IF (Pwr2_Status=TRUE) AND (MC_Axis001.Details.Homed=FALSE) THEN
   Hm2_Ex:=TRUE;
END_IF;
// After home is defined for axis 1, MC MoveVelocity is executed for axis 1.
IF MC_Axis000.Details.Homed=TRUE THEN
   Vel_Ex:=TRUE;
```

```
END_IF;
// MC_MoveLink is executed for axis 2 if home is defined for axis 2 and the target velocity was reached for axis
IF (MC_Axis001.Details.Homed=TRUE) AND (Vel_InVel=TRUE) THEN
   Mv_Link_Ex:=TRUE;
END_IF;
// The actuator is turned ON if axis 1 and axis 2 are synchronized.
IF Mv_Link_InSync=TRUE THEN
   Actuator:=TRUE;
ELSE
   Actuator:=FALSE;
END_IF;
// MC_Power1
PWR1(
   Axis
            := MC_Axis000,
   Enable := Pwr1_En,
            => Pwr1_Status,
   Status
            => Pwr1_Bsy,
   Busy
            => Pwr1_Err,
   Error
   ErrorID => Pwr1_ErrID
);
// MC Power2
PWR2(
   Axis
            := MC Axis001,
   Enable := Pwr2 En,
   Status => Pwr2_Status,
   Busy => Pwr2_Bsy,
   Error
           => Pwr2_Err,
   ErrorID => Pwr2_ErrID
);
// MC_Home1
HM1(
                     := MC_Axis000,
   Axis
                   := Hm1_Ex,
   Execute
  Done
                     => Hm1 D.
   Busy
                     => Hm1 Bsv.
   CommandAborted => Hm1_Ca,
   Error
                     => Hm1_Err,
                     => Hm1_ErrID
   ErrorID
);
// MC_Home2
HM2(
   Axis
                     := MC_Axis001,
   Execute
                    := Hm2 Ex,
   Done
                    => Hm2_D,
                    => Hm2_Bsy,
   Busv
   CommandAborted => Hm2_Ca,
   Error
                    => Hm2_Err,
   ErrorID
                     => Hm2_ErrID
);
// MC_MoveVelocity
VEL(
   Axis
                     := MC_Axis000,
   Execute
                     := Vel_Ex,
   Velocity
                    := Vel_Vel,
   Acceleration
                     := Vel_Acc,
   Deceleration
                     := Vel_Dec,
```

```
=> Vel_InVel,
   InVelocity
                      => Vel_Bsy,
   Busy
   Active
                      => Vel_Act,
   CommandAborted
                     => Vel_Ca,
   Error
                      => Vel_Err,
   ErrorID
                      => Vel_ErrID
);
// MC_MoveLink
MV_LINK(
   Master
                         := MC_Axis000,
   Slave
                         := MC_Axis001,
                         := Mv_Link_TrigRef,
   TriggerInput
   TriggerVariable
                         := Mv_Link_TrigVar,
                         := Mv_Link_Ex,
   Execute
   SlaveDistance
                         := Mv_Link_SlvDis,
   MasterDistance
                         := Mv_Link_MasDis,
   MasterDistanceInAcc
                         := Mv Link MasDisInAcc,
   MasterDistanceInDec
                         := Mv_Link_MasDisInDec,
   LinkOption
                          := Mv_Link_LnkOpt,
   Done
                          => Mv_Link_D,
                          => Mv_Link_InSync,
   InSync
                          => Mv_Link_Bsy,
   Busy
   Active
                          => Mv_Link_Act,
   CommandAborted
                         => Mv_Link_Ca,
   Error
                         => Mv_Link_Err,
   ErrorID
                         => Mv_Link_ErrID
);
```

# MC\_CombineAxes

The MC\_CombineAxes instruction outputs the sum or difference of the command positions of two axes as the command position.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_CombineAxes	Combine Axes	FB	MC_CombineAxes_instance  MC_CombineAxes Master — Master Auxiliary — Auxiliary Slave — Slave Execute InCombination CombineMode Busy RatioNumeratorMaster Active RatioDenominatorMaster CommandAborted RatioNumeratorAuxiliary Error RatioDenominatorAuxiliary ErrorID ReferenceTypeMaster ReferenceTypeAuxiliary BufferMode	MC_CombineAxes_instance ( Master :=parameter, Auxiliary :=parameter, Slave :=parameter, Execute :=parameter, CombineMode :=parameter, RatioNumeratorMaster :=parameter, RatioDenominatorMaster :=parameter, RatioNumeratorAuxiliary :=parameter, RatioDenominatorAuxiliary :=parameter, RatioDenominatorAuxiliary :=parameter, ReferenceTypeMaster :=parameter, ReferenceTypeAuxiliary :=parameter, BufferMode :=parameter, InCombination =>parameter, Busy =>parameter, Active =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorID =>parameter );

# Variables

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when Execute changes to TRUE.
CombineMode	Combine	_eMC	0: _mcAddAxes	0*	Specify the combining method.
	Mode	COMBINE_	1: _mcSubAxes		0: Addition
		MODE			1: Subtraction
Ratio Numerator Master	Master Axis Gear Ratio Numerator	UINT	Positive number	10000	Reserved
(Reserved)					
Ratio Denominator Master	Master Axis Gear Ratio Denominator	UINT	Positive number	10000	Reserved
(Reserved)					

Name	Meaning	Data type	Valid range	Default	Description
Ratio Numerator Auxiliary	Auxiliary Axis Gear Ratio Numerator	UINT	Positive number	10000	Reserved
Ratio Denominator Auxiliary (Reserved)	Auxiliary Axis Gear Ratio Denominator	UINT	Positive number	10000	Reserved
Reference TypeMaster	Master Axis Position Type Selection	_eMC_ REFERENCE_ TYPE	1: _mcFeedback 2: _mcLastestCommand	2*	Specify the position type of the master axis.  1: Actual position (value obtained in the same primary period)  2: Command position (value calculated in the same primary period)
Reference TypeAuxiliary	Auxiliary Axis Position Type Selection	_eMC_ REFERENCE_ TYPE	1: _mcFeedback 2: _mcLastestCommand	2*	Specify the position type of the auxiliary axis.  1: Actual position (value obtained in the same primary period)  2: Command position (value calculated in the same primary period)
BufferMode	Buffer Mode Selection	_eMC _BUFFER_ MODE	0: _mcAborting	0*	Specify the operation when executing more than one motion instruction.  O: Aborting

<sup>\*</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
InCombination	Axes Combined	BOOL	TRUE or FALSE	TRUE when axes are combined.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE	TRUE when the axis is being controlled.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
InCombination	When combining axes is started.	When Error changes to TRUE.  When CommandAborted changes to TRUE.
Busy	When Execute changes to TRUE.	When Error changes to TRUE.  When CommandAborted changes to TRUE.
Active	When the instruction is started.	When Error changes to TRUE.  When CommandAborted changes to TRUE.
CommandAborted	<ul> <li>When this instruction is aborted because another motion control instruction was executed with the Buffer Mode set to <i>Aborting</i>.</li> <li>When this instruction is canceled due to an error.</li> <li>When this instruction is executed while there is an error.</li> <li>When you start this instruction during MC_Stop instruction execution.</li> </ul>	<ul> <li>When Execute is TRUE and changes to FALSE.</li> <li>After one period when Execute is FALSE.</li> </ul>
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# **In-Out Variables**

Name	Meaning	Data type	Valid range	Description
Master	Master Axis	_sAXIS_REF		Specify the master axis.*
Auxiliary	Auxiliary Axis	_sAXIS_REF		Specify the auxiliary axis.*
Slave	Slave Axis	_sAXIS_REF		Specify the slave axis.*

<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are MC\_Axis\*\*\*.)



### **Precautions for Correct Use**

One of the following minor faults will occur if the different axes are not used for the master, slave, and auxiliary axes.

- Master and Slave Defined as Same Axis (error code 5436 hex)
- Master and Auxiliary Defined as Same Axis (error code 5437 hex)
- Auxiliary and Slave Defined as Same Axis (error code 548E hex)

### **Function**

The MC\_CombineAxes instruction starts combining axes when Execute changes to TRUE.



#### **Precautions for Safe Use**

Do not execute the MC\_SetPosition instruction for the *Master* (Master Axis) if you use this instruction. If the MC\_SetPosition instruction is executed for the *Master* (Master Axis), the *Slave* (Slave Axis) may follow the *Master* (Master Axis) quickly.


If you want to use the MC\_SetPosition instruction for the *Master* (Master Axis), disable the relationship between the *Master* (Master Axis) and *Slave* (Slave Axis) executing the instruction. Refer to *Precautions for Master and Auxiliary Axes in Synchronized Control* on page 1-7 for precautions on the master axis. This precaution also applies to *Auxiliary* (Auxiliary Axis) in the same way as for *Master* (Master Axis).

### **Instruction Details**

From the starting point, the relative value of the *Auxiliary* (Auxiliary Axis) position is added to or subtracted from the relative value of the *Master* (Master Axis) position and is output as a relative value for the *Slave* (Slave Axis) command position.


### CombineMode Set to \_mcAddAxes

Slave (Slave Axis) position = Master (Master Axis) position (relative position) + Auxiliary (Auxiliary Axis) position (relative position)



#### CombineMode Set to mcSubAxes

Slave (Slave Axis) position = Master (Master Axis) position (relative position) – Auxiliary (Auxiliary Axis) position (relative position)



- Adding or subtracting the position is performed as numerical operations without considering the Unit of Display for the axis in the axis parameters.
- Execute the MC\_Stop instruction to end this instruction.



#### **Precautions for Safe Use**

Depending on the values for the *Master* (Master Axis) and *Auxiliary* (Auxiliary Axis), the travel distance, velocity, and acceleration of the *Slave* (Slave Axis) can change rapidly. Use this setting with care.

### In-position Check

An in-position check is not performed for this instruction.

#### Override Factors

You cannot perform an MC SetOverride (Set Override Factors) override for this instruction.

#### ReferenceType (Position Type Selection)

You can select one of the following position types.

- \_mcFeedback: Value obtained in the same primary period
  The actual position of the master axis that was obtained in the same primary period is used.
- \_mcLatestCommand: Command position (value calculated in the same primary period)
  The command position of the master axis that was calculated in the same primary period is used.
  However, if \_mcLatestCommand is selected, the axis numbers of the master axis and auxiliary axis must be set lower than the axis number of the slave axis. If the axis numbers of the slave axis or auxiliary axis is lower than the axis number of the master axis, Error will change to TRUE. A Master/Slave Axis Numbers Not in Ascending Order error (error code: 5438 hex) will be output to ErrorID. There are no restrictions in the relationship of the axis numbers between the master axis and the auxiliary axis.

### Relationship between Axis Types and Position Types

The relationship between the axis types that you can monitor and position types that is monitored is shown below.


Avia Type	ReferenceType			
Axis Type	_mcFeedback	_mcLatestCommand		
Servo axis	OK	OK		
Encoder axis	OK	No*		
Virtual servo axis	OK	OK		
Virtual encoder axis	OK	No*		

<sup>\*</sup> A Position Type Selection Out of Range error (error code: 5430 hex) occurs when the instruction is executed.


# **Timing Charts**

- Busy (Executing) changes to TRUE at the same time as Execute changes to TRUE. Active (Controlling) changes to TRUE in the next period.
- InCombination (Axes Combined) changes to TRUE in the period where the combined output starts.
- If another instruction aborts this instruction, *CommandAborted* changes to TRUE and *Busy* (Executing), *Active* (Controlling), and *InCombination* (Axes Combined) change to FALSE.


### CombineMode Set to \_mcAddAxes



### CombineMode Set to \_mcSubAxes



#### When the Instruction Is Aborted



### **Re-execution of Motion Instructions**

This instruction cannot be re-executed.

A Motion Control Instruction Re-execution Disabled error (error code: 543B hex) occurs if re-execution is attempted.

# **Multi-execution of Motion Instructions**

For details on re-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

### Execution of Other Instructions during Instruction Execution


To use multi-execution of instructions for this instruction, specify the slave axis. When performing multi-execution of another instruction while this instruction is in execution, the following limits apply depending on *BufferMode* (Buffer Mode Selection).

• You can execute another instruction with the Buffer Mode set to *Aborting* during execution of this instruction. You cannot specify *Buffered* or a blending mode.

### **Errors**

### Timing Chart When Error Occurs

If an error occurs during instruction execution, *Error* will change to TRUE and the axis will stop. The axis decelerates to a stop at the maximum deceleration rate that is set in the axis parameters. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).






#### **Additional Information**


- This instruction is not affected by errors in the *Master* (Master Axis) or the *Auxiliary* (Auxiliary Axis).
- After the error is cleared and the *Master* (Master Axis) or the *Auxiliary* (Auxiliary Axis) is in motion, the *Slave* (Slave Axis) will resume the combined positioning operation. The *Master* (Master Axis) or the *Auxiliary* (Auxiliary Axis) are not affected if an error occurs for the slave axis during startup or execution of this instruction, but this instruction is aborted.

If a minor fault level error occurs during instruction execution, *CommandAborted* will change to TRUE and the axis will stop.

The axis decelerates to a stop at the maximum deceleration rate that is set in the axis parameters. You can find out the cause of the error by referring to the value output to the *MFalutLvl.Code* Axis Variable for the *Slave* (Slave Axis).



If you clear the error for this instruction, the instruction will not start until *Execute* changes to TRUE again.



### Error Codes

Refer to A-1 Error Codes for instruction errors.

# **MC\_Phasing**

The MC\_Phasing instruction shifts the phase of the master axis currently in synchronized control.

Instruction	Name	FB/FUN	Graphic expression	ST expression
MC_Phasing	Shift Master Axis Phase	FB	MC_Phasing_instance  MC_Phasing Master — Master — Slave — Slave — Slave — Done — PhaseShift — Busy — Acceleration — CommandAborted — Deceleration — Jerk — ErrorID — BufferMode	MC_Phasing_instance ( Master :=parameter, Slave :=parameter, Execute :=parameter, PhaseShift :=parameter, Velocity :=parameter, Acceleration :=parameter, Deceleration :=parameter, Jerk :=parameter, BufferMode :=parameter, Busy =>parameter, Busy =>parameter, Active =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorlD =>parameter);

# **Variables**

# Input Variables

Execute	BOOL	TOUE ENLOS		
		TRUE or FALSE	FALSE	The instruction is executed when Execute changes to TRUE.
Phase Shift Amount	LREAL	Negative number, positive number, or 0	0	Specify the master axis phase shift amount. The unit is command units.
Target Velocity	LREAL	Positive number	0	Specify the target velocity. The unit is command units/s.*1
Acceleration Rate	LREAL	Non-negative number	0	Specify the acceleration rate. The unit is command units/s <sup>2</sup> .* <sup>1</sup>
Deceleration Rate	LREAL	Non-negative number	0	Specify the deceleration rate. The unit is command units/s <sup>2</sup> .* <sup>1</sup>
Jerk	LREAL	Non-negative number	0	Specify the jerk. The unit is command units/s <sup>3</sup> .* <sup>1</sup>
Buffer Mode Selection	_eMC_BUFFER_ MODE	0: _mcAborting	0*2	Specify the operation when executing more than one motion instruction.  0: Aborting
	Amount  Target Velocity  Acceleration Rate  Deceleration Rate  Jerk  Buffer Mode	Amount  Target Velocity  Acceleration Rate  Deceleration LREAL  Deceleration LREAL  Jerk  LREAL  LREAL  Buffer ModeeMC_BUFFER_	Amount tive number, or 0  Target Velocity  Acceleration Rate  Deceleration Rate  Deceleration Rate  LREAL Non-negative number  Non-negative number  Non-negative number  LREAL Non-negative number  LREAL Non-negative number  Buffer ModeeMC_BUFFER_ 0: _mcAborting	Amount tive number, or 0  Target Velocity  Acceleration Rate  Deceleration Rate  Deceleration Rate  LREAL  Non-negative number  Non-negative number  O  LREAL  Non-negative number  O  Buffer Mode  LREAL  Non-negative number  O  Deceleration Rate  D  D  D  D  D  D  D  D  D  D  D  D  D

<sup>\*1</sup> Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.

<sup>\*2</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE	TRUE when the axis is being controlled.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

# Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When phase shift is completed.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
Active	When phase shift is started.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
CommandAborted	When this instruction is aborted because another motion control instruction was executed with the	When Execute is TRUE and changes to FALSE.
	Buffer Mode set to Aborting.	After one period when Execute is FALSE.
	When this instruction is canceled due to an error.	
	When this instruction is executed while there is an error.	
	When you start this instruction during MC_Stop instruction execution.	
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# **In-Out Variables**

Name	Meaning	Data type	Valid range	Description
Master	Master Axis	_sAXIS_REF		Specify the master axis.*
Slave	Slave Axis	_sAXIS_REF		Specify the slave axis.*

<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are MC\_Axis\*\*\*.)




### **Precautions for Correct Use**

If you specify the same axis for the master axis and slave axis, a Master and Slave Defined as Same Axis minor fault (error code 5436 hex) will occur.

### **Function**

- Except during execution of the MC\_CombineAxes instruction, if the MC\_Phasing instruction is executed when single-axis synchronized control is in progress, the phase of the master axis is shifted according to the settings of the *PhaseShift* (Phase Shift Amount), *Velocity* (Target Velocity), *Acceleration* (Acceleration Rate), and *Deceleration* (Deceleration Rate).
- The command current position and actual current position of the master axis do not change, and the
  relative shift between the command current position and actual current position of the master axis is
  taken as the phase of the master axis. The slave axis is synchronized to the shifted master axis
  phase.
- Done changes to TRUE when the PhaseShift (Phase Shift Amount) is reached.
- The shift is ended when the axis changed from single-axis synchronized control to another status. Even if the axis returns to single-axis synchronized control, the previous shift is not applied.
- You can shift the phase of the master axis for the following synchronization instructions: MC\_CamIn (Start Cam Operation), MC\_GearIn (Start Gear Operation), MC\_GearInPos (Positioning Gear Operation), and MC\_MoveLink (Synchronous Positioning).
- In the user program, place the MC\_Phasing instruction after synchronized control instructions as shown below.





#### **Precautions for Correct Use**

Refer to *Precautions for Master and Auxiliary Axes in Synchronized Control* on page 1-7 for precautions on the master axis.

# **Instruction Details**

This section describes the instruction in detail.

### Specifying Master (Master Axis) and Slave (Slave Axis)

Specify axes variable names to specify the axes for *Master* (Master Axis) and *Slave* (Slave Axis). An axis specification error will occur if you specify a *Master* (Master Axis) or *Slave* (Slave Axis) that is not *InSync* or *InGear* (Gear Ratio Achieved) state.

### PhaseShift (Phase Shift Amount)

Set the phase shift amount as viewed from the *Slave* (Slave Axis) as the *PhaseShift* (Phase Shift Amount). Specify the phase shift about as a relative value.

# Velocity (Target Velocity), Acceleration (Acceleration Rate), Deceleration (Deceleration Rate), and Jerk


Set *Velocity, Acceleration*, *Deceleration*, and *Jerk* to specify the target velocity (shift velocity), acceleration rate, deceleration rate, and jerk for the phase shift amount.

The target velocity (shift velocity) as viewed from the *Slave* (Slave Axis) is the velocity relative to the *Master* (Master Axis) velocity.

The target velocity (shift velocity) of the *Master* (Master Axis) as viewed from the *Slave* (Slave Axis) is shown below as specified by the phase shift amount, acceleration rate, deceleration rate, and jerk.

### **Example: Master Axis Phase Shift for an Electronic Cam**

The interpolation velocity as viewed from the *Slave* (Slave Axis) is the velocity relative to the *Master* (Master Axis) velocity.



- If you set the phase shift amount to 0, the phase shift amount of the *Master* (Master Axis) will be 0 and the instruction ends normally.
- If you set the target velocity (shift velocity) to 0, a *Slave* (Slave Axis) error will occur because the value is out of range.
- The sum of the specified target velocity (shift velocity) and the *Master* (Master Axis) velocity can exceed the maximum velocity of the *Master* (Master Axis).



### **Additional Information**

Error detection for the results of the MC\_Phasing instruction is performed for the operation of the synchronized *Slave* (Slave Axis). Therefore, error detection is not performed for the settings of the *Velocity* (Target Velocity), *Acceleration* (Acceleration Rate), and *Deceleration* (Deceleration Rate) variables when the MC\_Phasing instruction is executed.

### BufferMode (Buffer Mode Selection)

*BufferMode* specifies how to join the axis motions for this instruction and the previous instruction. There is currently only the following setting.

<b>Buffer Mode Selection</b>	Description
Aborting	If this instruction is re-executed, the shift for the instruction is started immediately.

Reversing operation for multi-execution of instructions is performed according to the Operation Selection at Reversing setting for the master axis.

For details on *BufferMode* (Buffer Mode Selection), refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

### In-position Check

When the phase shift operation is completed, phase shift output is ended and an in-position check is not performed.

### **Re-execution of Motion Instructions**

If you re-execute the instruction during instruction execution, you can change the *PhaseShift* (Phase Shift Amount), *Velocity* (Target Velocity), *Acceleration* (Acceleration Rate), and *Deceleration* (Deceleration Rate). They are changed in the same way as for relative positioning.

### **Multi-execution of Motion Instructions**

For details on re-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

### Execution of Other Instructions during Instruction Execution

You can execute another instruction with the Buffer Mode set to *Aborting* for the *Slave* (Slave Axis) during execution of this instruction.

You cannot specify Buffered Mode or blending.

### Multi-execution of MC\_Phasing

You can execute the MC\_Phasing instruction even if the MC\_Phasing instruction is already in execution for the specified slave axis.


# **Error**

If an error occurs during instruction execution, *Error* will change to TRUE and the slave axis will stop. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code). *CommandAborted* of the MC\_Phasing (Shift Master Axis Phase) instruction changes to TRUE when the *Slave* (Slave Axis) is released from synchronization due to an error.

The error state of the master axis does not affect the operation of this instruction.

### Timing Chart When Error Occurs

MC\_CamIn (Start Cam Operation) Instruction



### Error Codes

Refer to A-1 Error Codes for instruction errors.

# MC\_TorqueControl

The MC\_TorqueControl instruction uses the Torque Control Mode of the Servo Drive to control the torque.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_TorqueControl	Torque Control	FB	MC_TorqueControl_instance  MC_TorqueControl Axis Axis Execute InTorque Torque Busy TorqueRamp Active Velocity CommandAborted Direction Error BufferMode ErrorID	MC_TorqueControl_instance ( Axis :=parameter, Execute :=parameter, Torque :=parameter, TorqueRamp :=parameter, Velocity :=parameter, Direction :=parameter, BufferMode :=parameter, InTrque =>parameter, Busy =>parameter, Active =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorID =>parameter );

# **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when Execute changes to TRUE.
Torque	Target Torque	LREAL	0 to 1000.0	300.0	Specify the target torque to output to the Servo Drive in increments of 0.1%. Specify a percentage of the rated torque, i.e., the rated torque is 100.0%.*1 The unit is %.
TorqueRamp	Torque Ramp	LREAL	Non-negative number	0	Specify the change rate of torque from the current value to the target torque. The unit is %/s.
Velocity	Velocity Limit	LREAL	Non-negative number	0	Specify the target velocity. The unit is command units/s.*2
Direction	Direction	_eMC_ DIRECTION	0: _mcPositiveDirection 2: _mcNegativeDirection	0*3	Specify the direction of the target torque.
			_		0: Positive direction
					2: Negative direction
BufferMode	Buffer Mode Selection	_eMC_BUFFER _ MODE	0: _mcAborting 1: _mcBuffered	0*3	Specify the operation when executing more than one motion instruction.
					0: Aborting
					1: Buffered

<sup>\*1</sup> If a value that is higher than 1,000.0% is specified, it will be treated as 1,000.0%. If a negative value is specified, it will be treated as 0.0%.

<sup>\*2</sup> Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.

\*3 The default value for an enumeration variable is actually not the number, but the enumerator.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
InTorque	Target Torque Reached	BOOL	TRUE or FALSE	TRUE when the target torque is reached.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE	TRUE when the axis is being controlled.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

# Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
InTorque	When target torque is output.	When Error changes to TRUE. When CommandAborted changes to TRUE. When the instruction is re-executed and the target torque is changed.
Busy	When Execute changes to TRUE.	When Error changes to TRUE.     When CommandAborted changes to TRUE.
Active	When output of the torque command value starts.	When Error changes to TRUE.     When CommandAborted changes to TRUE.
CommandAborted	<ul> <li>When this instruction is aborted because another motion control instruction was executed with the Buffer Mode set to <i>Aborting</i>.</li> <li>When this instruction is canceled due to an error.</li> <li>When this instruction is executed while there is an error.</li> <li>When you start this instruction during MC_Stop instruction execution.</li> </ul>	<ul> <li>When Execute is TRUE and changes to FALSE.</li> <li>After one period when Execute is FALSE.</li> </ul>
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# **In-Out Variables**

Name	Meaning	Data type	Valid range	Description
Axis	Axis	_sAXIS_REF		Specify the axis.*

<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are MC\_Axis\*\*\*.)

### **Function**

- The MC\_TorqueControl instruction controls the output torque of the Servomotor by directly specifying the torque command value.
- Set the target torque in increments of 0.1%. If the second decimal place is specified, it will be rounded off.
- Use MC\_Stop instruction to stop the execution of this instruction.
- The Torque Control Mode of the Servo Drive is used to perform torque control.
- The previous Control Mode is maintained until it is changed.

**Example:** Changing from position control to torque control: Position control is performed until the Servo Drive changes to torque control.

Changing from torque control to position control: Torque control is performed until the Servo Drive changes to position control.

### Mapping Data Objects

To use the MC\_TorqueControl (Torque Control) instruction, map the following object data in the Detailed Settings Area of the Axis Basic Settings Display of the Sysmac Studio.

- Target torque (6071 hex)
- Modes of operation (6060 hex)
- Torque actual value (6077 hex)
- Modes of operation display (6061 hex)

If even one of the required objects is not set, a Process Data Object Setting Missing error (error code 3461 hex) occurs.

For details on mapping data objects, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

### **Instruction Details**

This section describes the instruction in detail.


### Specifying Axis


Axis specifies the axis for torque control.

### TorqueRamp

Specify the slope from the currently specified command torque until the target torque is output.

### **Example 1: Direction = Positive**





**Example 2: Direction = Negative** 



### **Precautions for Correct Use**

Set the target torque so that the maximum torque of the motor is not exceeded. The operation that is performed when the maximum torque of the motor is exceeded depends on the Servo Drive.

### Velocity (Velocity Limit)

*Velocity* limits the maximum velocity of the axis during torque control. When the axis velocity reaches this velocity limit, the Servo Drive reduces the torque to reduce the axis velocity. The velocity limit function uses the Servo Drive function.

For details, refer to information on the torque control function in the Servo Drive manual.



#### **Precautions for Correct Use**

- The axis velocity increases faster during torque control. Make sure that you set Velocity (velocity limit) for safety.
- When you use an OMRON G5-series Servo Drive, set the Velocity Limit Selection (3317 hex)
  of the Servo Drive to 1 (velocity limit value via EtherCAT communications). Otherwise, the
  velocity limit is not affected. Also, the axis does not stop even if the limit input signal turns ON.
- Process data 607F hex is used for the velocity limit value. When you use an OMRON G5-series Servo Drive, set the advanced settings in the Axis Parameter Settings of the Sysmac Studio to use the Velocity Limit Value (607F hex). To use a velocity limit with a servo drive from another manufacturer, refer to the manual for the servo drive.

### Direction

*Direction* specifies the direction to output the target torque. If you want to output torque in the positive direction of the axis, set the positive direction. If you want to output torque to the negative direction of the axis, set the negative direction.

### BufferMode (Buffer Mode Selection)

*BufferMode* specifies how to join the axis motions for this instruction and the previous instruction. There are two possible settings.

Buffer Mode Selection	Description
Aborting	Aborts the instruction being executed and switches to this instruction.
Buffered	Buffers this instruction and executes it automatically after the current instruction is completed.

For details on *BufferMode* (Buffer Mode Selection), refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

### Stopping Axes during Torque Control

If MC\_Stop is executed during MC\_TorqueControl execution for an OMRON G5-series Servo Drive, the deceleration rate that is specified for the MC\_Stop instruction is not used and an immediate stop is performed.

An immediate stop is performed even for errors that normally result in deceleration stops.

### Command Position and Actual Position during Torque Control

The following current positions are given in the system-defined variables for motion control during torque control for this instruction.

Actual current position: Contains the value returned by the Servo Drive multiplied by the

gear ratio.

Command current position: Contains the actual current position from the previous period.

### Applicable Axes and Execution Condition

- For a servo axis, this instruction is ready for execution as soon as *Enable* for the MC\_Power (Power Servo) instruction changes to TRUE (Servo ON).
- A virtual servo axis will acknowledge this instruction at any time. However, processing to switch the Control Mode of the Servo Drive is not performed.
- An error occurs if the instruction is executed for an encoder or virtual encoder axis.

acknowledged from the MC Function Module when the Servo is OFF.

### Operation When Servo Turns OFF

Processing to change to CSP Mode is performed by the MC Function Module when the Status output variable from the MC\_Power (Power Servo) instruction changes to FALSE. However, for an OMRON G5-series Servo Drive, commands to change the Controller Mode are not

#### Axis Variable Status

Status. Continuous (Continuous Motion) in the Axis Variable status changes to TRUE. Also, CST (Cyclic Synchronous Torque (CST) Control Mode) in *DrvStatus* (Servo Drive Status) in the Axis Variable changes to TRUE.

#### Home Status

Home remains defined.

### Software Limits

The software limits are applied.

They are applied even if one of the following is selected in the axis parameter: Deceleration stopping enabled for command position or Immediate stopping enabled for command position (stop using remaining pulses).

### When Count Mode Is Set to Linear Mode

The operation for underflows and overflows is the same as for operations that do not have target positions.

### Operation at Reversing


If re-execution is performed and the torque command value is reversed, operation is performed with *TorqueRamp* from this command and not with the setting of the Operation Selection at Reversing axis parameter.

The operation for reversing for multi-execution of instructions is as follows:

- If the command position reverses for multi-execution of an instruction that uses CSP during execution of this instructions, the operation at reversing is performed according to the Operation Selection at Reversing axis parameter.
- If the torque command value reverses when multi-execution of this instruction is performed during execution of an instruction that uses CSP or CSV, the torque command reverses according to *TorqueRamp*.
- If the torque command value reverses when multi-execution of this instruction is performed during execution of this instruction, the torque command reverses according to *TorqueRamp*.

# **Timing Charts**

# **Starting and Stopping the Instruction**



Torque

### **Instruction Execution to Abort Immediately Preceding Operation**

The following timing chart shows an application in which the axis stops and pressing is performed while this instruction is in execution.


Position Control Instruction (First Instruction) Execute Done Busy Active CommandAborted MC\_TorqueControl Instruction (Second Instruction) Execute InTorque Busy Active CommandAborted Current velocity Position control Torque control Velocity Axis current When the axis presses the workpiece velocity Time Position control Torque control Torque Current torque

Command torque

Time

### Instruction Execution for Buffered during Immediately Preceding Operation

The following timing chart shows an application in which the axis stops and pressing is performed while this instruction is in execution.



### Changing the Control Mode

- If you execute the MC\_TorqueControl instruction while a position control instruction, such as the MC\_MoveAbsolute (Absolute Positioning) or MC\_MoveRelative (Relative Positioning) instruction, is in execution, the operation depends on the setting of the *BufferMode* (Buffer Mode Selection) of the MC\_TorqueControl instruction.
  - If *BufferMode* is set to *Aborting*, the Control Mode changes to Torque Control as soon as the instruction is executed. If the Buffer Mode is set to *Buffered*, the Control Mode changes to Torque Control after the previous operation is completed.
- If the MC\_TorqueControl instruction is aborted by other instructions such as MC\_MoveAbsolute (Absolute Positioning), or if an axis error occurs, the Control Mode changes to Position Control at that point.
- Active (Controlling) changes when the instruction is executed, but it takes several periods for the Control Mode in the Servo Drive to change. The time that is required for the Control Mode to change depends on the Servo Drive.

### **Criteria for Changing the Control Mode**

When you stop an axis for an OMRON G5-series Servo Drive, the MC Function Module sets the Velocity Limit Value (607F hex) to 0. The Control Mode is changed to CSP Mode when the following criterion is met for three consecutive primary period tasks after that.

Actual current velocity ≤ Maximum velocity × 0.1

With a servo drive from another manufacturer, the Control Mode of the Servo Drive changes from CST to CSP Mode and the Servo is turned ON at the actual current position when the mode changes.

### **Failure to Change the Control Mode**

If the Servo Drive does not complete switching the Control Mode within 1 second after a Control Mode switch command is sent from the MC Function Module, an Error in Changing Servo Drive Control Mode (error code: 7439 hex) occurs and the Servo is turned OFF, i.e., a free-run stop occurs

For details on the Error in Changing Servo Drive Control Mode (error code: 7439 hex), refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

If the criteria for changing is not met within 10 seconds after the Velocity Limit Value is set to 0, the Servo is turned OFF in the same was as given above.

### **Operation Examples for Changing the Control Mode**


The relationship between the command torque and command velocity until the Control Mode changes is described in the following examples where the Control Mode is changed during axis operation.




#### **Precautions for Correct Use**

An error will occur in some Servo Drives if the Control Mode in the Servo Drive changes during axis motion.

### Changing from Position Control to Torque Control



### **Changing from Torque Control to Position Control**



# **Re-execution of Motion Instructions**

You can change the operation of the instruction if you change the input parameter during torque control and then change *Execute* to TRUE again. You can change the input variables *Torque* (Target Torque), *TorqueRamp*, and *Velocity* (Velocity Limit) by re-executing the motion control instruction. When the motion control instruction is re-executed to change *Torque* (Target Torque), *InTorque* (Target Torque Reached) operates for the new target torque that was set at re-execution. For details on re-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

### **Multi-execution of Motion Instructions**

For details on re-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

### Execution during Execution of Other Instructions

You can switch to this instruction or buffer this instruction if you execute it during execution of another instruction. You can buffer one instruction per axis. Specify the operation of this instruction by using *BufferMode* (Buffer Mode Selection) for multi-execution of instructions.

Buffer Mode Selection	Description		
Aborting	Aborts the instruction being executed and switches to this instruction.		
Buffered	Buffers this instruction and executes it automatically after the current instruction is completed.		


For details on *BufferMode* (Buffer Mode Selection), refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

### Execution of Other Instructions during Instruction Execution

If another instruction is executed during execution of this instruction, the *BufferMode* input variable to the other instruction must be set to *Aborting* or *Buffered*.

# **Errors**

If an error occurs during instruction execution, *Error* will change to TRUE and the axis will stop. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).



### Error Codes

Refer to A-1 Error Codes for instruction errors.

# MC\_SetTorqueLimit

The MC\_SetTorqueLimit instruction limits the torque output from the Servo Drive through the torque limit function of the Servo Drive.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_SetTorqueLimit	Set Torque Limit	FB	MC_SetTorqueLimit_instance  MC_SetTorqueLimit Axis Axis Axis Enable Enabled PositiveEnable Busy PositiveValue Error NegativeEnable ErrorID NegativeValue	MC_SetTorqueLimit_instance ( Axis := parameter, Enable := parameter, PositiveEnable := parameter, PositiveValue := parameter, NegativeEnable := parameter, NegativeValue := parameter, Enabled => parameter, Enabled => parameter, Error => parameter, Error => parameter );

# **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Enable	Enable	BOOL	TRUE or FALSE	FALSE	The instruction is executed when Enable is TRUE.
PositiveEnable	Positive Direction Enable	BOOL	TRUE or FALSE	FALSE	TRUE: Enables the positive torque limit. FALSE: Disables the positive torque limit.
PositiveValue	Positive Torque Limit	LREAL	0.1 to 1000.0 or 0.0	300.0	Set the torque limit in the positive direction in increments of 0.1%. If a value that exceeds the Maximum Positive Torque Limit axis parameter, the positive torque will be the Maximum Positive Torque Limit.  The value will be 0 if 0 or a negative value is specified.
NegativeEnable	Negative Direction Enable	BOOL	TRUE or FALSE	FALSE	TRUE: Enables the negative torque limit.  FALSE: Disables the negative torque limit.
NegativeValue	Negative Torque Limit	LREAL	0.1 to 1000.0 or 0.0	300.0	Set the torque limit in the negative direction in increments of 0.1%. If a value that exceeds the Maximum Negative Torque Limit axis parameter, the negative torque will be the Maximum Negative Torque Limit.  The value will be 0 if 0 or a negative value is specified.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Enabled	Enable	BOOL	TRUE or FALSE	TRUE when control is in progress.*1
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*2	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*1</sup> Enabled indicates the status of the instruction. It does not indicate the status of torque control by the Servo Drive.

### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Enabled	<ul> <li>When Enable changes to TRUE.</li> <li>When MC_Power is being executed.</li> </ul>	<ul> <li>One period after <i>Enable</i> changes to FALSE.</li> <li>When <i>Error</i> changes to TRUE.</li> <li>When <i>Enable</i> for MC_Power instruction changes to FALSE.</li> </ul>
Busy	When Enable changes to TRUE.	<ul><li>When <i>Error</i> changes to TRUE.</li><li>When <i>Enable</i> changes to FALSE.</li></ul>
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# In-Out Variables

Name	Meaning	Data type	Valid range	Description
Axis	Axis	_sAXIS_REF		Specify the axis.*

<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are MC\_Axis\*\*\*.)

### **Function**

- The MC\_SetTorqueLimit instruction sets the torque limits that are used by the Servo Drive.
- When Enable is TRUE and PositiveEnable (Positive Direction Enable) changes to TRUE, control is performed with PositiveValue (Positive Torque Limit).
   When Enable is TRUE and NegativeEnable (Negative Direction Enable) changes to TRUE, control is performed with NegativeValue (Negative Torque Limit).
- When *PositiveEnable* (Positive Direction Enable) changes to FALSE, the value of the Maximum Positive Torque Limit is set in the Servo Drive.
  - When *NegativeEnable* (Negative Direction Enable) changes to FALSE, the value of the Maximum Negative Torque Limit is set in the Servo Drive.
- When *Enable* to this instruction changes to FALSE, the values of the Maximum Positive Torque Limit and Maximum Negative Torque Limit are set in the Servo Drive. At the same time, *Busy* (Executing) and *Enabled* change to FALSE.
- The torque limits are set as a percentage of the motor torque in 0.1% increments. If the second decimal place is specified, it will be rounded off.

<sup>\*2</sup> Refer to A-1 Error Codes.



#### **Precautions for Correct Use**

Set the Maximum Positive Torque Limit and Maximum Negative Torque Limit axis parameters to the upper limits of torque control for your Servo Drive.

### Mapping Data Objects

To use the MC\_SetTorqueLimit instruction, map the following object data in the Detailed Settings Area of the Axis Basic Settings Display of the Sysmac Studio.

- Positive torque limit value (60E0 hex)
- Negative torque limit value (60E1 hex)

If even one of the required objects is not set, a Process Data Object Setting Missing error (error code 3461 hex) occurs.



### **Precautions for Correct Use**

- If you use a servo drive from a different manufacturer, set the servo drive so that the positive torque limit value (PDO 60E0 hex) and the negative torque limit value (PDO 60E1 hex) are used as the torque limits.
  - Refer to the manual for your servo drive for the setting procedure.
- This instruction cannot be used for servo drives from other manufacturers unless the positive torque limit value and the negative torque limit value can be mapped to PDOs.
   If they cannot be set to PDOs, use the support software of the manufacturer or SDO communications to set the torque limits.

For details on mapping data objects, refer to 2-3 PDO Mapping and to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

### Changing the Input Parameters

The following input parameters are continuously updated as long as *Enable* is TRUE.

- PositiveEnable (Positive Direction Enable)
- NegativeEnable (Negative Direction Enable)
- PositiveValue (Positive Torque Limit)
- Negative Value (Negative Torque Limit)

### Relation to Holding Operation of the MC\_Home Instruction for OMRON G5series Servo Drives

Torque limits that are set in the Servo Drive in advance are used for the Proximity Reverse Turn/Holding Time (12) or No Home Proximity Input/Holding Home Input (13) Homing Operation Modes to automatically start torque control in the holding direction.



#### **Precautions for Correct Use**

The automatic torque limit function of the MC\_Home instruction is not used for servo drives from other manufacturers.

Use the MC\_SetTorqueLimit instruction, SDO communications, or the Support Software for the Servo Drive to set suitable values.



### **Additional Information**

- The torque limits are continued even after a normal completion of homing.
- The torque limits are automatically released when an instruction that moves the axis in the opposite direction is executed.

For details on homing, refer to MC Home on page 3-16.

### Settings for OMRON G5-series Servo Drives

To use this instruction, you must use the Sysmac Studio of the servo drive to set the Torque Limit Selection (3521 hex) in the G5-series Servo Drive.

- Set the Torque Limit Selection to 6 to apply a torque limit in the home input detection direction during the holding operation for homing and to use the torque limit directions and values that are set with this instruction for other operation.
  - In that case, the values of the input variables to this instruction are ignored during the holding operation for homing.
- If the Torque Limit Selection to 4, the values of the input variables to this instruction are always used. You must set torque limits that are suitable for both for the holding operation during homing and for other operations.

		Torque Limit Selection (3521 hex)			
		6 (recommended)	4		
Positive Torque	Homing	Torque Limit 3 (3525 hex) is used.	The smaller of the PositiveValue		
Limit	Operations other than Homing	The smaller of the <i>PositiveValue</i> (Positive Torque Limit) for this instruction and Torque Limit 1 (3013 hex) is used.	(Positive Torque Limit) for this instruction and Torque Limit 1 (3013 hex) is used.		
Negative Torque	Homing*	Torque Limit 4 (3526 hex) is used.	The smaller of the NegativeValue		
Limit	Operations other than Homing	The smaller of the NegativeValue (Negative Torque Limit) for this instruction and Torque Limit 2 (3522 hex) is used.	(Negative Torque Limit) for this instruction and Torque Limit 2 (3522 hex) is used.		

<sup>\*</sup> Until the torque limit is automatically released.

Refer to the *G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications User's Manual* (Cat. No. 1576) for details.

### Relationship to the MC\_TorqueControl Instruction

The MC\_SetTorqueLimit and the MC\_TorqueControl instructions can be used together.

### Axes in Axes Groups

This instruction can be used for an axis in an enabled axes group.

### Relation to CPU Unit Operating Modes

The values that are set with this instruction in RUN mode are also used after the operating mode changes to PROGRAM mode.

### Applicable Axes and Execution Condition

You can use this instruction for a servo axis.
 The status of the *Enabled* output variable from this instruction, however, depends on the status of the Servo.

	Servo ON	Servo OFF
Status of Enabled	TRUE	FALSE*

<sup>\*</sup> If Enabled from this instruction is FALSE, the torque limits do not function on the Servo Drive.

- This instruction is acknowledged for a virtual servo axis, but torque is not limited.
- An error occurs if the instruction is executed for an encoder or virtual encoder axis.


### Axis Variable Status (Servo Drive Status)

When the internal limit function in the Servo Drive is in operation, *ILA* (Drive Internal Limiting) in the *DrvStatus* (Servo Drive Status) in the Axis Variable is TRUE.

This variable gives an OR of the following four: torque limits, velocity limit, drive prohibit inputs, and software limits.

# **Timing Charts**

The following chart shows the timing of the torque limits.



### **Re-execution of Motion Control Instructions**

You cannot re-execute motion instructions with Enable inputs.

### **Multi-execution of Motion Control Instructions**

For details on re-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

### Multi-execution of MC\_SetTorqueLimit Instructions

If an instance of this instruction is executed during execution of another instance, the instance that is executed last takes priority.

Enabled will be TRUE for both instructions.


NJ-series Motion Control Instructions Reference Manual (W508)

### **Errors**

If an error occurs during instruction execution, *Error* will change to TRUE and the axis will stop. You can find out the cause of the error by referring to the value output to *ErrorID* (Error Code).

### • Timing Chart When Error Occurs





### Error Codes

Refer to A-1 Error Codes for instruction errors.

# MC\_ZoneSwitch

The MC\_ZoneSwitch instruction determines if the command current position or actual current position of an axis is within a specified zone.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_ZoneSwitch	Zone Monitor	FB	MC_ZoneSwitch_instance  MC_ZoneSwitch Axis Axis Enabled FirstPosition InZone LastPosition Busy ReferenceType Error ErrorID	MC_ZoneSwitch_instance ( Axis :=parameter, Enable :=parameter, FirstPosition :=parameter, LastPosition :=parameter, ReferenceType :=parameter, Enabled =>parameter, InZone =>parameter, Busy =>parameter, Error =>parameter, ErrorlD =>parameter );

# **Variables**

# **Input Variables**

Name	Meaning	Data type	Valid range	Default	Description
Enable	Enable	BOOL	TRUE or FALSE	FALSE	The instruction is executed while <i>Enable</i> is TRUE.
FirstPosition	First Position	LREAL	Negative number, positive number, or 0	0	Specify the first position of the zone range.*1 The unit is command units.*2
LastPosition	Last Position	LREAL	Negative number, positive number, or 0	0	Specify the last position of the zone range.*3 The unit is command units.*1
RererenceType	Position Type Selection	_eMC_REFERENCE _TYPE	0: _mcCommand 1: _mcFeedback	0*4	Specify the axis information to monitor.  0: Command position (value calculated in the previous primary period)  1: Actual position (value obtained in the same primary period)

<sup>\*1</sup> Set a value that is smaller than the last position.

<sup>\*2</sup> Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.

<sup>\*3</sup> Set a value that is larger than the first position.

<sup>\*4</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Enabled	Enable	BOOL	TRUE or FALSE	TRUE while the axis is being controlled.
InZone	In Zone	BOOL	TRUE or FALSE	TRUE when the axes position is within the zone.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

# Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Enabled	When Enable changes to TRUE.	When Enable changes to FALSE.
InZone	When the zone is entered.	When the zone is exited.
		When Enable changes to FALSE.
Busy	When Enable changes to TRUE.	When Error changes to TRUE.
		When Enable changes to FALSE.
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# In-Out Variables

Name	Meaning	Data type	Valid range	Description
Axis	Axis	_sAXIS_REF		Specify the axis.*

<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are MC\_Axis\*\*\*.)

### **Function**

- If the axis command position or actual current position is above the *FirstPosition* and below the *Last Position* (i.e., if it is in the specified zone) when *Enable* of this instruction is TRUE, the output variable *InZone* will change to TRUE.
  - You can use *ReferenceType* (Position Type Selection) to set either the command position or actual position as the axis information to monitor.
- You can perform zone monitoring for any axis type.
- If FirstPosition or LastPosition is changed while Enable is TRUE, the new value is applied in the period in which it is changed.
- You can set multiple zones for one axis, and these zones can overlap. You can also set zones outside
  the software limits.



#### **Precautions for Correct Use**


If *FirstPosition* or *LastPosition* contains a non-terminating decimal number, e.g., resulting from division, error may cause unexpected processing results.

### **Instruction Details**

Set the *FirstPosition* and *LastPosition* so that the following relationships are established for the Counter Mode. An error occurs if the relationship is not established.

#### Linear Mode

Set FirstPosition to the same value or a smaller value than LastPosition.




### Rotary Mode

In Rotary Mode, there is a difference depending on whether the ring counter includes the maximum/minimum position.


### When Maximum/Minimum Position Is Not Included

Set FirstPosition to the same value or a smaller value than LastPosition.



### When Maximum/Minimum Position Is Included

Set FirstPosition to a larger value than LastPosition.



### ReferenceType (Position Type Selection)

You can select one of the following position types.

\_mcCommand: Command position (value calculated in the previous primary period)
 The master axis command position that was calculated in the previous primary period is used for the current period.

The command value that was calculated for the master axis in the last primary period is used to calculate the command position of the slave axis in the current period.

• \_mcFeedback: Value obtained in the same primary period
The actual position of the master axis that was obtained in the same primary period is used.

### Relationship between Axis Types and Position Types


The relationship between the axis types that you can monitor and position types that is monitored is shown below.

Axis Type	ReferenceType				
Axis Type	_mcCommand	_mcFeedback			
Servo axis	OK	OK			
Encoder axis	No*	ОК			
Virtual servo axis	OK	OK			
Virtual encoder axis	No*	ОК			


<sup>\*</sup> A Position Type Selection Out of Range error (error code: 5430 hex) occurs when the instruction is executed.

# **Timing Charts**

 When the Zone Is Entered during Operation or When Enable Changes to FALSE Within the Zone



### When Inside the Zone before the Instruction Is Executed and Then the Zone Is Exited



### **Re-execution of Motion Instructions**

You cannot re-execute enable-type motion instructions.


### **Multi-execution of Motion Instructions**

This instruction is executed independently from other instructions. The restrictions for multi-execution of motion instructions do not apply. For details on re-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

### **Errors**

If this instruction cannot be executed, an error occurs and *Error* of this instruction changes to TRUE. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).

### • Timing Chart When Error Occurs



### Error Codes

Refer to A-1 Error Codes for instruction errors.

# MC\_TouchProbe

The MC\_TouchProbe instruction records the position of an axis when a trigger signal occurs.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_TouchProbe	Enable External Latch	FB	MC_TouchProbe_instance  MC_TouchProbe  Axis	MC_TouchProbe_instance ( Axis := parameter, TriggerInput := parameter, TriggerVariable := parameter, Execute := parameter, WindowOnly := parameter, FirstPosition := parameter, LastPosition := parameter, ReferenceType := parameter, StopMode := parameter, Done => parameter, Busy => parameter, RecordedPosition => parameter, CommandAborted => parameter, Error => parameter, ErrorID => parameter);

# **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Execute</i> changes to TRUE.
WindowOnly	Window Only	BOOL	TRUE or FALSE	FALSE	Specify whether to enable or disable the window mask.
FirstPosition	First Position	LREAL	Negative number, positive number, or 0	0	Specify the position to start accepting the trigger. Use the type of position that is specified in <i>ReferenceType</i> (Position Type Selection).*1  The unit is command units.*2
LastPosition	Last Position	LREAL	Negative number, positive number, or 0	0	Specify the position to stop accepting the trigger. Use the type of position that is specified in <i>ReferenceType</i> (Position Type Selection).*1 The unit is command units.*2
ReferenceType (Reserved)	Position Type Selection	_eMC_ REFERENCE_ TYPE	1: _mcFeedback	1*3	(Reserved)
StopMode	Stop Mode	_eMC_STOP_ MODE	1: _mcImmediateStop 4: _mcNonStop	4*3	Specify the stopping method.  1: Perform an immediate stop  4: Do not stop

<sup>\*1</sup> Refer to WindowOnly on page 3-319 for details.

- \*2 Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.
- \*3 The default value for an enumeration variable is actually not the number, but the enumerator.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
RecordedPosition	Latched Position	LREAL	Negative number, positive number, or 0	Contains the latched position. The unit is in command units.*1
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*2	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*1</sup> Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.

<sup>\*2</sup> Refer to A-1 Error Codes.

# Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	<ul> <li>When the latched position is recorded and the instruction is completed after the trigger signal occurs.</li> <li>If stopping is specified, when the axis stops at the latched position after the latched position is recorded and the instruction is completed after the trigger signal occurs.</li> </ul>	<ul> <li>When Execute is TRUE and changes to FALSE.</li> <li>After one period when Execute is FALSE.</li> </ul>
Busy	When Execute changes to TRUE.	<ul> <li>When Done changes to TRUE.</li> <li>When Error changes to TRUE.</li> <li>When CommandAborted changes to TRUE.</li> </ul>
CommandAborted	<ul> <li>When this instruction is aborted because another motion control instruction was executed with the Buffer Mode set to Aborting.</li> <li>When this instruction is canceled due to an error.</li> <li>If StopMode is set tomcImmediateStop, when a change is made to a mode other than CSP Mode during execution.</li> <li>When the slave is disconnected.</li> <li>When a slave communications error occurs (except during process data communications).</li> <li>When the MC_AbortTrigger instruction is executed.</li> </ul>	When Execute is TRUE and changes to FALSE.     After one period when Execute is FALSE.
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# In-Out Variables

Name	Meaning	Data type	Valid range	Description
Axis	Axis	_sAXIS_REF		Specify the axis.*1
TriggerInput	Trigger Input Condition	_sTRIGGER_REF		Set the trigger condition.*2
TriggerVariable	Trigger Variable	BOOL	TRUE or FALSE	Specify a trigger input variable when the Controller Mode is specified with a trigger condition.

<sup>\*1</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are *MC\_Axis*\*\*\*.)

<sup>\*2</sup> Define a user-defined variable with a data type of \_sTRIGGER\_REF.

### \_sTRIGGER\_REF

Name	Meaning	Data type	Valid range	Function
Mode	Mode	_eMC_TRIGGER_	0: _mcDrive	Specify the trigger mode.
		MODE	1: _mcController	0: Drive Mode
				1: Controller Mode
LatchID	Latch ID	_eMC_TRIGGER_	0: _mcLatch1	Specify which of the two latch
	Selection	LATCH_ID	1: _mcLatch2	functions to use.
				0: Latch 1
				1: Latch 2
InputDrive	Trigger Input	_eMC_TRIGGER_	0: _mcEncoderMark	Specify the Servo Drive trigger
	Signal	INPUT_DRIVE	1: _mcEXT	signal to use in Drive Mode.
				0: Z-phase signal
				1: External input

### **Function**

- Latching is used to control positioning based on the point where a trigger signal occurs, such as a signal from a sensor input. The position of the axis is recorded (i.e., latched) when the trigger signal occurs.
- The position of the axis that is specified with Axis is output to *RecordedPosition* (Latched Position) according to the trigger settings.
  - As trigger settings, you can specify *TriggerInput* (Trigger Input Condition), *WindowOnly, FirstPosition*, *LastPosition*, and *StopMode*.
- The output value of *RecordedPosition* (Latched Position) is held until the axis position is recorded again by the same *MC\_TouchProbe* (Enable External Latch) instance.

### Mapping Data Objects

You must map the following object data when the MC\_TouchProbe (Enable External Latch) instruction is executed with *Mode* set to Drive Mode. Mapping is performed in the Detailed Setting Area of the Axis Basic Settings Display of the Sysmac Studio.

### **Axes Type Set to Servo Axis**

- Touch probe function (60B8 hex)
- Touch probe status (60B9 hex)
- Touch probe pos1 pos value (60BA hex)
- Touch probe pos2 pos value (60BC hex)

### **Axes Type Set to Encoder Axis**

- Touch probe function (4020 hex)
- Software Switch of Encoder's Input Slave (4020 hex)
- Touch probe status (4030 hex)
- Touch probe pos1 pos value (4012 hex)
- Touch probe pos2 pos value (4013 hex)
- Status of Encoder's Input Slave (4030 hex)

If even one of the required objects is not set, a Process Data Object Setting Missing error (error code 3461 hex) occurs.

For details on mapping data objects, refer to 2-3 PDO Mapping and to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

## **Instruction Details**

This section describes the instruction in detail.

## Specifying Axis

- Axis specifies the axis for which to latch the position.
- If the specified Axis is enabled by the MC\_GroupEnable (Enable Axes Group) instruction, the MC\_TouchProbe (Enable External Latch) instruction causes an error and is not executed.
- For each axis, you can specify *LatchID* to execute up to two MC\_TouchProbe (Enable External Latch) instructions at the same time.
- LatchID is also used to specify the latch to abort for the MC\_AbortTrigger (Disable External Latch) instruction.



### **Additional Information**

Latching a position is also possible if an encoder axis that is connected to an OMRON GX-series GX-EC02□□ EtherCAT Encoder Input Slave is used.

## Trigger Input Condition

Select the trigger conditions with *Mode*, *LatchID*, and *InputDrive* of the *TriggerInput* (Trigger Input Conditions) variable.

#### Mode

- The mode can be set to Drive Mode to specify a signal from the Servo Drive as the trigger, or to Controller Mode to specify a trigger with *TriggerVariable*.
- The trigger occurs on the rising edge of the trigger signal. The axis position is latched on the first trigger (FALSE to TRUE) after the MC\_TouchProbe instruction is executed.
- While this instruction is *Busy* (Executing), a change in *TriggerVariable* is taken as a trigger even if *Execute* is FALSE.




#### **Additional Information**

Set *Mode* to \_*mcDrive* (Servo Drive Mode) if you use an OMRON GX-series GX-EC02□□ Ether-CAT Encoder Input Slave.

#### **Drive Mode**

The latched actual position is more precise in Drive Mode than it is in Controller Mode. This is because Drive Mode uses a Servo Drive function to latch the position.



3-317



### **Precautions for Correct Use**

- When using Drive Mode, make sure that you connect the latch signal to the LatchID that you are going to use.
- The width of the latch signal depends on the performance of the Servo drive and other factors.




### **Additional Information**

Set *InputDrive* to \_mcEXT (External Input) if you use an OMRON GX-series GX-EC02 Ether-CAT Encoder Input Slave.

The OMRON GX-series GX-EC02 EtherCAT Encoder Input Slaves cannot latch on the Z phase. If you specify \_mcEncoderMark (Z phase), an error occurs when the instruction is executed. Error changes to TRUE and a Process Data Object Setting Missing error (error code: 3461 hex) is output to ErrorID when the instruction is executed.

#### **Controller Mode**

- You can specify a BOOL variable as the trigger in Controller Mode.
- Specify the BOOL variable that you want to use as a trigger for *TriggerVariable*.
- The Controller Mode causes a longer delay compared to the Drive Mode. This is due to the I/O refresh delay that occurs when the trigger input signal is updated in the BOOL variable.





### **Precautions for Correct Use**

If you use Controller Mode, the latch is performed each primary period. Therefore, the trigger variable must remain TRUE for at least one primary period.

Also, one primary period is required between when the trigger variable changes to TRUE and the MC Function Module processes the latch.

## LatchID

- You can execute up to two MC\_TouchProbe instructions per axis. Use LatchID to specify which of the two latches to use.
- If a *LatchID* specified for the same axis is already being executed, only the last instruction is valid. *CommandAborted* of the previous instruction will change to TRUE.
- LatchIDs indicate latch circuit 1 and latch circuit 2 in the Servo Drive.

For information on latch IDs, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).



#### **Additional Information**

The enumerators correspond to the signal names of the OMRON GX-series GX-EC02 Ether-CAT Encoder Input Slave as shown below.

Enumerator	Signal name on Encoder Input Terminal
_mcLatch1	External latch input A
_mcLatch2	External latch input B

## **InputDrive**

- You can select \_mcEncoderMark (Z phase) or \_mcEXT (External Input) as the trigger.
- Select \_mcEncoderMark (Z phase) to use the Z phase of the Servo Drive as the trigger. Select \_mcEXT to use an external signal input to the Servo Drive as the trigger.
- For an OMRON G5-series Servo Drive, there are three options for *\_mcEXT*: Ext1, Ext2, and Ext3. Use Sysmac Studio to make the setting. You can use the same setting for two triggers in the Servo Drive.


## WindowOnly

- WindowOnly specifies whether the window is enabled or disabled.
- If you specify *Disable*, triggers are detected for all axis positions.
- If you specify *Enable*, triggers are detected only when the axis position is within the range specified by *FirstPosition* and *LastPosition*.

The following timing chart shows the difference in operation depending on the WindowOnly setting.


## WindowOnly Set to Disable

The axis position when the first trigger occurs after *Execute* changes to TRUE is output to *RecordedPosition* (Latched Position).



## WindowOnly Set to Enable

Only trigger inputs within the window are detected to latch the axis position.



# 也

#### **Precautions for Correct Use**


- Latching is not possible immediately after WindowOnly changes to TRUE and until the latch function is activated.
- Time is needed until the latch function is activated. If the effective range for *WindowOnly* is too small, latching is not possible. The range in which latching is possible depends on the Servo Drive or Encoder Input Terminal performance, and on EtherCAT communications.

The range that is defined by *FirstPosition* and *LastPosition* depends on the Count Mode, as given below.

## **Linear Mode**

- The valid range of the window is as follows: FirstPosition must be less than or equal to the window range and the window range must be less than or equal to LastPosition.
- An error will occur if the FirstPosition is greater than the LastPosition.
- An error will also occur if a position beyond the position range of Linear Mode is specified.
- FirstPosition and LastPosition are LREAL variables. Do not set them to the same values. Refer to Treatment of REAL and LREAL Data on page 1-13 for information on LREAL data.

The window only range in Linear Mode is shown below.




Note The window only range can include the FirstPosition and LastPosition.


## **Rotary Mode**

- The FirstPosition can be less than, equal to, or greater than the LastPosition.
- If the *FirstPosition* is greater than the *LastPosition*, the setting range includes the maximum/minimum position of the ring counter.
- An error will occur if you specify a value beyond the upper and lower limits of the ring counter.

FirstPosition ≤ LastPosition




#### FirstPosition > LastPosition



### StopMode

- You can specify the StopMode for the specified Axis when a trigger occurs.
- If *mcNonStop* is specified, the axis will not stop even if a trigger occurs.
- If \_mcImmediateStop is specified, the axis stops at the latched position when a trigger occurs. CommandAborted of the instruction that was moving the axis changes to TRUE due to this stop.
- \_mcImmediateStop functions in CSP Mode.
- If \_mcImmediateStop is specified in CSV/CST Mode, an error occurs when the instruction is executed. If you change to CSV/CST Mode during execution for \_mcImmediateStop, CommandAborted changes to TRUE.
- For \_mcImmediateStop, Done changes to TRUE as soon as the axis command stops. Busy is TRUE until the axis stops at the latched position.
- An in-position check is not performed when stopping for \_mcImmediateStop.
- If an axis error occurs for an axis for which \_mcImmediateStop is specified and a trigger occurs before the axis is stopped, an immediate stop is performed for the axis by the OMRON G5-series Servo Drive.



The OMRON G5-series Servo Drive executes an immediate stop when the trigger occurs. When the MC Function Module detects that the OMRON G5-series Servo Drive has stopped, it performs an immediate stop.

The dotted line shows the target path when a trigger does not occur.



### **Precautions for Correct Use**

- For \_mcImmediateStop, the function of the Servo Drive is used to stop if an OMRON G5-series Servo Drive is used.
  - The MC Function Module processes the stop if a servo drive from another manufacturer is used. In either case, the axis will stop beyond the latched position, and the axis will then return to the latched position for a command from the Controller.
- If you use \_mcImmediateStop and the command velocity is high, the distance to return to the latched position is longer for both OMRON Servo Drives and servo drives from other manufacturers. Make sure that the command velocity is not too high.
- Specify \_mcNonStop (No Stop) for an encoder axis. If \_mcImmediateStop is specified, Error will change to TRUE when the instruction is executed. At the same time, an Enable External Latch Instruction Execution Disabled error (error code: 5492 hex) is output to ErrorID.
- If \_mcImmediateStop is used and both of the following processes are executed in the same control period, an OMRON G5-series Servo Drive enters the Target Ignore state.
  - Counter latch processing in the Servo Drive when the latch signal turns ON
  - Latch release processing when CommandAborted changes to TRUE for the MC\_TouchProbe (Enable External Latch) instruction


Make sure that *CommandAborted* for the instruction does not change to TRUE when the latch signal turns ON.

#### Axis Variable Status

If \_mcImmediateStop is specified for StopMode, Status.Stopping (Deceleration Stopping) in the Axis Variable is TRUE during stop processing for the trigger.

## **Aborting the Instruction**

End the MC\_TouchProbe (Enable External Latch) instruction with the MC\_AbortTrigger (Disable External Latch) instruction. Specify the *Axis* and the *LatchID* (Latch ID Selection) to stop for the MC\_AbortTrigger instruction and execute it to stop the axis.




## **Re-execution of Motion Instructions**

This instruction cannot be re-executed.

A Motion Control Instruction Re-execution Disabled error (error code: 543B hex) occurs if re-execution is attempted.

An error occurs if *Execute* changes to TRUE again before the MC\_TouchProbe instance completes reading *RecordedPosition* (Latched Position).




## **Multi-execution of Motion Instructions**

For details on re-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

## Execution during Execution of Other Instructions

You can execute only one trigger at a time for a single LatchID on the same Axis. If you execute another MC\_TouchProbe (Enable External Latch) instance for the same *LatchID* while an MC\_TouchProbe (Enable External Latch) instruction is in execution, *CommandAborted* of the first instruction changes to TRUE and the second instruction is executed.



 $<sup>^{\</sup>star}\,$  Here, the trigger input signal of the Servo Drive is used.




### **Additional Information**

If \_mcImmediateStop is specified for StopMode, CommandAborted for the second instruction changes to TRUE after the axis stops for the trigger.

## **Error**

If an error occurs during execution of the MC\_TouchProbe instruction, *Error* will change to TRUE. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).

## Timing Chart When Error Occurs



## Error Codes

Refer to A-1 Error Codes for instruction errors.

## **Sample Programming**

This section shows sample programming for position latching control by an external sensor.

## **Parameter Settings**

The minimum settings required for this sample programming are given below.

## Axis Parameters

## **Axis Type**

Axis	Axis Type	
Axis 1	Servo axis	

## **Count Mode**

Axis	Count Mode
Axis 1	Rotary Mode


## **Ring Counter**

Axis	Modulo maxi- mum position	Modulo mini- mum position
Axis 1	360	0


## **Unit of Display**

Axis	Unit of Display
Axis 1	degree

## **Operation Example**



## Operation Pattern



- Starting the Master AxisVelocity control is performed for axis 1.
- **2** Detecting Workpiece
  Sensor 1 detects the workpiece.
- 3 Latching the Position
  If the workpiece is detected in the window (Pos1 to Pos2), the position of axis 1 is latched.

## **Ladder Diagram**

## Main Variables

Name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 1.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 1.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
Pos1	LREAL		This variable specifies the first position of the window.


Name	Data type	Default	Comment
Pos2	LREAL		This variable specifies the last position of the win-
			dow.
StartPg	BOOL	FALSE	The Servo is turned ON if this variable is TRUE and EtherCAT process data communications are established.
InitFlag	BOOL	FALSE	This variable indicates if it is necessary to set the input parameters. Input parameters are set when this variable is FALSE. When setting the input parameters is completed, this variable changes to TRUE.

## Sample Programming

If StartPg is TRUE, EtherCAT communications are checked to see if process data communications are normal.

```
StartPg _EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress] _EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress] Lock1
```

If process data communications are active for axis 1, the Servo is turned ON.




If there is a minor fault level error for axis 1, the error handler for the device (FaultHandler) is executed. Design FaultHandler separately.

```
MC_Axis000.MFaultLvl.Active

FaultHandler
EN FaultHandler
```


If the Servo is ON and home is not defined, the Home instruction is executed.




The parameters are set for the MC\_MoveVelocity (Velocity Control) and MC\_TouchProbe (Enable External Latch) instructions.

```
Note: The contents of the inline ST are given below.
```

The MC\_MoveVelocity (Velocity Control) instruction is executed if home is defined for axis 1.



Latch processing is executed after the MC\_MoveVelocity (Velocity Control) instruction is started.



#### Contents of Inline ST

```
// MC_MoveVelocity parameters
   Vel_Vel
            := LREAL#1000.0;
   Vel_Acc := LREAL#1000.0;
   Vel_Dec := LREAL#1000.0;
   Vel Jrk
           := LREAL#1000.0;
// MC_TouchProbe parameters
   T_Probe_TrigRef.Mode
                               := _eMC_TRIGGER_MODE#_mcDrive;
   T Probe TrigRef.LatchID
                               := eMC TRIGGER LATCH ID# mcLatch1;
                               := _eMC_TRIGGER_INPUT_DRIVE#_mcEXT;
   T_Probe_TrigRef.InputDrive
   T Probe TrigVar
                               := FALSE;
   T Probe Wo
                               := TRUE;
   T_Probe_FstPos
                               := LREAL#1000.0;
   T_Probe_LstPos
                               := LREAL#2000.0;
   // Change InitFlag to TRUE after setting the input parameters.
   InitFlag:=TRUE;
```

## Structured Text (ST)

#### Main Variables

Name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 1.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 1.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
Pos1	LREAL		This variable specifies the first position of the window.
Pos2	LREAL		This variable specifies the last position of the window.
StartPg	BOOL	FALSE	The Servo is turned ON if this variable is TRUE and EtherCAT process data communications are established.
InitFlag	BOOL	FALSE	This variable indicates if it is necessary to set the input parameters. Input parameters are set when this variable is FALSE. When setting the input parameters is completed, this variable changes to TRUE.

## Sample Programming

Pwr\_En:=TRUE;

Pwr\_En:=FALSE;

**ELSE** 

END\_IF;

```
// Processing when input parameters are not set
IF InitFlag=FALSE THEN
  // MC_MoveVelocity parameters
   Vel_Vel := LREAL#1000.0;
   Vel_Acc := LREAL#1000.0;
   Vel_Dec := LREAL#1000.0;
  Vel_Jrk := LREAL#1000.0;
  // MC_TouchProbe parameters
  T_Probe_TrigRef.Mode
                              := _eMC_TRIGGER_MODE#_mcDrive;
  T_Probe_TrigRef.LatchID
                              := _eMC_TRIGGER_LATCH_ID#_mcLatch1;
  T_Probe_TrigRef.InputDrive := _eMC_TRIGGER_INPUT_DRIVE#_mcEXT;
  T_Probe_TrigVar
                              := FALSE;
  T_Probe_Wo
                              := TRUE;
  T_Probe_FstPos
                              := LREAL#1000.0;
  T_Probe_LstPos
                              := LREAL#2000.0;
  // Change InitFlag to TRUE after setting the input parameters.
  InitFlag:=TRUE;
END_IF;
// If StartPg is TRUE and EtherCAT communications are normal, the Servo is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
```

AND (\_EC\_CommErrTbl[MC\_Axis000.Cfg.NodeAddress]=FALSE) THEN

```
// Processing for a minor fault level error
// Implement FaultHandler separately.
IF MC_Axis000.MFaultLvl.Active=TRUE THEN
   FaultHandler();
END_IF;
// If the Servo is ON and home is not defined, the Home instruction is executed.
IF (Pwr_Status=TRUE) AND (MC_Axis000.Details.Homed=FALSE) THEN
   Hm_Ex:=TRUE;
END_IF;
// After home is defined, MC MoveVelocity is executed.
IF MC_Axis000.Details.Homed=TRUE THEN
   Vel_Ex:=TRUE;
END IF:
// After MC_MoveVelocity is executed, MC_TouchProbe is executed.
IF Vel_Act=TRUE THEN
   T_Probe_Ex:= TRUE;
END_IF;
//MC Power
PWR(
   Axis
             := MC Axis000.
   Enable
            := Pwr En,
   Status
             => Pwr Status.
   Busy
             => Pwr_Bsy,
   Error
             => Pwr_Err,
   ErrorID => Pwr_ErrID
);
//MC_Home
HM(
                      := MC_Axis000,
   Axis
   Execute
                      := Hm_Ex,
   Done
                      => Hm_D,
   Busv
                      => Hm_Bsy,
   CommandAborted => Hm Ca,
   Error
                      => Hm_Err,
   ErrorID
                      => Hm_ErrID
);
//MC_MoveVelocity
VEL(
   Axis
                      := MC_Axis000,
   Execute
                      := Vel_Ex,
   Velocity
                      := Vel Vel,
   Acceleration
                      := Vel_Acc,
                      := Vel_Dec,
   Deceleration
   Jerk
                      := Vel Jrk,
   InVelocity
                      => Vel_InVel,
   Busy
                      => Vel_Bsy,
   Active
                      => Vel_Act,
   CommandAborted => Vel_Ca,
   Error
                      => Vel_Err,
   ErrorID
                      => Vel_ErrID
//MC_TouchProbe
T_PROBE(
                      := MC_Axis000,
   Axis
   TriggerInput
                      := T_Probe_TrigRef,
```

```
TriggerVariable
                         := T_Probe_TrigVar,
    Execute
                           := T_Probe_Ex,
   Execute := I_Probe_Ex,
WindowOnly := T_Probe_Wo,
FirstPosition := T_Probe_FstPos,
LastPosition := T_Probe_LstPos,
-> T_Probe_D
                         => T_Probe_D,
    Done
                         => T_Probe_Bsy,
    Busy
    RecordedPosition => T_Probe_RecPos,
    CommandAborted => T_Probe_Ca,
                           => T_Probe_Err,
    Error
    ErrorID
                           => T_Probe_ErrID
);
```

# MC\_AbortTrigger

The MC\_AbortTrigger instruction aborts a current latch operation.

Instruction	Name	FB/FUN	Graphic expression	ST expression
MC_AbortTrigger	Disable External Latch	FB	MC_AbortTrigger_instance  MC_AbortTrigger  Axis	MC_AbortTrigger_instance ( Axis :=parameter, TriggerInput :=parameter, Execute :=parameter, Done =>parameter, Busy =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorID =>parameter );

## **Variables**

## Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Execute</i> changes to TRUE.

## **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

## Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When latching is stopped.	When Execute is TRUE and changes to FALSE.
	When this instruction is executed for a latch that is not in execution and pro- cessing ends.	After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	When Done changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
CommandAborted	<ul> <li>When this instruction is aborted because another motion control instruction was executed with the Buffer Mode set to <i>Aborting</i>.</li> <li>When this instruction is canceled due to an error.</li> </ul>	<ul> <li>When Execute is TRUE and changes to FALSE.</li> <li>After one period when Execute is FALSE.</li> </ul>
Error	When there is an error in the execution of or input parameters for the instruction.	When the error is cleared.

# In-Out Variables

Name	Meaning	Data type	Valid range	Description
Axis	Axis	_sAXIS_REF		Specify the target axis for latching.*1
TriggerInput	Trigger Selection	_sTRIGGER_REF		Use this variable to select the trigger condition.*2 Refer to the following table for _sTRIGGER_REF.

<sup>\*1</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are *MC\_Axis*\*\*\*.)

## • \_strigger\_ref

Name	Meaning	Data type	Valid range	Function
Mode	Mode	_eMC_TRIGGER_	0: _mcDrive	Specify the trigger mode.
		MODE	1: _mcController	0: Drive Mode
				1: Controller Mode
LatchID	Latch ID	_eMC_TRIGGER_	0: _mcLatch1	Specify which of the two latch
	Selection	LATCH_ID	1: _mcLatch2	functions to use.
				0: Latch 1
				1: Latch 2
InputDrive	Trigger Input	_eMC_TRIGGER_	0: _mcEncoderMark	Specify the Servo Drive trigger
	Signal	INPUT_DRIVE	1: _mcEXT	signal to use in Drive Mode.
				0: Z-phase signal
				1: External input

<sup>\*2</sup> Define a user-defined variable with a data type of \_sTRIGGER\_REF.

## **Function**

- The MC\_AbortTrigger cancels a latch operation.
- You can specify the latch operation to abort by specifying the *Axis* and *LatchID* for the MC\_AbortTrigger (Disable External Latch) instruction.
- If you execute MC\_AbortTrigger (Disable External Latch) for a trigger for which there is no latch request, MC\_AbortTrigger does nothing and ends normally. This is the same when MC\_AbortTrigger (Enable External Latch) is executed for a MC\_TouchProbe instruction for which *Done* is TRUE.




## **Precautions for Correct Use**

- If the MC\_GroupEnable (Enable Axes Group) instruction was executed for the Axis that is specified for the MC\_AbortTrigger (Disable External Latch) instruction, an error occurs for the MC\_AbortTrigger instruction and it is not executed.
- An error occurs for this instruction if the MC\_AbortTrigger (Disable External Latch) instruction is executed during execution of the MC\_Home, MC\_MoveFeed (Interrupt Feeding), or MC\_MoveLink (Synchronous Positioning) instruction.

## **Timing Charts**

• Done for the MC\_AbortTrigger (Disable External Latch) instruction changes to TRUE one period after Execute changes to TRUE.



# **Re-execution of Motion Instructions**

This instruction cannot be re-executed.

A Motion Control Instruction Re-execution Disabled error (error code: 543B hex) occurs if re-execution is attempted.


## **Multi-execution of Motion Instructions**

For details on re-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

## **Errors**

If an error occurs during execution of the MC\_AbortTrigger (Disable) instruction. *Error* will change to TRUE. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).

## MC\_AbortTrigger



## Error Codes

Refer to A-1 Error Codes for instruction errors.

# MC\_AxesObserve

The MC\_AxesObserve instruction monitors the deviation between the command position or feedback position for the specified axis to see if it exceeds the allowed value.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_AxesObserve	Monitor Axis Following Error	FB	MC_AxesObserve_instance  MC_AxesObserve Master — Master Slave — Slave Enable Enabled ReferenceType Invalid PermittedDeviation Busy DeviatedValue Error ErrorID	MC_AxesObserve_instance ( Master :=parameter, Slave :=parameter, Enable :=parameter, ReferenceType :=parameter, PermittedDeviation :=parameter, Enabled =>parameter, Invalid =>parameter, Busy =>parameter, DeviatedValue =>parameter, Error =>parameter, ErrorID =>parameter );

## **Variables**

## Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Enable	Enable	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Enable</i> is TRUE.
ReferenceType	Position Type	_eMC_	0: _mcCommand	0*1	Specify the position type.
	Selection	RERERENCE_TYPE   1: _mcFe	1: _mcFeedback		Command position (value calculated in the previous primary period)
					Actual position (value obtained in the same primary period)
Permitted Deviation	Permitted Following Error	LREAL	Non-negative number	0	Specify the permitted maximum value of the following error between the master and slave axes. The unit is command units.*2

<sup>\*1</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

<sup>\*2</sup> Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.

## **Output Variables**

Name	Meaning	Data type	Valid range	Description
Enabled	Enable	BOOL	TRUE or FALSE	TRUE when the axis is being controlled.
Invalid	Excessive Following Error between Axes	BOOL	TRUE or FALSE	TRUE when the permitted following error between axes is exceeded.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
DeviatedValue	Following Error between Axes	LREAL	Negative num- ber, positive number, or 0	Contains the difference between the specified master and slave axes. The unit is command units.*1
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*2	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*1</sup> Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.

## Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Enabled	When Enable changes to TRUE.	When Error changes to TRUE.
		When Enable changes to FALSE.
Invalid	When the permitted following error	When Error changes to TRUE.
	between axes is exceeded.	When Enable changes to FALSE.
		When the permitted following error between axes is not exceeded.
Busy	When Enable changes to TRUE.	When Error changes to TRUE.
		When Enable changes to FALSE.
DeviatedValue*	When Enable is TRUE.	
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

<sup>\*</sup> DeviatedValue does not return to FALSE when Enable changes to FALSE.

## **In-Out Variables**

Name	Meaning	Data type	Valid range	Description
Master	Master Axis	_sAXIS_REF		Specify the master axis.*
Slave	Slave Axis	_sAXIS_REF		Specify the slave axis.*

<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are *MC Axis*\*\*\*.)



## **Precautions for Correct Use**

If you specify the same axis for the master axis and slave axis, a Master and Slave Defined as Same Axis minor fault (error code 5436 hex) will occur.

<sup>\*2</sup> Refer to A-1 Error Codes.




#### Additional Information

You can also set axes that belong to groups.

## **Function**

- If the command positions of the specified Master (Master Axis) and Slave (Slave Axis) or the difference between the actual positions exceeds the permitted following error, Invalid (Excessive Following Error between Axes) changes to TRUE.
  - Invalid (Excessive Following Error between Axes) changes to TRUE when the following conditions are met.
  - When | Deviated Value (Following Error between Axes) | > Permitted Deviation (Permitted Following Error)
- The operation of the axis is not affected by this instruction.
- Use the state of the *Invalid* (Excessive Following Error between Axes) output variable to program processes, such as stopping an axis.





## **Precautions for Correct Use**

- Use the same Count Mode for the *Master* (Master Axis) and *Slave* (Slave Axis).
   If a different mode is set, the axes will be compared in Linear Mode.
   Even if both axes are in Rotary Mode, comparisons are made in Linear Mode if the ranges set for the ring counters are not the same.
- If *PermittedDeviation* (Permitted Following Error) contains a non-terminating decimal number, e.g., resulting from division, error may cause unexpected processing results.

## **Instruction Details**

This section describes the instruction in detail.

## ReferenceType (Position Type Selection)

Any of the following position types can be selected for the master axis to which the slave axis is synchronized.

- \_mcCommand: Command position (value calculated in the previous primary period)
   The master axis command position that was calculated in the previous primary period is used for the current period.
  - The command value that was calculated for the master axis in the last primary period is used to calculate the command position of the slave axis in the current period.
- \_mcFeedback: Value obtained in the same primary period
   The actual position of the master axis that was obtained in the same primary period is used.

## Relationship between Axis Types and Position Types

The relationship between the axis types that you can monitor and position types that is monitored is shown below.

Axis type	Referer	псеТуре
Axis type	_mcCommand	_mcFeedback
Servo axis	OK	OK
Encoder axis	No*	OK
Virtual servo axes	OK	ОК
Virtual encoder axis	No*	ОК

<sup>\*</sup> A Position Type Selection Out of Range error (error code: 5430 hex) occurs when the instruction is executed.

## • Calculation Examples for *DeviatedValue* (Following Error between Axes)

The DeviatedValue (Following Error between Axes) is calculated as described below.

#### **Linear Mode**

## ReferenceType (Position Type Selection) Set to \_mcCommand

DeviatedValue (Following Error between Axes) = Command current position of *Master* (Master Axis) – Command current position of *Slave* (Slave Axis)

### ReferenceType (Position Type Selection) Set to \_mcFeedback

DeviatedValue (Following Error between Axes) = Actual current position of *Master* (Master Axis) – Actual current position of *Slave* (Slave Axis)

## **Rotary Mode**

### ReferenceType (Position Type Selection) Set to \_mcCommand

The *DeviatedValue* (Following Error between Axes) is the shorter distance between the command current position of the *Master* (Master Axis) and the command current position of the *Slave* (Slave Axis) in the range of the ring counter. The sign of the *DeviatedValue* (Following Error between Axes) is the sign for the shorter direction, as given below.


- If the command current position of the *Master* (Master Axis) is greater than or equal to the command current position of the *Slave* (Slave Axis), the value is positive.
- If the command current position of the *Master* (Master Axis) is less than the command current position of the *Slave* (Slave Axis), the value is negative.

## ReferenceType (Position Type Selection) Set to \_mcFeedback

The *DeviatedValue* (Following Error between Axes) is the shorter distance between the actual current position of the *Master* (Master Axis) and the actual current position of the *Slave* (Slave Axis) in the range of the ring counter. The sign of the *DeviatedValue* (Following Error between Axes) is the sign for the shorter direction, as given below.

- If the actual current position of the *Master* (Master Axis) is greater than or equal to the actual current position of the *Slave* (Slave Axis), the value is positive.
- If the actual current position of the *Master* (Master Axis) is less than the actual current position of the *Slave* (Slave Axis), the value is negative.

DeviatedValue (Following Error between Axes) Calculation Example in Rotary Mode when ReferenceType (Position Type Selection) Is Set to \_mcCommand




|DeviatedValue| is 70 (because 70 is less than 100). The sign is positive because the command current position of the *Master* is greater than or equal to the command current position of the *Slave*, so the *DeviatedValue* is +70.

If *ReferenceType* (Position Type Selection) is \_mcFeedback in Rotary Mode, the "command current position" in the above diagram would be the "actual current position."

## **Timing Charts**

An error for this instruction does not affect the operation of the axis or axes group. A timing chart is given below for when *PermittedDeviation* (Permitted Following Error) is 10.0.



## **Re-execution of Motion Instructions**

You cannot re-execute enable-type motion instructions.


## **Multi-execution of Motion Instructions**

There are no restrictions for multi-execution of instructions.

For details on re-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

## **Errors**

- If an error occurs during instruction execution, Error will change to TRUE.
- You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).
- Error information for this instruction is output to Minor Fault in the MC Common motion variable.



## Error Codes

Refer to A-1 Error Codes for instruction errors.

# MC\_SyncMoveVelocity

The MC\_SyncMoveVelocity instruction outputs the value set for the target velocity every primary period to the Servo Drive in Cyclic Synchronous Velocity Mode.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_SyncMoveVelocity	Cyclic Synchronous Velocity Control	FB	MC_SyncMoveVelocity_instance  MC_SyncMoveVelocity Axis Axis Execute InVelocity Velocity Busy CmdPosMode Active BufferMode CommandAborted Error ErrorID	MC_SyncMoveVelocity_ instance ( Axis :=parameter, Execute :=parameter, Velocity :=parameter, CmdPosMode :=parameter, BufferMode :=parameter, InVelocity =>parameter, Busy =>parameter, Active =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorlD =>parameter );

## **Variables**

## Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Execute</i> changes to TRUE.
Velocity	Target Veloc-	LREAL	Negative number,	0	Set the target velocity.
	ity		positive number, or 0		0: Set the velocity command value to 0.
					Positive value: Move in the positive direction.
					Negative value: Move in the negative direction.
CmdPosMode	Command Current Posi- tion Count Selection	_eMC_CMDPOS_ MODE	0: _mcCount	0*	0: Use the actual current position and update the command current position. Home remains defined.
BufferMode	Buffer Mode Selection	_eMC_BUFFER_ MODE	0: _mcAborting 1: _mcBuffered	0*	Specify the operation when executing more than one motion instruction.  0: Aborting 1: Buffered

 $<sup>^{\</sup>star}\,$  The default value for an enumeration variable is actually not the number, but the enumerator.

## **Output Variables**

Name	Meaning	Data type	Valid range	Description
InVelocity	Target Veloc- ity Reached	BOOL	TRUE or FALSE	TRUE when the command velocity reaches the target velocity.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE	TRUE when control is in progress.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

## Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
InVelocity	When the target velocity is reached.	When Error changes to TRUE.
		When CommandAborted changes to TRUE.
Busy	When Execute changes to TRUE.	When Error changes to TRUE.
		When CommandAborted changes to TRUE.
Active	When the instruction is started.	When Error changes to TRUE.
		When CommandAborted changes to TRUE.
CommandAborted	When this instruction is canceled due to	When Execute is TRUE and changes to FALSE.
	another instruction.	After one period when Execute is FALSE.
	When this instruction is canceled due to an error in another instruction.	
	When this instruction is executed while there is an axis error.	
	When you start this instruction during MC_Stop instruction execution.	
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

## **In-Out Variables**


Name	Meaning	Data type	Valid range	Description
Axis	Axis	_sAXIS_REF		Specify the axis.*

<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are MC\_Axis\*\*\*.)


## **Function**

- The MC\_SyncMoveVelocity instruction outputs the target velocity from the user program every primary period to the Servo Drive in Cyclic Synchronous Velocity (CSV) Mode.
- When *Execute* changes to TRUE, the Control Mode of the Servo Drive is changed and a command velocity is output.

• If this instruction is executed in the primary periodic task, the target velocity is reached in the next period.



• If this instruction is executed in the priority-16 periodic task, the target velocity is reached in the next task period.



# 也

### **Precautions for Correct Use**

Refer to *Precautions for Master and Auxiliary Axes in Synchronized Control* on page 1-7 for precautions on using this instruction for the master axis of synchronized control.



## **Additional Information**

The MC\_SetOverride (Set Override Factors) instruction is not effective for the MC\_SyncMoveVelocity (Cyclic Synchronous Velocity Control) instruction.

## Mapping Data Objects

To use the MC\_SyncMoveVelocity (Cyclic Synchronous Velocity Control) instruction, map the following object data in the Detailed Settings Area of the Axis Basic Settings Display of the Sysmac Studio.

- Target velocity (60FF hex)
- Modes of operation (6060 hex)
- Modes of operation display (6061 hex)

If even one of the required objects is not set, a Process Data Object Setting Missing error (error code 3461 hex) occurs.

For details on mapping data objects, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

## **Instruction Details**

This section describes the instruction in detail.

## Velocity (Target Velocity)

The Velocity (Target Velocity) input variable can be set to LREAL data in reference to 0.

The axis moves in the positive direction for a positive value and in the negative direction for a negative value.

If 0 is set, the command velocity is 0 and *Status.Continuous* (Continuous Motion) remains TRUE. You can set *Velocity* (Target Velocity) from the user program every period.

If the specified target velocity is different from the last period, the new target velocity is used. If the specified target velocity is the same as the last period, the previous target velocity is used.




#### **Precautions for Correct Use**

- When you set the target velocity, make sure that an excessive load is not placed on the mechanical composition of the system for the change in velocity.
- If the axis that you use in this instruction is the master axis for synchronized control, setting the target velocity of the main axis may cause the slave axis to move suddenly.
- When the Control Mode is changed, the command current position may change suddenly.

## Command Current Position

If you select \_mcCount for the CmdPosMode (Command Current Position Count Selection) input variable, the command current position will be the actual current position from the previous period when this instruction is executed. The actual current position is used until the instruction is ended. While the OMRON G5-series Servo Drive is processing the switch to CSP Mode, the CSP reference position that was mapped in advance is sent in the PDO. Until processing to switch from CSV to CSP Mode is completed, this reference position is used as the command current position. When switching to CSP Mode is completed, the command current position is set to the command position.



## When Using an OMRON G5-series Servo Drive

To use the CSP reference position of the Servo Drive when changing the Control Mode, map the CSP Reference Position (4020 hex) to process data. Map the CSP Reference Position (4020 hex) to process data in the PDO Edit Tab Page of the Sysmac Studio. Then map the CSP Change Reference Position in the MC Function Model and the CSP Reference Position (4020 hex) in the Detailed Settings Area of the Axis Basic Settings Tab Page.



### **Precautions for Correct Use**

If the CSP Reference Position (4020 hex) is mapped to a PDO, set the primary period to 1 ms or longer. If the primary period is less than 1 ms, an error will occur in the G5-series Servo Drive. Refer to the *G5-series AC Servomotors/Servo Drives With Built-in EtherCAT Communications User's Manual* (Cat. No. 1576) for details.

## When Using a Servo Drive Other Than an OMRON G5-series Servo Drive

An error may occur in processing to switch the Command Mode for some Servo Drives when this instruction is executed or when an instruction that uses CSP Mode is executed during execution of this instruction.

If that occurs, stop the axis (velocity of 0) and then execute this instruction or use multi-execution of instructions that use the CSP Mode.

## Stop Processing

This Stop Modes and command velocities that are used to stop axis motion are described below. For a deceleration stop, the target velocity of this instruction is used as the initial velocity and the axis is decelerated to a stop with the deceleration rate for the specified Stop Mode.

## Stopping with the MC\_ImmediateStop Instruction

The command velocity is changed to 0. The Control Mode is changed to CSP Mode when the change criterion that is given below is satisfied.

## Stopping with the MC\_Stop Instruction

The command velocity is changed to 0 at the deceleration rate of the instruction. The Control Mode is changed to CSP Mode when the change criterion that is given below is satisfied.

## Stopping for a Minor Fault Level Error

The command velocity is changed to 0 at the deceleration rate of each error. The Control Mode is changed to CSP Mode when the change criterion that is given below is satisfied.

## Stopping for a Major Fault Level Error or a Partial Fault Level Error

The command velocity is changed to 0. The Control Mode is changed to CSP Mode when the change criterion that is given below is satisfied.

However, depending on the error level, it may not be possible to switch the Control Mode normally, and the axis may stop in CSV Mode.

## Stopping by Turning OFF the Servo

The command velocity is changed to 0 with the specified method. The Control Mode is not changed.

# Stopping When the Operating Mode of the CPU Unit Changes to PROGRAM Mode

The command velocity is changed to 0 with the specified method. The Control Mode is changed to CSP Mode when the change criterion that is given below is satisfied.

## Change Criterion

Whether it is possible to change the Control Mode depends on Servo Drive specifications.

To ensure that the Control Mode is switched to CSP Mode during stop processing for stop instructions or errors, it is necessary to sufficiently decelerate the Servomotor first.

The Control Mode is changed to CSP Mode when the following criterion is met for three consecutive primary period tasks after the command velocity changes to 0.

Actual current velocity ≤ Maximum velocity × 0.1

## Recovery to Cyclic Synchronous Positioning Mode

It is not always possible to normally change to CSP Mode for a stop.

For example, it may not be possible when a partial fault level error occurs in the MC Function Module.

Therefore, processing to change to CSP Mode is performed when the *Status* output variable from the MC\_Power (Power Servo) instruction changes to FALSE.

## Operation for Failure to Switch Control Mode

If the Servo Drive does not complete switching the Control Mode within 1 second after a Control Mode switch command is sent to the Servo Drive, a Error in Changing Servo Drive Control Mode (error code: 7439 hex) occurs.

Also, if the switching criterion is not met within 10 seconds after the command velocity is changed to 0 for a Control Mode switching command to the Servo Drive, an Error in Changing Servo Drive Control Mode (error code: 7439 hex) occurs.

When an Error in Changing Servo Drive Control Mode (error code: 7439 hex) occurs, the command velocity is changed to 0 and the Servo is turned OFF (free-run stop).

## Applicable Axes and Execution Condition

- You can use this instruction for a servo axis.
   To use this instruction, change Enable for the MC Power instruction to TRUE (Servo ON).
- A virtual servo axis will acknowledge this instruction at any time.
   However, processing to switch the Control Mode of the Servo Drive is not performed.
- An error occurs if the instruction is executed for an encoder or virtual encoder axis.

#### Axis Variable Status

Status. Continuous (Continuous Motion) in the Axis Variable status changes to TRUE. Use *DrvStatus* (Servo Drive Status) in the Axis Variable to check the Control Mode that is set in the Servo Drive. The Servo Drive status is given in the following table.

Name	Data type	Meaning	Description	
CSP	BOOL	Cyclic Synchronous Position (CSP) Mode	TRUE when the Servo is ON and the Servo Drive is in CSP Mode.	
CSV	BOOL	Cyclic Synchronous Velocity (CSV) Mode	TRUE when the Servo is ON and the Servo Drive is in CSV Mode.	
CST	BOOL	Cyclic Synchronous Torque (CST) Mode	TRUE when the Servo is ON and the Servo Drive is in CST Mode.	

## Home Status

If CmdPosMode (Command Current Position Count Selection) is set to \_mcCount, the home will remain defined.

### Overrides

Overrides are disabled for this instruction.

## Software Limits


Software limits are enabled for this instruction. These are enabled even for the following axis parameter settings.

- Deceleration stopping enabled for command position
- Immediate stopping enabled for command position (stop using remaining pulses)

## **Timing Charts**

- Busy (Executing) changes to TRUE at the same time as Execute changes to TRUE. Active (Controlling) changes to TRUE in the next period.
- InVelocity (Target Velocity Reached) changes to TRUE when the command velocity reaches Velocity (Target Velocity).
- If another instruction aborts this instruction, *CommandAborted* changes to TRUE and *Busy* (Executing), *Active* (Controlling), and *InVelocity* (Target Velocity Reached) change to FALSE.
- The MC\_Stop instruction is used to stop this instruction.

The following timing charts show operation for when this instruction is used in the primary periodic task.





## **Additional Information**

The MC Function Mode sends a command to the Servo Drive to change the Control Mode as shown in the above timing chart. The timing of implementing the change in the Servo Drive depends on Servo Drive specifications.

## **Re-execution of Motion Control Instructions**

This instruction cannot be re-executed.

A Motion Control Instruction Re-execution Disabled error (error code: 543B hex) occurs if re-execution is attempted.

## **Multi-execution of Motion Control Instructions**

For details on multi-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

## Execution during Execution of Other Instructions

You can execute this instruction with *BufferMode* (Buffer Mode Selection) set to *Aborting* or *Buffered* during execution of other instructions in the same as for the MC\_MoveVelocity (Velocity Control) instruction.

The Control Mode is switched when processing the instruction is started.

For details on *BufferMode* (Buffer Mode Selection), refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

## Execution of Other Instructions during Instruction Execution

You can execute other instructions with *BufferMode* (Buffer Mode Selection) set to *Aborting* or *Buffered* during execution of this instruction in the same as for the MC\_MoveVelocity (Velocity Control) instruction.


If the other instruction is buffered, then it is executed when *InVelocity* (Target Velocity Reached) changes to TRUE.

The Control Mode is switched when processing the instruction is started.

## **Errors**

If an error occurs during instruction execution, *Error* will change to TRUE and the axis will stop. You can find out the cause of the error by referring to the value output to *ErrorID* (Error Code).

## Timing Chart When Error Occurs



#### Error Codes

Refer to A-1 Error Codes for instruction errors.

# **MC\_Reset**

The MC\_Reset instruction clears axis errors.

Instruction	Name	FB/FUN	Graphic expression	ST expression
MC_Reset	Reset Axis Error	FB	MC_Reset_instance  MC_Reset Axis Execute Axis Done Busy Failure Error ErrorID	MC_Reset_instance ( Axis :=parameter, Execute :=parameter, Done =>parameter, Busy =>parameter, Failure =>parameter, Error =>parameter, ErrorID =>parameter );

## **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Execute</i> changes to TRUE.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Failure	Failure End	BOOL	TRUE or FALSE	TRUE when the instruction is not executed normally.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

#### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When error clear processing is completed normally.	<ul><li>When Execute is TRUE and changes to FALSE.</li><li>After one period when Execute is FALSE.</li></ul>
Busy	When Execute changes to TRUE.	<ul> <li>When Done changes to TRUE.</li> <li>When Error changes to TRUE.</li> <li>When Failure changes to TRUE.</li> </ul>
Failure	<ul> <li>When an error reset is executed while decelerating an axis to a stop for an error.</li> <li>When an error reset is executed during an axis error for an axis common error.</li> </ul>	<ul> <li>When Execute is TRUE and changes to FALSE.</li> <li>After one period when Execute is FALSE.</li> </ul>
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

### **In-Out Variables**

Name	Meaning	Data type	Valid range	Description
Axis	Axis	_sAXIS_REF		Specify the axis.*

<sup>\*</sup> Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio. (The default axis variable names are *MC\_Axis*\*\*\*.)

#### **Function**

- The MC\_Reset instruction starts error clear processing for the axis specified by Axis when Execute
  changes to TRUE. The error processing resets axis errors and, if errors have occurred in the Servo
  Drive, drive errors.
- You can use this instruction for any axis type.
- Error clear processing is executed only for axes with errors.
- If there is a drive error for an axis, the drive error is cleared first. Error clear processing is then performed. Reset processing for the drive error is continued until the drive error is cleared or continues for the Drive Error Reset Monitoring Time in the axis parameters.
- If this instruction is executed while the axis is decelerating to a stop for an error, the instruction is not executed and *Failure* will change to TRUE. *Failure* will also change to TRUE if an axis error that results from an MC common error cannot be cleared by this instruction. This is to ensure that the error is not reset before the axis stops.
  - MC Common errors include MC Common Partial Faults and MC Common Minor Faults.
- Only errors that existed when Execute changes to TRUE are cleared. Errors that occur while clearing
  errors are not cleared.



#### **Precautions for Correct Use**

- The error clear processing that is performed by this instruction sometimes requires more than one control period.
- If an MC Common Partial Fault or MC Common Minor Fault occurs or the axis is in motion, Failure (Failure End) from the instruction will change to TRUE. Remove the cause of the error, and then retry the process until *Done* changes to TRUE.
- After you remove the cause of the error, execute the instruction only after you confirm that the axes have stopped completely.

*Act. Vel* (Actual Current Velocity) in the Axis Variable is 0 if the axis is completely stopped. Use this to confirm when the axis is completely stopped.




#### **Additional Information**

The following errors cannot be cleared with this instruction.

- All axis common errors: Execute the ResetMcError (Reset All Errors) instruction.
- All axes group errors: Execute the MC\_GroupReset (Group Reset) instruction.


The causes of network errors, such as slave communications error, are not cleared by executing MC\_Reset. Execute the ResetECATError instruction.

# **Timing Charts**



# **Aborting the Instruction**

The instruction is aborted if it is not possible to clear errors that occur when the axis is decelerating to a stop for an error or errors that occur during axis errors resulting from axis common errors.



## **Error Codes**

Refer to A-1 Error Codes for instruction errors.

_			
2	Λvic	Command	Instructions
Э.	HXIS	Command	บารบนบนบาร



# **Axes Group Instructions**

This section describes the instructions to perform multi-axes coordinated control for the MC Function Module.

MC_GroupEnable	4-2
MC_GroupDisable	4-6
MC_MoveLinear	4-10
MC_MoveLinearAbsolute	<b>4-36</b>
MC_MoveLinearRelative	4-39
MC_MoveCircular2D	<b>4-42</b>
MC_GroupStop	<b>4-66</b>
MC_GroupImmediateStop	<b>1-75</b>
MC_GroupSetOverride	<b>4-80</b>
MC_GroupReset	<b>4-84</b>

# MC\_GroupEnable

The MC\_GroupEnable instruction enables an axes group.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_GroupEnable	Enable Axes Group	FB	MC_GroupEnable_instance  MC_GroupEnable AxesGroup Execute  CommandAborted Error ErrorID	MC_GroupEnable_instance ( AxesGroup :=parameter, Execute :=parameter, Done =>parameter, Busy =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorID =>parameter );

### **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when Execute changes to TRUE.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description	
Done	Done	BOOL	TRUE or TRUE when the instruction is completed.		
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.	
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.	
Error	Error	BOOL	TRUE or FALSE		
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.	

<sup>\*</sup> Refer to A-1 Error Codes.

#### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When the instruction is completed.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
CommandAborted	When this instruction is executed while	When Execute is TRUE and changes to FALSE.
there is an axes group error.		After one period when Execute is FALSE.
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# **In-Out Variables**

Name	Meaning	Data type	Valid range	Description
AxesGroup	Axes Group	_sGROUP_REF		Specify the axes group.*

<sup>\*</sup> Specify an Axes Group Variable that was created in the Axes Group Basic Settings of the Sysmac Studio. (The default axes group variable names are *MC\_Group*\*\*\*.)

### **Function**

Before describing the function of this instruction, the different states of axes groups are explained.

• Axes groups have two states, the GroupEnable and GroupDisable states.

State	Description					
GroupEnable	Multi-axes coordinated control is enabled. You can execute any multi-axes coordinated control instructions.					
GroupDisable	Multi-axes coordinated control is disabled. You can execute only the following multi-axes coordinated control instructions.					
	MC_GroupEnable (Enable Axes Group) instruction					
	MC_GroupDisable (Disable Axes Group) instruction					
	MC_GroupReset (Reset Axes Group Errors) instruction					
	MC_GroupSetOverride (Set Group Overrides) instruction					

• To perform multi-axes coordinated control, an axes group must be in a GroupEnable state.

You can monitor the Axes Group Variables in the system-defined variables for motion control to see if axes groups are enabled or disabled.

Name	Meaning	Description
_MC_GRP**.Status.Ready	Axes Group Ready	TRUE when the axes group is stopped and preparations to execute an axes group instruction are completed.
_MC_GRP**.Status.Disabled	Axes Group Dis- abled	TRUE when the axes group is disabled and stopped.

Note "\*\*" in "\_MC\_GRP\*\*" is replaced by a number between 0 and 31.

#### **Basic Function**


- The MC\_GroupEnable (Enable Axes Group) instruction places the axes group specified by Axes-Group into the GroupEnable state.
- When an axes group is in the GroupEnable state, you can execute any multi-axes coordinated control instructions for the axes group.
- You can set only servo axes and virtual servo axes in an axes group. An error will occur if you include other axis types.
- All axes that belong to an axes group must be in a stopped state to enable the group. An axis is stopped if the Status. Disabled (Axis Disabled) or Status. Standstill (Stopped) in the Axis Variable is TRUE.
- If there are axes that already belong to another axes group and the other axes group is enabled, the MC\_GroupEnable instruction is not executed and an error will occur if you attempt to execute it.
- When an axes group is enabled, the axes in the axes group change to Coordinated Motion status. Status. Coordinated (Coordinated Motion) in the Axis Variable changes to TRUE.
- · An axes group is disabled if the MC\_GroupDisable (Disable Axes Group) instruction is executed, if operation is stopped by changing to PROGRAM mode, or if a MC Test Run is started.



#### **Precautions for Correct Use**


To use an axes group, create an axes group on the Sysmac Studio and download the settings to the CPU Unit. You cannot change the axes in an axes group from the user program. Use the Synchronize Menu of the Sysmac Studio to download the project.

### Timing Charts



# **Errors**

If an error occurs during execution of the MC\_GroupEnable instruction, *Error* will change to TRUE. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).





#### **Additional Information**

Errors do not occur for individual axes in an axes group even if an error occurs for the axes group.

#### Error Codes

Refer to A-1 Error Codes for instruction errors.

# MC\_GroupDisable

The MC\_GroupDisable instruction disables an axes group.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_GroupDisable	Disable Axes Group	FB	MC_GroupDisable_instance  MC_GroupDisable AxesGroup Execute  CommandAborted Error ErrorID	MC_GroupDisable_instance ( AxesGroup :=parameter, Execute :=parameter, Done =>parameter, Busy =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorID =>parameter );

### **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when Execute changes to TRUE.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

#### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When the axes group state is changed to <i>GroupDisable</i> .	<ul><li>When Execute is TRUE and changes to FALSE.</li><li>After one period when Execute is FALSE.</li></ul>
Busy	When Execute changes to TRUE.	<ul> <li>When <i>Done</i> changes to TRUE.</li> <li>When <i>Error</i> changes to TRUE.</li> <li>When <i>CommandAborted</i> changes to TRUE.</li> </ul>
CommandAborted	Never changes to TRUE. (Reserved)	<ul><li>When Execute is TRUE and changes to FALSE.</li><li>After one period when Execute is FALSE.</li></ul>
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

## In-Out Variables


Name	Meaning	Data type	Valid range	Description
AxesGroup	Axes Group	_sGROUP_REF		Specify the axes group.*

<sup>\*</sup> Specify an Axes Group Variable that was created in the Axes Group Basic Settings of the Sysmac Studio. (The default axes group variable names are *MC\_Group*\*\*\*.)

#### **Function**


- The MC\_GroupDisable instruction disables an axes group. For details on the axes group states, refer to *Function* on page 4-3.
- The MC\_GroupDisable (Disable Axes Group) instruction places the axes group specified by *Axes-Group* into the *GroupDisable* state. When an axes group is in the *GroupDisable* state, the axes group stops acknowledging multi-axes coordinated control instructions.
- Any buffered instruction of the specified *AxesGroup* is cleared when the axes group state changes to *GroupDisable*.
- The axes group is disabled even while operation is stopped.
   When an axes group is disabled, the status of the axes in the axes group changes from TRUE for Status. Coordinated (Coordinated Motion) to the status of each axis.
   Use Status (Axis Status) in the Axis Variable to determine the status of each axis.

# **Timing Charts**




If you execute the MC\_GroupDisable instruction for an AxisGroup that is under multi-axes coordinated control, CommandAborted of multi-axes coordinated control instruction will change to TRUE. CommandAborted of any buffered multi-axes coordinated control instruction will also change to TRUE. If the axes are moving, they will decelerate to a stop at the maximum deceleration rate for each axis.





## **Errors**

If an error occurs during execution of the MC\_GroupDisable instruction, *Error* will change to TRUE. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).



#### Error Codes

Refer to A-1 Error Codes for instruction errors.

# **MC\_MoveLinear**

The MC\_MoveLinear instruction performs linear interpolation.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_MoveLinear	Linear Interpolation	FB	MC_MoveLinear_instance  MC_MoveLinear AxesGroup — AxesGroup Execute Done Position Busy Velocity Active Acceleration CommandAborted Deceleration Error Jerk ErrorID CoordSystem BufferMode TransitionMode MoveMode	MC_MoveLinear_instance ( AxesGroup :=parameter, Execute :=parameter, Position :=parameter, Velocity :=parameter, Acceleration :=parameter, Deceleration :=Åparameter, Jerk :=parameter, CoordSystem :=parameter, BufferMode :=parameter, TransitionMode :=parameter, MoveMode :=parameter, Done =>parameter, Busy =>parameter, Active =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorlD =>parameter);

## **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Execute</i> changes to TRUE.
Position	Target Position	ARRAY [03] OF LREAL	Negative number, positive number, or 0	0	Specify the target position for linear interpolation. The unit is command units.*1
Velocity*2	Target Velocity	LREAL	Positive number	0	Specify the target velocity. The unit is command units/s.*1
Acceleration	Accelera- tion Rate	LREAL	Non-negative number	0	Specify the acceleration rate. The unit is command units/s <sup>2</sup> .* <sup>1</sup>
Deceleration	Decelera- tion Rate	LREAL	Non-negative number	0	Specify the deceleration rate. The unit is command units/s <sup>2</sup> .* <sup>1</sup>
Jerk	Jerk	LREAL	Non-negative number	0	Specify the jerk. The unit is command units/s <sup>3</sup> .
CoordSystem	Coordinate System	_eMC_ COORD_ SYSTEM	0: _mcACS	0*3	Specify the coordinate system.  0: Axis coordinate system (ACS)

Name	Meaning	Data type	Valid range	Default	Description
BufferMode	Buffer Mode Selection	_eMC_ BUFFER_ MODE	0: _mcAborting 1: _mcBuffered 2: _mcBlendingLow 3: _mcBlendingPrevious 4: _mcBlendingNext 5: _mcBlendingHigh	0*3	Specify the operation when executing more than one motion instruction.  0: Aborting 1: Buffered 2: Blend with low 3: Blend with previous 4: Blend with next 5: Blend with high
TransitionMode	Transition Mode	_eMC_ TRANSITION_ MODE	0: _mcTMNone 10: _mcTMCornerSuperimposed	0*3	Specify the path of motion. 0: Transition disabled 10: Superimpose corners
MoveMode	Travel Mode	_eMC_MOVE_ MODE	0: _mcAbsolute 1: _mcRelative	0*3	Select the travel method.  0: Absolute positioning  1: Relative positioning

<sup>\*1</sup> Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE	TRUE when the axes group is being controlled.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

<sup>\*2</sup> Always set the target velocity. If the axes are moved without setting a target velocity, an error will occur.

<sup>\*3</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

#### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When positioning is completed.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
Active	When the axes move.	When Done changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
CommandAborted	When this instruction is aborted because another motion control instruction was exe-	When Execute is TRUE and changes to FALSE.
	cuted with the Buffer Mode set to Aborting.	After one period when <i>Execute</i> is FALSE.
	When this instruction is canceled due to an error.	
	• When this instruction is executed while there is an error.	
	<ul> <li>When you start this instruction during MC_GroupStop instruction execution.</li> </ul>	
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# **In-Out Variables**

Name	Meaning	Data type Valid range		Description
AxesGroup	Axes Group	_sGROUP_REF		Specify the axes group.*

Specify an Axes Group Variable that was created in the Axes Group Basic Settings of the Sysmac Studio. (The default axes group variable names are MC\_Group\*\*\*.)

#### **Function**

• The MC\_MoveLiner instruction performs linear interpolation for 2 to 4 axes.



#### **Precautions for Correct Use**

- An Instruction Execution Error with Undefined Home (error code: 5466 hex) occurs if home is undefined for any of the composition axes in the axes group.
- · You cannot execute an instruction to perform linear interpolation if a limit input is ON for any of the logical axes that belong to the axes group.

### **Instruction Details**

This section describes the instruction in detail.

#### Linear Interpolation Procedure


Use the following procedure to perform linear interpolation.

### **1** Registering Axes Groups for Interpolation

- Select the axes group to perform interpolation.
   An axes group is represented by "\_MC\_GRP[\*\*\*]".
- Specify the axis composition with *Compsition* in the Axis Group Variable. You can specify two to four axes.
- Specify the combination of axes to perform interpolation with the Axis Selection Axes Group Variable.
- Use logical axes (axis A0 to A3) for the axes, and not axis numbers (axis 0 to 63).
- Specify axis numbers 0 to 63 for the logical axes A0 to A3 in order from the lowest number using the Axis Selection Axes Group Variable.

Logical axis	Axis number
Axis A0	Axis 0 to Axis 63
Axis A1	Axis 0 to Axis 63
Axis A2	Axis 0 to Axis 63
Axis A3	Axis 0 to Axis 63

 In the Axes Group Basic Settings of the Sysmac Studio, select the axis composition to use and assign an axis number to the logical axis. The following example shows a 3-axis axes group that is called MC\_Group000 with the following axes registered in it: MC\_Axis000, MC\_Axis001, and MC\_Axis002.





#### **Precautions for Correct Use**

An axis type error will occur and operation will end if an encoder axis or virtual encoder axis is included in the axes group. Make sure that you select only servo axes or virtual servo axes.

# **2** Enabling the Axes Group

- Execute the MC\_GroupEnable instruction to enable the registered axes group.
- Turn ON the Servo for the composition axes and change *Execute* of the MC\_Stop instruction to FALSE.

Using the Linear Interpolation instruction is now enabled.


#### Position (Target Position)

- Set the target position in Position (Target Position) for all of the axes specified in the Axis Selection Axes Group Variable.
- You must create a 1×4 array variable in the Sysmac Studio to assign *Position* (A0, A1, A2, and A3). You can use any variable name.

Assign the target positions for the axis to the elements of that array.

Always create a 1×4 array even if there are fewer than four axes in the axes group.

An example is shown below when the Pos1 array variable is declared on the Sysmac Studio.




The following example shows assigning the target positions to *Pos1* with inline ST. In the figure, target positions (1000.0, 2000.0, 3000.0) are assigned to axes A0 to A2.

```
EnterVariable
                     1 Pos1[0]:=LREAL#1000.0; (* A0 *)
                     2 Pos1[1]: =LREAL#2000.0; (* A1 *)
                     3 Pos1[2]:=LREAL#3000.0; (* A2 *)
```

• If an axis with the Count Mode set to Rotary Mode is set as an interpolation axis and you specify absolute position, the target value will be the same as if Direction was set to No direction specified. For details, refer to *Direction* on page 3-42.

# Velocity (Target Velocity), Acceleration (Acceleration Rate), Deceleration (Deceleration Rate), and Jerk

Set *Velocity, Acceleration, Deceleration,* and *Jerk* to specify the interpolation velocity, acceleration rate, deceleration rate, and jerk for linear interpolation. Linear interpolation separates the interpolated motion into motion on each axis. As an example, the following figure shows linear interpolation of 2 axes from point A to point B.



For linear interpolation of four axes, the interpolation velocity and travel distance of each axis determine the target velocities as shown below.

F: Specified interpolation feeding velocity

Fa0: Interpolation feeding velocity based on expansion of F to axis A0

Fa1: Interpolation feeding velocity based on expansion of F to axis A1

Fa2: Interpolation feeding velocity based on expansion of F to axis A2

Fa3: Interpolation feeding velocity based on expansion of F to axis A3

Ta: Interpolation acceleration time

Td: Interpolation deceleration time

L: Travel distance on the specified path

La0, La1, La2, and La3: Travel distances of axis A0, axis A1, axis A2, and axis A3.

L, Fa0, Fa1, Fa2, and Fa3 can be expressed with the following formulas.

$$Fa0 = F \times \frac{La0}{L}$$

$$Fa1 = F \times \frac{La1}{L}$$

$$Fa2 = F \times \frac{La2}{L}$$

$$Fa3 = F \times \frac{La3}{L}$$

$$L = \sqrt{La0^2 + La1^2 + La2^2 + La3^2}$$


#### **Velocity** (Target Velocity)

- An interpolation velocity specification error will occur if *Velocity* (Target Velocity) is set to 0. All axes will stop if an axis in the specified axes group is in operation.
- If any of the calculated target velocities Fa0 to Fa3 for *Velocity* (Target Velocity) exceed the maximum velocity, the *Velocity* (Target Velocity) will be automatically adjusted so that one of the axes operates at the maximum velocity.

#### Jerk


The relationships between *Acceleration* (Acceleration Rate), *Deceleration* (Deceleration Rate), and *Velocity* (Target Velocity) when *Jerk* is set to 0 and when it is set to any other value are shown below.

Jerk Set to 0
 The command value for the velocity is created with acceleration rate At and deceleration rate Dt.




Vt: Specified interpolation velocity, At: Specified acceleration rate, Dt: Specified deceleration rate.

• Short Travel Distance When *Jerk* Is 0
The interpolation velocity will not reach the specified Vt (Target Velocity).




Vt: Specified interpolation velocity, At: Specified acceleration rate, Dt: Specified deceleration rate.

Jerk Set to Value Other Than 0
 The command value for the velocity is created with At as the upper acceleration limit and Dt as the upper deceleration limit.



Vt: Specified interpolation velocity, At: Specified acceleration rate, Dt: Specified deceleration rate, Jt: Specified jerk

• Short Travel Distance When Jerk Is Not 0 The interpolation velocity will not reach the specified Vt (Target Velocity).



Vt: Specified interpolation velocity, At: Specified acceleration rate, Dt: Specified deceleration rate, Jt: Specified jerk



#### **Additional Information**

- If 0 is specified for Acceleration (Acceleration Rate), the specified Velocity (Target Velocity) is used immediately.
- If 0 is specified for *Deceleration* (Deceleration Rate), the axis stops immediately. However, if the Buffer Mode is set to a blending mode, axis operation will change to the target velocity specified by the next operation without stopping. For details, refer to BufferMode (Buffer Mode Selection) on page 4-19.
- When the Acceleration (Acceleration Rate) or Deceleration (Deceleration Rate) is 0, the jerk setting is disabled.

#### CoordSystem (Coordinate System)

CoordSystem specifies the coordinate system to use for linear interpolation. Only an axis coordinate system (ACS) consisting of two or more axes is supported.

#### • BufferMode (Buffer Mode Selection)

- BufferMode specifies how to join the axis motions for this interpolation instruction and the previous interpolation instruction.
- There are the following six settings.

Buffer	r Mode Selection	Description
Aborting		Aborts the instruction being executed and switches to this instruction.  If the direction of axis motion is reversed by switching instructions, the motion will be reversed according to the Operation at Reversing axis parameter.
Buffered		Buffers this instruction and executes it automatically after the current instruction is completed.
Blending		Starts the buffered instruction at the velocity (transit velocity) at which the current instruction reaches the target position. The operation of the current instruction is changed so that the axes reach the target position at the transit velocity. There are four methods to specify the transit velocity. These are described below. You can also specify a Transition Mode as an option to the Blending Mode (see below).
	Blend with low	The lower of the target velocities of the current instruction and the buffered instruction is used as the transit velocity.
	Blend with previous	The target velocity of the current instruction is used as the transit velocity.
	Blend with next	The target velocity of the buffered instruction is used as the transit velocity.
	Blend with high	The higher of the target velocities of the current instruction and the buffered instruction is used as the transit velocity.

For details on *BufferMode* (Buffer Mode Selection), refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### TransitionMode

- *TransitionMode* specifies how to combine the paths created by the previous interpolation operation and the next interpolation operation.
- Set the *TransitionMode* to either *\_mcTMNone* (Transition Disabled) or *\_mcTMCornerSuperimposed* (Superimpose Corners).
- *TransitionMode* is enabled when blending is specified for *BufferMode*.
- An error will occur if you do not set *TransitionMode* to \_mcTMNone (Transition Disabled) when blending is not used.


#### **Transition Disabled**

The path is given priority when creating the velocity command value, so velocity command values of the axes may change rapidly when switching from one operation to the next.

#### Operation Example

The Velocity (Target Velocity), BufferMode, and TransitionMode when transitioning from P1 to P2, and from P2 to P3 are shown below.

- Motion from P1 to P2: Velocity = F, BufferMode = Aborting, TransitionMode = \_mcTMNone (TransitionMode) sition Disabled)
- Motion from P2 to P3: Velocity = F, BufferMode = Blend with next, TransitionMode = \_mcTMNone (Transition Disabled)
- The motion starts from position P1 and goes through position P2. Linear interpolation is performed to position P3.
- The linear interpolation velocity F is maintained when passing position P2. Because of this, the velocity is discontinuous at position P2 as shown in the following figure.




#### **Superimpose Corners**

Use the superimpose corners specification when you want make the axes command velocities continuous.

#### Operation Example

The *Velocity* (Target Velocity), *BufferMode*, and *TransitionMode* when transitioning from P1 to P2, and from P2 to P3 are shown below.

- Motion from P1 to P2: Velocity = F, BufferMode = Aborting, TransitionMode = \_mcTMNone (Transition Disabled)
- Motion from P2 to P3: Velocity = F, BufferMode = Blend with next, TransitionMode = \_mcTMCornerSuperimposed (Superimpose Corners)
- The motion starts from position P1 and passes near position P2. Linear interpolation is performed to position P3.
- To make the axes command velocities continuous, the deceleration range of the previous motion
  and the acceleration range of the current motion are combined to create the command velocity.
  For this reason, the acceleration time of the current motion is the same as the deceleration time of
  the previous motion.



The combined path passes near P2.

The distance from P2 to the path is longer when the interpolation velocity is faster or the deceleration rate of the previous instruction is smaller. It is shorter when the interpolation velocity is slower or the deceleration rate of the previous instruction is larger.




#### **Additional Information**

The Jerk settings are disabled in the region with superimposed corners.

# **Re-execution of Motion Control Instructions**

This instruction cannot be re-executed. A Motion Control Instruction Re-execution Disabled error (error code: 543B hex) occurs if re-execution is attempted, and all axes in the linear interpolation motion stop.




### Multi-execution of Motion Control Instructions

A restriction applies to the instructions that can be used while this instruction is in execution. For details on multi-execution of motion control instructions, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

#### **Errors**

If an error occurs during instruction execution, Error will change to TRUE and the axes will stop. You can find out the cause of the error by referring to the value output by ErrorID (Error Code).



#### Error Codes

Refer to A-1 Error Codes for instruction errors.

## **Sample Programming**

This section shows sample programming for linear interpolation with periodic multi-execution of instructions.

# **Parameter Settings**

The minimum settings required for this sample programming are given below.

#### Setting Axis Parameters

#### **Axis Types**

Axis	Axis Type		
Axis 1	Servo axis		
Axis 2	Servo axis		

#### **Count Modes**

Axis	Count Mode
Axis 1	Linear Mode
Axis 2	Linear Mode

#### **Units of Display**

Axis	Unit of Display
Axis 1	mm
Axis 2	mm

#### Axes Group Parameter Settings

#### **Axis Composition**

Two axes are set.


#### **Axis Selection**

Axis 1 and axis 2 are set.

# Operation Example

The following is an example of operation that performs linear interpolation automatically and then returns to home and stops. Linear interpolations (2) to (7) are executed with multi-execution of instructions while linear interpolation (1) is being executed. Set the Buffer Mode Selection to Buffered. In this sample, multi-execution of instructions is performed for (2) to (7) if the Active (Controlling) output variable from linear interpolation (1) is TRUE. For multiaxes coordinated operation, multi-execution is possible for up to seven instructions.

#### Operation Pattern



Positioning is performed using linear interpolations in the order (Axis1, Axis2) = (50.00 mm, 5.00 mm)  $\rightarrow$  (0.00 mm, 10.00 mm)  $\rightarrow$  (50.00 mm, 15.00 mm)  $\rightarrow$  (0.00 mm, 20.00 mm)  $\rightarrow$  (50.00 mm,  $25.00 \text{ mm}) \rightarrow (50.00 \text{ mm}, 0.00 \text{ mm}) \rightarrow (0.00 \text{ mm}, 0.00 \text{ mm}), \text{ then stop.}$ 

# **Ladder Diagram**

#### Main Variables


Name	Data type	Default	Comment
MC_Group000	_sGROUP _REF		This is the Axes Group Variable for axes group 0.
MC_Group000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axes group 0.
MC_Group000.Status.Disabled	BOOL	FALSE	The value is TRUE when axes group 0 is disabled.
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 1.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 1.
MC_Axis001	_sAXIS_REF		This is the Axis Variable for axis 2.
MC_Axis001.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 2.
MC_Axis001.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 2.
Pwr1_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.

Name	Data type	Default	Comment
Pwr2_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR2 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
StartPg	BOOL	FALSE	The Servos for the axes in the axes group are turned ON if this variable is TRUE and Ether-CAT process data communications are established.
InitFlag	BOOL	FALSE	This variable indicates if it is necessary to set the input parameters. Input parameters are set when this variable is FALSE. When setting the input parameters is completed, this variable changes to TRUE.

#### Sample Programming


If StartPg is TRUE, EtherCAT communications for the axes are checked to see if process data communications are normal.

If process data communications are active, the Servo is turned ON for the axes.




If there is a minor fault level error for a composition axis, the error handler for the device (FaultHandler) is executed. Design FaultHandler separately.






If the Servo is ON for axis 2 and home is not defined, the Home instruction is executed to define home.



After home is defined for axis 1 and axis 2, the axes group is enabled.




The parameters are set for linear interpolation.

```
Note: The contents of the inline ST are given below.
```


If the axes group is enabled, linear interpolation (1) is executed.

```
MV_LIN1
                                                                   MC_MoveLinear
                                                                                                      Mv_Lin1_D
                                                           AxesGroup -
                                           MC_Group000 -
Grp_En_D
                                                                              AxesGroup
                                                           Execute
                                                                                    Done
                                            Mv_Lin1_Pos -
                                                                                            Mv_Lin1_Bsy
                                                           Position
                                                                                    Busy
                                            Mv_Lin1_Vel -
                                                                                   Active
                                                                                            Mv_Lin1_Act
                                                           Velocity
                                            Mv_Lin1_Acc -
                                                                                            Mv_Lin1_Ca
                                                           Acceleration CommandAborted
                                            Mv_Lin1_Dec -
                                                                                    Error
                                                                                            Mv_Lin1_Err
                                                           Deceleration
                                                                                  ErrorID
                                                                                            Mv_Lin1_ErrID
                                                            Jerk
                                                           CoordSystem
                                                           BufferMode
                                                            TransitionMode
                                                            MoveMode
                                            Mv_Lin1_Mm -
```


Linear interpolation (2) is executed with multi-execution of instructions after linear interpolation (1) is started.




Linear interpolation (3) is executed with multi-execution of instructions after linear interpolation (1) is started.



Linear interpolation (4) is executed with multi-execution of instructions after linear interpolation (1) is started.





BufferMode TransitionMode


MoveMode

Linear interpolation (5) is executed with multi-execution of instructions after linear interpolation (1) is started.


Linear interpolation (6) is executed with multi-execution of instructions after linear interpolation (1) is started.

Mv\_Lin5\_Bm -

Mv\_Lin5\_Mm -



Linear interpolation (7) is executed with multi-execution of instructions after linear interpolation (1) is started.



#### **Contents of Inline ST**

```
// MV_LIN1 parameters
  Mv_Lin1_Pos[0]
                     := LREAL#10#50.0;
  Mv_Lin1_Pos[1]
                     := LREAL#10#5.0;
  Mv_Lin1_Vel
                     := LREAL#10#100.0;
  Mv_Lin1_Acc
                     := LREAL#10#100.0;
  Mv_Lin1_Dec
                     := LREAL#10#100.0;
                     := _eMC_MOVE_MODE#_mcAbsolute;
  Mv_Lin1_Mm
// MV_LIN2 parameters
  Mv_Lin2_Pos[0]
                     := LREAL#10#0.0;
  Mv_Lin2_Pos[1]
                     := LREAL#10#10.0;
  Mv_Lin2_Vel
                     := LREAL#10#100.0;
  Mv_Lin2_Acc
                     := LREAL#10#100.0;
```

```
Mv_Lin2_Dec
                     := LREAL#10#100.0;
   Mv_Lin2_Bm
                     := _eMC_BUFFER_MODE#_mcBuffered;
                     := _eMC_MOVE_MODE#_mcAbsolute;
   Mv_Lin2_Mm
// MV_LIN3 parameters
   Mv_Lin3_Pos[0]
                     := LREAL#10#50.0;
   Mv_Lin3_Pos[1]
                     := LREAL#10#15.0;
   Mv_Lin3_Vel
                     := LREAL#10#100.0;
   Mv_Lin3_Acc
                    := LREAL#10#100.0;
   Mv_Lin3_Dec
                    := LREAL#10#100.0;
                    := _eMC_BUFFER_MODE#_mcBuffered;
   Mv_Lin3_Bm
   Mv_Lin3_Mm
                     := _eMC_MOVE_MODE#_mcAbsolute;
// MV_LIN4 parameters
   Mv Lin4 Pos[0]
                     := LREAL#10#0.0;
   Mv_Lin4_Pos[1]
                     := LREAL#10#20.0;
   Mv_Lin4_Vel
                     := LREAL#10#100.0;
   Mv Lin4 Acc
                     := LREAL#10#100.0;
   Mv_Lin4_Dec
                     := LREAL#10#100.0;
   Mv_Lin4_Bm
                     := _eMC_BUFFER_MODE#_mcBuffered;
   Mv_Lin4_Mm
                     := _eMC_MOVE_MODE#_mcAbsolute;
// MV_LIN5 parameters
   Mv_Lin5_Pos[0]
                     := LREAL#10#50.0;
   Mv_Lin5_Pos[1]
                     := LREAL#10#25.0;
   Mv_Lin5_Vel
                     := LREAL#10#100.0;
   Mv Lin5 Acc
                     := LREAL#10#100.0;
   Mv Lin5 Dec
                     := LREAL#10#100.0:
                     := eMC BUFFER MODE# mcBuffered;
   Mv Lin5 Bm
   Mv_Lin5_Mm
                     := _eMC_MOVE_MODE#_mcAbsolute;
// MV_LIN6 parameters
   Mv_Lin6_Pos[0]
                     := LREAL#10#50.0;
   Mv_Lin6_Pos[1]
                     := LREAL#10#0.0;
   Mv_Lin6_Vel
                     := LREAL#10#100.0;
   Mv_Lin6_Acc
                    := LREAL#10#100.0;
   Mv_Lin6_Dec
                    := LREAL#10#100.0;
                     := _eMC_BUFFER_MODE#_mcBuffered;
   Mv_Lin6_Bm
                     := _eMC_MOVE_MODE#_mcAbsolute;
   Mv_Lin6_Mm
// MV_LIN7 parameters
   Mv_Lin7_Pos[0]
                     := LREAL#10#0.0;
   Mv_Lin7_Pos[1]
                     := LREAL#10#0.0;
   Mv_Lin7_Vel
                     := LREAL#10#100.0;
   Mv_Lin7_Acc
                     := LREAL#10#100.0;
   Mv_Lin7_Dec
                     := LREAL#10#100.0;
   Mv_Lin7_Bm
                     := _eMC_BUFFER_MODE#_mcBuffered;
   Mv_Lin7_Mm
                     := _eMC_MOVE_MODE#_mcAbsolute;
// InitFlag is changed to TRUE after input parameters are set.
```

InitFlag := TRUE;

# Structured Text (ST)

#### Main Variables

Name	Data type	Default	Comment
MC_Group000	_sGROUP _REF		This is the Axes Group Variable for axes group 0.
MC_Group000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axes group 0.
MC_Group000.Status.Disabled	BOOL	FALSE	The value is TRUE when axes group 0 is disabled.
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 1.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 1.
MC_Axis001	_sAXIS_REF		This is the Axis Variable for axis 2.
MC_Axis001.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 2.
MC_Axis001.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 2.
Pwr1_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
Pwr2_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR2 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
StartPg	BOOL	FALSE	The Servos for the axes in the axes group are turned ON if this variable is TRUE and Ether-CAT process data communications are established.
InitFlag	BOOL	FALSE	This variable indicates if it is necessary to set the input parameters. Input parameters are set when this variable is FALSE. When setting the input parameters is completed, this variable changes to TRUE.

#### Sample Programming

// Processing when input parameters are not set IF InitFlag=FALSE THEN

```
// MV_LIN1 parameters
```

 $Mv\_Lin1\_Pos[0] \qquad := LREAL\#10\#50.0;$  $Mv\_Lin1\_Pos[1] \qquad := LREAL\#10\#5.0;$ 

 Mv\_Lin1\_Vel
 := LREAL#10#100.0;

 Mv\_Lin1\_Acc
 := LREAL#10#100.0;

 Mv\_Lin1\_Dec
 := LREAL#10#100.0;

 Mv\_Lin1\_Mm
 := \_eMC\_MOVE\_MO

:= \_eMC\_MOVE\_MODE#\_mcAbsolute;

```
// MV_LIN2 parameters
   Mv_Lin2_Pos[0]
                     := LREAL#10#0.0;
   Mv_Lin2_Pos[1]
                     := LREAL#10#10.0;
   Mv_Lin2_Vel
                     := LREAL#10#100.0;
   Mv_Lin2_Acc
                     := LREAL#10#100.0;
   Mv_Lin2_Dec
                     := LREAL#10#100.0;
   Mv_Lin2_Bm
                     := _eMC_BUFFER_MODE#_mcBuffered;
   Mv_Lin2_Mm
                     := _eMC_MOVE_MODE#_mcAbsolute;
   // MV_LIN3 parameters
                     := LREAL#10#50.0;
   Mv_Lin3_Pos[0]
   Mv_Lin3_Pos[1]
                     := LREAL#10#15.0;
   Mv_Lin3_Vel
                     := LREAL#10#100.0;
   Mv_Lin3_Acc
                     := LREAL#10#100.0;
   Mv Lin3 Dec
                     := LREAL#10#100.0;
                     := _eMC_BUFFER_MODE#_mcBuffered;
   Mv_Lin3_Bm
   Mv_Lin3_Mm
                     := _eMC_MOVE_MODE#_mcAbsolute;
   // MV_LIN4 parameters
   Mv_Lin4_Pos[0]
                     := LREAL#10#0.0;
   Mv_Lin4_Pos[1]
                     := LREAL#10#20.0;
   Mv_Lin4_Vel
                     := LREAL#10#100.0;
                     := LREAL#10#100.0;
   Mv_Lin4_Acc
   Mv_Lin4_Dec
                     := LREAL#10#100.0;
   Mv_Lin4_Bm
                     := _eMC_BUFFER_MODE#_mcBuffered;
                     := \_eMC\_MOVE\_MODE\#\_mcAbsolute;
   Mv_Lin4_Mm
   // MV LIN5 parameters
   Mv Lin5 Pos[0]
                     := LREAL#10#50.0;
   Mv_Lin5_Pos[1]
                     := LREAL#10#25.0;
   Mv_Lin5_Vel
                     := LREAL#10#100.0;
   Mv_Lin5_Acc
                     := LREAL#10#100.0;
   Mv_Lin5_Dec
                     := LREAL#10#100.0;
   Mv_Lin5_Bm
                     := _eMC_BUFFER_MODE#_mcBuffered;
   Mv_Lin5_Mm
                     := _eMC_MOVE_MODE#_mcAbsolute;
   // MV_LIN6 parameters
                     := LREAL#10#50.0;
   Mv_Lin6_Pos[0]
                     := LREAL#10#0.0;
   Mv_Lin6_Pos[1]
   Mv_Lin6_Vel
                     := LREAL#10#100.0;
   Mv_Lin6_Acc
                     := LREAL#10#100.0:
   Mv Lin6 Dec
                     := LREAL#10#100.0;
   Mv_Lin6_Bm
                     := _eMC_BUFFER_MODE#_mcBuffered;
   Mv_Lin6_Mm
                     := _eMC_MOVE_MODE#_mcAbsolute;
   // MV_LIN7 parameters
   Mv_Lin7_Pos[0]
                     := LREAL#10#0.0;
   Mv_Lin7_Pos[1]
                     := LREAL#10#0.0;
   Mv_Lin7_Vel
                     := LREAL#10#100.0;
   Mv_Lin7_Acc
                     := LREAL#10#100.0;
   Mv_Lin7_Dec
                     := LREAL#10#100.0;
   Mv_Lin7_Bm
                     := _eMC_BUFFER_MODE#_mcBuffered;
   Mv_Lin7_Mm
                     := _eMC_MOVE_MODE#_mcAbsolute;
   // Change InitFlag to TRUE after setting the input parameters.
   InitFlag := TRUE;
END_IF;
// If StartPq is TRUE and EtherCAT communications are normal, the Servo for axis 1 is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
```

```
AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
   Pwr1_En:=TRUE;
                         // Turn ON the Servo for axis 1.
ELSE
                          // Turn OFF the Servo for axis 1.
   Pwr1_En:=FALSE;
END_IF;
// If StartPg is TRUE and EtherCAT communications are normal, the Servo for axis 2 is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis001.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis001.Cfg.NodeAddress]=FALSE) THEN
                         // Turn ON the Servo for axis 2.
   Pwr2_En:=TRUE;
FLSE
   Pwr2_En:=FALSE;
                          // Turn OFF the Servo for axis 2.
END IF;
// Processing for a minor fault level error
// Implement FaultHandler separately.
IF (MC_Axis000.MFaultLvl.Active=TRUE) OR (MC_Axis001.MFaultLvl.Active=TRUE) OR
(MC_Group000.MFaultLvl.Active=TRUE)THEN
   FaultHandler():
END_IF;
// If the Servo is ON for axis 1 and home is not defined, the Home instruction is executed.
IF (Pwr1_Status=TRUE) AND (MC_Axis000.Details.Homed=FALSE) THEN
   Hm1_Ex:=TRUE;
END_IF;
// If the Servo is ON for axis 2 and home is not defined, the Home instruction is executed.
IF (Pwr2 Status=TRUE) AND (MC Axis001.Details.Homed=FALSE) THEN
   Hm2_Ex:=TRUE;
END_IF;
// If axes group 0 is disabled while home is defined for axis 1 and axis 2, it is enabled.
IF (Hm1_D=TRUE) AND (Hm2_D=TRUE) AND (MC_Group000.Status.Disabled=TRUE) THEN
      Grp_En_Ex:= TRUE;
END IF:
// After the MC_GroupEnable (Enable Axes Group) instruction is completed, linear interpolation (1) is executed.
IF Grp En D=TRUE THEN
   Mv_Lin1_Ex:=TRUE;
END_IF;
// Linear interpolations (2) to (7) are executed with multi-execution of instructions while the Active output
variable for linear interpolation (1) is TRUE.
IF Mv_Lin1_Act=TRUE THEN
   Mv_Lin2_Ex:=TRUE;
   Mv_Lin3_Ex:=TRUE;
   Mv_Lin4_Ex:=TRUE;
   Mv_Lin5_Ex:=TRUE;
   Mv_Lin6_Ex:=TRUE;
   Mv_Lin7_Ex:=TRUE;
END_IF;
// MC_Power for axis 1
PWR1(
   Axis
             := MC_Axis000,
   Enable
            := Pwr1_En,
   Status
            => Pwr1_Status,
             => Pwr1_Bsy,
   Busy
            => Pwr1_Err,
   Error
   ErrorID
            => Pwr1_ErrID
);
// MC_Power for axis 2
```

```
PWR2(
            := MC_Axis001,
   Axis
   Enable
            := Pwr2_En,
   Status
            => Pwr2_Status,
   Busy
            => Pwr2_Bsy,
   Error
            => Pwr2_Err,
   ErrorID
            => Pwr2_ErrID
);
// MC_Home for axis 1
HM1(
                      := MC_Axis000,
   Axis
   Execute
                      := Hm1_Ex,
   Done
                      => Hm1_D,
                      => Hm1_Bsy,
   Busy
   CommandAborted
                      => Hm1_Ca,
   Error
                      => Hm1_Err,
   ErrorID
                      => Hm1 ErrID
);
// MC_Home for axis 2
HM2(
   Axis
                      := MC_Axis001,
   Execute
                      := Hm2_Ex,
                      => Hm2_D,
   Done
                      => Hm2_Bsy,
   Busy
   CommandAborted
                      => Hm2 Ca,
                      => Hm2 Err.
   Error
   ErrorID
                      => Hm2 ErrID
);
// Axes group 0 is enabled.
GRP EN(
                      := MC_Group000,
   AxesGroup
                      := Grp\_En\_Ex,
   Execute
                      => Grp_En_D,
   Done
   Busy
                      => Grp_En_Bsy,
   CommandAborted => Grp_En_Ca,
   Error
                      => Grp_En_Err,
   ErrorID
                      => Grp_En_ErrID
);
// Linear interpolation (1)
MV_LIN1(
   AxesGroup
                      := MC_Group000,
   Execute
                      := Mv_Lin1_Ex,
   Position
                      := Mv_Lin1_Pos,
   Velocity
                      := Mv_Lin1_Vel,
   Acceleration
                      := Mv_Lin1_Acc,
   Deceleration
                      := Mv Lin1 Dec.
   MoveMode
                      := Mv_Lin1_Mm,
   Done
                      => Mv_Lin1_D,
   Busy
                      => Mv Lin1 Bsy,
   Active
                      => Mv_Lin1_Act,
   CommandAborted
                      => Mv_Lin1_Ca,
   Error
                      => Mv_Lin1_Err,
   ErrorID
                      => Mv_Lin1_ErrID
);
// Linear interpolation (2)
MV_LIN2(
                      := MC_Group000,
   AxesGroup
   Execute
                      := Mv_Lin2_Ex,
   Position
                      := Mv_Lin2_Pos,
```

ErrorID

=> Mv\_Lin5\_ErrID

```
);
// Linear interpolation (6)
MV_LIN6(
   AxesGroup
                      := MC_Group000,
   Execute
                      := Mv_Lin6_Ex,
   Position
                      := Mv_Lin6_Pos,
   Velocity
                      := Mv_Lin6_Vel,
   Acceleration
                      := Mv_Lin6_Acc,
   Deceleration
                      := Mv_Lin6_Dec,
   BufferMode
                      := Mv_Lin6_Bm,
   MoveMode
                      := Mv_Lin6_Mm,
   Done
                      => Mv_Lin6_D,
   Busy
                      => Mv_Lin6_Bsy,
                      => Mv_Lin6_Act,
   Active
   CommandAborted
                      => Mv_Lin6_Ca,
   Error
                      => Mv_Lin6_Err,
   ErrorID
                      => Mv_Lin6_ErrID
);
// Linear interpolation (7)
MV_LIN7(
   AxesGroup
                      := MC_Group000,
   Execute
                      := Mv_Lin7_Ex,
                      := Mv_Lin7_Pos,
   Position
                      := Mv_Lin7_Vel,
   Velocity
                      := Mv_Lin7_Acc,
   Acceleration
                      := Mv Lin7 Dec.
   Deceleration
   BufferMode
                      := Mv_Lin7_Bm,
   MoveMode
                      := Mv Lin7 Mm,
   Done
                      => Mv Lin7 D,
   Busy
                      => Mv_Lin7_Bsy,
   Active
                      => Mv_Lin7_Act,
   CommandAborted
                      => Mv_Lin7_Ca,
   Error
                      => Mv_Lin7_Err,
                      => Mv_Lin7_ErrID
   ErrorID
);
```

# MC\_MoveLinearAbsolute

The MC\_MoveLinearAbsolute instruction performs linear interpolation for a specified absolute position.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_MoveLinearAbsolute	Absolute Linear Interpolation	FB	MC_MoveLinearAbsolute instance  MC_MoveLinearAbsolute AxesGroup — AxesGroup — AxesGroup — Position Busy Velocity Active Acceleration CommandAborted Deceleration Error Jerk ErrorID — CoordSystem BufferMode TransitionMode	MC_MoveLinearAbsolute_instance ( AxesGroup :=parameter, Execute :=parameter, Position :=parameter, Velocity :=parameter, Acceleration :=parameter, Deceleration :=parameter, Jerk :=parameter, CoordSystem :=parameter, BufferMode :=parameter, TransitionMode :=parameter, Done =>parameter, Busy =>parameter, Active =>parameter, Active =>parameter, Error =>parameter, Error =>parameter, ErrorID =>parameter);

## **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Execute</i> changes to TRUE.
Position	Target Position	ARRAY [03] OF LREAL	Negative number, positive number, or 0	0	Specify the target position for linear interpolation. The unit is command units.*1
Velocity*2	Target Velocity	LREAL	Positive number	0	Specify the target velocity. The unit is command units/s.*1
Acceleration	Acceleration Rate	LREAL	Non-negative number	0	Specify the acceleration rate. The unit is command units/s <sup>2</sup> .* <sup>1</sup>
Deceleration	Deceleration Rate	LREAL	Non-negative number	0	Specify the deceleration rate. The unit is command units/s <sup>2</sup> .* <sup>1</sup>
Jerk	Jerk	LREAL	Non-negative number	0	Specify the jerk. The unit is command units/s <sup>3</sup> .* <sup>1</sup>

Name	Meaning	Data type	Valid range	Default	Description
CoordSystem	Coordinate System	_eMC_ COORD_ SYSTEM	0: _mcACS	0*3	Specify the coordinate system.  0: Axis coordinate sys-
BufferMode	Buffer Mode Selection	_eMC_ BUFFER_ MODE	0: _mcAborting 1: _mcBuffered 2: _mcBlendingLow 3: _mcBlendingPrevious 4: _mcBlendingNext 5: _mcBlendingHigh	0*3	tem (ACS)  Specify the operation when executing more than one motion instruction.  0: Aborting 1: Buffered 2: Blend with low 3: Blend with previous 4: Blend with next 5: Blend with high
TransitionMode	Transition Mode	_eMC_ TRANSITION_ MODE	0: _mcTMNone 10: _mcTMCornerSuperimposed	0*3	Specify the path of motion.  0: Transition disabled  10: Superimpose corners

<sup>\*1</sup> Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE	TRUE when the axes group is being controlled.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

<sup>\*2</sup> Always set the target velocity. If the axes are moved without setting a target velocity, an error will occur.

<sup>\*3</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

#### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When positioning is completed.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
Active	When the axis starts moving.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
CommandAborted	When this instruction is aborted because another motion control instruction was exe-	When Execute is TRUE and changes to FALSE.
	cuted with the Buffer Mode set to <i>Aborting</i> .	After one period when <i>Execute</i> is FALSE.
	When this instruction is canceled due to an error.	7 mon one pener milen 2/100m is 17 m2021
	When this instruction is executed while there is an error.	
	When you start this instruction during MC_GroupStop instruction execution.	
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

## **In-Out Variables**

Name	Meaning	Data type	Valid range	Description
AxesGroup	Axes Group	_sGROUP_REF		Specify the axes group.*

Specify an Axes Group Variable that was created in the Axes Group Basic Settings of the Sysmac Studio. (The default axes group variable names are MC\_Group\*\*\*.)

#### **Function**

- The MC\_MoveLinearAbsolute instruction performs linear interpolation for 2 to 4 axes.
- The target position is specified as an absolute position.

Other specifications are the same as those for the MC\_MoveLinear (Linear Interpolation) instruction. For details, refer to Function on page 4-12.



#### **Precautions for Correct Use**

- An error occurs if home is undefined for any of the composition axes in the axes group.
- · You cannot execute an instruction to perform linear interpolation if a limit input is ON for any of the logical axes that belong to the axes group.

# MC\_MoveLinearRelative

The MC\_MoveLinearRelative instruction performs linear interpolation for a specified relative position.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_MoveLinearRelative	Relative Linear Interpolation	FB	MC_MoveLinearRelative    MC_MoveLinearRelative    AxesGroup  — AxesGroup    Execute	MC_MoveLinearRelative_instance ( AxesGroup :=parameter, Execute :=parameter, Distance :=parameter, Velocity :=parameter, Acceleration :=parameter, Deceleration :=parameter, Jerk :=parameter, CoordSystem :=parameter, BufferMode :=parameter, TransitionMode :=parameter, Done =>parameter, Busy =>parameter, Active =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorlD =>parameter);

## **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Execute</i> changes to TRUE.
Distance	Travel Distance	ARRAY [03] OF LREAL	Negative number, positive number, or 0	0	Specify the target position for linear interpolation. The unit is command units.*1
Velocity*2	Target Velocity	LREAL	Positive number	0	Specify the target velocity. The unit is command units/s.*1
Acceleration	Accelera- tion Rate	LREAL	Non-negative number	0	Specify the acceleration rate. The unit is command units/s <sup>2</sup> .* <sup>1</sup>
Deceleration	Decelera- tion Rate	LREAL	Non-negative number	0	Specify the deceleration rate. The unit is command units/s <sup>2</sup> .* <sup>1</sup>
Jerk	Jerk	LREAL	Non-negative number	0	Specify the jerk. The unit is command units/s <sup>3</sup> .*1

Name	Meaning	Data type	Valid range	Default	Description
CoordSystem	Coordinate System	_eMC_ COORD_ SYSTEM	0: _mcACS	0*3	Specify the coordinate system.  0: Axis coordinate
-					system (ACS)
BufferMode	Buffer Mode Selection	_eMC_ BUFFER_ MODE	0: _mcAborting 1: _mcBuffered 2: _mcBlendingLow 3: _mcBlendingPrevious 4: _mcBlendingNext 5: _mcBlendingHigh	0*3	Specify the operation when executing more than one motion instruction.  0: Aborting  1: Buffered  2: Blend with low  3: Blend with previous  4: Blend with next  5: Blend with high
TransitionMode	Transition Mode	_eMC_ TRANSITION_ MODE	0: _mcTMNone 10: _mcTMCornerSuperimposed	0*3	Specify the path of motion.  0: Transition disabled  10: Superimpose corners

<sup>\*1</sup> Refer to Unit Conversion Settings in the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507) for information on command units.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE	TRUE when the axes group is being controlled.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

<sup>\*2</sup> Always set the target velocity. If the axes are moved without setting a target velocity, an error will occur.

<sup>\*3</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

#### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When positioning is completed.	When Execute is TRUE and changes to FALSE.
		After one period when <i>Execute</i> is FALSE.
Busy	When Execute changes to TRUE.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
Active	When the axis starts moving.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
CommandAborted	When this instruction is aborted because another motion control instruction was exe-	When Execute is TRUE and changes to FALSE.
	cuted with the Buffer Mode set to Aborting.	After one period when <i>Execute</i> is FALSE.
	When this instruction is canceled due to an error.	·
	When this instruction is executed while there is an error.	
	When you start this instruction during MC_GroupStop instruction execution.	
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

## **In-Out Variables**

Name	Meaning	Data type	Valid range	Description
AxesGroup	Axes Group	_sGROUP_REF		Specify the axes group.*

<sup>\*</sup> Specify an Axes Group Variable that was created in the Axes Group Basic Settings of the Sysmac Studio. (The default axes group variable names are MC\_Group\*\*\*.)

#### **Function**

- The MC\_MoveLinearRelative instruction performs linear interpolation for 2 to 4 axes.
- The target position is specified as a relative position.

Other specifications are the same as those for the MC\_MoveLinear (Linear Interpolation) instruction. For details, refer to *Function* on page 4-12.



#### **Precautions for Correct Use**

- An error occurs if home is undefined for any of the composition axes in the axes group.
- You cannot execute an instruction to perform linear interpolation if a limit input is ON for any of the logical axes that belong to the axes group.

# MC\_MoveCircular2D

The MC\_MoveCircular2D instruction performs circular interpolation for two axes.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_MoveCircular2D	Circular 2D Interpolation	FB	MC_MoveCircular2D_instance  MC_MoveCircular2D  AxesGroup — AxesGroup  Execute Done CircAxes Busy CircMode Active AuxPoint CommandAborted EndPoint Error PathChoice ErrorID  Velocity Acceleration Deceleration Jerk CoordSystem BufferMode TransitionMode MoveMode	MC_MoveCircular2D_instance ( AxesGroup :=parameter, Execute :=parameter, CircAxes :=parameter, CircMode :=parameter, AuxPoint :=parameter, EndPoint :=parameter, PathChoice :=parameter, Velocity :=parameter, Acceleration :=parameter, Deceleration :=parameter, Jerk :=parameter, CoordSystem :=parameter, BufferMode :=parameter, TransitionMode :=parameter, MoveMode :=parameter, Done =>parameter, Busy =>parameter, Active =>parameter, CommandAborted =>parameter, Error =>parameter, Error =>parameter);

## **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Execute</i> changes to TRUE.
CircAxes	Circular Axes	ARRAY [0,1] OF UINT	0 to 3	0	Specify the axes for circular interpolation.
					0: Axis A0 1: Axis A1 2: Axis A2 3: Axis A3
CircMode	Circular Interpolation	_eMC_CIRC_ MODE	0: _mcBorder 1: mcCenter	0*1	Specify the method for circular interpolation.
	Mode		2: _mcRadius		0: Border point
					1: Center
					2: Radius
AuxPoint	Auxiliary Point	ARRAY [0,1] OF LREAL	Negative number, positive number, or 0	0	Specify the border point, center, or radius. The unit is command units.*2

Name	Meaning	Data type	Valid range	Default	Description
EndPoint	End Point	ARRAY [0,1] OF LREAL	Negative number, positive number, or 0	0	Specify the target position. The unit is command units.*2
PathChoice	Path Choice	_eMC_CIRC_ PATHCHOICE	0: _mcCW 1: _mcCCW	0*1	Specify the path direction.  0: CW  1: CCW
Velocity*3	Target Velocity	LREAL	Positive number	0	Specify the target velocity. The unit is command units/s.*2
Acceleration	Acceleration Rate	LREAL	Non-negative number	0	Specify the acceleration rate. The unit is command units/s <sup>2</sup> .* <sup>2</sup>
Deceleration	Decelera- tion Rate	LREAL	Non-negative number	0	Specify the deceleration rate. The unit is command units/s <sup>2</sup> .* <sup>2</sup>
Jerk	Jerk	LREAL	Non-negative number	0	Specify the jerk. The unit is command units/s <sup>3</sup> .* <sup>2</sup>
CoordSystem	Coordinate System	_eMC_ COORD_ SYSTEM	0: _mcACS	0*1	Specify the coordinate system.  0: Axis coordinate system (ACS)
BufferMode	Buffer Mode Selection	_eMC_ BUFFER_ MODE	0: _mcAborting 1: _mcBuffered 2: _mcBlendingLow 3: _mcBlendingPrevious 4: _mcBlendingNext 5: _mcBlendingHigh	0*1	Specify the operation when executing more than one motion instruction.  0: Aborting 1: Buffered 2: Blend with low 3: Blend with previous 4: Blend with next 5: Blend with high
TransitionMode	Transition Mode	_eMC_ TRANSITION_ MODE	0: _mcTMNone 10: _mcTMCornerSuperimpose	0*1	Specify the path of motion.  0: Transition disabled  10: Superimpose corners
MoveMode	Travel Mode	_eMC_MOVE_ MODE	0: _mcAbsolute 1: _mcRelative	0*1	O: Absolute positioning     1: Relative positioning

<sup>\*1</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

<sup>\*2</sup> Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.

<sup>\*3</sup> Always set the target velocity. If the axes are moved without setting a target velocity, an error will occur.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE	TRUE when the axes group is being controlled.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When positioning is completed.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
Active	When the axis starts moving.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
CommandAborted	When this instruction is aborted because	When Execute is TRUE and changes to
	another motion control instruction was exe-	FALSE.
	cuted with the Buffer Mode set to <i>Aborting</i> .	After one period when Execute is FALSE.
	When this instruction is canceled due to an error.	
	When this instruction is executed while there is an error.	
	When you start this instruction during MC_GroupStop instruction execution.	
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# In-Out Variables

Name	Meaning	Data type	Valid range	Description
AxesGroup	Axes Group	_sGROUP_REF		Specify the axes group.*

Specify an Axes Group Variable that was created in the Axes Group Basic Settings of the Sysmac Studio. (The default axes group variable names are MC\_Group\*\*\*.)

#### **Function**

The MC\_MoveCircular2D instruction performs 2D circular interpolation for two axes.



#### **Precautions for Correct Use**

- An error occurs if home is undefined for any of the composition axes in the axes group.
- You cannot execute an instruction to perform circular 2D interpolation if a limit input is ON for any of the logical axes that belong to the axes group.

#### **Instruction Details**

This section describes the instruction in detail.

#### Circular Interpolation Procedure

Use the following procedure to perform circular interpolation.

- 1 Registering Axes Groups for Interpolation
  - Determine the axes group to perform interpolation.
     An axes group is represented by "\_MC\_GRP\*\*\*".
  - · Specify the axis composition with the Composition Axes Group Variable.
  - Specify the combination of axes to perform interpolation with the Axis Selection Axes Group Variable.
  - Use logical axes (axis A0 to A3) for the axes, and not axis numbers (axis 0 to 63).
  - Specify axis numbers 0 to 63 for the logical axes A0 to A3 in order from the lowest number using the Axis Selection Axes Group Variable.

Logical axis	Axis number
Axis A0	Axis 0 to Axis 63
Axis A1	Axis 0 to Axis 63
Axis A2	Axis 0 to Axis 63
Axis A3	Axis 0 to Axis 63

**Example:** The following specifications are used to specify axis numbers 0 and 1 for axes A0 and A1 with a 2-axis composition.

Logical axis	Axis number	Description
Axis A0	Axis 0	Specify axis numbers to the logical axes from axis A0
Axis A1	Axis 1	in order from the lowest number.



#### **Precautions for Correct Use**

An axis type error will occur and operation will end if an encoder axis or virtual encoder axis is included in the axes group. Make sure that you select only servo axes or virtual servo axes.


# **2** Enabling the Axes Group

- Execute MC\_GroupEnable (Enable Axes Group) instruction to enable the registered axes group.
- Turn ON the Servo for the composition axes and change *Execute* of the MC\_Stop instruction to FALSE.

Using the Circular Interpolation instruction is now enabled.

#### CircAxes (Circular Axes)

Circular interpolation uses the X axis and Y axis.



Specify the axes to use as the X axis and Y axis with CircAxes (Circular Axes). Use logical axes (axis A0 to A3) for the axes, and not axis numbers (axis 0 to 63).



#### **Precautions for Correct Use**

Specify the Count Mode to Linear Mode for the axes that you use for the X axis and Y axis. If you specify Rotary Mode, a Circular Interpolation Execution Error Due to Count Mode (error code: 544A hex) will occur at execution.


#### • CircMode (Circular Interpolation Mode)

There are three methods of circular interpolation: border point, center, and radius. You can specify one of these methods with CircMode (Circular Interpolation Mode). Absolute positioning or relative positioning can be used to specify the position with these methods. You can specify absolute or relative positioning with MoveMode (Travel Mode).


MoveMode	Description
Absolute positioning	The border point for a border point specification or the center point and end point for a center point specification are specified as absolute positions from home in the axis coordinate system.
Relative positioning	The border point for a border point specification or the center point and end point for a center point specification are specified as relative positions from the start point.

The difference between absolute positioning and relative positioning using a border point is described below as an example.

Circular Interpolation Method: Border Point Specification with Absolute Positioning




Circular Interpolation Method: Border Point Specification with Relative Positioning




The following sections describe the operation assuming that absolute positioning has been specified as the *MoveMode* (Travel Mode).

#### **Border point**

The current position is the starting point. Circular interpolation is performed through the border point AuxPoint(X,Y) to the end point EndPoint(X,Y).



If the start point, border point, and end point are along the same line, if the border point and the end point are at the same point, or if the start point and the border point are the same point, linear interpolation is performed from the start point to the end point.






#### **Precautions for Correct Use**


- The points are considered to be on a straight line if the distance between the border point and the line that connects the start and end point is less than one pulse for both the X and Y coordinates
- An error occurs if the start point, border point, and end point are the same point.
  The start point, border point, and end point are considered to be the same point if the command positions are the same for the command unit. If the command positions in the command unit are different, the points are not considered to be the same point and an error does not occur even if the positions are the same when they are converted to pulses.

If the start point and the end point are the same point, a complete circle is drawn with the start point and the border point as the diameter. PathChoice is specified as the circular interpolation direction.



#### Center

The current position is the starting point. Circular interpolation is performed for circle specified by the center point AuxPoint(X,Y) to the end point End-Point(X,Y). PathChoice is used to specify the circular interpolation direction. A complete circle is drawn when the start point and end point are at the same point. If the radius from the specified center to the start point is different to the radius to the end point, the average of the two radiuses is used to perform circular interpolation. In this case, the center is calculated in the same way as specifying the radius, and the calculated radius and center are used.




#### **Precautions for Correct Use**

If the Axes Group Parameter check method for circular interpolation center point specification is set to any value other than 0, a center point specification error will occur when the specified center point exceeds the circle calculated as follows:

The radius of the circle in which the center point must be positioned is the calculated radius multiplied by the percentage that is set for the center point specification check method divided by 100. (The radius calculated from the corrected center point it taken as 100%.)

#### Radius

The current position is the starting point. Circular interpolation is performed for the circle specified by the radius AuxPoint(X,Y) to the end point End-*Point(X,Y)*. The radius is specified by the first element in AuxPoint(X, Y). The second element is not used. For example, for a radius of 100, set AuxPoint(X, Y) to *AuxPoint(100,0)*. If the sign of the radius is negative, a circle with a long arc will be drawn. If the sign is positive, a circle with a short arc will be drawn. Path-Choice is used to specify the circular interpolation direction.





#### **Precautions for Correct Use**

- If the start point and the end point are the same, a same circular interpolation start and end point error will occur and operation will stop for all axes in the group.
- If the specified radius is less than half the length of the distance between the start point and end point, a circle is impossible and an error will occur.

# Velocity (Target Velocity), Acceleration (Acceleration Rate), Deceleration (Deceleration Rate), and Jerk

Set *Velocity, Acceleration, Deceleration,* and *Jerk* to specify the interpolation velocity, acceleration rate, deceleration rate, and jerk for circular interpolation. If you set the interpolation velocity for circular interpolation to 0, a velocity specification error will occur and operation will stop for all axes in the group. If the specified interpolation velocity exceeds the maximum velocity of an axis, the following operation is executed.

If only one axis exceeds the maximum velocity:

This axis moves at the maximum velocity and the interpolation velocity is adjusted accordingly.


If both axes exceed the maximum velocity:

The interpolation velocity is automatically adjusted so that the axes move at the maximum velocity of the two axes that is slower.

#### Jerk


The relationships between Acceleration (Acceleration Rate), Deceleration (Deceleration Rate), and Velocity (Target Velocity) when Jerk is set to 0 and when it is set to any other value are shown below.

• Jerk Set to 0 The command value for the velocity is created with acceleration rate At and deceleration rate Dt.




Vt: Specified interpolation velocity, At: Specified acceleration rate, Dt: Specified deceleration rate.

• Short Travel Distance When Jerk Is 0 The interpolation velocity will not reach the specified Vt (Target Velocity).




Vt: Specified interpolation velocity, At: Specified acceleration rate, Dt: Specified deceleration rate.

• Jerk Set to Value Other Than 0
The command value for the velocity is created with At as the upper acceleration limit and Dt as the upper deceleration limit.



Vt: Specified interpolation velocity, At: Specified acceleration rate, Dt: Specified deceleration rate, Jt: Specified jerk

• Short Travel Distance When *Jerk* Is Other Than 0
The interpolation velocity will not reach the specified Vt (Target Velocity).



Vt: Specified interpolation velocity, At: Specified acceleration rate, Dt: Specified deceleration rate, Jt: Specified jerk



#### **Precautions for Correct Use**

- If 0 is specified for Acceleration (Acceleration Rate), the specified interpolation velocity is used immediately.
- If 0 is specified for Deceleration (Deceleration Rate), the axis stops immediately. However, if the Buffer Mode is set to Blending, axis operation will change to the interpolation velocity specified by the next operation without stopping. For details, refer to BufferMode (Buffer Mode Selection) on page 4-52.
- When the Acceleration (Acceleration Rate) or Deceleration (Deceleration Rate) is 0, the setting of Jerk is disabled.

#### CoordSystem (Coordinate System)

- CoordSystem specifies the coordinate system to use for circular interpolation.
- Only an axis coordinate system (ACS) consisting of two or more axes is supported.

#### BufferMode (Buffer Mode Selection)

- BufferMode specifies how to join the axis motions for this interpolation instruction and the previous interpolation instruction.
- There are the following six settings.

Buffer	Mode Selection	Description
Aborting		Aborts the instruction being executed and switches to this instruction.  If the direction of axis motion is reversed by switching instructions, the motion will be reversed according to the Operation at Reversing axis parameter.
Buffered		Buffers this instruction and executes it automatically after the current instruction is completed.
Blending		Starts the buffered instruction at the velocity (transit velocity) at which the current instruction reaches the target position. The operation of the current instruction is changed so that the axes reach the target position at the transit velocity. There are four methods to specify the transit velocity. These are described below. You can also specify a Transition Mode as an option to the Blending Mode (see below).
	Blend with low	The lower of the target velocities of the current instruction and the buffered instruction is used as the transit velocity.
	Blend with previous	The target velocity of the current instruction is used as the transit velocity.
	Blend with next	The target velocity of the buffered instruction is used as the transit velocity.
	Blend with high	The higher of the target velocities of the current instruction and the buffered instruction is used as the transit velocity.

For details on BufferMode (Buffer Mode Selection), refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

#### TransitionMode


- TransitionMode specifies how to join the motions for this interpolation instruction and the previous interpolation instruction.
- If BufferMode (Buffer Mode Selection) is set to Blending, TransitionMode is enabled.
- An error will occur if you do not set *TransitionMode* to *mcTMNone* (Transition Disabled) when blending is not used.

For details, refer to *TransitionMode* on page 4-19.

#### **Re-execution of Motion Control Instructions**

This instruction cannot be re-executed.

A Motion Control Instruction Re-execution Disabled error (error code: 543B hex) occurs if re-execution is attempted, and all axes in the circular interpolation motion stop.




## **Multi-execution of Motion Control Instructions**

A restriction applies to the instructions that can be used while this instruction is in execution. For details on multi-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### **Errors**

If an error occurs during instruction execution, *Error* will change to TRUE and the axes will stop. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).



#### Error Codes

Refer to A-1 Error Codes for instruction errors.

### Sample Programming

This section shows sample programming for circular interpolation with multi-execution of instructions.

# **Parameter Settings**

The minimum settings required for this sample programming are given below.

#### Setting Axis Parameters

#### **Axis Types**

Axis	Axis Type
Axis 1	Servo axis
Axis 2	Servo axis

#### **Count Modes**

Axis	Count Mode
Axis 1	Linear Mode
Axis 2	Linear Mode

#### **Units of Display**

Axis	Unit of Display
Axis 1	mm
Axis 2	mm

### Axes Group Parameter Settings

#### **Axis Composition**

Two axes are set.


#### **Axis Selection**

Axis 1 and axis 2 are set.

# **Operation Example**

The following is an example of operation where the axes automatically perform positioning by using linear interpolation and circular interpolation. The axes move to the final target position (20.00 mm, 20.00 mm) using linear interpolation and circular interpolation. The Buffer Mode is set to Buffered and multiexecution of instructions is used. In this sample, multi-execution of instructions is performed for (2) to (4) if the Active output variable from linear interpolation (1) is TRUE. For multi-axes coordinated operation, multi-execution is possible for up to seven instructions.

### Operation Pattern



# **1** Execution

When you turn ON the operation start switch at home, the axes move to the point (10.00 mm, 5.00 mm) via linear interpolation.

### **2** Continuous Motion

The axes continue to move to the point (15.00 mm, 10.00 mm) via circular interpolation, to the point (15.00 mm, 15.00 mm) via linear interpolation, and to the point (20.00 mm, 20.00 mm) via circular interpolation. Here, the velocity is 10.00 mm/s.

# **Ladder Diagram**

#### Main Variables


Name	Data type	Default	Comment
MC_Group000	_sGROUP _REF		This is the Axes Group Variable for axes group 0.
MC_Group000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axes group 0.
MC_Group000.Status.Disabled	BOOL	FALSE	The value is TRUE when axes group 0 is disabled.
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 1.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 1.
MC_Axis001	_sAXIS_REF		This is the Axis Variable for axis 2.
MC_Axis001.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 2.
MC_Axis001.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 2.
Pwr1_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.

Name	Data type	Default	Comment
Pwr2_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR2 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
StartPg	BOOL	FALSE	The Servos for the axes in the axes group are turned ON if this variable is TRUE and Ether-CAT process data communications are established.
InitFlag	BOOL	FALSE	This variable indicates if it is necessary to set the input parameters. Input parameters are set when this variable is FALSE. When setting the input parameters is completed, this variable changes to TRUE.


#### Sample Programming

If StartPg is TRUE, EtherCAT communications for the axes are checked to see if process data communications are normal.

If process data communications are active, the Servo is turned ON.




If there is a minor fault level error for a composition axis, the error handler for the device (FaultHandler) is executed. Design FaultHandler separately.




If the Servo is ON for axis 1 and home is not defined, the Home instruction is executed.

```
HM<sub>1</sub>
                                                                       MC_Home
                                                                                                                 Hm<sub>1</sub> D
                                            MC_Axis000 ·
                                                            Axis
                                                                                        Axis
Pwr1_Status
              MC_Axis000.Details.Homed
                                                            Execute
                                                                                       Done
                                                                                       Busy
                                                                                               - Hm1_Bsy
                                                                          CommandAborted
                                                                                             - Hm1_Ca
                                                                                            — Hm1_Err
                                                                                       Error
                                                                                     ErrorID
                                                                                             — Hm1_ErrID
```

If the Servo is ON for axis 2 and home is not defined, the Home instruction is executed.




After home is defined for axis 1 and axis 2, the axes group is enabled.




The parameters are set for linear interpolation and circular interpolation.

```
InitFlag
  ₩
                                           Note: The contents of the inline ST
                                                 are given below.
```


If the axes group is enabled, linear interpolation (1) is executed.




Circular interpolation (2) is executed with multi-execution of instructions after linear interpolation (1) is started.



Linear interpolation (3) is executed with multi-execution of instructions after linear interpolation (1) is started.



Circular interpolation (4) is executed with multi-execution of instructions after linear interpolation (1) is started.



#### **Contents of Inline ST**

```
// MV CIRC1 parameters
   Mv Circ1 CircAxes[0]
                            := UINT#10#0;
   Mv_Circ1_CircAxes[1]
                            := UINT#10#1;
                            := _eMC_CIRC_MODE#_mcRadius;
   Mv_Circ1_CircMode
   Mv_Circ1_AuxPoint[0]
                           := LREAL#5.0;
   Mv_Circ1_AuxPoint[1]
                           := LREAL#0.0;
   Mv_Circ1_EndPoint[0]
                           := LREAL#15.0;
   Mv_Circ1_EndPoint[1]
                           := LREAL#10.0;
   Mv_Circ1_Pc
                            := _eMC_CIRC_PATHCHOICE#_mcCCW;
   Mv_Circ1_Vel
                            := LREAL#100.0;
   Mv Circ1 Acc
                           := LREAL#20.0;
   Mv Circ1 Dec
                           := LREAL#20.0:
   Mv Circ1 Bm
                           := eMC BUFFER MODE# mcBuffered;
   Mv Circ1 Mm
                           := eMC MOVE MODE# mcAbsolute;
// MV_CIRC2 parameters
   Mv_Circ2_CircAxes[0]
                            := UINT#10#0;
   Mv_Circ2_CircAxes[1]
                            := UINT#10#1;
   Mv_Circ2_CircMode
                            := _eMC_CIRC_MODE#_mcCenter;
   Mv_Circ2_AuxPoint[0]
                           := LREAL#15.0;
   Mv_Circ2_AuxPoint[1]
                           := LREAL#20.0;
   Mv_Circ2_EndPoint[0]
                           := LREAL#20.0;
   Mv_Circ2_EndPoint[1]
                           := LREAL#20.0;
                  := _eMC_CIRC_PATHCHOICE#_mcCW;
   Mv_Circ2_Pc
   Mv_Circ2_Vel
                  := LREAL#100.0:
   Mv Circ2 Acc
                  := LREAL#20.0;
```

```
Mv_Circ2_Dec := LREAL#20.0;
   Mv_Circ2_Bm := _eMC_BUFFER_MODE#_mcBuffered;
   Mv_Circ2_Mm := _eMC_MOVE_MODE#_mcAbsolute;
// MV_LIN1 parameters
   Mv_Lin1_Pos[0]
                   := LREAL#10#10.0;
   Mv_Lin1_Pos[1] := LREAL#10#5.0;
   Mv_Lin1_Vel := LREAL#10#100.0;
Mv_Lin1_Acc := LREAL#10#20.0;
   Mv_Lin1_Dec := LREAL#10#20.0;
   Mv_Lin1_Mm
                     := _eMC_MOVE_MODE#_mcAbsolute;
// MV_LIN2 parameters
   Mv\_Lin2\_Pos[0] := LREAL#10#15.0;
   Mv\_Lin2\_Pos[1] := LREAL#10#15.0;
   Mv\_Lin2\_Vel := LREAL#10#100.0;
                   := LREAL#10#20.0;
   Mv_Lin2_Acc
   Mv_Lin2_Dec := LREAL#10#20.0;
Mv_Lin2_Bm := _eMC_BUFFER_
Mv_Lin2_Mm := _eMC_MOVE_M0
                     := _eMC_BUFFER_MODE#_mcBuffered;
   Mv_Lin2_Mm
                     := _eMC_MOVE_MODE#_mcAbsolute;
// Change InitFlag to TRUE after setting the input parameters.
```

# Structured Text (ST)

InitFlag := TRUE;

#### Main Variables

Name	Data type	Default	Comment
MC_Group000	_sGROUP _REF		This is the Axes Group Variable for axes group 0.
MC_Group000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axes group 0.
MC_Group000.Status.Disabled	BOOL	FALSE	The value is TRUE when axes group 0 is disabled.
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 1.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 1.
MC_Axis001	_sAXIS_REF		This is the Axis Variable for axis 2.
MC_Axis001.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 2.
MC_Axis001.MFaultLvl.Active	BOOL	FALSE	TRUE while there is a minor fault level error for axis 2.
Pwr1_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
Pwr2_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR2 instance of the MC_Power instruction. This variable changes to TRUE when the Servo is turned ON.
StartPg	BOOL	FALSE	The Servos for the axes in the axes group are turned ON if this variable is TRUE and Ether-CAT process data communications are established.

Name	Data type	Default	Comment
InitFlag	BOOL	FALSE	This variable indicates if it is necessary to set the input parameters. Input parameters are set when this variable is FALSE. When setting the input parameters is completed, this variable changes to TRUE.
Hm1_Ex	BOOL	FALSE	The HM1 instance of MC_Home is executed when this variable changes to TRUE.
Hm2_Ex	BOOL	FALSE	The HM2 instance of MC_Home is executed when this variable changes to TRUE.
Grp_En_Ex	BOOL	FALSE	The GRP_EN instance of MC_GroupEnable is executed when this variable changes to TRUE.
Mv_Lin1_Ex	BOOL	FALSE	The MV_LIN1 instance of MC_MoveLinear is executed when this variable changes to TRUE.
Mv_Lin2_Ex	BOOL	FALSE	The MV_LIN2 instance of MC_MoveLinear is executed when this variable changes to TRUE.
Mv_Circ1_Ex	BOOL	FALSE	The MV_CIRC1 instance of MC_MoveCircular is executed when this variable changes to TRUE.
Mv_Circ2_Ex	BOOL	FALSE	The MV_CIRC2 instance of MC_MoveCircular is executed when this variable changes to TRUE.

#### Sample Programming

// Processing when input parameters are not set IF InitFlag=FALSE THEN

```
// MV CIRC1 parameters
Mv_Circ1_CircAxes[0]
                        := UINT#10#0;
Mv_Circ1_CircAxes[1]
                        := UINT#10#1;
Mv_Circ1_CircMode
                        := _eMC_CIRC_MODE#_mcRadius;
Mv_Circ1_AuxPoint[0]
                        := LREAL#5.0;
Mv_Circ1_AuxPoint[1]
                        := LREAL#0.0;
Mv_Circ1_EndPoint[0]
                        := LREAL#15.0;
Mv_Circ1_EndPoint[1]
                        := LREAL#10.0;
                        := _eMC_CIRC_PATHCHOICE#_mcCCW;
Mv_Circ1_Pc
Mv_Circ1_Vel
                        := LREAL#100.0;
Mv_Circ1_Acc
                        := LREAL#20.0;
Mv_Circ1_Dec
                        := LREAL#20.0;
                        := _eMC_BUFFER_MODE#_mcBuffered;
Mv_Circ1_Bm
Mv_Circ1_Mm
                        := _eMC_MOVE_MODE#_mcAbsolute;
// MV_CIRC2 parameters
Mv_Circ2_CircAxes[0]
                        := UINT#10#0;
Mv_Circ2_CircAxes[1]
                        := UINT#10#1;
Mv_Circ2_CircMode
                        := _eMC_CIRC_MODE#_mcCenter;
Mv_Circ2_AuxPoint[0]
                        := LREAL#15.0;
Mv_Circ2_AuxPoint[1]
                        := LREAL#20.0;
Mv_Circ2_EndPoint[0]
                        := LREAL#20.0;
Mv_Circ2_EndPoint[1]
                        := LREAL#20.0;
Mv_Circ2_Pc
                        := _eMC_CIRC_PATHCHOICE#_mcCW;
Mv_Circ2_Vel
                        := LREAL#100.0;
Mv_Circ2_Acc
                        := LREAL#20.0;
Mv_Circ2_Dec
                        := LREAL#20.0;
Mv_Circ2_Bm
                        := _eMC_BUFFER_MODE#_mcBuffered;
Mv_Circ2_Mm
                        := _eMC_MOVE_MODE#_mcAbsolute;
// MV_LIN1 parameters
Mv_Lin1_Pos[0]
                  := LREAL#10.0;
Mv_Lin1_Pos[1]
                  := LREAL#5.0;
Mv_Lin1_Vel
                  := LREAL#100.0;
Mv_Lin1_Acc
                  := LREAL#20.0;
```

```
Mv_Lin1_Dec
                      := LREAL#20.0;
   Mv_Lin1_Mm
                      := _eMC_MOVE_MODE#_mcAbsolute;
   // MV_LIN2 parameters
   Mv_Lin2_Pos[0]
                     := LREAL#15.0;
   Mv_Lin2_Pos[1]
                     := LREAL#15.0;
   Mv_Lin2_Vel
                     := LREAL#100.0;
   Mv_Lin2_Acc
                     := LREAL#20.0;
   Mv_Lin2_Dec
                     := LREAL#20.0;
   Mv_Lin2_Bm
                      := _eMC_BUFFER_MODE#_mcBuffered;
   Mv_Lin2_Mm
                      := _eMC_MOVE_MODE#_mcAbsolute;
   // Change InitFlag to TRUE after setting the input parameters.
   InitFlag := TRUE;
END_IF;
// If StartPq is TRUE and EtherCAT communications are normal, the Servo for axis 1 is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
                         // Turn ON the Servo for axis 1.
   Pwr1_En:=TRUE;
ELSE
   Pwr1_En:=FALSE;
                         // Turn OFF the Servo for axis 1.
END IF;
// If StartPq is TRUE and EtherCAT communications are normal, the Servo for axis 2 is turned ON.
// If EtherCAT communications are not normal, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis001.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis001.Cfg.NodeAddress]=FALSE) THEN
   Pwr2_En:=TRUE;
                         // Turn ON the Servo for axis 2.
ELSE
   Pwr2_En:=FALSE;
                         // Turn OFF the Servo for axis 2.
END_IF;
// Processing for a minor fault level error
// Implement FaultHandler separately.
IF (MC_Axis000.MFaultLvI.Active=TRUE) OR (MC_Axis001.MFaultLvI.Active=TRUE) OR
(MC Group000.MFaultLvl.Active=TRUE) THEN
   FaultHandler();
END_IF;
// If the Servo is ON for axis 1 and home is not defined, the Home instruction is executed.
IF (Pwr1_Status=TRUE) AND (MC_Axis000.Details.Homed=FALSE) THEN
   Hm1_Ex:=TRUE;
END_IF;
// If the Servo is ON for axis 2 and home is not defined, the Home instruction is executed.
IF (Pwr2_Status=TRUE) AND (MC_Axis001.Details.Homed=FALSE) THEN
   Hm2_Ex:=TRUE;
END IF;
// If axes group 0 is disabled after homing is completed for axis 1 and axis 2, it is enabled.
IF (Hm1_D=TRUE) AND (Hm2_D=TRUE) AND (MC_Group000.Status.Disabled=TRUE) THEN
   Grp_En_Ex:= TRUE;
END_IF;
// If axes group 0 is enabled, linear interpolation (1) is executed.
IF Grp_En_D=TRUE THEN
   Mv_Lin1_Ex:=TRUE;
END_IF;
```

```
// The rest of the instructions are executed with multi-execution of instructions when the Active output variable
for linear interpolation (1) changes to TRUE.
IF Mv_Lin1_Act=TRUE THEN
   Mv_Circ1_Ex:=TRUE;
   Mv_Lin2_Ex:=TRUE;
   Mv_Circ2_Ex:=TRUE;
END_IF;
// MC_Power for axis 1
PWR1(
   Axis
             := MC_Axis000,
   Enable
             := Pwr1_En,
             => Pwr1_Status,
   Status
   Busy
             => Pwr1 Bsv.
   Error
             => Pwr1_Err,
   ErrorID
            => Pwr1_ErrID
);
// MC_Power for axis 2
PWR2(
             := MC_Axis001,
   Axis
             := Pwr2_En,
   Enable
             => Pwr2_Status,
   Status
   Busy
             => Pwr2_Bsy,
   Error
             => Pwr2 Err,
            => Pwr2 ErrID
   ErrorID
);
// MC Home for axis 1
HM1(
   Axis
                      := MC_Axis000,
   Execute
                      := Hm1_Ex,
   Done
                      => Hm1_D,
   Busy
                      => Hm1_Bsy,
   CommandAborted
                      => Hm1_Ca,
   Error
                      => Hm1_Err,
   ErrorID
                      => Hm1_ErrID
);
// MC_Home for axis 2
HM2(
                      := MC_Axis001,
   Axis
   Execute
                      := Hm2_Ex,
                      => Hm2_D,
   Done
   Busy
                      => Hm2_Bsy,
   CommandAborted
                      => Hm2_Ca,
                      => Hm2_Err,
   Error
   ErrorID
                      => Hm2_ErrID
);
// Axes Group 0 is enabled.
GRP EN(
                      := MC_Group000,
   AxesGroup
   Execute
                      := Grp_En_Ex,
   Done
                      => Grp_En_D,
   Busy
                      => Grp_En_Bsy,
   CommandAborted
                      => Grp_En_Ca,
   Error
                      => Grp_En_Err,
   ErrorID
                      => Grp_En_ErrID
);
// Linear interpolation 1
MV_LIN1(
```

```
AxesGroup
                      := MC_Group000,
   Execute
                      := Mv_Lin1_Ex,
   Position
                      := Mv_Lin1_Pos,
                      := Mv_Lin1_Vel,
   Velocity
                      := Mv_Lin1_Acc,
   Acceleration
   Deceleration
                      := Mv_Lin1_Dec,
   MoveMode
                      := Mv_Lin1_Mm,
   Done
                      => Mv_Lin1_D,
   Busy
                      => Mv_Lin1_Bsy,
                      => Mv_Lin1_Act,
   Active
   CommandAborted
                     => Mv_Lin1_Ca,
   Error
                      => Mv_Lin1_Err,
   ErrorID
                      => Mv_Lin1_ErrID
);
// Circular interpolation (2)
MV_CIRC1(
   AxesGroup
                      := MC Group000.
   Execute
                      := Mv_Circ1_Ex,
   CircAxes
                      := Mv_Circ1_CircAxes,
   CircMode
                      := Mv_Circ1_CircMode,
                      := Mv_Circ1_AuxPoint,
   AuxPoint
                      := Mv_Circ1_EndPoint,
   EndPoint
                      := Mv_Circ1_Pc,
   PathChoice
                      := Mv_Circ1_Vel,
   Velocity
   Acceleration
                      := Mv_Circ1_Acc,
   Deceleration
                      := Mv Circ1 Dec.
                      := Mv_Circ1_Bm,
   BufferMode
                      := Mv Circ1 Mm,
   MoveMode
                      => Mv Circ1 D,
   Done
   Busy
                      => Mv_Circ1_Bsy,
   Active
                      => Mv_Circ1_Act,
   CommandAborted => Mv_Circ1_Ca,
   Error
                      => Mv_Circ1_Err,
   ErrorID
                      => Mv_Circ1_ErrID
);
// Linear interpolation (3)
MV_LIN2(
                      := MC Group000.
   AxesGroup
                      := Mv_Lin2_Ex,
   Execute
   Position
                      := Mv Lin2 Pos,
   Velocity
                      := Mv_Lin2_Vel,
   Acceleration
                      := Mv_Lin2_Acc,
   Deceleration
                      := Mv_Lin2_Dec,
   BufferMode
                      := Mv_Lin2_Bm,
   MoveMode
                      := Mv_Lin2_Mm,
   Done
                      => Mv_Lin2_D,
   Busy
                      => Mv_Lin2_Bsy,
                      => Mv_Lin2_Act,
   Active
   CommandAborted
                     => Mv_Lin2_Ca,
   Error
                      => Mv_Lin2_Err,
   ErrorID
                      => Mv_Lin2_ErrID
);
// Circular interpolation (4)
MV_CIRC2(
                      := MC_Group000,
   AxesGroup
                      := Mv_Circ2_Ex,
   Execute
   CircAxes
                      := Mv_Circ2_CircAxes,
   CircMode
                      := Mv_Circ2_CircMode,
   AuxPoint
                      := Mv_Circ2_AuxPoint,
   EndPoint
                      := Mv_Circ2_EndPoint,
   PathChoice
                      := Mv_Circ2_Pc,
   Velocity
                      := Mv_Circ2_Vel,
```

```
Acceleration
                     := Mv_Circ2_Acc,
   Deceleration
                     := Mv_Circ2_Dec,
   BufferMode
                     := Mv_Circ2_Bm,
                     := Mv_Circ2_Mm,
   MoveMode
                     => Mv_Circ2_D,
   Done
                     => Mv_Circ2_Bsy,
   Busy
   Active
                     => Mv_Circ2_Act,
   CommandAborted => Mv_Circ2_Ca,
   Error
                     => Mv_Circ2_Err,
   ErrorID
                     => Mv_Circ2_ErrID
);
```

# MC\_GroupStop

The MC\_GroupStop instruction decelerates all of the axes in an interpolated motion to a stop.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_GroupStop	Group Stop	FB	MC_GroupStop_instance  MC_GroupStop AxesGroup Execute Deceleration Jerk BufferMode CommandAborted Error ErrorID	MC_GroupStop_instance ( AxesGroup :=parameter, Execute :=parameter, Deceleration :=parameter, Jerk :=parameter, BufferMode :=parameter, Done =>parameter, Busy =>parameter, Active =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorID =>parameter );

### **Variables**

# Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Execute</i> changes to TRUE.
Deceleration	Deceleration Rate	LREAL	Non-negative number	0	Specify the deceleration rate. The unit is command units/s <sup>2</sup> .* <sup>1</sup>
Jerk	Jerk	LREAL	Non-negative number	0	Specify the jerk. The unit is command units/s <sup>3</sup> .* <sup>1</sup>
BufferMode	Buffer Mode Selection	_eMC_ BUFFER_ MODE	0: _mcAborting	0*2	Specify the operation when executing more than one motion instruction.
					0: Aborting

Refer to Unit Conversion Settings in the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507) for information on command units.

<sup>\*2</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

# **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Active	Controlling	BOOL	TRUE or FALSE	TRUE when the axes group is being controlled.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When the instruction is completed.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
Active	When the instruction is started.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
CommandAborted	<ul> <li>When this instruction is aborted because another motion control instruction was executed with the Buffer Mode set to <i>Aborting</i>.</li> <li>When this instruction is canceled due to an error.</li> <li>When this instruction is executed while there is an error.</li> </ul>	<ul> <li>When Execute is TRUE and changes to FALSE.</li> <li>After one period when Execute is FALSE.</li> </ul>
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

# In-Out Variables

Name	Meaning	Data type	Valid range	Description
AxesGroup	Axes Group	_sGROUP_REF		Specify the axes group.*

<sup>\*</sup> Specify an Axes Group Variable that was created in the Axes Group Basic Settings of the Sysmac Studio. (The default axes group variable names are *MC\_Group*\*\*\*.)

#### **Function**

- This instruction decelerates all of the axes that are in motion for an interpolation instruction (i.e., all of the axes in the axes group that is specified with AxesGroup) from the actual velocity to a velocity of 0 (i.e. until they stop), and then disables the axes group command. It can be used for the following interpolation instructions: MC\_MoveLinearAbsolute (Absolute Linear Interpolation), MC\_MoveLinearRelative (Relative Linear Interpolation), and MC\_MoveCircular2D (Circular 2D Interpolation).
- CommandAborted for the interpolation instruction that is currently in operation will change to TRUE when this instruction is executed.
- If you execute this instruction while an interpolation instruction is in execution, the axes will decelerate to a stop along the linear interpolation or circular interpolation path.
- The deceleration stop operation starts when Execute changes to TRUE.



#### **Precautions for Correct Use**

This instruction is not executed if Status. Error Stop (Error Deceleration Stopping) in the Axes Group Variable is TRUE.

Use the MC GroupImmediateStop instruction to stop the motion of an axes group that is decelerating to a stop for an error.

### **Instruction Details**

This section describes the instruction in detail.

### Deceleration (Deceleration Rate) and Jerk


Set the input variables *Deceleration* and *Jerk* to set the deceleration rate and jerk when decelerating to a stop. When this instruction is executed, Deceleration (Deceleration Rate) and Jerk specified for this instruction are used for the interpolation velocity.

#### Jerk

The relationships between the deceleration rate and interpolation velocity when Jerk is set to 0 and when it is set to any other value are shown below.

Jerk Set to 0


The command value for the velocity is created with deceleration rate Dt.



Vt: Velocity when deceleration starts, Dt: Specified deceleration rate

#### • Jerk Set to Value Other Than 0

The command value for the velocity is created based on the current velocity with Dt as the upper limit to the deceleration rate.



Vt: Velocity when deceleration starts, Dt: Specified deceleration rate, Jt: Specified jerk



#### **Additional Information**

- If 0 is specified for the deceleration rate, an immediate stop is performed and the axis stops immediately.
- An immediate stop occurs regardless of the setting of the Acceleration/Deceleration Over Limit Selection axis parameter only when the deceleration rate is set to 0.

#### BufferMode (Buffer Mode Selection)

*BufferMode* specifies how to join the axis motions for this interpolation instruction and the previous interpolation instruction. There is only the following setting.

Buffer Mode Selection	Description
Aborting	Aborts the instruction being executed and executes this instruction.

For details on *BufferMode* (Buffer Mode Selection), refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### In-position Check


An in-position check is not performed when stopping for this instruction.

## **Timing Charts**

- Busy (Executing) changes to TRUE at the same time as Execute changes to TRUE. Active (Controlling) changes to TRUE in the next period.
- Done changes to TRUE when a velocity of 0 is reached.
- If another instruction aborts this instruction, CommandAborted changes to TRUE and Busy (Executing) and Active (Controlling) change to FALSE.

The following chart shows decelerating to a stop for linear interpolation. CommandAborted for the interpolation instruction that is currently in operation will change to TRUE when MC\_GroupStop is executed.






#### **Re-execution of Motion Control Instructions**

The deceleration rate changes if *Execute* changes to TRUE again while this instruction is being executed. The *Jerk* setting is not changed when a motion control instruction is re-executed.

#### Jerk Set to Value Other Than 0

The velocity command value is created with Dt2 as the upper limit of the deceleration rate after it has changed based on the actual velocity and actual deceleration rate.



Vt: Velocity when deceleration starts, Dt: Specified deceleration rate, Jt: Specified jerk

## **Multi-execution of Motion Control Instructions**

There are restrictions to execution of this instruction, and to other instructions executed during execution of this instruction. For details on multi-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### Execution during Execution of Other Instructions

#### When Axes Group Is Disabled

An error occurs for the axes group if the MC\_GroupStop instruction is executed for a disable axes group. However, this will not affect the axes.

#### When the Status. Stopping (Axes Group Deceleration Stopping) in the Axes **Group Variable Is TRUE**

Status. Stopping (Deceleration Stopping) in the Axis Variable changes to TRUE in the following cases.

- While the axes group is decelerating for the MC GroupStop Instruction
- While Execute is TRUE for one or more MC\_GroupStop instructions

If you execute one of the following instructions for an axes group that is decelerating to a stop, CommandAborted of the executed instruction changes to TRUE.

- MC\_MoveLinear (Linear Interpolation) instruction
- MC\_MoveLinearAbsolute (Absolute Linear Interpolation) instruction
- MC\_MoveLinearRelative (Relative Linear Interpolation) instruction
- MC\_MoveCircular2D (Circular 2D Interpolation) instruction

When the MC GroupStop instruction is in execution, you can execute another MC GroupStop instruction with multi-execution of instructions. Done from the MC GroupStop instruction that is in execution changes to TRUE.

#### When the Status. Error Stop (Axes Group Error Deceleration Stopping) in the **Axes Group Variable Is TRUE**

Status. Error Stop (Error Deceleration Stopping) in the axes group status is TRUE while there is an error for the axes group.


If the MC GroupStop instruction is executed when Status. ErrorStop (Error Deceleration Stopping) is TRUE, CommandAborted changes to TRUE.

Use the MC\_GroupImmediateStop (Axes Group Stop) instruction instead.

#### **Errors**


If an error occurs during instruction execution, *Error* will change to TRUE and the axes will stop. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).

Previous Instruction: MC\_MoveLinear



#### Operation When Error is Cleared

If an error occurs for this instruction and the error is reset while *Execute* is TRUE, Error changes to FALSE, *Done* changes to TRUE, and *Status.Stopping* (Deceleration Stopping) in the axis status changes to TRUE in the same way as for a normal execution of a deceleration stop. Reset errors after the axes group has stopped. Do not reset errors during axes group motion.



• Error Codes

Refer to A-1 Error Codes for instruction errors.

## MC\_GroupImmediateStop

The MC\_GroupImmediateStop instruction stops all axes in an interpolated motion. If the specified axes group is enabled, all of the composition axes are stopped according to the stop mode that is specified in Immediate Stop Input Stop Method Selection regardless of the current status of the axes.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_GroupImmediateStop	Axes Group Immediate Stop	FB	MC_GroupImmediateStop_instance  MC_GroupImmediateStop AxesGroup — AxesGroup Execute Done Busy CommandAborted Error ErrorID	MC_GroupImmediateStop_instance ( AxesGroup :=parameter, Execute :=parameter, Done =>parameter, Busy =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorID =>parameter );

## **Variables**

## **Input Variables**

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when <i>Execute</i> changes to TRUE.

## **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

4-75

#### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When the immediate stop is completed.	<ul><li>When Execute is TRUE and changes to FALSE.</li><li>After one period when Execute is FALSE.</li></ul>
Busy	When Execute changes to TRUE.	<ul> <li>When Done changes to TRUE.</li> <li>When Error changes to TRUE.</li> <li>When CommandAborted changes to TRUE.</li> </ul>
CommandAborted	<ul> <li>When this instruction is aborted because another deceleration stop instruction was executed with the Buffer Mode set to <i>Aborting</i>.</li> <li>When this instruction is canceled due to an error.</li> </ul>	<ul> <li>When Execute is TRUE and changes to FALSE.</li> <li>After one period when Execute is FALSE.</li> </ul>
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

## In-Out Variables

Name	Meaning	Data type	Valid range	Description
AxesGroup	Axes Group	_sGROUP_REF		Specify the axes group.*

Specify an Axes Group Variable that was created in the Axes Group Basic Settings of the Sysmac Studio. (The default axes group variable names are MC\_Group\*\*\*.)


#### **Function**

- You can execute the MC\_GroupImmediateStop instruction for an entire axes group that is in motion for an interpolation instruction (i.e., the axes in the axes group that is specified with AxesGroup) or for an axes group that is stopping for the MC\_GroupStop instruction or error. You can execute it for the following interpolation instructions: MC\_MoveLinear (Linear Interpolation), MC\_MoveLinearAbsolute (Absolute Linear Interpolation), MC\_MoveLinearRelative (Relative Linear Interpolation), and MC MoveCircular2D (Circular 2D Interpolation).
- When this instruction is executed, the axis stops immediately according to the setting of the Immediate Stop Input Stop Method axis parameter. CommandAborted changes to TRUE for the instruction that is currently in operation.
- When the instruction is executed, Status. ErrorStop (Error Deceleration Stopping) in the axis status changes to TRUE and an Axes Group Immediate Stop Instruction Executed error (error code: 5486 hex) occurs when the instruction is executed.
  - For details on the Axes Group Immediate Stop Instruction Executed error (error code: 5486 hex), refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

## **Timing Charts**

- Busy (Executing) changes to TRUE when Execute changes to TRUE.
- Done changes to TRUE when processing of this instruction is completed.

MC\_MoveLiner Instruction



## **Re-execution of Motion Control Instructions**

This instruction cannot be re-executed.

A Motion Control Instruction Re-execution Disabled error (error code: 543B hex) occurs if re-execution is attempted, and the axis stops.

## **Multi-execution of Motion Control Instructions**

For details on multi-execution of motion control instructions, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

#### Execution during Execution of Other Instructions

#### When the Axes Group Is Disabled

An axes group error will occur if this instruction is executed for a disabled axes group. However, this will not affect the axes.

#### When the Status. Stopping (Deceleration Stopping) in the Axes Group Variable Is TRUE

Status. Stopping (Deceleration Stopping) in the Axes Group Variable changes to TRUE in the following cases.

- While the axis is decelerating for the MC\_GroupStop Instruction
- While *Execute* is TRUE for one or more MC GroupStop instructions

You can execute this instruction for an axes group that is currently decelerating to a stop. When this instruction is executed, CommandAborted for the MC\_GroupStop instruction that is in operation will change to TRUE.

#### When the Status. Error Stop (Error Deceleration Stopping) in the Axes Group Variable Is TRUE

Status. Error Stop (Error Deceleration Stopping) in the axes group status is TRUE while there is an error for the axes group. You can also execute this instruction for an axes group that is decelerating to a stop for an error.

## **Errors**

If an error occurs during instruction execution, *Error* will change to TRUE and the axis will stop. You can find out the cause of the error by referring to the value output to *ErrorID* (Error Code).

#### Error Codes

Refer to A-1 Error Codes for instruction errors.

# MC\_GroupSetOverride

The MC\_GroupSetOverride instruction changes the combined target velocity during an interpolated motion.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_GroupSetOverride	Set Group Overrides	FB	MC_GroupReset  AxesGroup  Execute  AxesGroup  Busy Failure ErrorlD	MC_GroupSetOverride_ instance ( AxesGroup :=parameter, Enable :=parameter, VelFactor :=parameter, AccFactor :=parameter, JerkFactor :=parameter, Enabled =>parameter, Enabled =>parameter, Error =>parameter, ErrorlD =>parameter );

## **Variables**

## **Input Variables**

Name	Meaning	Data type	Valid range	Default	Description
Enable	Enable	BOOL	TRUE or FALSE	FALSE	The override factors are enabled when <i>Enable</i> is TRUE. The override factors return to 100% when Enable changes to FALSE.
VelFactor	Velocity Override Factor	LREAL	0 to 500	100	Specify the velocity override factor. The valid range of the override factor is between 0.01 and 500.00.  Values above 500.00 are treated as 500 and values less than 0.01 (including negative values) are treated as 0.01.  The override factor will be 0 only when 0 is specified.  The unit is %.
AccFactor (Reserved)	Acceleration/ Deceleration Override Factor	LREAL	0 to 500	100	(Reserved)
JerkFactor (Reserved)	Jerk Override Factor	LREAL	0 to 500	100	(Reserved)

## **Output Variables**

Name	Meaning	Data type	Valid range	Description
Enabled	Enabled	BOOL	TRUE or FALSE	TRUE when the axes group is being controlled.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorlD	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

#### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Enabled	When this instruction is started.	<ul><li>After one period when <i>Enable</i> is FALSE.</li><li>When <i>Error</i> changes to TRUE.</li></ul>
Busy	When Enable changes to TRUE.	When Error changes to TRUE.
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

## In-Out Variables

Name	Meaning	Data type	Valid range	Description
AxesGroup	Axes Group	_sGROUP_REF		Specify the axes group.*

<sup>\*</sup> Specify an Axes Group Variable that was created in the Axes Group Basic Settings of the Sysmac Studio. (The default axes group variable names are *MC\_Group\*\*\**.)

#### **Function**

 This instruction changes the override factors related to the interpolation target velocity for the group controlled by the next instruction. Changes the target velocity of the axes in operation by changing the override.

The override factors apply to the following instructions.

MC_MoveLinear (Linear Interpolation) instruction	MC_MoveLinearRelative (Relative Linear Interpolation) instruction
MC_MoveLinearAbsolute (Absolute Linear Interpolation) instruction	MC_MoveCircular2D (Circular 2D Interpolation) instruction

- The following is the new target velocity.
   Target velocity after the change = Interpolation velocity of the current instruction × Override factor (%)
- The unit for override factors is %. A setting of 100 indicates 100%.
- If the interpolation velocity that results from the override exceeds the maximum interpolation velocity set in the Axes Group Variables, the maximum interpolation velocity is used.
- The axis will accelerate or decelerate to the interpolation velocity that results from the override.
- If the velocity override factor is set to 0, the target velocity will be 0. Axes group operation will decelerate to a velocity of 0, and operation will continue. *Status.Moving* in the Axes Group Variable is TRUE during axes group motion. If you want to pause the axis motion while keeping the operation status, set the override factor to 0.
- The override factors will return to 100% when Enable changes to FALSE.

• If an axes group error occurs during MC\_GroupSetOverride execution, the value of Enable for MC GroupSetOverride is maintained.




#### **Precautions for Correct Use**


When Enable to this instruction changes to FALSE, Enabled and Busy from this instruction change to FALSE.

The axis will accelerate or decelerate to a velocity with a 100% override factor.

## **Timing Charts**

Using this Instruction for the MC\_MoveLinear (Linear Interpolation) Instruction





## **Re-execution of Motion Control Instructions**

You cannot re-execute enable-type motion control instructions.

## **Multi-execution of Motion Control Instructions**


For details on multi-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### Execution of Other Instructions during Instruction Execution

If another instance of the MC\_GroupSetOverride instruction is executed during MC\_GroupSetOverride execution for the same axes group, the last MC\_GroupSetOverride instance that is executed takes priority. *Enabled* will be TRUE for both instructions.

#### **Errors**

If an error occurs during instruction execution, *Error* will change to TRUE. If an axes group minor fault occurs, the axes group will stop. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).



#### Error Codes

Refer to A-1 Error Codes for instruction errors.

## MC\_GroupReset

The MC\_GroupReset instruction clears axes group errors and axis errors.

Instruction	Name	FB/FUN	Graphic expression	ST expression
MC_GroupReset	Group Reset	FB	MC_GroupReset_instance  MC_GroupReset AxesGroup Execute  Done Busy Failure Error ErrorID	MC_GroupReset_instance ( AxesGroup :=parameter, Execute :=parameter, Done =>parameter, Busy =>parameter, Failure =>parameter, Error =>parameter, ErrorID =>parameter );

## **Variables**

## **Input Variables**

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL TRUE or FALSE	FALSE	The instruction is executed when	
					Execute changes to TRUE.*

Specify an Axes Group Variable that was created in the Axes Group Basic Settings of the Sysmac Studio. (The default axes group variable names are MC\_Group\*\*\*.)

## **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
Failure	Failure End	BOOL	TRUE or FALSE	TRUE when the instruction was not executed correctly.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

#### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When error clear processing is completed normally.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	<ul> <li>When <i>Done</i> changes to TRUE.</li> <li>When <i>Error</i> changes to TRUE.</li> <li>When <i>Failure</i> changes to TRUE.</li> </ul>
Failure	<ul> <li>When an instruction is executed while an axis or axes group is decelerating to a stop caused by an error.</li> <li>When an instruction is executed while there is an axes group error that is caused by an axis common error.</li> </ul>	<ul> <li>When Execute is TRUE and changes to FALSE.</li> <li>After one period when Execute is FALSE.</li> </ul>
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

## In-Out Variables

Name	Meaning	Data type	Valid range	Description
AxesGroup	Axes Group	_sGROUP_REF		Specify the axes group.*

<sup>\*</sup> Specify an Axes Group variable that was created in the Axes Group Basic Settings of the Sysmac Studio. (The default Axes Group variables are *MC\_Group\*\*\**.)

#### **Function**

- When Execute changes to TRUE, the error of the axes group specified by AxesGroup in the GroupEnable state and axis errors of axes belonging to the axes group are cleared.
   The following are reset: minor faults or observations that occur for axes or axes groups and drive errors.
- Error clear processing is performed regardless of whether the Servo is ON or OFF for the axes.
- If there is a drive error for an axis, the drive error is cleared first. Error clear processing is then performed.
- Reset processing for the drive error is continued until the drive error is cleared or continues for the Drive Error Reset Monitoring Time in the axis parameters. The drive error reset process is executed for all axes belonging to the axes group at the same time.
- Only errors that existed when *Execute* changed to TRUE are reset. Errors that occur while clearing errors are not cleared.
- If this instruction is executed while the axes group is decelerating to a stop for an axes group error and the instruction is not executed, Failure will change to TRUE. This is so that the error cannot be reset before the axis stops. *Failure* will also change to TRUE if an axis error that results from an axis common error cannot be cleared by this instruction.



#### **Precautions for Correct Use**


- · The error clear processing that is performed by this instruction sometimes requires more than
- The Failure output variable from the instruction will change to TRUE if the axis is in motion. Remove the cause of the error, and then retry the process until Done changes to TRUE.
- After you remove the cause of the error, execute the instruction only after you confirm that the axes have stopped completely.



#### **Additional Information**


- You can clear axis errors only when the axes group is enabled.
- The following errors cannot be cleared with this instruction. All axis common errors
  - To clear axis common errors, execute the ResetMcError (Reset All Errors) instruction separately.
- If you execute this instruction on an axes group for which there is no error, the instruction is completed normally and the current status is continued.

## **Timing Charts**




## Aborting the Instruction

The instruction is aborted if it is not possible to clear errors that occur when the axes group is decelerating to a stop for an error or errors that occur during axes group errors resulting from axis common errors.



## **Re-execution of Motion Control Instructions**

If the instruction is re-executed by changing *Execute* to TRUE again, the re-executed instruction is ignored and error clear processing is continued.




The command from re-executing the instruction is not acknowledged and the current processing is continued.

### **Multi-execution of Motion Control Instructions**

For details on multi-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### Execution of Other Instructions during Instruction Execution

If another instance of the MC\_GroupReset instruction is executed for the same axes group, both instructions are executed. If a slave error occurs, processing may wait until the Drive Error Reset Monitoring Time that is set for the axis expires. The elapsed time is counted for each instruction instance. If MC\_Reset (Reset Axis Error) is executed for the axes belonging to the specified axes group while this instruction is in execution, both instructions are executed.



#### **Error Codes**

Refer to A-1 Error Codes for instruction errors.



## **Common Command Instructions**

This section describes the instructions that are used for both axes and axes groups.

MC_SetCamTableProperty	 	5-2
MC_SaveCamTable	 	5-8
MC_Write	 	5-12

## MC\_SetCamTableProperty

The MC\_SetCamTableProperty instruction changes the end point index of the cam table that is specified in an in-out parameter.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_SetCamTableProperty	Setting Cam Table Properties	FB	MC_SetCamTableProperty_instance  MC_SetCamTableProperty CamTable ————————————————————————————————————	MC_SetCamTableProperty_ instance ( CamTable :=parameter, Execute :=parameter, Done =>parameter, EndPointIndex =>parameter, MaxDataNumber =>parameter, Busy =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorID =>parameter );

#### **Variables**

## Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when Execute changes to TRUE.

## **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
EndPointIndex	End Point Index	UDINT	Non-negative number	Contains the cam table end point index.
MaxDataNumber	Maximum Number of Cam Data	UDINT	Positive number	Contains the maximum number of cam data.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

#### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When overwriting cam table data is completed.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
CommandAborted	When there is a reason to abort this instruction.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

## **In-Out Variables**

Name	Meaning	Data type	Valid range	Description
CamTable	Cam Table	ARRAY[0N] OF _sMC_CAM_REF		Specify the cam data structure _sMC_CAM_REF array variable as the cam table.*

<sup>\*</sup> N in the array variable is set automatically by the Sysmac Studio. Specify a cam data variable that was created on Cam Editor of the Sysmac Studio.

#### **Function**

- The MC\_SetCamTableProperty instruction changes the end point index of the cam table that is specified in an in-out parameter.
- The end point is the data located one cam data before the first cam data with a phase of 0 after the start point in the cam table.
- The array number of the end point is output to *EndPointIndex*.
- Any data that is detected after the 0 phase is detected is treated as invalid cam data, and the phase/displacement values are ignored.
- The maximum number of cam data is the value that was specified when the structure array is declared with the Sysmac Studio.
- When the user program changes the cam data end point index, the end point must be updated. Use
  this instruction to update the number of valid cam data.

For details on cam tables, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).




#### **Precautions for Correct Use**

- When searching the cam table, an error will occur if the phases are not in ascending order before the 0 phase is found.
- You cannot change the maximum number of cam data from the user program.
- Execute this instruction after changing the end point in the can data or overwriting values in the cam data.
  - If the end point index is not changed or the phases are not in ascending order, the cam operation and the operation of the EndOfProfile (End of Cam Cycle) of the MC\_CamIn (Start Cam Operation) instruction may not be as expected.
- If the cam table is changed while this instruction is being processed, the update process will not be performed correctly. Wait for execution of this instruction to be completed before you change the cam data from the user program.
- · Cam data variables are global variables. You can therefore access or change the values of cam data variables from more than one task. If you change the values of cam data variables from more than one task, program the changes so that there is no competition in writing the value from more than one task.
- If you use exclusive control of global variables between tasks for a cam data variable, do not use the cam data variable for motion control instructions while exclusive control is in effect for the cam data variable. An Incorrect Cam Table Specification error (error code: 5439 hex) will occur.

## **Instruction Details**


For example, refer to the following cam table. The EndPointIndex is 999 and the MaxDataNumber (Maximum Number of Cam Data) is 5,000.



The following tables show the relationship between overwriting of the cam data and the *EndPointIndex*.

If this instruction is executed with a cam table in which the phases for MyCam1[1000] on are 0, End-PointIndex will be 999.

If this instruction is executed for a cam table after the phase for *MyCam1*[997] is changed to 0, *End-PointIndex* will be 996.



Cam data structure array Phase Displacement Phase Displacement MyCam1 [0] 0 0 0 0 MyCam1 [998] 359.9 1 100.3 20.3 (360.0)0 End point 100.4 20.4 MyCam1 [999] 100.5 20.5 MyCam1 [1000] 0 0 Invalid MyCam1 [4996] 0 359.99 0 0.01 data (360.00) End point MyCam1 [4997] 0 0 0.0 MyCam1 [4998] 0 0 0 Invalid data MyCam1 [4999] 0 0 0

If this instruction is executed for a cam table after the phases for MyCam1[1000] to MyCam1[4997] are changed anything other than 0, EndPointIndex will be 4997.

If this instruction is not executed even though the phases for MyCam1[1000] to MyCam1[4997] were overwritten to values other than 0, cam operation will be executed between MyCam1[0] to MyCam1[999]. The cam table is overwritten, but the EndPointIndex does not change.


For information on the cam table data structure, refer to MC CamIn on page 3-156.

## Timing Charts

The following chart shows two ways to execute the instruction. A normal end is indicated for either method.

The first time, Execute is changed to TRUE and then it is changed to FALSE before execution of the instruction is completed.

The second time, the value of *Execute* is held.



### **Re-execution of Motion Control Instructions**

This instruction cannot be re-executed.

A Motion Control Instruction Re-execution Disabled error (error code: 543B hex) occurs if re-execution is attempted.

## **Multi-execution of Motion Control Instructions**

#### Execution during Execution of Other Instructions


Multi-execution of instructions cannot be used for this instruction if the cam table specified by *CamTable* is used by another instruction such as MC\_SaveCamTable or MC\_SetCamTableProperty.

#### Execution of Other Instructions during Instruction Execution

Multi-execution of instructions cannot be used for other instructions such as MC\_SaveCamTable or MC\_SetCamTableProperty if the same cam table is specified with *CamTable* for this instruction.

#### **Errors**

If an error occurs during instruction execution, *Error* will change to TRUE. You can find out the cause of the error by referring to the value output by *ErrorID*.



#### Error Codes

Refer to A-1 Error Codes for instruction errors.

## MC\_SaveCamTable

The MC\_SaveCamTable instruction saves the cam table specified with the input parameter to non-volatile memory.

Instruction	Name	FB/ FUN	Graphic expression	ST expression
MC_SaveCamTable	Save Cam Table	FB	MC_SaveCamTable_instance  MC_SaveCamTable CamTable — CamTable Execute Done Busy CommandAborted Error ErrorID	MC_SaveCamTable_instance ( CamTable :=parameter, Execute :=parameter, Done =>parameter, Busy =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorID =>parameter );

## **Variables**

## Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when Execute changes to TRUE.

## **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

## Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When saving cam table data is completed.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	When <i>Done</i> changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
Command-	When there is a reason to abort this instruction.	When Execute is TRUE and changes to FALSE.
Aborted		After one period when Execute is FALSE.
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

## **In-Out Variables**

Name	Meaning	Data type	Valid range	Description
CamTable	Cam Table	ARRAY[0N] OF _sMC_CAM_REF		Specify the start of a cam data structure _sMC_CAM_REF array variable as the cam table.*

N in the array variable is set automatically by the Sysmac Studio. Specify a cam data variable that was created on Cam Editor of the Sysmac Studio.

#### **Function**

- The MC\_SaveCamTable instruction saves the cam table specified with the in-out variable to non-volatile memory.
- \_MC\_COM.Status.CamTableBusy (Cam Table File Save Busy) in the system-defined variables for motion control is TRUE while the cam table is saved.

For information on the cam table data, refer to MC\_CamIn on page 3-156.



#### **Precautions for Correct Use**

- Use this instruction to save the cam data after it is overwritten before you turn OFF the Controller. If you turn OFF the Controller without saving the cam data, the overwritten data will be lost.
- If the cam table is changed while this instruction is being processed, the update process will not be performed correctly. Do not write to the cam table while this instruction is being processed when changing the cam table from the user program.
- This instruction has a considerably longer processing time compared with other instructions. The processing time is greatly affected by the processing load on the CPU Unit. If the next instruction is executed taking the completion of this instruction as a trigger, take care with the timing of execution of the next instruction.
- Do not turn OFF the Controller while this instruction is being processed. The data is not saved correctly if the Controller is turned OFF. The cam data in non-volatile memory may become corrupted.
- You cannot upload cam data, download cam data, start online operation, perform online editing, or start data traces during execution of this instruction. If this instruction is executed during a cam data upload, cam data download, or online editing, a Cannot Execute Save Cam Table Instruction error (error code 743C hex) occurs. Perform retry processing until the cam data is saved normally. Use the Synchronize Menu of the Sysmac Studio to upload and download the data
- There is a limit to the number of times that you can write non-volatile memory. The life of the non-volatile memory will expire faster if this instruction is executed frequently. Do not execute it any more than is necessary.
- Cam data variables are global variables. You can therefore access or change the values of cam data variables from more than one task. If you change the values of cam data variables from more than one task, program the changes so that there is no competition in writing the value from more than one task.
- If you use exclusive control of global variables between tasks for a cam data variable, do not
  use the cam data variable for motion control instructions while exclusive control is in effect for
  the cam data variable. An Incorrect Cam Table Specification error (error code: 5439 hex) will
  occur.

#### Relation to CPU Unit Operating Modes

Cam data save processing for this instruction continues even if the operating mode of the CPU Unit changes to PROGRAM mode.

To see if cam data save processing is in progress in PROGRAM mode, place the Sysmac Studio online and monitor the MC COM.Status.CamTableBusy system-defined variable for motion con-

#### Deleting Instruction with Online Editing


Cam data save processing for this instruction continues even if this instruction is deleted with online editing.

## **Timing Charts**

The following chart shows two ways to execute the instruction. A normal end is indicated for either method.

The first time, Execute is changed to TRUE and then it is changed to FALSE before execution of the instruction is completed.

The second time, the value of *Execute* is held.



#### **Re-execution of Motion Control Instructions**

This instruction cannot be re-executed.

A Motion Control Instruction Re-execution Disabled error (error code: 543B hex) occurs if re-execution is attempted.

#### **Multi-execution of Motion Control Instructions**

For details on multi-execution of motion control instructions, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

#### Execution during Execution of Other Instructions


Multi-execution of instructions cannot be used for this instruction if the cam table specified by CamTable is used by another instruction, such as MC SetCamTableProperty. This instruction also cannot be executed during execution of another instance of the instruction.

#### Execution of Other Instructions during Instruction Execution

instructions cannot be used other MC\_SetCamTableProperty, if the same cam table is specified with *CamTable* for this instruction. This instruction also cannot be executed during execution of another instance of this instruction.

## **Errors**

If an error occurs during instruction execution, *Error* will change to TRUE. You can find out the cause of the error by referring to the value output by *ErrorID*.



#### Error Codes

Refer to A-1 Error Codes for instruction errors.

## **MC\_Write**

The MC\_Write instruction writes parts of the motion control parameters in the MC Function Module.



#### **Precautions for Correct Use**

The values that are written by this instruction are not saved in non-volatile memory. Any values that are written are lost when the power supply to the Controller is turned OFF, when settings are downloaded, or when the MC Function Module is restarted. They return to the values that were set from the Sysmac Studio.



#### **Additional Information**

Use the Synchronize Menu of the Sysmac Studio to download the project.

Instruction	Name	FB/FUN	Graphic expression	ST expression
MC_Write	Write MC Setting	FB	MC_Write_instance    Target	MC_Write_instance ( Target :=parameter, SettingValue :=parameter, Execute :=parameter, ParameterNumber :=parameter, Done =>parameter, Busy =>parameter, CommandAborted =>parameter, Error =>parameter, ErrorID =>parameter );

#### **Variables**

## Input Variables

Name	Meaning	Data type	Valid range	Default	Description
Execute	Execute	BOOL	TRUE or FALSE	FALSE	The instruction is executed when Execute changes to TRUE.
Parameter	Parameter	_eMC_	0: _mcChkVel	0*	Specify the parameter to write.
Number	Number	PARAMETER_	1: _mcChkAcc		0: Velocity Warning Value
		NUMBER	2: _mcChkDec		1: Acceleration Warning Value
			3: _mcPosiChkTrq		2: Deceleration Warning Value
			4: _mcNegaChkTrq		3: Positive Torque Warning Value
			5: _mcFELmt		4: Negative Torque Warning Value
			6: _mcChkFELmt		5: Following Error Over Limit Value
			7: _mcSwLmtMode		6: Following Error Warning Value
			8: _mcPosiSwLmt		7: Software Limits
			9: _mcNegaSwLmt		8: Positive Software Limit
			10: _mcInPosTime		9: Negative Software Limit
					10: In-position Check Time

<sup>\*</sup> The default value for an enumeration variable is actually not the number, but the enumerator.

## • Parameter Data Types and Valid Ranges

	Parameter	Data type	Valid range	Comments
0	Velocity Warning Value	UINT	0 to 100	The unit is %.
1	Acceleration Warning Value	UINT	0 to 100	The unit is %.
2	Deceleration Warning Value	UINT	0 to 100	The unit is %.
3	Positive Torque Warning Value	UINT	0 to 1000	The unit is %.
4	Negative Torque Warning Value	UINT	0 to 1000	The unit is %.
5	Following Error Limit Value	LREAL	Positive number	The unit is command units.*
6	Following Error Warning Value	LREAL	Positive number	Set a value that is less than the value of the Following Error Limit Value. The unit is command units.*
7	Software Limits	Enumer- ation	0: _mcNonSwLmt 1: _mcCmdDecelerationStop 2: _mcCmdImmediateStop 3: _mcActDecelerationStop 4: _mcActImmediateStop	O: Disabled 1: Deceleration stopping enabled for command position 2: Immediate stopping enabled for command position (stop using remaining pulses) 3: Deceleration stopping enabled for actual position 4: Immediate stopping enabled for actual position (stop using remaining pulses)
8	Positive Soft- ware Limit	LREAL	Negative number, positive number, or 0	The unit is command units.*
9	Negative Soft- ware Limit	LREAL	Negative number, positive number, or 0	The unit is command units.*
10	In-position Check Time	UINT	0 to 10,000	The unit is milliseconds.

<sup>\*</sup> Refer to Unit Conversion Settings in the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for information on command units.

## **Output Variables**

Name	Meaning	Data type	Valid range	Description
Done	Done	BOOL	TRUE or FALSE	TRUE when the instruction is completed.
Busy	Executing	BOOL	TRUE or FALSE	TRUE when the instruction is acknowledged.
CommandAborted	Command Aborted	BOOL	TRUE or FALSE	TRUE when the instruction is aborted.
Error	Error	BOOL	TRUE or FALSE	TRUE while there is an error.
ErrorID	Error Code	WORD	*	Contains the error code when an error occurs. A value of 16#0000 indicates normal execution.

<sup>\*</sup> Refer to A-1 Error Codes.

#### Output Variable Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
Done	When the instruction is completed.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Busy	When Execute changes to TRUE.	When Done changes to TRUE.
		When Error changes to TRUE.
		When CommandAborted changes to TRUE.
CommandAborted	When another instruction causes an error and aborts this instruction.	When Execute is TRUE and changes to FALSE.
		After one period when Execute is FALSE.
Error	When there is an error in the execution conditions or input parameters for the instruction.	When the error is cleared.

## **In-Out Variables**

Name	Meaning	Data type	Valid range	Description
Target	Write Target	_sAXIS_ REF or _sGROUP_ REF		Specify the axis or axes group for which to write a parameter.*1
SettingValue	Setting Value	Depends on the data type of the speci- fied vari- able.*2		Specify the value to write.  The valid range follows the motion control parameter that is specified by ParameterNumber.  Default: 0

Specify an Axis Variable that was created in the Axis Basic Settings of the Sysmac Studio or Axes Group Variable that was created in the Axes Group Basic Settings of the Sysmac Studio. (The default axis variable names are MC\_Axis\*\*\*. The default axes group variable names are MC\_Group\*\*\*.)

#### In-Out Variable Update Timing

Name	Write Timing
SettingValue	When <i>Done</i> changes to TRUE.

#### **Function**

- The MC\_Write instruction writes the SettingValue to the system-defined variable for motion control specified by Target (Write Target) and ParameterNumber when Execute changes to TRUE.
- The parameters that are specified with the input variables are used if motion starts when Status. Standby in the Axes Group Variable or Status. Standstill in the Axis Variable is TRUE, and for multi-execution of instructions when the Buffer Mode is set to Aborting.
  - Therefore these parameters are not applied when operation is continued after restarting or for multiexecution of instructions with Buffer Mode set to any value other than Aborting.




#### **Precautions for Correct Use**

Values changed by this instruction are not saved in the non-volatile memory. When the power supply to the Controller is turned OFF, the value that was set for the parameter is lost. Use the Sysmac Studio and transfer the parameters to save them to non-volatile memory.

<sup>\*2</sup> For details on the data types of variables, refer to the NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).

## **Timing Charts**

The following timing chart shows the operation for when 20 is written to \_mcChkDec (Deceleration Warning Value) in the axis parameter settings.




## **Multi-execution of Motion Control Instructions**

For details on multi-execution of motion control instructions, refer to the *NJ-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

#### **Errors**

If an error occurs during instruction execution, *Error* will change to TRUE and parameters are not written. The value before the instruction was executed will be held. You can find out the cause of the error by referring to the value output by *ErrorID* (Error Code).

#### Timing Chart When Error Occurs



#### Error Codes

Refer to A-1 Error Codes for instruction errors.


## Sample Programming

The following sample programming writes the Positive Software Limit Value, Negative Software Limit Value, and In-position Check Time when *Exec* changes to TRUE.

## **Main Variables**

Name	Data type	Description
MC_Axis000	_sAXIS_REF	Axis Variable for axis 1
SwPosiWrite_VALUE	LREAL	Positive Software Limit Value
SwNegaWrite_VALUE	LREAL	Negative Software Limit Value
PosTimeWrite_VALUE	UINT	In-position Check Time
SwPosiWrite_NO	_eMC_PARAMETER_NUMBER	Positive Software Limit Specification
SwNegaWrite_NO	_eMC_PARAMETER_NUMBER	Negative Software Limit Specification
PosTimeWrite_NO	_eMC_PARAMETER_NUMBER	In-position Check Time Specification

## **Ladder Diagram**





# **Appendices**

The appendices describe the error codes that are generated by the instructions.

A-1	Error Codes		 ٠.	 	 ٠.	 ٠.	٠.	٠.	٠.	 	٠.	٠.	٠.	٠.	-	 	 ٠.	. /	4-2
<b>A-2</b>	<b>Error Code D</b>	etails	 	 	 	 				 						 	 	A	-19

## **A-1** Error Codes

The following table lists the error codes that are output to *ErrorID* when errors occur in execution of the instructions.

The upper four digits of the event codes that are given in the following table are output as the error code to *ErrorID*.

Refer to A-2 Error Code Details for details on the error codes.

Maj: Major fault level Prt: Partial fault level Min: Minor fault level Obs: Observation Info: Information

Refer to the *NJ-series Troubleshooting Manual* (Cat. No. W503) for all of the event codes that may occur in an NJ-series Controller.

Event sade	Event nem	Magning	Accumed			Leve	I		Deference
Event code	Event name	Meaning	Assumed cause	Maj	Prt	Min	Obs	Info	Reference
34610000 hex	Process Data Object Set- ting Missing	The PDO mapping is not correct.	<ul> <li>The PDOs that are required for the motion control instruction are not mapped.</li> <li>A motion control instruction that specifies phase Z         (_mcEncoderMark) as the trigger conditions was executed for an axis that is mapped to an OMRON GX-EC02□□ Ether-CAT Encoder slave.</li> </ul>			V			page A-20
54200000 hex	Electronic Gear Ratio Numerator Setting Out of Range	The parameter specified for the RatioNumerator input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-20
54210000 hex	Electronic Gear Ratio Denominator Setting Out of Range	The parameter specified for the RatioDenominator input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-21
54220000 hex	Target Velocity Setting Out of Range	The parameter specified for the <i>Velocity</i> input variable to a motion control instruction is out of range.	The Target Velocity (input variable <i>Velocity</i> ) is still at the default (0).			√			page A-21
54230000 hex	Acceleration Setting Out of Range	The parameter specified for the <i>Acceleration</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-22

Event ands	Event neme	Mooning	Acquired series			Leve			Doforeres
Event code	Event name	Meaning	Assumed cause	Maj	Prt	Min	Obs	Info	Reference
54240000 hex	Deceleration Setting Out of Range	The parameter specified for the Deceleration input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√ 			page A-22
54250000 hex	Jerk Setting Out of Range	The parameter specified for the <i>Jerk</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-23
54270000 hex	Torque Ramp Setting Out of Range	The parameter specified for the TorqueRamp input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-23
54280000 hex	Master Coef- ficient Scal- ing Out of Range	The parameter specified for the <i>MasterScaling</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-24
54290000 hex	Slave Coefficient Scaling Out of Range	The parameter specified for the SlaveScaling input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-24
542A0000 hex	Feeding Velocity Set- ting Out of Range	The parameter specified for the FeedVelocity input variable to a motion control instruction is out of range.	The Feed Velocity (input variable FeedVelocity) is still at the default (0).			√			page A-24
542B0000 hex	Buffer Mode Selection Out of Range	The parameter specified for the <i>BufferMode</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√ 			page A-25
542C0000 hex	Coordinate System Selection Out of Range	The parameter specified for the <i>CoordSystem</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√ 			page A-25
542D0000 hex	Circular Inter- polation Mode Selec- tion Out of Range	The parameter specified for the <i>Cir-cMode</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			1			page A-26
542E0000 hex	Direction Selection Out of Range	The parameter specified for the <i>Direction</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			<b>V</b>			page A-26

Event code	Event name	Meaning	Assumed cause			Leve			Reference
vent code	Lvent name		Assumed Cause	Maj	Prt	Min	Obs	Info	Helefelice
542F0000 hex	Path Selection Out of Range	The parameter specified for the <i>PathChoice</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-26
54300000 hex	Position Type Selection Out of Range	The parameter specified for the ReferenceType input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-27
54310000 hex	Travel Mode Selection Out of Range	The parameter specified for the <i>MoveMode</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			1			page A-27
54320000 hex	Transition Mode Selec- tion Out of Range	The parameter specified for the <i>TransitionMode</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.     _mcAborting or _mcBuffered was specified for BufferMode and _mcTMCornerSuperimpose was specified for Transition-Mode.			V			page A-28
54330000 hex	Continue Method Selection Out of Range	The value of the reserved input variable <i>Continuous</i> to a motion control instruction changed.	The value of the reserved input variable <i>Continuous</i> changed.			V			page A-28
54340000 hex	Combine Mode Selec- tion Out of Range	The parameter specified for the CombineMode input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-29
54350000 hex	Synchroniza- tion Start Condition Selection Out of Range	The parameter specified for the <i>LinkOption</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			1			page A-29
54360000 hex	Master and Slave Defined as Same Axis	The same axis is specified for the <i>Master</i> and <i>Slave</i> input variables to a motion control instruction.	The parameter is the same for the <i>Master</i> and <i>Slave</i> input vari- ables to the instruction.			V			page A-29
54370000 hex	Master and Auxiliary Defined as Same Axis	The same axis is specified for the <i>Master</i> and <i>Auxiliary</i> input variables to a motion control instruction.	The parameter is the same for the <i>Master</i> and <i>Auxiliary</i> input variables to the instruction.			V			page A-30

From the contract of	Francis	Manager	A			Leve			Deferm
Event code	Event name	Meaning	Assumed cause	Maj	Prt	Min	Obs	Info	Reference
54380000 hex	Master/Slave Axis Num- bers Not in Ascending Order	The axis numbers specified for the Master and Slave input variables to a motion control instruction are not in ascending order.	The parameters for the Master and Slave input variables to the instruction were not in ascending order when _mcLatestCommand was specified for the ReferenceType input variable to the instruction.			√			page A-30
54390000 hex	Incorrect Cam Table Specification	The parameter specified for the <i>CamTable</i> input variable to a motion control instruction is out of range.	Something other than a cam data variable was specified for the <i>CamTable</i> input variable to the instruction.			V			page A-31
543A0000 hex	Synchronization Stopped	A synchronized control motion control instruction was executed, but conditions required for execution were not met.	The MC_CamOut (End Cam Operation) instruction was executed even though the MC_CamIn (Start Cam Operation) instruction is not being executed.  The MC_GearOut (End Gear Operation) instruction was executed even though the MC_GearIn (Start Gear Operation) or the MC_GearInPos (Positioning Gear Operation) instruction is not being executed.  The MC_Phasing (Shift Master Axis Phase) instruction was executed even though the MC_CamIn (Start Cam Operation), MC_GearInPos (Start Gear Operation), or MC_MoveLink (Synchronous Positioning) instruction is not being executed.			√ ·			page A-31
543B0000 hex	Motion Control Instruction Reexecution	An attempt was made to re-execute a motion control instruction that cannot be re-executed.	A motion control instruction that cannot be re-executed was re- executed.			V			page A-32
543C0000 hex	Motion Con- trol Instruc- tion Multi- execution Disabled	Multiple functions that cannot be exe- cuted simulta- neously were executed for the same target (MC common or axis).	Multiple functions that cannot be executed simultaneously were executed for the same tar- get (MC common or axis).			√			page A-32
543D0000 hex	Instruction Not Allowed for Encoder Axis Type	An operation instruction was executed for an encoder axis.	An operation instruction was executed for an encoder axis.			√			page A-33
543E0000 hex	Instruction Cannot Be Executed during Multi- axes Coordi- nated Control	An operation instruction was executed for an axis that was in a coordinated multi-axes motion.	An operation instruction was executed for an axis that was in a multi-axes coordinated motion.			<b>V</b>			page A-33

Event code	Event neme	Mooning	Assumed cause			Leve	ı		Doforonos
Event code	Event name	Meaning	Assumed cause	Maj	Prt	Min	Obs	Info	Reference
543F0000 hex	Multi-axes Coordinated Control Instruction Executed for Disabled Axes Group	A multi-axes coordi- nated control instruction was exe- cuted for an axes group that was in the Axes Group Disabled state.	A multi-axes coordinated con- trol instruction was executed for an axes group that was in the Axes Group Disabled state.			√			page A-34
54400000 hex	Axes Group Cannot Be Enabled	Execution of the MC_GroupEnable (Enable Axes Group) instruction failed.	When the MC_GroupEnable (Enable Axes Group) instruction was executed, there was a composition axis that was not stopped.  When the MC_GroupEnable (Enable Axes Group) instruction was executed, there was a composition axis for which the MC_TouchProbe (Enable External Latch) instruction was being executed.			√			page A-34
54410000 hex	Impossible Axis Opera- tion Speci- fied when the Servo is OFF	An operation instruction was exe- cuted for an axis for which the Servo is OFF.	<ul> <li>An operation instruction was executed for an axis for which the Servo is OFF.</li> <li>Home was preset with the MC_Home instruction for an axis for which EtherCAT process data communications are not established.</li> </ul>			<b>V</b>			page A-35
54420000 hex	Composition Axis Stopped Error	A motion instruction was executed for an axes group while the MC_Stop instruction was being executed for a composition axis.	A motion instruction was executed for an axes group while the MC_Stop instruction was being executed for a composition axis.			<b>V</b>			page A-35
54430000 hex	Motion Con- trol Instruc- tion Multi- execution Buffer Limit Exceeded	The number of motion control instructions that is buffered for Buffered or Blending Buffer Modes exceeded the buffer limit.	<ul> <li>An axis instruction was executed when there was already a current instruction and a buffered instruction for the same axis.</li> <li>An axes group instruction was executed when there was already eight current instructions and buffered instructions for the same axis.</li> </ul>			<b>V</b>			page A-36
54440000 hex	Insufficient Travel Dis- tance	The specified motion cannot be executed for the deceleration rate or acceleration rate that was specified for multi-execution or re-execution of a positioning instruction.	Stopping at the target position was not possible for the specified acceleration/deceleration rate for multi-execution or reexecution of a positioning instruction when the Acceleration/Deceleration Over parameter was set to generate a minor fault and stop.			1			page A-37
54450000 hex	Insufficient Travel Distance to Achieve Blending Transit Velocity	There is not sufficient travel distance to accelerate or decelerate to the transit velocity.	There was not sufficient travel distance to accelerate the current command to the transit velocity when the Acceleration/Deceleration Over parameter was set to generate a minor fault and stop.			√			page A-37

Event code	Event name	Meaning	Assumed cause			Leve	l		Reference
Eveni code	Event name	Meaning	Assumed Cause	Maj	Prt	Min	Obs	Info	neierence
54460000 hex	Move Link Constant Velocity Insufficient Travel Dis- tance	The constant-velocity travel distance of the master axis is less than zero.	The constant velocity travel distance of the master axis is below 0 for the MC_MoveLink (Synchronous Positioning) instruction.			<b>√</b>			page A-38
54470000 hex	Positioning Gear Opera- tion Insuffi- cient Target Velocity	For the MC_GearInPos (Positioning Gear Operation) instruction, the target velocity of the slave axis is too small to achieve the required velocity.	For the MC_GearInPos (Positioning Gear Operation) instruction, the value of the Velocity (Target Velocity) input variable is smaller than the master axis velocity multiplied by the gear ratio when the instruction was executed.			V			page A-38
54480000 hex	Same Start Point and End Point for Circular Inter- polation	The start point and end point were the same when the radius method was specified for the MC_MoveCircular2 D (Circular 2D Interpolation) instruction. Or, the start point, end point, and border point were the same when the border point method was specified.	The start point and end point were the same when the radius method was specified for the MC_MoveCircular2D (Circular 2D Interpolation) instruction.  The start point, end point, and border point were the same when the border point method was specified for the MC_MoveCircular2D (Circular 2D Interpolation) instruction.			<b>V</b>			page A-39
54490000 hex	Circular Interpolation Center Specification Position Out of Range	The position specified for the center point exceeded the allowed range when the center method was specified for the MC_MoveCircular2 D (Circular 2D Interpolation) instruction.	The difference between the distance from the start point to the center point and the distance between the end point to the center point exceeded the permitted value specified for the correction allowance ratio in the axes group settings when the center designation method was specified for the MC_MoveCircular2D (Circular 2D Interpolation) instruction.			1			page A-39
544A0000 hex	Circular Interpolation Cannot Be Executed with Rotary (Infinite) Axis	The MC_MoveCircular2 D (Circular 2D Interpolation) instruction was executed for an axis for which the Count Mode was set to Rotary Mode.	An axis in Rotary Mode was used with the MC_MoveCircular2D (Circular 2D Interpolation) instruction.			1			page A-40
544C0000 hex	Parameter Selection Out of Range	The parameter specified for the ParameterNumber input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-40
544D0000 hex	Stop Method Selection Out of Range	The parameter specified for the <i>StopMode</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			<b>√</b>			page A-40

Event code	Event name	Meaning	Assumed cause			Leve			Reference
Eveni code	Lvent name	Wearing	Assumed Eduse	Maj	Prt	Min	Obs	Info	nelelelice
544E0000 hex	Latch ID Selection Out of Range for Trigger Input Condition	The parameter specified for the TriggerIn-put::LatchID input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			V			page A-41
544F0000 hex	Setting Out of Range for Writing MC Setting	The parameter specified for the Setting Value input variable to a motion control instruction is out of range.	<ul> <li>Instruction input parameter exceeded the valid range of the input variable.</li> <li>The parameter specification and the data type of the setting value do not agree.</li> </ul>			<b>V</b>			page A-41
54500000 hex	Trigger Input Condition Mode Selec- tion Out of Range	The parameter specified for the TriggerInput:: Mode input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-42
54510000 hex	Drive Trigger Signal Selec- tion Out of Range for Trigger Input Condition	The parameter specified for the TriggerInput::Input-Drive input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-42
54530000 hex	Motion Control Instruction Resecution Disabled (Axis Specification)	An attempt was made to change the parameter for the Axis input variable when re-executing a motion control instruction. (This input variable cannot be changed when re-executing an instruction.)	A parameter for an input variable that cannot be changed for re-execution was changed.			<b>V</b>			page A-43
54540000 hex	Motion Control Instruction Reexecution Disabled (Buffer Mode Selection)	An attempt was made to change the parameter for the BufferMode input variable when reexecuting a motion control instruction. (This input variable cannot be changed when re-executing an instruction.)	A parameter for an input variable that cannot be changed for re-execution was changed.			V			page A-43
54550000 hex	Motion Control Instruction Re- execution Disabled (Direction Selection)	An attempt was made to change the parameter for the <i>Direction</i> input variable when re-executing a motion control instruction. (This input variable cannot be changed when re-executing an instruction.)	An input variable that cannot be changed for re-execution was changed.			<b>V</b>			page A-44

						Leve	I		5.4
Event code	Event name	Meaning	Assumed cause	Maj	Prt	Min	Obs	Info	Reference
54560000 hex	Motion Control Instruction Re- execution Disabled (Execution Mode)	An attempt was made to change the parameter for the <i>ExecutionMode</i> input variable when re-executing a motion control instruction. (This input variable cannot be changed when re-executing an instruction.)	A parameter for an input variable that cannot be changed for re-execution was changed.			٧			page A-44
54570000 hex	Motion Control Instruction Re- execution Disabled (Axes Group Specification)	An attempt was made to change the parameter for the <i>AxesGroup</i> input variable when reexecuting a motion control instruction. (This input variable cannot be changed when re-executing an instruction.)	A parameter for an input variable that cannot be changed for re-execution was changed.			<b>√</b>			page A-45
54580000 hex	Motion Control Instruction Reexecution Disabled (Jerk Setting)	An attempt was made to change the parameter for the Jerk input variable when re-executing a motion control instruction. (This input variable cannot be changed when re-executing an instruction.)	A parameter for an input variable that cannot be changed for re-execution was changed.			√ 			page A-45
54590000 hex	Motion Control Instruction Re- execution Disabled (Master Axis)	An attempt was made to change the parameter for the <i>Master</i> input variable when re-executing a motion control instruction. (This input variable cannot be changed when re-executing an instruction.)	A parameter for an input variable that cannot be changed for re-execution was changed.			<b>V</b>			page A-46
545A0000 hex	Motion Control Instruction Re- execution Disabled (MasterOff- set)	An attempt was made to change the parameter for the MasterOffset input variable when reexecuting a motion control instruction. (This input variable cannot be changed when re-executing an instruction.)	A parameter for an input variable that cannot be changed for re-execution was changed.			√ 			page A-46

Event code	Event name	Meaning	Assumed cause			Leve			Reference
Event code	Event name	Meaning	Assumed cause	Maj	Prt	Min	Obs	Info	Reference
545B0000 hex	Motion Con- trol Instruc- tion Re- execution Disabled (MasterScal- ing)	An attempt was made to change the parameter for the MasterScaling input variable when reexecuting a motion control instruction. (This input variable cannot be changed when re-executing an instruction.)	A parameter for an input variable that cannot be changed for re-execution was changed.			V			page A-47
545C0000 hex	Motion Control Instruction Resecution Disabled (MasterStart-Distance)	An attempt was made to change the parameter for the MasterStartDistance input variable when re-executing a motion control instruction. (This input variable cannot be changed when re-executing an instruction.)	A parameter for an input variable that cannot be changed for re-execution was changed.			V			page A-47
545D0000 hex	Motion Control Instruction Reexecution Disabled (Continuous)	An attempt was made to change the parameter for the Continuous input variable when reexecuting a motion control instruction. (This input variable cannot be changed when re-executing an instruction.)	A parameter for an input variable that cannot be changed for re-execution was changed.			V			page A-48
545E0000 hex	Motion Control Instruction Reexecution Disabled (MoveMode)	An attempt was made to change the parameter for the <i>MoveMode</i> input variable when reexecuting a motion control instruction. (This input variable cannot be changed when re-executing an instruction.)	A parameter for an input variable that cannot be changed for re-execution was changed.			1			page A-48
545F0000 hex	Illegal Auxiliary Axis Specification	The axis specified for the <i>Auxiliary</i> input variable to a motion control instruction does not exist.	An axis does not exist for the variable specified for the <i>Auxiliary</i> input variable to the instruction.			√			page A-49
54600000 hex	Illegal Axis Specification	The axis specified for the <i>Axis</i> input variable to a motion control instruction does not exist.	An axis does not exist for the variable specified for the Axis input variable to the instruction.			1			page A-49
54610000 hex	Illegal Axes Group Speci- fication	The axes group specified for the <i>AxesGroup</i> input variable to a motion control instruction does not exist or is not a used group.	<ul> <li>An axes group does not exist for the variable specified for the <i>AxesGroup</i> input variable to the instruction.</li> <li>The axes group specified for the <i>AxesGroup</i> input variable to the instruction is not specified as a used group.</li> </ul>			√			page A-50

Event code	Event name	Meaning	Assumed cause			Leve	I		Reference
Event code	_vent name	Meaning	Assumed Cause	Maj	Prt	Min	Obs	Info	Helefelice
54620000 hex	Illegal Mas- ter Axis Specification	The axis specified for the <i>Master</i> input variable to a motion control instruction does not exist or is not a sync master axis.	<ul> <li>An axis does not exist for the variable specified for the <i>Master</i> input variable to the instruction.</li> <li>The axis that was specified for the <i>Master</i> input variable to the <i>MC_Phasing</i> (Shift Master Axis Phase) instruction is not the master axis for syncing.</li> </ul>			1			page A-50
54630000 hex	Motion Control Instruction Reexecution Disabled (SlaveOffset)	An attempt was made to change the SlaveOffset input variable when reexecuting a motion control instruction. (This input variable cannot be changed when re-executing an instruction.)	A parameter for an input variable that cannot be changed for re-execution was changed.			V			page A-51
54640000 hex	Motion Control Instruction Reexecution Disabled (SlaveScaling)	An attempt was made to change the SlaveScaling input variable when reexecuting a motion control instruction. (This input variable cannot be changed when re-executing an instruction.)	A parameter for an input variable that cannot be changed for re-execution was changed.			V			page A-51
54650000 hex	Motion Control Instruction Reexecution Disabled (StartPosition)	An attempt was made to change the StartPosition input variable when reexecuting a motion control instruction. (This input variable cannot be changed when re-executing an instruction.)	A parameter for an input variable that cannot be changed for re-execution was changed.			√			page A-52
54660000 hex	Instruction Execution Error with Undefined Home	High-speed hom- ing or an interpola- tion instruction was executed when home was unde- fined.	<ul> <li>High-speed homing was executed when home was undefined.</li> <li>An interpolation instruction was executed for an axes group that includes an axis with no defined home.</li> </ul>			<b>√</b>			page A-52
54670000 hex	Motion Control Instruction Reexecution Disabled (Position Type)	An attempt was made to change the Reference Type input variable when re-executing a motion control instruction. (This input variable cannot be changed when re-executing an instruction.)	A parameter for an input variable that cannot be changed for re-execution was changed.			<b>V</b>			page A-53
54680000 hex	Unused Axis Specification for Master Axis	The master axis specified for a motion control instruction is an unused axis.	The master axis specified for a motion control instruction is an unused axis.			√			page A-53

Event code	Event name	Meaning	Assumed cause			Leve			Reference
Lvent code	Event name	Wealing	Assumed Cause	Maj	Prt	Min	Obs	Info	Helefelice
54690000 hex	First Position Setting Out of Range	The parameter specified for the FirstPosition input variable to a motion control instruction is out of range.	<ul> <li>Instruction input parameter exceeded the valid range of the input variable.</li> </ul>			V			page A-54
546A0000 hex	Last Position Setting Out of Range	The parameter specified for the <i>LastPosition</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-54
546B0000 hex	Illegal First/Last Position Size Relationship (Linear Mode)	The parameter specified for the LastPosition input variable to a motion control instruction is smaller than the parameter specified for the FirstPosition input variable.	The value of the LastPosition input parameter is less than the value of the FirstPosition input variable for the instruction when the Count Mode is set to Linear Mode.			V			page A-55
546C0000 hex	Master Sync Start Posi- tion Setting Out of Range	The parameter specified for the MasterSyncPosition input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			1			page A-55
546D0000 hex	Slave Sync Start Posi- tion Setting Out of Range	The parameter specified for the SlaveSyncPosition input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			1			page A-56
546E0000 hex	Duplicate Latch ID for Trigger Input Condition	The same latch ID was specified for more than one motion control instruction.	The same latch ID is used simultaneously for more than one of the following instructions: MC_TouchProbe (Enable External Latch) instruction, MC_MoveLink (Synchronous Positioning) instruction, and MC_MoveFeed (Interrupt Feeding) instruction.  The MC_AbortTrigger (Disable External Latch) instruction was executed to cancel a latch that was used by an instruction other than the MC_TouchProbe (Enable External Latch) instruction.			<b>V</b>			page A-56
546F0000 hex	Jerk Over- ride Factor Out of Range	The parameter specified for the <i>JerkFactor</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-57
54700000 hex	Accelera- tion/Deceler- ation Override Fac- tor Out of Range	The parameter specified for the <i>AccFactor</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-57

Event code	Event neme	Mooning	Assumed asses			Leve	I		Doforos
Event code	Event name	Meaning	Assumed cause	Maj	Prt	Min	Obs	Info	Reference
54710000 hex	First Position Method Specification Out of Range  StartMode input variable to a motion control instruction is out of range.		Instruction input parameter exceeded the valid range of the input variable.	eeded the valid range of the	page A-57				
54720000 hex	Motion Con- trol Instruc- tion Re- execution Disabled (First Position Method)	An attempt was made to change the StartMode input variable when reexecuting a motion control instruction. (This input variable cannot be changed when re-executing an instruction.)	A parameter for an input variable that cannot be changed for re-execution was changed.			√			page A-58
54740000 hex	Unused Axis Specification for Auxiliary Axis	The axis specified for the <i>Auxiliary</i> input variable to a motion control instruction is an unused axis.	The axis specified for the Auxiliary input variable to the instruction is an unused axis.			V			page A-58
54750000 hex	Position Gear Value Error	Synchronized motion is not possible for the velocity, acceleration rate, and deceleration rate that were input to a motion control instruction.	The specified synchronized motion cannot be performed at the velocity, acceleration rate, or deceleration rate that is input to the instruction.			√			page A-59
54760000 hex	Position Gear Master Axis Zero Velocity	The velocity of the master axis was zero when a motion control instruction was started.	The velocity of the master axis was 0 when the instruction was started.			1			page A-59
54780000 hex	Target Position Setting Out of Range	The parameter specified for the <i>Position</i> input variable to a motion control instruction is out of range.	<ul> <li>Instruction input parameter exceeded the valid range of the input variable.</li> <li>The target position of a Rotary Mode axis is not within the ring setting range.</li> </ul>			√			page A-60
54790000 hex	Travel Distance Out of Range	The parameter that was specified for the <i>Distance</i> input variable to a motion control instruction is out of range or the target position with the value of <i>Distance</i> added is out of range.	<ul> <li>The absolute value of the instruction input parameter exceeded the range of 40-bit data when it is converted to pulses.</li> <li>For a Linear Mode axis, the target position with the travel distance added exceeded signed 40-bit data when the absolute value is converted to pulses.</li> </ul>			√			page A-60
547A0000 hex	Cam Table Start Point Setting Out of Range	The parameter specified for the StartPosition input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-61
547B0000 hex	Cam Master Axis Follow- ing First Posi- tion Setting Out of Range	The parameter specified for the <i>MasterStartDistance</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-61

Event code	Event name	Meaning	Assumed cause			Leve			Reference
Event code	Event name	Meaning	Assumed cause	Maj	Prt	Min	Obs	Info	Reference
547C0000 hex	Circular Interpolation Radius Setting Error	It was not possible to create a circular path for the specified radius when the radius method was specified for the MC_MoveCircular2 D (Circular 2D Interpolation) instruction.	For the MC_MoveCircular2D (Circular 2D Interpolation) instruction, it was not possible to create a circular path for the specified radius when the radius method was specified for circular interpolation.			V			page A-62
547D0000 hex	Circular Interpolation Radius Overflow	For the MC_MoveCircular2 D (Circular 2D Interpolation) instruction, the radius of the circle exceeded the maximum value for the border point or center specification method.	For the MC_MoveCircular2D (Circular 2D Interpolation) instruction, the radius of the circle exceeded 40-bit data when converted to pulses for the border point or center specification method.			<b>V</b>			page A-62
547E0000 hex	Circular Interpolation Setting Out of Range	The parameter specified for the <i>Cir-cAxes</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.     The axes that were specified in <i>CircAxes</i> are not included in the composition axes in the Axes Group Settings.     The same axis was specified for both axes of <i>CircAxes</i> .			٧			page A-63
547F0000 hex	Auxil- iary/Slave Axis Num- bers Not in Ascending Order	The values of the parameters for the Auxiliary and Slave input variables to a motion control instruction are not in ascending order.	The parameters for the Auxiliary and Slave input variables to the instruction are not in ascending order.			<b>V</b>			page A-63
54800000 hex	Cam Table Property Ascending Data Error at Update	A phase that was not in ascending order was found during calculating the number of valid data. Or, after calculations, the number of valid data is 0.	A phase that was not in ascending order was found when calculating the number of valid data.      After calculations, the number of valid data is 0.			٧			page A-64
54810000 hex	MC_Write Target Out of Range	The parameter specified for the <i>Target</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-64
54820000 hex	Master Travel Distance Specification Out of Range	The parameter specified for the MasterDistance input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			<b>V</b>			page A-64

Event code	Event name	Meaning	Assumed cause			Leve			Reference
L vont code		Meaning	Accument cause	Maj	Prt	Min	Obs	Info	ricicience
54830000 hex	Master Dis- tance in Acceleration Specification Out of Range	The parameter specified for the MasterDistance-ACC input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			1			page A-65
54840000 hex	Master Dis- tance in Deceleration Specification Out of Range	The parameter specified for the MasterDistance-DEC input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			V			page A-65
54870000 hex	Execution Mode Selec- tion Out of Range	The parameter specified for the <i>ExecutionMode</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			<b>√</b>			page A-65
54880000 hex	Permitted Following Error Out of Range	The parameter specified for the PermittedDeviation input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-66
54890000 hex	Border Point/Center Posi- tion/Radius Specification Out of Range	The parameter specified for the <i>AuxPoint</i> input variable to a motion control instruction is out of range.	<ul> <li>The value of AutPoint exceeded signed 40-bit data when converted to pulses for the border point or center specification method.</li> <li>For a radius specifications, the absolute value of AuxPoint[0] exceeded 40-bit data when converted to pulses.</li> </ul>			√			page A-66
548A0000 hex	End Point Specification Out of Range	The parameter specified for the <i>EndPoint</i> input variable to a motion control instruction is out of range.	The instruction input parameter exceeded the range of signed 40-bit data when it is converted to pulses.			V			page A-67
548B0000 hex	Slave Travel Distance Specification Out of Range	The parameter specified for the SlaveDistance input variable to a motion control instruction is out of range.	The instruction input parameter exceeded the range of 40-bit data when it is converted to pulses.			1			page A-67
548C0000 hex	Phase Shift Amount Out of Range	The parameter specified for the <i>PhaseShift</i> input variable to a motion control instruction is out of range.	The absolute value of the instruction input parameter exceeded the range of 40-bit data when it is converted to pulses.			√			page A-67
548D0000 hex	Feeding Distance Out of Range	The parameter specified for the FeedDistance input variable to a motion control instruction is out of range.	The absolute value of the instruction input parameter exceeded the range of 40-bit data when it is converted to pulses.			√			page A-68

Event code	Event name	Meaning	Assumed cause			Leve			- Reference
Lveni code	Event name	Wearing	Assumed Cause	Maj	Prt	Min	Obs	Info	Helefelice
548E0000 hex	Auxiliary and Slave Defined as Same Axis	The same axis was specified for the Auxiliary and Slave input variables to a motion control instruction.	The parameter is the same for the <i>Auxiliary</i> and <i>Slave</i> input variables to the instruction.			√			page A-68
548F0000 hex	Relative Position Selection Out of Range	The parameter specified for the <i>Relative</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-68
54900000 hex	Cam Transition Specification Out of Range	The parameter specified for the <i>CamTransition</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-69
54910000 hex	Synchro- nized Con- trol End Mode Selec- tion Out of Range	The parameter specified for the <i>OutMode</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			<b>V</b>			page A-69
54920000 hex	Enable Exter- nal Latch Instruction Execution Disabled	_mcImmediateStop was specified for the StopMode input variable when the MC_TouchProbe (Enable External Latch) instruction was executed in Drive Mode, but the Control Mode was not CSP Mode.	_mcImmediateStop was specified for the StopMode input variable when the MC_TouchProbe (Enable External Latch) instruction was executed in Drive Mode, but the Control Mode was not CSP Mode or the Servo was OFF.			√			page A-70
54930000 hex	Master Axis Offset Out of Range	The parameter specified for the <i>MasterOffset</i> input variable to a motion control instruction is out of range.	The instruction input parameter exceeded the range of signed 40-bit data when it is converted to pulses.			√			page A-70
54940000 hex	Slave Axis Offset Out of Range	The parameter specified for the SlaveOffset input variable to a motion control instruction is out of range.	The instruction input parameter exceeded the range of signed 40-bit data when it is converted to pulses.			√			page A-71
54950000 hex	Command Current Posi- tion Count Selection Out of Range	The parameter specified for the <i>CmdPosMode</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-71
54960000 hex	Master Axis Gear Ratio Numerator Out of Range	The parameter specified for the <i>RatioNumerator-Master</i> input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-71

						Leve	I		
Event code	Event name	Meaning	Assumed cause	Maj	Prt	Min	Obs	Info	Reference
54970000 hex	Master Axis Gear Ratio Denominator Out of Range	The parameter specified for the RatioDenominator-Master input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-72
54980000 hex	Auxiliary Axis Gear Ratio Numerator Out of Range	The parameter specified for the RatioNumeratorAuxiliary input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-72
54990000 hex	Auxiliary Axis Gear Ratio Denominator Out of Range	The parameter specified for the RatioDenominatorAuxiliary input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-72
549A0000 hex	Master Axis Position Type Selection Out of Range	The parameter specified for the Reference Type-Master input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-73
549B0000 hex	Auxiliary Axis Position Type Selection Out of Range	The parameter specified for the Reference Type Auxiliary input variable to a motion control instruction is out of range.	Instruction input parameter exceeded the valid range of the input variable.			√			page A-73
549C0000 hex	Target Position Ring Counter Out of Range	Operation is not possible because the target position is out of range for the ring counter of the executed instruction.	High-speed homing was exe- cuted when 0 was not included in the ring counter.			√			page A-74
64400000 hex	Target Position Positive Software Limit Exceeded	The specified position exceeds the positive software limit.	The parameter specified for the Position input variable to the instruction is beyond the positive software limit. The first position is beyond the positive software limit and an instruction that specifies motion in the opposite direction of the software limit was executed. The parameter that was specified for the AuxPoint input variable to a border point MC_MoveCircular2D (Circular 2D Interpolation) instruction is beyond the positive software limit			√			page A-74

Front and	Front name	Magning	Assumed source			Leve			Deference
Event code	Event name	Meaning	Assumed cause	Maj	Prt	Min	Obs	Info	Reference
64410000 hex	Target Position Negative Software Limit Exceeded	The specified position exceeds the negative software limit.	<ul> <li>The parameter specified for the <i>Position</i> input variable to the instruction is beyond the negative software limit.</li> <li>The first position is beyond the negative software limit and an instruction that specifies motion in the opposite direction of the software limit was executed</li> <li>The parameter that was specified for the <i>AuxPoint</i> input variable to a border point MC_MoveCircular2D (Circular 2D Interpolation) instruction is beyond the negative software limit</li> </ul>			√			page A-75
64420000 hex	Command Position Over- flow/Under- flow	Positioning, an instruction in the underflow/overflow direction, or an instruction for which the direction is not specified was executed when there was an underflow/overflow in the command position.	One of the following was executed when there was a command position overflow/underflow.     A positioning instruction     A continuous control instruction in the underflow/overflow direction     An instruction for which the direction is not specified (syncing or torque control)			1			page A-76
64430000 hex	Positive Limit Input	An instruction was executed for a motion in the positive direction when the positive limit input was ON.	An instruction for a motion in the positive direction was exe- cuted when the positive limit input was ON, or an instruction for a motion with no direction specification was executed when the positive limit input was ON.			<b>V</b>			page A-76
64440000 hex	Negative Limit Input	An instruction for a motion in the negative direction was executed when the negative limit input was ON.	An instruction for a motion in the negative direction was exe- cuted when the negative limit input was ON, or an instruction for a motion with no direction specification was executed when the negative limit input was ON.			√			page A-77
74220000 hex	Servo Main Circuits OFF	An attempt was made to turn ON the Servo when the main circuit power supply to the Servo Drive was OFF.	An attempt was made to turn ON the Servo when the main circuit power supply to the Servo Drive was OFF.			√			page A-77

### A-2 Error Code Details

#### **Controller Error Descriptions**

The items that are used to describe individual errors (events) are described in the following copy of an error table.

Event name	Gives the name of	the error.		Event code	Gives the code of	the error.		
Meaning	Gives a short desc	cription of the error.						
Source	Gives the source of	of the error.	Source details	Gives details on the source of the error.	Detection timing	Tells when the error is detected.		
Error attributes	Level	Tells the level of influence on control.*1	Recovery	Gives the recovery method.*2	Log category	Tells which log the error is saved in.*3		
Effects	User program	Tells what will happen to execution of the user program.*4	Operation	Provides special ir from the error.	nformation on the op	peration that results		
Indicators				EtherCAT port indic		us is given only for		
System-defined	Variable		Data type		Name			
variables				stem-defined variable gs that cause the err		t error notification,		
Cause and cor-	Assumed cause		Correction		Prevention			
rection	Lists the possible	causes, corrections,	and preventive mea	sures for the error.				
Attached information	This is the attache	d information that is	displayed by the Sy	smac Studio or an N	S-series PT.			
Precautions/ Remarks	Provides precaution	ons, restrictions, and	supplemental inforr	nation.				

\*1 One of the following:

Major fault: Major fault level Partial fault: Partial fault level Minor fault: Minor fault level

Observation Information

\*2 One of the following:

Automatic recovery: Normal status is restored automatically when the cause of the error is removed.

Error reset: Normal status is restored when the error is reset after the cause of the error is removed.

Cycle the power supply: Normal status is restored when the power supply to the Controller is turned OFF and then back ON after the cause of the error is removed.

Controller reset: Normal status is restored when the Controller is reset after the cause of the error is removed.

Depends on cause: The recovery method depends on the cause of the error.

\*3 One of the following:

System: System event log Access: Access event log

\*4 One of the following:

Continues: Execution of the user program will continue.

Stops: Execution of the user program stops. Starts: Execution of the user program starts.

#### **Error Descriptions**

The following table describes the error codes that are output to *ErrorID* when errors occur in execution of the instructions. The upper four digits of the event codes that are given in the following table are output as the error code to *ErrorID*.

Event name	Process Data Obje	ect Setting Missing		Event code	34610000 hex			
Meaning	The PDO mapping	is not correct.						
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation	Operation is not po	ossible for relevant a	xis.		
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFault	LvI.Active	BOOL		Axis Warning Activ	re		
Cause and	Assumed cause		Correction		Prevention			
correction	The PDOs that are motion control inst mapped.		Map the PDOs that the instruction. Re- section of the relevant the required PDOs	fer to the <i>Function</i> vant instruction for	Map the PDOs that the instructions that to the <i>NJ-series Control User's Mai</i> W507) for the PDO tings) that you must instruction.	at are used. Refer PU Unit Motion nual (Cat. No. Os (Servo Drive set-		
	A motion control ir ifies phase Z (_mc the trigger condition for an axis that is r OMRON GX-EC02 Encoder slave.	ns was executed mapped to an	Use an external in the trigger condition is mapped to an O	ns for an axis that MRON GX-	Use an external in the trigger condition is mapped to an O	ns for an axis that MRON GX-		
Attached information	None							
Precautions/ Remarks	None							
Event name	Flectronic Gear Ba	atio Numerator Settir	ng Out of Bange	Event code	54200000 hex			
Meaning		ecified for the <i>RatioN</i>	<u> </u>			of range		
Source	Motion Control Fu		Source details	Axis	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation		ossible for relevant s ates to a stop if it is i			
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFault	Lvl.Active	BOOL		Axis Minor Fault O	ccurrence		
Cause and	Assumed cause		Correction		Prevention			
correction	Instruction input pa the valid range of t	arameter exceeded the input variable.	•	eter so that the nput variable is not elevant instruction.		neter to the instruc- d range of the input eeded.		
Attached information	None							
Precautions/ Remarks	None							

Event name	Electronic Gear Ra	atio Denominator Se	tting Out of Range	Event code	54210000 hex			
Meaning	The parameter spe	The parameter specified for the RatioDenominator input variable to a motion control ins						
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation		esible for relevant slave axis. Relevantes to a stop if it is in motion.			
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault C	occurrence		
Cause and	Assumed cause		Correction		Prevention			
correction	Instruction input pa the valid range of t	arameter exceeded the input variable.	_	eter so that the input variable is not elevant instruction.	' '	meter to the instruc- id range of the input eeded.		
Attached information	None							
Precautions/ Remarks	None							

Event name	Target Velocity Set	tting Out of Range		Event code	54220000 hex				
Meaning	The parameter specified for the <i>Velocity</i> input variable to a motion control instruction is out of range.								
Source	Motion Control Fu	nction Module	Source details	Axis/axes group	Detection timing	At instruction execution			
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System			
Effects	User program	Continues.	Operation		the source details, operation is not axis. Relevant axis decelerates to a .				
				not possible for rel	iven for the source of evant axes group. R op if it is in motion.	•			
System-defined	Variable		Data type		Name				
variables	_MC_AX[*].MFault	Lvl.Active	BOOL		Axis Minor Fault O	ccurrence			
	_MC_GRP[*].MFa	MC_GRP[*].MFaultLvl.Active		BOOL		Fault Occurrence			
Cause and	Assumed cause		Correction		Prevention				
correction	The Target Velocity Velocity) is still at t	· ` '	Specify a positive Velocity (input vari	value for the Target able <i>Velocity</i> ).	' '	meter to the instruc- d range of the input eeded.			
Attached information	None								
Precautions/ Remarks	None								

Event name	Acceleration Settin	ng Out of Range		Event code	54230000 hex	
Meaning	The parameter spe	ecified for the Accele	eration input variable	to a motion control	instruction is out of r	ange.
Source	Motion Control Fu	nction Module	Source details	Axis/axes group	Detection timing	At instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	possible for releva stop if it is in motic If "axes group" is g not possible for rel	r the source details, nt axis. Relevant axion. given for the source clevant axes group. Rtop if it is in motion.	details, operation is
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFaul	tLvl.Active	BOOL		Axis Minor Fault O	ccurrence
	_MC_GRP[*].MFa	ultLvl.Active	BOOL		Axes Group Minor	Fault Occurrence
Cause and	Assumed cause		Correction		Prevention	
correction	Instruction input pathe valid range of	arameter exceeded the input variable.	•	neter so that the input variable is not relevant instruction.		meter to the instruc- d range of the input eeded.
Attached information	None		•			
Precautions/ Remarks	None					
Event name	Deceleration Setting	ng Out of Bange		Event code	54240000 hex	
Meaning			eration input variable	e to a motion control		ange
Source	Motion Control Fu		Source details	Axis/axes group	Detection timing	At instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation		r the source details, nt axis. Relevant axion.	•
				not possible for re	given for the source of levant axes group. R top if it is in motion.	
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFaul	tLvl.Active	BOOL		Axis Minor Fault O	ccurrence
	_MC_GRP[*].MFa	ultLvl.Active	BOOL		Axes Group Minor	Fault Occurrence
Cause and	Assumed cause		Correction		Prevention	
correction	Instruction input path the valid range of	arameter exceeded the input variable.		neter so that the input variable is not relevant instruction.		meter to the instruc- d range of the input eeded.
Attached information	None					
Precautions/ Remarks	None					

Event name	Jerk Setting Out of	f Range		Event code	54250000 hex				
Meaning	The parameter sp	ecified for the <i>Jerk</i> in	put variable to a mo	tion control instruction	ı is out of range.				
Source	Motion Control Fu	nction Module	Source details	Axis/axes group	Detection timing	At instruction execution			
Error attributes	Level	Minor fault	Recovery	Error reset	Log category System				
Effects	User program	Continues.	Operation		the source details, operation is not taxis. Relevant axis decelerates to a n.				
					iven for the source details, operation i evant axes group. Relevant axes grou op if it is in motion.				
System-defined	Variable		Data type		Name				
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault O	ccurrence			
	_MC_GRP[*].MFa	ultLvl.Active	BOOL		Axes Group Minor	Fault Occurrence			
Cause and	Assumed cause		Correction		Prevention				
correction	Instruction input p the valid range of	arameter exceeded the input variable.	_	eter so that the input variable is not elevant instruction.	· · ·	neter to the instruc- d range of the input eeded.			
Attached information	None								
Precautions/ Remarks	None								

Event name	Torque Ramp Setting Out of Range			Event code	54270000 hex	
Meaning	The parameter spe	ecified for the <i>Torque</i>	<i>Ramp</i> input variable	e to a motion control	instruction is out of	range.
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	Operation is not possible for relevant axis. Relevant axis decelerates to a stop if it is in motion.		
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention	
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.	
Attached information	None					
Precautions/ Remarks	None					

Event name	Master Coefficien	t Scaling Out of Rang	ge	Event code	54280000 hex		
Meaning	The parameter sp	ecified for the Master	rScaling input variat	ole to a motion contro	ol instruction is out o	of range.	
Source	Motion Control Fu	unction Module	Source details	Axis	Detection timing	Controller	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant sates to a stop if it is	slave axis. Relevant in motion.	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFau	ItLvI.Active	BOOL		Axis Minor Fault C	Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	Instruction input parameter exceeded the valid range of the input variable.		•	neter so that the input variable is not relevant instruction.		meter to the instruc id range of the input eeded.	
Attached information	None						
Precautions/ Remarks	None						
Event name	Slave Coefficient	Scaling Out of Range	)	Event code	54290000 hex		
Meaning		pecified for the SlaveS		e to a motion control	instruction is out of	range.	
Source	Motion Control Fu	unction Module	Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ssible for relevant slave axis. Relevant tes to a stop if it is in motion.		
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFau	ItLvI.Active	BOOL		Axis Minor Fault C	Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction		parameter exceeded the input variable.	Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruc- tion so that the valid range of the input variable is not exceeded.		
Attached information	None						
Precautions/ Remarks	None						
Event name	Feeding Velocity	Setting Out of Range		Event code	542A0000 hex		
Meaning	The parameter sp	pecified for the FeedV	<i>elocity</i> input variable	e to a motion control	instruction is out of	range.	
Source	Motion Control Fu	unction Module	Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant a op if it is in motion.	axis. Relevant axis	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFau	ItLvI.Active	BOOL		Axis Minor Fault C	Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	The Feed Velocity FeedVelocity) is s	/ (input variable till at the default (0).	Specify a positive value for the Feed Velocity (input variable <i>FeedVelocity</i> ).		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.		
Attached information	None						
Precautions/ Remarks	None						

Event name	Buffer Mode Selec	tion Out of Range		Event code	542B0000 hex		
Meaning	The parameter spe	ecified for the Bufferl	Mode input variable	to a motion control ir	nstruction is out of ra	ınge.	
Source	Motion Control Function Module		Source details	Axis/axes group	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program Continues.		Operation	If "axis" is given for the source details, operation is not possible for relevant axis. Relevant axis decelerates to a stop if it is in motion.			
				If "axes group" is given for the source details, operation is not possible for relevant axes group. Relevant axes group decelerates to a stop if it is in motion.			
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFault	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
	_MC_GRP[*].MFai	ultLvl.Active	BOOL		Axes Group Minor Fault Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.		
Attached information	None						
Precautions/ Remarks	None						

Event name	Coordinate System	Selection Out of Ra	ange	Event code	542C0000 hex			
Meaning	The parameter spe	The parameter specified for the <i>CoordSystem</i> input variable to a motion control instruction is out of range.						
Source	Motion Control Function Module S		Source details	Axes group	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation	Operation is not possible for relevant axes group. Releva axes group decelerates to a stop if it is in motion.				
System-defined	Variable		Data type		Name			
variables	_MC_GRP[*].MFaultLvl.Active		BOOL		Axes Group Minor Fault Occurrence			
Cause and	Assumed cause		Correction		Prevention			
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.			
Attached information	None							
Precautions/ Remarks	None							

Event name	Circular Interpola	tion Mode Selection C	Out of Range	Event code	542D0000 hex		
Meaning	The parameter sp	ecified for the CircMo	ode input variable to	a motion control ins	truction is out of rar	ige.	
Source	Motion Control Fu	ınction Module	Source details	Axes group	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		essible for relevant a	• ,	
System-defined	Variable		Data type		Name		
variables	_MC_GRP[*].MFa	aultLvl.Active	BOOL		Axes Group Mino	r Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	Instruction input parameter exceeded the valid range of the input variable.		•	neter so that the input variable is not relevant instruction.		meter to the instruction in the inpute eded.	
Attached information	None						
Precautions/ Remarks	None						
Event name	Direction Selectio	n Out of Range		Event code	542E0000 hex		
Meaning	The parameter sp	ecified for the <i>Directi</i>	on input variable to	a motion control inst	ruction is out of ran	ge.	
Source	Motion Control Fu	unction Module	Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	Operation is not po	ssible for relevant axis. Relevant axis op if it is in motion.		
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFau	ItLvI.Active	BOOL		Axis Minor Fault 0	Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction		parameter exceeded the input variable.	Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.		
Attached information	None						
Precautions/ Remarks	None						
Event name	Path Selection Ou	ut of Range		Event code	542F0000 hex		
Meaning		ecified for the PathCi	hoice input variable			ange.	
Source	Motion Control Fu		Source details	Axes group	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		essible for relevant a rates to a stop if it is		
System-defined	Variable		Data type		Name		
variables	_MC_GRP[*].MFa	aultLvl.Active	BOOL		Axes Group Mino	r Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction		parameter exceeded the input variable.	-	neter so that the input variable is not relevant instruction.		put parameter to the instruc at the valid range of the input s not exceeded.	
Attached information	None						
Precautions/ Remarks	None						

Event name	Position Type Selection Out of Range			Event code	54300000 hex		
Meaning	The parameter sp	The parameter specified for the <i>ReferenceType</i> input variable to a motion control instruction is out of range.					
Source	Motion Control Function Module		Source details	MC common or axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	Operation Operation is not possible for relevant axis. Relev decelerates to a stop if it is in motion.		ixis. Relevant axis	
System-defined	Variable		Data type		Name		
variables	_MC_COM.MFaultLvl.Active		BOOL		MC Common Minor Fault Occurrence		
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault C	occurrence	
Cause and	Assumed cause	Assumed cause		Correction		Prevention	
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.		
Attached information	None	None					
Precautions/ Remarks	None						

Event name	Travel Mode Selection Out of Range			Event code	54310000 hex				
Meaning	The parameter spe	The parameter specified for the <i>MoveMode</i> input variable to a motion control instruction is out of range.							
Source	Motion Control Function Module		Source details	Axis/axes group	Detection timing	At instruction execution			
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System			
Effects	User program	Continues.	Operation	If "axis" is given for the source details, operation is not possible for relevant axis. Relevant axis decelerates to a stop if it is in motion.					
				If "axes group" is given for the source details, operation is not possible for relevant axes group. Relevant axes group decelerates to a stop if it is in motion.					
System-defined	Variable		Data type		Name				
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence				
	_MC_GRP[*].MFa	ultLvl.Active	BOOL		Axes Group Minor Fault Occurrence				
Cause and	Assumed cause		Correction		Prevention				
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.				
Attached information	None								
Precautions/ Remarks	None								

Event name	Transition Mode S	election Out of Rang	ie	Event code	54320000 hex		
Meaning	The parameter sp	ecified for the <i>Transi</i>	tionMode input varia	ble to a motion conti	rol instruction is out	of range.	
Source	Motion Control Fu		Source details	Axes group	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		essible for relevant averates to a stop if it is		
System-defined	Variable		Data type	•	Name		
variables	_MC_GRP[*].MFa	ultLvl.Active	BOOL		Axes Group Minor	Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	Instruction input p the valid range of	arameter exceeded the input variable.	•	eter so that the nput variable is not elevant instruction.		meter to the instruc- d range of the input eeded.	
	_mcAborting or _mcBuffered was specified for BufferMode and _mcTMCornerSuperimpose was specified for TransitionMode.		If you specify _mcAborting or _mcBuffered for BufferMode, specify _mcTMNone for TransitionMode. If you specify _mcTMCornerSuperimpose for TransitionMode, specify _mcBlendingLow, _mcBlendingPrevious, _mcBlendingNext, or _mcBlendingHigh for BufferMode.		If you specify _mcAborting or _mcBuffered for BufferMode, specify _mcTMNone for TransitionMode. If you specify _mcTMCornerSuperimpose for TransitionMode, specify _mcBlendingLow, _mcBlendingPrevious, _mcBlendingNext, or _mcBlendingHigh for BufferMode.		
Attached information	None						
Precautions/ Remarks	None						
Event name		Selection Out of Ran	<u> </u>	Event code	54330000 hex		
Meaning		eserved input variabl	e <i>Continuous</i> to a m	otion control instruc	tion changed.		
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	Operation is not po decelerates to a st	ossible for relevant a top if it is in motion.	xis. Relevant axis	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaul	tLvl.Active	BOOL		Axis Minor Fault O	ccurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	The value of the rable Continuous of	eserved input vari- hanged.	of the reserved inp	Correct the program so that the value of the reserved input variable <i>Continuous</i> does not change.		Write the user program so that the value of the reserved input variable <i>Continuous</i> does not change.	
Attached information	None						
Precautions/ Remarks	None						

Event name	Combine Mode Se	election Out of Range	е	Event code	54340000 hex			
Meaning	The parameter spe	The parameter specified for the <i>CombineMode</i> input variable to a motion control instruction is out of range.						
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation		ossible for relevant axis. Relevant axis top if it is in motion.			
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault	Occurrence		
Cause and	Assumed cause	Assumed cause		Correction		Prevention		
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.			
Attached information	None							
Precautions/ Remarks	None							

Event name	Synchronization S	tart Condition Select	tion Out of Range	Event code	54350000 hex			
Meaning	The parameter spe	The parameter specified for the LinkOption input variable to a motion control instruction is out of range.						
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation		Operation is not possible for relevant axis. Relevant axis decelerates to a stop if it is in motion.			
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence			
Cause and	Assumed cause	Assumed cause		Correction		Prevention		
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.			
Attached information	None							
Precautions/ Remarks	None							

Event name	Master and Slave	Defined as Same A	xis	Event code	54360000 hex		
Meaning	The same axis is specified for the <i>Master</i> and <i>Slave</i> input variables to a motion control instruction.						
Source	Motion Control Function Module Source details		Source details	MC common or axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	Operation is not possible for relevant slave axis. Relesslave axis decelerates to a stop if it is in motion.			
System-defined	Variable		Data type		Name		
variables	_MC_COM.MFaultLvl.Active		BOOL		MC Common Minor Fault Occurrence		
	_MC_AX[*].MFaultLvl.Active		BOOL	BOOL		ccurrence	
Cause and	Assumed cause		Correction		Prevention	Prevention	
correction	The parameter is the same for the <i>Master</i> and <i>Slave</i> input variables to the instruction.		ent axes are spec	Correct the parameters so that different axes are specified for the <i>Master</i> and <i>Slave</i> input variables to the instruction.		Specify different axes for the <i>Master</i> and <i>Slave</i> input variables to the instruction.	
Attached information	None		•				
Precautions/ Remarks	None						

Event name	Master and Auxilia	ary Defined as Same	Axis	Event code	54370000 hex	
Meaning	The same axis is	specified for the Mas	ter and Auxiliary inp	ut variables to a mot	tion control instruction	n.
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	· ·	ossible for relevant s ates to a stop if it is i	
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFaul	tLvl.Active	BOOL		Axis Minor Fault C	ccurrence
Cause and	Assumed cause		Correction		Prevention	
correction	The parameter is a Master and Auxilia to the instruction.		Correct the parameters so that different axes are specified for the <i>Master</i> and <i>Auxiliary</i> input variables to the instruction.		Specify different a and <i>Auxiliary</i> input instruction.	
Attached information	None					
Precautions/ Remarks	None					
Event name	Master/Slave Axis	Numbers Not in Asc	ending Order	Event code	54380000 hex	
Meaning	The axis numbers order.	specified for the Mas	ster and Slave input	variables to a motion	control instruction a	re not in ascending
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	· ·	ossible for relevant s ates to a stop if it is i	
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFaul	tLvl.Active	BOOL		Axis Minor Fault C	ccurrence
Cause and	Assumed cause		Correction		Prevention	
The parameters for the <i>Master</i> and <i>Slave</i> input variables to the instruction were not in ascending order when _mcLatestCommand was specified for the <i>ReferenceType</i> input variable to the instruction.		When specifying _mcLatestCommand for the ReferenceType input variable to the instruction, correct the parameters so that the axis numbers specified for the Master and Slave input variables to the instruction are in ascending order. Or, specify _mcCommand for the Position Type Selection.		When specifying _mcLatestCommand for the ReferenceType input variable, make sure to specify the master axis and slave axis input variables so that they are in ascending order.		
Attached information	None					
Precautions/ Remarks	None					

Event name	Incorrect Cam Table Specification			Event code	54390000 hex		
Meaning	The parameter specified for the CamTable input variable to a motion control instruction is out of range.						
Source	Motion Control Function Module		Source details	MC common or axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	es. Operation	If "MC Common" i is not affected.	If "MC Common" is given for the source details, operation is not affected.		
				If "axis" is given for the source details, operation is not possible for relevant slave axis.			
System-defined	Variable		Data type	Data type		Name	
variables	_MC_COM.MFaultLvl.Active		BOOL		MC Common Minor Fault Occurrence		
	_MC_AX[*].MFaultLvl.Active		BOOL	BOOL		Axis Minor Fault Occurrence	
Cause and	Assumed cause		Correction	Correction		Prevention	
correction	Something other than a cam data variable was specified for the <i>CamTable</i> input variable to the instruction.		the <i>CamTable</i> inp	Correct the parameter specified for the <i>CamTable</i> input variable to the instruction so that it is a cam data variable.		Specify a cam data variable for the <i>CamTable</i> input variable to the instruction.	
Attached information	None		·		•		
Precautions/ Remarks	None						

Event name	Synchronization Stopped			Event code	543A0000 hex	
Meaning	A synchronized control motion control instruction was executed, but conditions required for execution were not met					
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation		essible for relevant slave axis. Relevan tes to a stop if it is in motion.	
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFault	Lvl.Active	BOOL		Axis Minor Fault O	ccurrence
Cause and	Assumed cause	Assumed cause			Prevention	
correction	The MC_CamOut (End Cam Operation) instruction was executed even though the MC_CamIn (Start Cam Operation) instruction is not being executed.      The MC_GearOut (End Gear Operation) instruction was executed even though the MC_GearIn (Start Gear Operation) or the MC_GearInPos (Positioning Gear Operation) instruction is not being executed.      The MC_Phasing (Shift Master Axis Phase) instruction was executed even though the MC_CamIn (Start Cam Operation), MC_GearIn (Start Gear Operation), MC_GearInPos (Start Gear Operation), or MC_MoveLink (Synchronous Positioning) instruction is not being executed.		Correct the progra conditions are met tion is executed.		Prevention  Make sure that required conditions for execution are met when you execute sync instructions.	
Attached information	None					
Precautions/ Remarks	None					

F	Matian Cantual Inc	Lancette and Decrease at the	- Disabled	Frank and	5.40D0000 ls		
Event name		truction Re-executio		Event code	543B0000 hex		
Meaning	An attempt was made to re-execute a		motion control instru		re-executed.		
Source	Motion Control Fu	nction Module	Source details	MC common, axis, or axes group	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	is not affected.  If "axis" is given for possible for releval stop if it is in motion.  If "axes group" is g	iven for the source details, operation		
System-defined	Variable		Data type		Name		
variables	_MC_COM.MFault	Lvl.Active	BOOL		MC Common Mino	or Fault Occurrence	
	_MC_AX[*].MFault	Lvl.Active	BOOL		Axis Minor Fault O	ccurrence	
	_MC_GRP[*].MFa	ultLvl.Active	BOOL		Axes Group Minor	Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	A motion control in not be re-executed				When using instructions that cannot be re-executed, include a condition the <i>Execute</i> input variable so that does not change to TRUE unless <i>Busy</i> output variable for the previous instruction is FALSE. Or, stop the instruction before executing it against the conditions of the condi		
Attached information	None						
Precautions/ Remarks	None						
Event name	Motion Control Inc	truction Multi-execut	tion Disabled	Event code	543C0000 hex		
						nommon or avia)	
Meaning			-	were executed for th		At multi-execution	
Source	Motion Control Fu	· · · · · · · · · · · · · · · · · · ·	Source details	MC common or axis	Detection timing	of instructions	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	Operation If "MC Common" is given for the source detail is not affected.			
			9		r the source details, operation is not nt axis. Relevant axis decelerates to a on.		
System-defined	Variable		Data type		Name		
variables	_MC_COM.MFault	Lvl.Active	BOOL		MC Common Minor Fault Occurrence		
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	Multiple functions that cannot be executed simultaneously were executed for the same target (MC common or axis).		Check the specifications of multi-execution of instructions for this instruction and do not execute instructions that cannot be executed at the same time.		Check the specifications for multi-exe cution of instructions for the instruction and do not execute instructions that cannot be executed at the same time.		
Attached information	None						
Precautions/ Remarks	None						

Event name	Instruction Not Al	lowed for Encoder Ax	is Type	Event code	543D0000 hex		
Meaning	An operation instruction was executed for an encoder axis.						
Source	Motion Control Fu	unction Module	Source details	Axis	Detection At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	Operation is not po	ossible for relevant a	xis.	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFau	ItLvI.Active	BOOL		Axis Minor Fault C	ccurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	An operation instr for an encoder ax	uction was executed is.	,		Only execute motion instructions Servo axes or virtual Servo axes.		
Attached information	None						
Precautions/ Remarks	None						
Event name		ot Be Executed during	Multi-axes Coordi-	Event code	543E0000 hex		
	nated Control						
Meaning	· ·	ruction was executed					
Source	Motion Control Fu	inction Module	Source details	Axis	Detection timing	At multi-execution of instructions	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	The axes group de	ecelerates to a stop.		
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFau	ItLvI.Active	BOOL		Axis Minor Fault Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	An operation instruction was executed for an axis that was in a multi-axes coordinated motion.		Correct the program so that the instruction is executed when the relevant axis is not in a multi-axes coordinated motion.		Make sure to execute axis operation instructions only for axes that are no in coordinated motion.		
Attached information	None nated motion.						

Precautions/

Remarks

None

Event name	Multi-axes Coordir Disabled Axes Gro	nated Control Instruc oup	tion Executed for	Event code	543F0000 hex		
Meaning	A multi-axes coord	linated control instru	ction was executed f	or an axes group tha	at was in the Axes Gr	oup Disabled state.	
Source	Motion Control Fu	nction Module	Source details	Axes group	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		essible for relevant ax rates to a stop if it is		
System-defined	Variable		Data type		Name		
variables	_MC_GRP[*].MFaultLvl.Active		BOOL		Axes Group Minor	Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	A multi-axes coord instruction was exe group that was in t abled state.		Correct the progra instruction is exect changing the axes Group Enabled sta MC_GroupEnable Group) instruction group to the Axes state.	uted only after group to the Axes ate. Execute the (Enable Axes to change an axes	Axes the axes group. Execute the MC_GroupEnable (Enable Axes Group) instruction to change an axes group to the Axes Group Enabled		
Attached information	None				-		
Precautions/ Remarks	None						
Event name	Axes Group Canno	ot Be Enabled		Event code	54400000 hex		
Meaning	Execution of the M	IC_GroupEnable (Er	nable Axes Group) ir	struction failed.			
Source	Motion Control Fu	nction Module	Source details	ů i		At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant a emposition axes will o	0 1	
System-defined	Variable		Data type		Name		
variables	_MC_GRP[*].MFa	ultLvl.Active	BOOL		Axes Group Minor	Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	When the MC_GroupEnable (Enable Axes Group) instruction was executed, there was a composition axis that was not stopped.		Correct the program so that the MC_GroupEnable (Enable Axes Group) instruction is executed only when all composition axes are stopped. An axis is stopped if Status.Disabled or Status.Standstill is TRUE in the Axis Variable.		Write the programs so that the MC_GroupEnable (Enable Axes Group) instruction is executed only when all composition axes are stopped. An axis is stopped if Status.Disabled or Status.Standstill is TRUE in the Axis Variable.		
	When the MC_GroupEnable (Enable Axes Group) instruction was executed, there was a composition axis for which the MC_TouchProbe (Enable External Latch) instruction was being executed.		Correct the program so that the MC_GroupEnable (Enable Axes Group) instruction is executed only when the MC_TouchProbe (Enable External Latch) instruction is not being executed for any of the composition axes.		Write the program MC_GroupEnable Group) instruction when the MC_Tou External Latch) ins being executed for sition axes.	(Enable Axes is executed only chProbe (Enable	
Attached information	None		1		1		

Remarks

Event name	Impossible Axis C	peration Specified w	Event code	54410000 hex		
Meaning	An operation instruction was executed for an axis for which the Servo is OFF.					
Source	Motion Control Fu	unction Module	3 1 1		Detection timing	At instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The motion instruc	ction will not start.	
System-defined	Variable	_	Data type		Name	
variables	_MC_AX[*].MFau	ItLvI.Active	BOOL		Axis Minor Fault C	Occurrence
	_MC_GRP[*].MFa	aultLvl.Active	BOOL		Axes Group Minor	r Fault Occurrence
Cause and	Assumed cause		Correction		Prevention	
correction		uction was executed ch the Servo is OFF.		Correct the program so that the instruction is executed after the Servo is turned ON.		cute the axis opera er the Servo is
	Home was preset with the MC_Home instruction for an axis for which Ether-CAT process data communications are not established.		If the _EC_PDSlavTbl (Process Data Communicating Slave Table) system-defined variable for the EtherCAT master of the master axis is FALSE, remove the cause and execute the MC_Home instruction to preset home after _EC_PDSlavTbl changes to TRUE.		If you execute the MC_Home instru- tion to preset home immediately aftr you turn ON the power supply to the Controller, download data, reset a slave communications error, discon- nect the slave, or reconnect the slav write the program to make sure that the _EC_PDSlavTbl (Process Data Communicating Slave Table) system defined variable for the EtherCAT master is TRUE before you execute MC_Home.	
Attached information	Axis: 0	ion 1: Depends on th		curred		
Precautions/ Remarks	None None	ber of the logical axis		Journal		
Event name	Composition Axis	Stopped Error		Event code	54420000 hex	
Meaning		• • • • • • • • • • • • • • • • • • • •	an axes group while	e the MC_Stop instru		cuted for a compos
Source	Motion Control Function Module		Source details	Axes group	Detection timing	At instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	Operation is not p	ossible for relevant a	axes group.
System-defined	Variable		Data type		Name	
variables	_MC_GRP[*].MFaultLvl.Active		BOOL		Axes Group Minor Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention	
correction	A motion instruction was executed for		Change the Execute input variable to		Change the Execute input variables	

the MC\_Stop instruction for the com-

position axis to FALSE, reset the

control instruction.

Attached information 1: Number of the logical axis that was stopped.

error, and then execute the motion

an axes group while the MC\_Stop

composition axis.

None

Attached

Remarks

information Precautions/ instruction was being executed for a

the MC\_Stop instructions for all of the

composition axes to FALSE before

you execute motion control instruc-

tion.

Event name	Motion Control Ins Exceeded	truction Multi-execut	ion Buffer Limit	Event code	54430000 hex			
Meaning	The number of motion control instructions that is buffered for Buffered or Blending Buffer Modes exceeded the buffer limit.							
Source	Motion Control Function Module		Source details	Axis/axes group	Detection timing	Controller		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation	If "axis" is given for the source details, operation is not possible for relevant axis. Relevant axis decelerates to a stop if it is in motion.				
				If "axes group" is given for the source details, operation is not possible for relevant axes group. Relevant axes group decelerates to a stop if it is in motion.				
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence			
	_MC_GRP[*].MFaultLvl.Active		BOOL		Axes Group Minor Fault Occurrence			
Cause and	Assumed cause		Correction		Prevention			
correction	An axis instruction was executed when there was already a current instruction and a buffered instruction for the same axis.		Correct the program so that the number of executed instructions does not exceed the buffer limit.		Do not execute an axis instruction when there is already a current instruction and a buffered instruction for the same axis.			
	An axes group instruction was executed when there was already eight current instructions and buffered instructions for the same axis.					axes group instruc- e already eight cur- nstructions for the		
Attached information	None							
Precautions/ Remarks	None							

Event name	Insufficient Travel Distance Event code 54440000 hex						
Meaning		on cannot be execut tion of a positioning i		on rate or accelerati	on rate that was spe	ecified for multi-exe-	
Source	Motion Control Fu	nction Module	9. 3 p		At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		r the source details, nt axis. Relevant axi n.	•	
				If "axes group" is given for the source details, opera not possible for relevant axes group. Relevant axes decelerates to a stop if it is in motion.			
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault C	ccurrence	
	_MC_GRP[*].MFaultLvl.Active		BOOL	BOOL		Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	Stopping at the target position was not possible for the specified acceleration/deceleration rate for multi-execution or re-execution of a positioning instruction when the Acceleration/Deceleration Over parameter was set to generate a minor fault and stop.		operating specifical instruction so that is not exceeded at rate or acceleration multi-execution or positioning instruction.	Correct the program based on the operating specifications for the instruction so that the target position is not exceeded at the deceleration rate or acceleration rate specified for multi-execution or re-execution of the positioning instruction. Or, change the Acceleration/Deceleration Over parameter to a setting other than to		Check the operating specifications for the relevant instruction and write the program so that this error does not occur. Or, change the Acceleration/Deceleration Over parameter to a setting other than to generate a minor fault and stop.	
Attached information	None		L		L		
Precautions/ Remarks	None						

Event name	Insufficient Travel Distance to Achieve Blending Transit Velocity			Event code	54450000 hex		
Meaning	There is not suffic	ient travel distance to	o accelerate or dece	lerate to the transit v	elocity.		
Source	Motion Control Fu	nction Module	Source details	The second secon		At multi-execution of instructions	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program Continues.		Operation		r the source details, nt axis. Relevant axis n.	•	
				If "axes group" is given for the source details, operation is not possible for relevant axes group. Relevant axes group decelerates to a stop if it is in motion.			
System-defined	Variable		Data type	Data type			
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault O	ccurrence	
	_MC_GRP[*].MFaultLvl.Active		BOOL		Axes Group Minor	Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	tance to accelerate the current command to the transit velocity when the Acceleration/Deceleration Over parameter was set to generate a minor fault and stop.		cient travel distand operating specification. Or, change the tion/Deceleration (	Correct the program to allow a sufficient travel distance according to the operating specifications of the instruction. Or, change the Acceleration/Deceleration Over parameter to a setting other than to generate a minor fault and stop.		Check the operating specifications for the relevant instruction and write the program so that this error does not occur. Or, change the Accelera- tion/Deceleration Over parameter to a setting other than to generate a minor fault and stop.	
Attached information	None		•				
Precautions/ Remarks	None						

Event name	Move Link Consta	nt Velocity Insufficier	nt Travel Distance	Event code	54460000 hex	
Meaning	The constant-velo	city travel distance o	f the master axis is I	ess than zero.	•	
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation		ossible for relevant at top if it is in motion.	axis. Relevant axis
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFaul	tLvl.Active	BOOL		Axis Minor Fault C	Occurrence
Cause and	Assumed cause		Correction		Prevention	
correction	The constant velo of the master axis MC_MoveLink (Sy tioning) instruction	nchronous Posi-	Correct the program so that the master distance is greater than or equal to the master distance in acceleration plus the master distance in deceleration.		·	ng specifications for ction and write the nis error does not
Attached information	None				•	
Precautions/ Remarks	None					
Event name	Positioning Gear (	Operation Insufficient	Target Velocity	Event code	54470000 hex	
Meaning	For the MC_Gearl achieve the requir	nPos (Positioning Ge	ear Operation) instru	uction, the target velo	ocity of the slave axi	s is too small to
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation		ossible for relevant a top if it is in motion.	axis. Relevant axis
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFaul	tLvl.Active	BOOL		Axis Minor Fault C	Occurrence
Cause and	Assumed cause		Correction		Prevention	
For the MC_GearInPos Gear Operation) instruction of the Velocity (Target variable is smaller than axis velocity multiplied ratio when the instruction cuted.		estruction, the value rget Velocity) input than the master blied by the gear	Set the value of the <i>Velocity</i> (Target Velocity) input variable to a value that is greater than the master axis velocity multiplied by the gear ratio when the instruction is executed based on the operating specifications of the instruction.			ng specifications for ction and write the nis error does not
Attached information	None				1	
Precautions/ Remarks	None					

Event name	Same Start Point and End Point for Circular Interpolation			Event code	54480000 hex		
Meaning	The start point and end point were the same when the radius method was specified for the MC_MoveCircular2D (lar 2D Interpolation) instruction. Or, the start point, end point, and border point were the same when the border p method was specified.						
Source	Motion Control Fu	ınction Module	Source details Axes group		Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	Operation is not possible for relevant axes group. Relevances group decelerates to a stop if it is in motion.			
System-defined	Variable		Data type	Data type		Name	
variables	_MC_GRP[*].MFa	aultLvl.Active	BOOL		Axes Group Minor Fault Occurrence		
Cause and	Assumed cause		Correction	Correction			
correction	same when the ra	The start point and end point were the same when the radius method was specified for the MC_MoveCircular2D (Circular 2D Interpolation) instruction.		Correct the program so that the radius specification is not used when the start point and end point for the instruction are the same.		Do not use the same start point and end point when you execute circular interpolation with a radius specification.	
	The start point, end point, and border point were the same when the border point method was specified for the MC_MoveCircular2D (Circular 2D Interpolation) instruction.		Correct the program so that border point specification is not used when the start point, end point, and border point for the instruction are the same.		Do not use the same start point, end point, and border point when you execute circular interpolation with a border point specification.		
Attached information	None				•		
Precautions/ Remarks	None						

Event name	Circular Interpolation Center Specification Position Ou Range			Event code	54490000 hex			
Meaning		The position specified for the center point exceeded the allowed range when the center method was specified for the MC_MoveCircular2D (Circular 2D Interpolation) instruction.						
Source	Motion Control Function Module		Source details	Axes group	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation	Operation is not possible for relevant axes group. F axes group decelerates to a stop if it is in motion.		• .		
System-defined	Variable		Data type		Name			
variables	_MC_GRP[*].MFa	ultLvl.Active	BOOL		Axes Group Minor Fault Occurrence			
Cause and	Assumed cause		Correction		Prevention			
correction	The difference between the distance from the start point to the center point and the distance between the end point to the center point exceeded the permitted value specified for the correction allowance ratio in the axes group settings when the center designation method was specified for the MC_MoveCircular2D (Circular 2D Interpolation) instruction.		Correct the center point so that the difference between the distance from the start point to the center point input variables and the distance between the end point to the center point input variables is less than the permitted value specified for the correction allowance ratio in the axes group settings.		Correct the difference between the distance from the start point to the center point and the distance between the end point to the center point so that is does not exceed the correction allowance ratio in the axes group settings.			
Attached information	None							
Precautions/ Remarks	None							

Event name	Circular Interpolati (Infinite) Axis	on Cannot Be Execu	uted with Rotary	Event code	544A0000 hex		
Meaning	The MC_MoveCirc	•	Interpolation) instru	ction was executed f	or an axis for which	the Count Mode	
Source	Motion Control Fu	nction Module	Source details	Axes group	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		essible for relevant a rates to a stop if it is		
System-defined	Variable		Data type		Name		
variables	_MC_GRP[*].MFa	ultLvl.Active	BOOL		Axes Group Minor	Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	,	flode was used with ular2D (Circular 2D uction.	Change the Count vant axis to Linear		Set the Count Modused in the Circula instruction to Linea		
Attached information	None						
Precautions/ Remarks	None						
Event name	Parameter Selection	on Out of Range		Event code	544C0000 hex		
Meaning	The parameter spe	ecified for the Param	eterNumber input va	ariable to a motion co	ontrol instruction is o	out of range.	
Source	Motion Control Fu	nction Module	Source details	MC Common	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	The instruction is r	ot executed.		
System-defined	Variable		Data type		Name		
variables	_MC_COM.MFault	Lvl.Active	BOOL		MC Common Minor Fault Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	Instruction input pa the valid range of t	arameter exceeded he input variable.	Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.		
Attached information	None						
Precautions/ Remarks	None						
_							
Event name	Stop Method Selec			Event code	544D0000 hex		
Meaning	<u> </u>	· · · · · · · · · · · · · · · · · · ·		a motion control ins	struction is out of rar		
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant a op if it is in motion.	xis. Relevant axis	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFault	Lvl.Active	BOOL		Axis Minor Fault C	ccurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	Instruction input pa the valid range of t	arameter exceeded he input variable.	•	eter so that the input variable is not elevant instruction.		meter to the instruc- d range of the input eeded.	
Attached information	None						
Precautions/ Remarks	None						

Event name	Latch ID Selection Out of Range for Trigger Input Condition			Event code	544E0000 hex	
Meaning	The parameter sp	ecified for the Trigge	rInput::LatchID inpu	t variable to a motion	control instruction i	s out of range.
Source	Motion Control Function Module Source of		Source details	Axis	Detection timing	At instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	Operation is not possible for relevant axis. Relevan decelerates to a stop if it is in motion.		xis. Relevant axis
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention	
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.	
Attached information	None	None				
Precautions/ Remarks	None					

Event name	Setting Out of Range for Writing MC Set		etting	Event code 544F0000 hex		
Meaning	The parameter spe	The parameter specified for the Setting Value input variable to a motion control instruction is out of range.				
Source	Motion Control Fu	nction Module			Detection timing	At instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The relevant instru	ction is not executed	d.
System-defined	Variable		Data type		Name	
variables	_MC_COM.MFaultLvl.Active		BOOL		MC Common Minor Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention	
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruc- tion so that the valid range of the input variable is not exceeded.	
	The parameter specification and the data type of the setting value do not agree.		Make corrections so that the parameter settings and the data types of the settings agree.		Make sure the parameter settings and the data type of the setting values agree.	
Attached information	None				•	
Precautions/ Remarks	None					

Event name	Trigger Input Cond	dition Mode Selection	Out of Range	Event code	54500000 hex	4500000 hex		
Meaning	The parameter sp	ecified for the Trigge	rInput:: Mode input v	variable to a motion o	control instruction is	out of range.		
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation		ossible for relevant a cop if it is in motion.	xis. Relevant axis		
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFaul	tLvl.Active	BOOL		Axis Minor Fault O	ccurrence		
Cause and	Assumed cause (		Correction		Prevention			
correction	Instruction input p the valid range of	arameter exceeded the input variable.	Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.			neter to the instruc- d range of the input eeded.		
Attached information	None	None						
Precautions/ Remarks	None							
Event name	Drive Trigger Sign Input Condition	al Selection Out of R	ange for Trigger	Event code 54510000 hex				
Meaning	The parameter sp	ecified for the Trigge	rInput::InputDrive inp	out variable to a mot	ion control instructio	n is out of range.		
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation		ossible for relevant a op if it is in motion.	xis. Relevant axis		
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFaul	tLvl.Active	BOOL		Axis Minor Fault O	ccurrence		
Cause and	Assumed cause		Correction		Prevention			
correction		truction input parameter exceeded valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.		
Attached information	None							
Precautions/ Remarks	None							

Event name	Motion Control Ins Specification)	struction Re-executio	n Disabled (Axis	Event code	54530000 hex	54530000 hex		
Meaning				<i>tis</i> input variable whe cuting an instruction.)		tion control instruc-		
Source	Motion Control Fu	inction Module	Source details	Axis	Detection timing	At instruction re- execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation		ossible for relevant at top if it is in motion.	ssible for relevant axis. Relevant axis op if it is in motion.		
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFau	ItLvI.Active	BOOL		Axis Minor Fault 0	Occurrence		
Cause and	Assumed cause		Correction		Prevention			
correction	A parameter for an input variable that cannot be changed for re-execution was changed.		Correct the program so that the parameter for the relevant input variable does not change when the relevant instruction is re-executed.		Check the manual to see if the input variables to the relevant motion control instruction can be changed by reexecution. Write the program so that the input parameters for any input variable that cannot be changed do not change upon re-execution.			
Attached information	None							
Precautions/ Remarks	None							
Event name	Motion Control Instruction Re-execution Disabled (Buffer Mode Selection)		Event code	54540000 hex				
Meaning				<i>ifferMode</i> input variating an instru		g a motion control		
Source	Motion Control Fu	inction Module	Source details	Axis/axes group	Detection timing	At instruction re- execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation	possible for releva stop if it is in motio If "axes group" is not possible for re	or the source details, ant axis. Relevant ax on. given for the source elevant axes group. F top if it is in motion.	is decelerates to a details, operation is		
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFau	ItLvI.Active	BOOL		Axis Minor Fault (	Occurrence		
	_MC_GRP[*].MFa	aultLvl.Active	BOOL		Axes Group Mino	r Fault Occurrence		
Cause and	Assumed cause		Correction		Prevention			
correction	A parameter for an input variable that cannot be changed for re-execution was changed.		Correct the program so that the parameter for the relevant input variable does not change when the relevant instruction is re-executed.		Check the manual to see if the input variables to the relevant motion control instruction can be changed by reexecution. Write the program so that the input parameters for any input variable that cannot be changed do not change upon re-execution.			
Attached information	None		1		1 32 34 31	<del>-</del>		
Precautions/ Remarks	None							

Event name	Motion Control Ins (Direction Selection	truction Re-execution)	n Disabled	Event code	de 54550000 hex		
Meaning		ade to change the panput variable cannot				a motion control	
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction re- execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant top if it is in motion.	axis. Relevant axis	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaul	tLvl.Active	BOOL		Axis Minor Fault (	Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction			parameter for the able does not char	Correct the program so that the parameter for the relevant input variable does not change when the relevant instruction is re-executed.		Il to see if the input elevant motion con- n be changed by re- he program so that ters for any input not be changed do re-execution.	
Attached information	None						
Precautions/ Remarks	None						
Event name	Motion Control Instion Mode)	truction Re-executio	n Disabled (Execu-	Event code	54560000 hex		
Meaning		ade to change the panis input variable can				cuting a motion con-	
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction re- execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant top if it is in motion.	axis. Relevant axis	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaul	tLvl.Active	BOOL		Axis Minor Fault (	Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	A parameter for all cannot be change was changed.	n input variable that d for re-execution	Correct the progra parameter for the able does not char vant instruction is	relevant input vari- nge when the rele-	Check the manual to see if the input variables to the relevant motion control instruction can be changed by reexecution. Write the program so that the input parameters for any input variable that cannot be changed do not change upon re-execution.		
Attached information	None		1		, , ,		
Precautions/ Remarks	None						

Event name	Motion Control Ins Group Specification	struction Re-executio	n Disabled (Axes	Event code	54570000 hex	
Meaning				resGroup input variab re-executing an instru		g a motion control
Source	Motion Control Fu	inction Module	Source details	Axes group	Detection timing	At instruction re- execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation		ossible for relevant a erates to a stop if it is	
System-defined	Variable		Data type		Name	
variables	_MC_GRP[*].MFa	aultLvl.Active	BOOL		Axes Group Minor	r Fault Occurrence
Cause and	Assumed cause  A parameter for an input variable that cannot be changed for re-execution was changed.		Correction		Prevention	
correction			Correct the program so that the parameter for the relevant input variable does not change when the relevant instruction is re-executed.		Check the manual to see if the input variables to the relevant motion control instruction can be changed by reexecution. Write the program so that the input parameters for any input variable that cannot be changed do not change upon re-execution.	
Attached information	None					
Precautions/ Remarks	None					
Event name	Motion Control Instruction Re-execution Disabled (Jerk Setting)				54580000 hex	
Meaning				rk input variable where uting an instruction.)		tion control instruc-
Source	Motion Control Fu	inction Module	Source details	Axis/axes group	Detection timing	At instruction re- execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	possible for releva stop if it is in motion If "axes group" is of not possible for re	or the source details, ant axis. Relevant ax on.  given for the source levant axes group. For the it is in motion.	is decelerates to a details, operation is
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFau	ItLvI.Active	BOOL		Axis Minor Fault C	Occurrence
	_MC_GRP[*].MFa	aultLvl.Active	BOOL		Axes Group Minor	r Fault Occurrence
Cause and	Assumed cause		Correction		Prevention	
correction	A parameter for an input variable that cannot be changed for re-execution was changed.		Correct the program so that the parameter for the relevant input variable does not change when the relevant instruction is re-executed.		Check the manual to see if the input variables to the relevant motion control instruction can be changed by reexecution. Write the program so that the input parameters for any input variable that cannot be changed do not change upon re-execution.	
Attached information	None		ı		1	
Precautions/ Remarks	None					

Event name	Motion Control Instruction Re-execution Disabled (Master Axis) Event code 54590000 he				54590000 hex	
Meaning		ade to change the panput variable cannot		•	•	motion control
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction re- execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation		ossible for relevant top if it is in motion.	axis. Relevant axis
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFaul	tLvl.Active	BOOL		Axis Minor Fault	Occurrence
Cause and	Assumed cause		Correction		Prevention	
correction	A parameter for an input variable that cannot be changed for re-execution was changed.		parameter for the able does not cha	Correct the program so that the parameter for the relevant input variable does not change when the relevant instruction is re-executed.		al to see if the input elevant motion con- n be changed by re- the program so that ters for any input not be changed do re-execution.
Attached information	None					
Precautions/ Remarks	None					
Event name	Motion Control Ins (MasterOffset)	truction Re-executio	n Disabled	Event code	545A0000 hex	
Meaning		ade to change the panput variable cannot				ting a motion control
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction re- execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation		ossible for relevant top if it is in motion.	
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFaul	tLvl.Active	BOOL		Axis Minor Fault	Occurrence
Cause and	Assumed cause		Correction		Prevention	
correction	A parameter for all cannot be change was changed.	n input variable that d for re-execution	Correct the program so that the parameter for the relevant input variable does not change when the relevant instruction is re-executed.		Check the manual to see if the input variables to the relevant motion control instruction can be changed by reexecution. Write the program so that the input parameters for any input variable that cannot be changed do not change upon re-execution.	
Attached information	None		1			
Precautions/ Remarks	None					

Event name	Motion Control In (MasterScaling)	struction Re-executio	n Disabled	Event code	545B0000 hex			
Meaning		An attempt was made to change the parameter for the <i>MasterScaling</i> input variable when re-executing a motion cor instruction. (This input variable cannot be changed when re-executing an instruction.)						
Source	Motion Control Fu	unction Module	Source details	Axis	Detection timing	At instruction re execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation		ossible for relevant a top if it is in motion.	axis. Relevant axis		
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFau	ItLvI.Active	BOOL		Axis Minor Fault C	Occurrence		
Cause and	Assumed cause Correction		Correction		Prevention			
correction	A parameter for an input variable that cannot be changed for re-execution was changed.		Correct the program so that the parameter for the relevant input variable does not change when the relevant instruction is re-executed.		variables to the re trol instruction car execution. Write the the input paramet	ot be changed do		
Attached information	None							
Precautions/ Remarks	None							
	Turi o i ii		B: 11 1	I =	T-1-000001			
Event name	(MasterStartDista	struction Re-executio ince)			545C0000 hex			
Meaning		nade to change the pa n. (This input variable				-executing a motio		
Source	Motion Control Fu	unction Module	Source details	Axis	Detection timing	At instruction re execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation		ossible for relevant a top if it is in motion.	axis. Relevant axis		
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFau	ItLvI.Active	BOOL		Axis Minor Fault C	Occurrence		
Cause and	Assumed cause		Correction		Prevention			
correction	•	n input variable that ed for re-execution	Correct the program so that the parameter for the relevant input variable does not change when the relevant instruction is re-executed.		Check the manual to see if the input variables to the relevant motion control instruction can be changed by reexecution. Write the program so that the input parameters for any input variable that cannot be changed do not change upon re-execution.			
Attached information	None				•			
Precautions/	None							

Remarks

Event name	Motion Control Instruction Re-execution Disabled Event code 545D0000 hex (Continuous)					
Meaning		ade to change the panput variable cannot		•		g a motion control
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction re- execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation		ossible for relevant at top if it is in motion.	axis. Relevant axis
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFaul	tLvl.Active	BOOL		Axis Minor Fault 0	Occurrence
Cause and	Assumed cause		Correction		Prevention	
correction	A parameter for an input variable that cannot be changed for re-execution was changed.		parameter for the able does not char	Correct the program so that the parameter for the relevant input variable does not change when the relevant instruction is re-executed.		Il to see if the input elevant motion con- n be changed by re- he program so that ers for any input tot be changed do re-execution.
Attached information	None					
Precautions/ Remarks	None					
Event name	Motion Control Ins (MoveMode)	truction Re-executio	n Disabled	Event code	545E0000 hex	
Meaning		ade to change the panput variable cannot				g a motion control
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction re- execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation		ossible for relevant at top if it is in motion.	axis. Relevant axis
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFaul	tLvl.Active	BOOL		Axis Minor Fault 0	Occurrence
Cause and	Assumed cause		Correction		Prevention	
correction		parameter for an input variable that annot be changed for re-execution as changed.		nm so that the relevant input vari- nge when the rele- re-executed.	Check the manual to see if the input variables to the relevant motion control instruction can be changed by reexcution. Write the program so that the input parameters for any input variable that cannot be changed do not change upon re-execution.	
Attached information	None		1			
Precautions/ Remarks	None					

Event name	Illegal Auxiliary Axis Specification			Event code	545F0000 hex		
Meaning	The axis specified	for the <i>Auxiliary</i> inpu	ut variable to a motion	on control instruction	does not exist.		
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ssible for relevant slave axis. The slave a stop if it is in motion.		
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence		
Cause and	Assumed cause	Assumed cause		Correction		Prevention	
correction	An axis does not exist for the variable specified for the <i>Auxiliary</i> input variable to the instruction.		Correct the instruction so that the variable exists for the axis that was specified for the instruction.		Make sure to specify variables that exist when specifying variables for the input parameters to an instruction.		
Attached information	None						
Precautions/ Remarks	None						

Event name	Illegal Axis Specifi	Illegal Axis Specification			54600000 hex			
Meaning	The axis specified	The axis specified for the Axis input variable to a motion control instruction does not exist.						
Source	Motion Control Function Module		Source details	MC Common	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation The relevant instruction is not executed.		d.			
System-defined	Variable		Data type		Name			
variables	_MC_COM.MFaultLvl.Active		BOOL		MC Common Minor Fault Occurrence			
Cause and	Assumed cause	Assumed cause		Correction		Prevention		
correction	An axis does not exist for the variable specified for the <i>Axis</i> input variable to the instruction.		Correct the instruction so that the variable exists for the axis that was specified for the instruction.		Make sure to specify a variable that exists when specifying a variable for an input parameter to an instruction.			
Attached information	None							
Precautions/ Remarks	None							

Event name	Illegal Axes Group	Specification		Event code	54610000 hex		
Meaning	The axes group sp group.	ecified for the Axes	<i>Group</i> input variable t	o a motion control in	struction does not ex	xist or is not a used	
Source	Motion Control Fur	nction Module	Source details	MC Common	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	The relevant instru	ction is not executed	d.	
System-defined	Variable		Data type		Name		
variables	_MC_COM.MFault	Lvl.Active	BOOL		MC Common Mino	or Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	An axes group doe variable specified finput variable to the	or the <i>AxesGroup</i>	Correct the specific instruction so that group exists.		Specify a variable specifying a variab parameter to an in	le for an input	
	The axes group specified for the AxesGroup input variable to the instruction is not specified as a used group.		Correct the axes g the instruction to a		Set a used axes gray Group input variab tion.		
Attached information	None						
Precautions/ Remarks	None						
Event name	Illegal Master Axis Specification			Event code	54620000 hex		
Meaning	The axis specified for the <i>Master</i> input variable to a motion control instruction does not exist or is not a sync master axis.						
Source	Motion Control Fur	nction Module	Source details	MC common or axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant sl o a stop if it is in moti		
System-defined	Variable		Data type		Name		
variables	_MC_COM.MFault	Lvl.Active	BOOL		MC Common Mino	r Fault Occurrence	
	_MC_AX[*].MFault	Lvl.Active	BOOL		Axis Minor Fault O	ccurrence	
Cause and	Assumed cause		Correction		Prevention		
correction		xist for the variable aster input variable	variable exists for t	Correct the instruction so that the variable exists for the axis that was specified for the instruction.		Specify a variable that exists when specifying a variable for an input parameter to an instruction.	
	The axis that was specified for the <i>Master</i> input variable to the <i>MC_Phasing</i> (Shift Master Axis Phase) instruction is not the master axis for syncing.		Correct the variable that is input to the <i>Master</i> input variable of the <i>MC_Phasing</i> (Shift Master Axis Phase) instruction to the axis variable that is specified as the master axis of the sync instruction.		Set the variable that is input to the <i>Master</i> input variable of the <i>MC_Phasing</i> (Shift Master Axis Phase) instruction to the axis variable that is specified as the master axis of the sync instruction.		
Attached information	None						
Precautions/ Remarks	None						

Event name	Motion Control In: Offset)	struction Re-executio	n Disabled (Slave-	Event code	54630000 hex		
Meaning		nade to change the <i>S</i> not be changed whe			ting a motion control	instruction. (This	
Source	Motion Control Fu	unction Module	Source details	Axis	Detection timing	At instruction re execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant attop if it is in motion.	axis. Relevant axis	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFau	ItLvI.Active	BOOL		Axis Minor Fault C	Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	A parameter for an input variable that cannot be changed for re-execution was changed.		Correct the program so that the parameter for the relevant input variable does not change when the relevant instruction is re-executed.		Check the manual variables to the re trol instruction car execution. Write the input parameter variable that cannot change upon	levant motion con to be changed by rene program so tha ers for any input ot be changed do	
Attached information	None						
Precautions/ Remarks	None						
Event name	Motion Control In: (SlaveScaling)	struction Re-executio	n Disabled	Event code	54640000 hex		
Meaning		nade to change the <i>S</i> not be changed whe			uting a motion contro	ol instruction. (Thi	
Source	Motion Control Fu	unction Module	Source details	Axis	Detection timing	At instruction re execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant atop if it is in motion.	axis. Relevant axis	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFau	ItLvI.Active	BOOL		Axis Minor Fault C	Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction		A parameter for an input variable that cannot be changed for re-execution was changed.		Correct the program so that the parameter for the relevant input variable does not change when the relevant instruction is re-executed.		Check the manual to see if the input variables to the relevant motion control instruction can be changed by reexecution. Write the program so that the input parameters for any input variable that cannot be changed do not change upon re-execution.	
Attached information	None				1		
Precautions/	None						

Remarks

Event name	Motion Control Ins Position)	struction Re-executio	n Disabled (Start-	Event code	54650000 hex				
Meaning		nade to change the <i>S</i> not be changed whe		ariable when re-execustruction.)	uting a motion contro	ol instruction. (This			
Source	Motion Control Fu	inction Module	Source details	Axis	Detection timing	At instruction re- execution			
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System			
Effects	User program	Continues.	Operation		ossible for relevant a top if it is in motion.	xis. Relevant axis			
System-defined	Variable		Data type		Name				
variables	_MC_AX[*].MFaul	ItLvI.Active	BOOL		Axis Minor Fault C	Occurrence			
Cause and	Assumed cause		Correction		Prevention				
correction	A parameter for an input variable that cannot be changed for re-execution was changed.		Correct the program so that the parameter for the relevant input variable does not change when the relevant instruction is re-executed.		Check the manual to see if the input variables to the relevant motion control instruction can be changed by reexecution. Write the program so that the input parameters for any input variable that cannot be changed do not change upon re-execution.				
Attached information	None	lone							
Precautions/ Remarks	None								
Event name	Instruction Execution Error with Undefined Home Event code				54660000 hex				
Meaning	High-speed homir	ng or an interpolation	instruction was exe	ecuted when home w	as undefined.				
Source	Motion Control Fu	inction Module	Source details	Axis/axes group	Detection timing	At instruction execution			
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System			
Effects	User program	Continues.	Operation	possible for releva stop if it is in motic If "axes group" is g not possible for rel	r the source details, nt axis. Relevant axi on. given for the source of levant axes group. Rotop if it is in motion.	s decelerates to a details, operation is			
System-defined	Variable		Data type		Name				
variables	_MC_AX[*].MFaul	ItLvI.Active	BOOL		Axis Minor Fault Occurrence				
	_MC_GRP[*].MFa	ultLvl.Active	BOOL		Axes Group Minor Fault Occurrence				
Cause and	Assumed cause		Correction		Prevention				
correction	High-speed homin when home was u	•		Execute the high-speed homing operation only after homing to define					
	·	nstruction was exe- group that includes efined home.	Perform homing to define home for all axes in the axes group before executing the interpolation instruction.		Perform homing to define home for all axes in the axes group before executing the interpolation instruction.				
Attached information	Attached informat Axis: 0 Axes group: Logic	ion 1: Depends on th	e source details.						
Precautions/ Remarks	If you execute the			homing, home will a	gain be undefined. \	You must perform			

Event name	Motion Control Instruction Re-execution Disabled (Position Type)			Event code	54670000 hex			
Meaning	· ·	An attempt was made to change the <i>ReferenceType</i> input variable when re-executing a motion control instruction. (This input variable cannot be changed when re-executing an instruction.)						
Source	Motion Control Function Module Source details Axis		Detection timing	At instruction re- execution				
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation	Operation is not possible for relevant axis. Releva decelerates to a stop if it is in motion.		axis. Relevant axis		
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence			
Cause and	Assumed cause		Correction		Prevention			
correction	A parameter for an input variable that cannot be changed for re-execution was changed.		parameter for the relevant input variables to able does not change when the relevant instruction is re-executed.  variables to trol instruction execution. We the input parameter for the relevant instruction is re-executed.		variables to the re trol instruction car execution. Write the the input paramet	ot be changed do		
Attached information	None							
Precautions/ Remarks	None		None					

Event name	Unused Axis Specification for Master Axis			Event code	54680000 hex			
Meaning	The master axis s	The master axis specified for a motion control instruction is an unused axis.						
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation		Operation is not possible for relevant slave axis. Relessave axis decelerates to a stop if it is in motion.			
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence			
Cause and	Assumed cause		Correction		Prevention			
correction	The master axis specified for a motion control instruction is an unused axis.		Set a used axis for the master axis that is specified for the instruction.		Make sure the master axis specified for the motion control instruction is a used axis.			
Attached information	None							
Precautions/ Remarks	None			,	,			

Event name	First Position Setti	ng Out of Range		Event code	54690000 hex		
Meaning	The parameter spe	ecified for the FirstPo	osition input variable	to a motion control i	nstruction is out of ra	ange.	
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	Operation is not po decelerates to a st		ssible for relevant axis. Relevant axis p if it is in motion.	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFault	Lvl.Active	BOOL		Axis Minor Fault O	ccurrence	
Cause and	Assumed cause Correction  Instruction input parameter exceeded the valid range of the input variable.  Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Prevention				
correction			nput variable is not	Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.			
Attached information	None				,		
Precautions/ Remarks	None	None					
Event name	Last Position Setti	ng Out of Range		Event code	546A0000 hex		
Meaning	The parameter spe	ecified for the LastPo	osition input variable	to a motion control i	nstruction is out of ra	ange.	
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	Operation is not po decelerates to a st	ossible for relevant a op if it is in motion.	xis. Relevant axis	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFault	Lvl.Active	BOOL		Axis Minor Fault O	ccurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.		
Attached information	None				•		
Precautions/ Remarks	None						

Event name	Illegal First/Last Po	sition Size Relation	ship (Linear Mode)	Event code	546B0000 hex		
Meaning		The parameter specified for the <i>LastPosition</i> input variable to a motion control instruction is smaller than the parameter specified for the <i>FirstPosition</i> input variable.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		n is not possible for relevant axis. Relevant axi tes to a stop if it is in motion.		
System-defined			Data type		Name		
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	The value of the <i>LastPosition</i> input parameter is less than the value of the <i>FirstPosition</i> input variable for the instruction when the Count Mode is set to Linear Mode.		Correct the program so that the value of the LastPosition specified for the instruction is larger than the value of the FirstPosition. Or, change the value of the Count Mode to Rotary Mode.		Write the program so that the value of the LastPosition specified for the instruction is larger than the value of the FirstPosition. Or, check to make sure that the Count Mode of the relevant axis is set to Rotary Mode.		
Attached information	None						
Precautions/ Remarks	None						

Event name	Master Sync Start	Position Setting Out	of Range	Event code	546C0000 hex		
Meaning	The parameter spe	ecified for the Master	rSyncPosition input v	ariable to a motion o	control instruction is	out of range.	
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	Operation is not possible for relevant slave axis. Releva slave axis decelerates to a stop if it is in motion.			
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.		
Attached information	None		,	,	,		
Precautions/ Remarks	None	None					

Event name	Slave Sync Start	Position Setting Out of	of Range	Event code	546D0000 hex		
Meaning	The parameter sp	pecified for the Slaves	SyncPosition input	variable to a motion c	ontrol instruction is o	out of range.	
Source	Motion Control Fu	unction Module	Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant a top if it is in motion.	xis. Relevant ax	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFau	ltLvl.Active	BOOL		Axis Minor Fault C	Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	Instruction input parameter exceeded the valid range of the input variable.		valid range of th	Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		meter to the inst id range of the in eeded.	
Attached nformation	None	None					
Precautions/ Remarks	None						
Event name	Duplicate Latch ID for Trigger Input Condition Event co		Event code	546E0000 hex			
Meaning	The same latch ID was specified for more than one motion control instruction.						
Source	Motion Control Fu	unction Module	Source details Axis		Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant a top if it is in motion.	ixis. Relevant ax	
System-defined	Variable		Data type Name				
variables	_MC_AX[*].MFau	ltLvl.Active	BOOL		Axis Minor Fault Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	The same latch ID is used simultaneously for more than one of the following instructions: MC_TouchProbe (Enable External Latch) instruction, MC_MoveLink (Synchronous Positioning) instruction, and MC_MoveFeed (Interrupt Feeding) instruction.		latch ID is not us instruction at the instruction. Eithe ID or do not exe that use the san same time. Both are treated as b	Correct the program so that the same latch ID is not used by another instruction at the same time as this instruction. Either use a different latch ID or do not execute any instructions that use the same latch ID at the same time. Both latch 1 and latch 2 are treated as being in use during execution of the MC_Home instruc-		Do not use the same latch ID simulation neously for more than one of the following instructions: MC_TouchPro (Enable External Latch) instruction MC_MoveLink (Synchronous Positioning) instruction, and MC_MoveFeed (Interrupt Feeding) instruction.	
	The MC_AbortTrigger (Disable External Latch) instruction was executed to cancel a latch that was used by an instruction other than the MC_TouchProbe (Enable External Latch) instruction.		instruction to ca used by an instr	Do not use the Disable External Latch instruction to cancel a latch that is used by an instruction other than the Enable External Latch instruction.		e Disable Externor a latch that is stion other than tatch instruction.	
Attached information	None						
Precautions/ Remarks	If you decide to c	hange the latch ID, m	ake sure that sam	e latch ID is not used	by any other instruct	ions.	

A-57

Event name	Jerk Override Factor Out of Range			Event code	546F0000 hex		
Meaning	The parameter spe	ecified for the JerkFa	actor input variable to	o a motion control in	struction is out of ra	nge.	
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	Operation is not po decelerates to a st	ossible for relevant axis. Relevant axis op if it is in motion.		
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence		
Cause and	Assumed cause	Assumed cause		Correction		Prevention	
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.		
Attached information	None						
Precautions/ Remarks	None						

Event name	Acceleration/Dece	leration Override Fac	ctor Out of Range	Event code	54700000 hex			
Meaning	The parameter sp	The parameter specified for the AccFactor input variable to a motion control instruction is out of range.						
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation		eration is not possible for relevant axis. Relevant axis elerates to a stop if it is in motion.			
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFaul	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence		
Cause and	Assumed cause	Assumed cause		Correction		Prevention		
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.			
Attached information	None							
Precautions/ Remarks	None							

Event name	First Position Met	hod Specification Ou	t of Range	Event code	54710000 hex		
Meaning	The parameter sp	The parameter specified for the StartMode input variable to a motion control instruction is out of range.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant axis. Relevant axis top if it is in motion.		
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence		
Cause and	Assumed cause	Assumed cause		Correction		Prevention	
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.		
Attached information	None						
Precautions/ Remarks	None						

Event name	Motion Control In Position Method)	Motion Control Instruction Re-execution Disabled (First Position Method)  Event code 54720000 hex					
Meaning		nade to change the S not be changed whe	•	able when re-executinestruction.)	ng a motion control i	nstruction. (This	
Source	Motion Control Fu	unction Module	Source details	Axis	Detection timing	At instruction re- execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant at top if it is in motion.	axis. Relevant axis	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFau	ItLvI.Active	BOOL		Axis Minor Fault C	Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	A parameter for an input variable that cannot be changed for re-execution was changed.		Correct the program so that the parameter for the relevant input variable does not change when the relevant instruction is re-executed.		Check the manual to see if the input variables to the relevant motion control instruction can be changed by reexecution. Write the program so that the input parameters for any input variable that cannot be changed do not change upon re-execution.		
Attached information	None		•				
Precautions/ Remarks	None						
	Tu unio	· · · · · · · · · · · · · · · · · · ·		I	T-17100001		
Event name	· ·	cification for Auxiliary			54740000 hex		
Meaning				ion control instruction		1	
Source	Motion Control Fu	inction Module	Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant s ates to a stop if it is		
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFau	ItLvI.Active	BOOL		Axis Minor Fault C	Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction		d for the <i>Auxiliary</i> he instruction is an	specified for the i	Set a used axis for the axis that is specified for the instruction. Or, correct the parameter so that it specifies a used axis.		Make sure that the axis specified for the instruction is a used axis.	
Attached information	None						
Precautions/ Remarks	None						

Event name	Position Gear Valu	e Error		Event code	54750000 hex			
Meaning	1	Synchronized motion is not possible for the velocity, acceleration rate, and deceleration rate that were input to a motion control instruction.						
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation	Operation is not possible for relevant slave axis. Relessave axis decelerates to a stop if it is in motion.				
System-defined variables	Variable		Data type		Name			
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence			
Cause and	Assumed cause		Correction		Prevention			
correction	The specified synchronized motion cannot be performed at the velocity, acceleration rate, or deceleration rate that is input to the instruction.		Correct the program to enable synchronized motion according to the operating specifications of the MC_GearInPos (Positioning Gear Operation) instruction.		Check the processing of the relevant instruction and set a value that allows for synchronized motion.			
Attached information	None	None						
Precautions/ Remarks	None							

Event name	Position Gear Master Axis Zero Velocity			Event code	54760000 hex			
Meaning	The velocity of the	The velocity of the master axis was zero when a motion control instruction was started.						
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation		ot possible for relevant slave axis. Relevant elerates to a stop if it is in motion.			
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence			
Cause and	Assumed cause	Assumed cause		Correction		Prevention		
correction	The velocity of the master axis was 0 when the instruction was started.		Correct the program so that the velocity of the master axis is not 0 when the instruction is started.		Write the program so that the velocity of the master axis is not 0 when the instruction is started.			
Attached information	None							
Precautions/ Remarks	None							

A-59

Event name							
	Target Position Set	ting Out of Range		Event code 54780000 hex			
Meaning	The parameter spe	ecified for the <i>Positio</i>	n input variable to a	motion control instru	uction is out of range	).	
Source	Motion Control Fur	nction Module	Source details	Axis/axes group	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	possible for relevant stop if it is in motion If "axes group" is g	iven for the source o	s decelerates to a details, operation is	
System-defined	Variable		Data type	decelerates to a st	Name		
variables	_MC_AX[*].MFault	I vI Active	BOOL		Axis Minor Fault O	ccurrence	
	_MC_GRP[*].MFai		BOOL		Axes Group Minor		
Cause and	Assumed cause		Correction		Prevention		
correction	Instruction input pa the valid range of t		Correct the parame valid range of the in exceeded for the re	nput variable is not	Set the input parar tion so that the vali variable is not exce	d range of the inpu	
	The target position axis is not within thrange.		Correct the target p Rotary Mode axis t setting range.		Set the target posi Mode axis to within range.	•	
Attached	Depends on the so	ource details.					
information	Axis: None						
	Axes group: Logica	al axis number					
Precautions/ Remarks	None						
Event name	Travel Distance Ou	it of Range		Event code	54790000 hex		
Meaning		•	ne <i>Distance</i> input var		ntrol instruction is or	ut of range or the	
Source	Motion Control Function Module		O a company all a traille				
	Wouldn't Gontrol 1 di	iction wodule	Source details	Axis/axes group	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Axis/axes group  Error reset			
Error attributes Effects			_	Error reset  If "axis" is given for	timing  Log category  r the source details, nt axis. Relevant axis	execution System operation is not	
	Level	Minor fault	Recovery	Error reset  If "axis" is given for possible for relevar stop if it is in motio  If "axes group" is g	timing  Log category  r the source details, nt axis. Relevant axis n.  iven for the source cevant axes group. Re	execution  System operation is not sedecelerates to a details, operation is	
Effects System-defined	Level	Minor fault	Recovery	Error reset  If "axis" is given for possible for relevar stop if it is in motio  If "axes group" is g not possible for relevance possible	timing  Log category  r the source details, nt axis. Relevant axis n.  iven for the source cevant axes group. Re	execution  System operation is not s decelerates to a details, operation is	
Effects System-defined	Level User program	Minor fault Continues.	Recovery Operation	Error reset  If "axis" is given for possible for relevar stop if it is in motio  If "axes group" is g not possible for relevance possible	timing  Log category  r the source details, nt axis. Relevant axis n.  iven for the source cevant axes group. Reop if it is in motion.	execution  System operation is not sidecelerates to a details, operation is elevant axes group	
Effects System-defined	Level User program  Variable	Minor fault Continues.  Lvl.Active	Recovery Operation  Data type	Error reset  If "axis" is given for possible for relevar stop if it is in motio  If "axes group" is g not possible for relevance possible	timing  Log category  r the source details, nt axis. Relevant axis.  iven for the source cevant axes group. Reop if it is in motion.	execution  System operation is not sidecelerates to a details, operation is elevant axes group occurrence	
Effects	Level User program  Variable _MC_AX[*].MFault	Minor fault Continues.  Lvl.Active	Recovery Operation  Data type BOOL	Error reset  If "axis" is given for possible for relevar stop if it is in motio  If "axes group" is g not possible for relevance possible	timing  Log category  r the source details, nt axis. Relevant axis n. iven for the source cevant axes group. Rop if it is in motion.  Name  Axis Minor Fault O	execution  System operation is not sidecelerates to a details, operation is elevant axes group occurrence	
System-defined variables  Cause and	Level User program  Variable _MC_AX[*].MFault _MC_GRP[*].MFault	Minor fault Continues.  Lvl.Active altLvl.Active of the instruction acceded the range	Data type BOOL BOOL Correction Correct the input properties of the Distance input properties of the target position of the target position.	Error reset  If "axis" is given for possible for relevariatop if it is in motion if "axes group" is gonot possible for reledecelerates to a state of the control of the con	timing  Log category  r the source details, nt axis. Relevant axis.  iven for the source of evant axes group. Roop if it is in motion.  Name  Axis Minor Fault O  Axes Group Minor	execution  System operation is not s decelerates to a decelerates to a details, operation is elevant axes group  ccurrence  Fault Occurrence so that the travel arget position for	
Effects  System-defined variables	Variable  _MC_AX[*].MFault _MC_GRP[*].MFau  Assumed cause The absolute value input parameter ex of 40-bit data when pulses. For a Linear Mode position with the tradded exceeded s	Minor fault Continues.  Lvl.Active  Ltvl.Active  e of the instruction acceded the range in it is converted to axis, the target avel distance	Recovery Operation  Data type BOOL BOOL Correction Correct the input p for the Distance inp instruction so that the	Error reset  If "axis" is given for possible for relevariatop if it is in motion if "axes group" is gonot possible for reledecelerates to a state of the control of the con	timing Log category r the source details, nt axis. Relevant axis n. iven for the source devant axes group. Rop if it is in motion.  Name Axis Minor Fault O Axes Group Minor Prevention Write the program distance and the ta	execution  System  operation is not sedecelerates to a decelerates to a details, operation is elevant axes group  ccurrence  Fault Occurrence  so that the travel arget position for	
System-defined variables  Cause and	Variable  _MC_AX[*].MFault _MC_GRP[*].MFault _MC_GRP[*].MFault _MC_GRD[*].MFault _MC	Minor fault Continues.  Lvl.Active  Ltvl.Active  e of the instruction acceded the range in it is converted to axis, the target avel distance igned 40-bit data	Data type BOOL BOOL Correction Correct the input properties of the Distance input properties of the target position of the target position.	Error reset  If "axis" is given for possible for relevariatop if it is in motion if "axes group" is gonot possible for reledecelerates to a state of the control of the con	timing Log category r the source details, nt axis. Relevant axis n. iven for the source devant axes group. Rop if it is in motion.  Name Axis Minor Fault O Axes Group Minor Prevention Write the program distance and the ta	execution  System  operation is not sedecelerates to a decelerates to a details, operation is elevant axes group  ccurrence  Fault Occurrence  so that the travel arget position for	

Event name	Cam Table Start P	oint Setting Out of R	ange	Event code	547A0000 hex		
Meaning	The parameter spe	The parameter specified for the StartPosition input variable to a motion control instruction is out of range.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	Operation is not po decelerates to a st	ssible for relevant axis. Relevant axis op if it is in motion.		
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFault	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.		
Attached information	None						
Precautions/ Remarks	None						

Event name	Cam Master Axis Following First Position Setting Out of Range			Event code	547B0000 hex	
Meaning	The parameter spe	ecified for the Master	variable to a motion	control instruction is	out of range.	
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	Operation is not po decelerates to a st	ossible for relevant axis. Relevant axis op if it is in motion.	
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention	
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.	
Attached information	None		•		•	
Precautions/ Remarks	None					

Event name	Circular Interpolat	ion Radius Setting E	rror	Event code	547C0000 hex		
Meaning	· ·	e to create a circular   2D (Circular 2D Inter	•		dius method was sp	ecified for the	
Source	Motion Control Fu	nction Module	Source details	Axes group	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		essible for relevant a erates to a stop if it is		
System-defined	Variable		Data type		Name		
variables	_MC_GRP[*].MFa	ultLvl.Active	BOOL		Axes Group Minor	Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	For the MC_MoveCircular2D (Circular 2D Interpolation) instruction, it was not possible to create a circular path for the specified radius when the radius method was specified for circular interpolation.		Correct the radius so that the circular path can be created.		Check the process instruction and set allows the creation	-	
Attached information	None						
Precautions/ Remarks	None						
Event name	Circular Interpolat	ion Radius Overflow		Event code	547D0000 hex		
Meaning		Circular2D (Circular ser point or center spe		D Interpolation) instruction, the radius of the circle exceeded the maximum fication method.			
Source	Motion Control Fu	nction Module	Source details	Axes group	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		essible for relevant as rates to a stop if it is		
System-defined	Variable		Data type		Name		
variables	_MC_GRP[*].MFa	ultLvl.Active	BOOL		Axes Group Minor	Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	For the MC_MoveCircular2D (Circular 2D Interpolation) instruction, the radius of the circle exceeded 40-bit data when converted to pulses for the border point or center specification method.		Correct the input parameter so that the circle radius does not exceed 40-bit data when converted to pulses based on the operating specifications of the instruction.  Center point specification: Start point, end point, and center point  Radius specification: Radius		Check the process tion and correct th so that the circle ra exceed 40-bit data pulses.	e input parameters	
Attached information	None				l		
Precautions/ Remarks		dius is exceeded who	•	cation method is use	ed, a Border Point/C	enter Posi-	

Event name	Circular Interpolat	ion Setting Out of Ra	ange	Event code	547E0000 hex			
Meaning	The parameter sp	ecified for the CircAx	es input variable to	es input variable to a motion control instruction is out of range.				
Source	Motion Control Function Module		Source details	Axes group	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation Operation is not possible for relevant axes ground axes group decelerates to a stop if it is in motion		•			
System-defined	Variable		Data type		Name			
variables	_MC_GRP[*].MFaultLvl.Active		BOOL		Axes Group Minor	Fault Occurrence		
Cause and	Assumed cause		Correction		Prevention			
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameters to the instruction so that the valid range of the input variables is not exceeded.			
	cAxes are not incl	The axes that were specified in <i>CircAxes</i> are not included in the composition axes in the Axes Group Settings.		Set the axes that are specified for <i>Cir-cAxes</i> so that they are in an axes group configuration.		Make sure that the axes that are specified for <i>CircAxes</i> are in an axes group configuration.		
	The same axis was specified for both axes of <i>CircAxes</i> .		Correct the settings so that the two axes specified for <i>CircAxes</i> are different axes.		Write the program so that the two axes specified for <i>CircAxes</i> are different axes.			
Attached information	None							
Precautions/ Remarks	None	None						

Event name	Auxiliary/Slave Axis Numbers Not in Ascending Order			Event code	547F0000 hex			
Meaning	The values of the pascending order.	The values of the parameters for the <i>Auxiliary</i> and <i>Slave</i> input variables to a motion control instruction are not in ascending order.						
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation Operation is not possible for relevant axis. Relevant a decelerates to a stop if it is in motion.			xis. Relevant axis		
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault O	ccurrence		
Cause and	Assumed cause		Correction		Prevention			
correction	The parameters for the <i>Auxiliary</i> and <i>Slave</i> input variables to the instruction are not in ascending order.		Correct the axis numbers specified for the <i>Auxiliary</i> and <i>Slave</i> input parame- ters to the instruction so that they are in ascending order.		Write the program so that the axis numbers specified for <i>Auxiliary</i> and <i>Slave</i> are in ascending order.			
Attached information	None							
Precautions/ Remarks	None							

Event name	Cam Table Proper	ty Ascending Data E	rror at Update	Event code	54800000 hex		
Meaning	A phase that was the number of vali		er was found durin	g calculating the numl	ber of valid data. Or	, after calculations,	
Source	Motion Control Fu	nction Module	Source details	MC common	Detection timing	During instruc- tion execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	Not affected.		•	
System-defined	Variable		Data type		Name		
variables	_MC_COM.MFaul	tLvl.Active	BOOL		MC Common Min	or Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	A phase that was order was found w number of valid da	hen calculating the	Place the phase order in the cam	data into ascending table data.	Place the phase of order in the cam t	lata into ascending able data.	
	After calculations, data is 0.	the number of valid	Correct the cam	table data so that it that are not 0.	Create the cam to includes phases t		
Attached information	None						
Precautions/ Remarks	None						
Event name	MC_Write Target	Out of Range		Event code	54810000 hex		
Meaning	The parameter sp	he parameter specified for the Target input variable to a motion control instruction is out of range.					
Source	Motion Control Fu	nction Module	Source details	MC common	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	Not affected.			
System-defined	Variable		Data type		Name		
variables	_MC_COM.MFaul	tLvl.Active	BOOL		MC Common Minor Fault Occurred		
Cause and	Assumed cause		Correction		Prevention		
correction	Instruction input p the valid range of	arameter exceeded the input variable.	Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruc- tion so that the valid range of the input variable is not exceeded.		
Attached information	None						
Precautions/ Remarks	None						
	I	0 15 11 0		I =	I		
Event name		ance Specification O		Event code	54820000 hex		
Meaning			<u> </u>	iable to a motion cont			
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant sates to a stop if it is	slave axis. Relevant in motion.	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaul	tLvl.Active	BOOL		Axis Minor Fault (	Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	Instruction input p the valid range of	arameter exceeded the input variable.	Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruc- tion so that the valid range of the input variable is not exceeded.		
Attached information	None	None					
Precautions/	None						

Event name	Master Distance in Range	Acceleration Specif	fication Out of	Event code	54830000 hex		
Meaning	The parameter spe	ecified for the Master	rDistanceACC input	variable to a motion	control instruction is	out of range.	
Source	Motion Control Fur	nction Module	Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant s ates to a stop if it is i		
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFault	Lvl.Active	BOOL		Axis Minor Fault O	ccurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	Instruction input parameter exceeded the valid range of the input variable.		_	neter so that the input variable is not relevant instruction.	Set the input parar tion so that the vali variable is not exce	d range of the inp	
Attached information	None		1		1		
Precautions/ Remarks	None						
Event name	Master Distance in Range	Deceleration Speci	fication Out of	Event code	54840000 hex		
Meaning	The parameter specified for the MasterDistanceDEC input variable to a motion control instruction is out of range						
Source	Motion Control Fur	nction Module	Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant slave axis. Releva ates to a stop if it is in motion.		
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFault	Lvl.Active	BOOL		Axis Minor Fault Occurrence		
Cause and	Assumed cause		Correction	Correction			
correction	Instruction input pa the valid range of t	arameter exceeded he input variable.	Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instrution so that the valid range of the input variable is not exceeded.		
Attached information	None						
Precautions/ Remarks	None						
Event name	Execution Mode S	election Out of Rang	je	Event code	54870000 hex		
Meaning	The parameter spe	ecified for the Execut	tionMode input varia	able to a motion cont	rol instruction is out	of range.	
Source	Motion Control Fur	nction Module	Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant a top if it is in motion.	xis. Relevant axi	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFault	Lvl.Active	BOOL		Axis Minor Fault O	ccurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	Instruction input pa the valid range of t	arameter exceeded he input variable.	Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instr tion so that the valid range of the in variable is not exceeded.		
Attached information	None						
Precautions/	None						

Remarks

Event name	Permitted Followin	g Error Out of Range	е	Event code	54880000 hex		
Meaning	The parameter spe	ecified for the <i>Permit</i>	tedDeviation input va	ariable to a motion c	ontrol instruction is o	out of range.	
Source	Motion Control Fur	nction Module	Source details	MC Common	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	The instruction is r	not executed.		
System-defined	Variable		Data type		Name		
variables	_MC_COM.MFaultLvl.Active		BOOL		MC Common Mino	r Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	Instruction input pa the valid range of t	arameter exceeded he input variable.	Correct the parametrial valid range of the interest exceeded for the results.	nput variable is not		neter to the instruc- d range of the input eeded.	
Attached information	None						
Precautions/ Remarks	None	None					
Event name	Border Point/Center	er Position/Radius S	pecification Out of Event code 54890000 hex				
Meaning	The parameter spe	ecified for the AuxPo	int input variable to a	a motion control instr	ruction is out of rang	e.	
Source	Motion Control Fur	nction Module	Source details	Axes group	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ssible for relevant ax rates to a stop if it is	• .	
System-defined	Variable		Data type		Name		
variables	_MC_GRP[*].MFai	ultLvl.Active	BOOL		Axes Group Minor	Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	signed 40-bit data pulses for the bord	The value of <i>AutPoint</i> exceeded signed 40-bit data when converted to pulses for the border point or center specification method.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.	
	For a radius specifications, the absolute value of <i>AuxPoint[0]</i> exceeded 40-bit data when converted to pulses.						
Attached information	None						
Precautions/ Remarks	None						

Event name	End Point Specification Out of Range			Event code	548A0000 hex			
Meaning	The parameter spe	The parameter specified for the EndPoint input variable to a motion control instruction is out of range.						
Source	Motion Control Function Module		Source details	Axes group	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation		ation is not possible for relevant axes group. Relevant group decelerates to a stop if it is in motion.			
System-defined	Variable		Data type		Name			
variables	_MC_GRP[*].MFaultLvl.Active		BOOL		Axes Group Minor Fault Occurrence			
Cause and	Assumed cause	Assumed cause		Correction		Prevention		
correction	The instruction input parameter exceeded the range of signed 40-bit data when it is converted to pulses.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.			
Attached information	None							
Precautions/ Remarks	None							

Event name	Slave Travel Distance Specification Out of Range			Event code	548B0000 hex			
Meaning	The parameter spe	The parameter specified for the <i>SlaveDistance</i> input variable to a motion control instruction is out of range.						
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation	Operation is not possible for relevant slave axis. Relevant slave axis decelerates to a stop if it is in motion.				
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence			
Cause and	Assumed cause		Correction		Prevention			
correction	The instruction input parameter exceeded the range of 40-bit data when it is converted to pulses.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.			
Attached information	None							
Precautions/ Remarks	None							

Event name	Phase Shift Amou	nt Out of Range		Event code	548C0000 hex		
Meaning	The parameter spe	The parameter specified for the <i>PhaseShift</i> input variable to a motion control instruction is out of range.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation Operation is not possible for relevant slave a slave axis decelerates to a stop if it is in moti				
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	The absolute value of the instruction input parameter exceeded the range of 40-bit data when it is converted to pulses.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.		
Attached information	None						
Precautions/ Remarks	None						

Event name	Feeding Distance	Out of Range		Event code	548D0000 hex		
Meaning	, ,		Distance input variat	ole to a motion contro	II Il instruction is out o	f range.	
Source	Motion Control Fu		Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant atop if it is in motion.	xes. Relevant axis	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaul	Lvl.Active	BOOL		Axis Minor Fault C	ccurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	The absolute value of the instruction input parameter exceeded the range of 40-bit data when it is converted to pulses.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.			meter to the instruc id range of the input eeded.	
Attached information	None	None					
Precautions/ Remarks	None						
Front	Applicant end Of	Dofined as Orman		Front and	E40E0000 h		
Event name		e Defined as Same A		Event code  ut variables to a motion	548E0000 hex		
Meaning Source	Motion Control Fu	•	Source details	Axis	Detection	At instruction	
E H	Lavel	N.C C II	D		timing	execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		essible for relevant slave axis. Relevan ttes to a stop if it is in motion.		
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaul	Lvl.Active	BOOL		Axis Minor Fault C	ccurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	The parameter wa Auxiliary and Slave the instruction.	s the same for the e input variables to	Correct the parameters so that different axes are specified for the <i>Auxiliary</i> and <i>Slave</i> input variables to the instruction.		Specify different axes for the auxiliary axis and slave axis for a motion control instruction.		
Attached information	None						
Precautions/ Remarks	None						
Event name	Relative Position S	Selection Out of Rang	ge	Event code	548F0000 hex		
Meaning	The parameter sp	ecified for the Relativ	e input variable to	a motion control instr	uction is out of range	9.	
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant s ates to a stop if it is		
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaul	Lvl.Active	BOOL		Axis Minor Fault C	ccurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	Instruction input path the valid range of	arameter exceeded the input variable.	valid range of the	Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.	
Attached information	None						
Precautions/ Remarks	None						

Event name	Cam Transition Sp	ecification Out of Ra	ınge	Event code	54900000 hex		
Meaning	The parameter spe	The parameter specified for the CamTransition input variable to a motion control instruction is out of range.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		possible for relevant slave axis. Relevant erates to a stop if it is in motion.		
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence		
Cause and	Assumed cause	Assumed cause		Correction		Prevention	
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.		
Attached information	None						
Precautions/ Remarks	None						

Event name	Synchronized Control End Mode Selection Out of Range			Event code	54910000 hex			
Meaning	The parameter spe	The parameter specified for the <i>OutMode</i> input variable to a motion control instruction is out of range.						
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation	Operation is not possible for relevant slave axis. Re slave axis decelerates to a stop if it is in motion.				
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault O	ccurrence		
Cause and	Assumed cause		Correction		Prevention			
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.			
Attached information	None							
Precautions/ Remarks	None							

Event name	Enable External La	atch Instruction Exec	cution Disabled	Event code	54920000 hex			
Meaning			he <i>StopMode</i> input ve, but the Control Mo		_ `	ble External Latch)		
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation		ossible for relevant a op if it is in motion.	xis. Relevant axis		
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFault	Lvl.Active	BOOL		Axis Minor Fault O	ccurrence		
Cause and	Assumed cause		Correction		Prevention			
correction	_mcImmediateStop was specified for the StopMode input variable when the MC_TouchProbe (Enable External Latch) instruction was executed in Drive Mode, but the Control Mode was not CSP Mode or the Servo was OFF.		Set the Control Mode to CSP Mode to execute the Enable External Latch instruction in Drive Mode and specify _mcImmediateStop.		Set the Control Mode to CSP Mode to execute the Enable External Latch instruction in Drive Mode and specify _mcImmediateStop.			
Attached information	None	None						
Precautions/ Remarks	None							
Event name	Master Axis Offset	Out of Range	Event code 54930000 hex					
Meaning	The parameter spe	ecified for the Maste	rOffset input variable to a motion control instruction is out of range.					
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation		ossible for the slave a			
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFault	Lvl.Active	BOOL		Axis Minor Fault O	ccurrence		
Cause and	Assumed cause		Correction		Prevention			
correction	The instruction input parameter exceeded the range of signed 40-bit data when it is converted to pulses.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.			
Attached information	None							
Precautions/ Remarks	None							

Event name	Slave Axis Offset Out of Range			Event code	54940000 hex		
Meaning	The parameter specified for the SlaveOffset input variable to a motion control instruction is out of range.						
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ot possible for relevant slave axis. Relevant elerates to a stop if it is in motion.		
System-defined variables	Variable		Data type		Name		
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence		
Cause and correction	Assumed cause		Correction		Prevention		
	The instruction input parameter exceeded the range of signed 40-bit data when it is converted to pulses.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.		
Attached information	None						
Precautions/ Remarks	None						

Event name	Command Current Position Count Selection Out of Range			Event code	54950000 hex		
Meaning	The parameter specified for the CmdPosMode input variable to a motion control instruction is out of range.						
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		is not possible for relevant axis. Relevant axis es to a stop if it is in motion.		
System-defined variables	Variable		Data type		Name		
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence		
Cause and correction	Assumed cause		Correction		Prevention		
	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.		
Attached information	None						
Precautions/ Remarks	None						

Event name	Master Axis Gear	Ratio Numerator Ou	t of Range	Event code	54960000 hex		
Meaning	The parameter specified for the RatioNumeratorMaster input variable to a motion control instruction is out of range.						
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category System		
Effects	User program	Continues.	Operation		tion is not possible for relevant slave axis. Relevant axis decelerates to a stop if it is in motion.		
System-defined variables	Variable		Data type		Name		
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence		
Cause and correction	Assumed cause		Correction		Prevention		
	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.		
Attached information	None				•		
Precautions/ Remarks	None						

Event name	Master Axis Gear	aster Axis Gear Ratio Denominator Out of Range Event code 54970000 hex					
Meaning	The parameter sp	ecified for the RatioD	enominatorMaster input variable to a mo		otion control instruction is out of range.		
Source	Motion Control Fu	unction Module	Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant slave axis. Relevantes to a stop if it is in motion.		
System-defined	Variable		Data type		Name	lame	
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence		
Cause and correction	Assumed cause		Correction		Prevention		
	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the inpuvariable is not exceeded.		
Attached information	None						
Precautions/ Remarks	None						
Event name	Auxiliary Axis Ge	ar Ratio Numerator O	ut of Range	Event code	54980000 hex		
Meaning	The parameter specified for the <i>RatioNumeratorAuxiliary</i> input variable to a motion control instruction is out of				ion is out of range.		
Source	Motion Control Fu	unction Module	Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		essible for relevant slave axis. Relevant stes to a stop if it is in motion.		
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFau	ItLvI.Active	BOOL		Axis Minor Fault Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.		
Attached information	None						
Precautions/ Remarks	None						
Event name	Auxiliary Axis Ge	ar Ratio Denominator	Out of Range	Event code	54990000 hex		
Meaning	The parameter sp	ecified for the RatioD	enominatorAuxiliary input variable to a motic		notion control instru	otion control instruction is out of range	
Source	Motion Control Fu	unction Module	Source details	Axis	Detection At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant sates to a stop if it is		
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence		
Cause and correction	Assumed cause		Correction		Prevention		
	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.		
Attached information	None						
Precautions/ Remarks	None						

Event name	Master Axis Position Type Selection Out of Range			Event code	549A0000 hex		
Meaning	The parameter spe	ecified for the <i>Refere</i>	enceTypeMaster inpu	ıt variable to a motio	n control instruction	is out of range.	
Source	Motion Control Fu	Motion Control Function Module		Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ation is not possible for relevant slave axis. Relevan axis decelerates to a stop if it is in motion.		
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaul	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.		
Attached information	None						
Precautions/ Remarks	None						

Event name	Auxiliary Axis Position Type Selection Out of Range			Event code	549B0000 hex		
Meaning	The parameter spe	The parameter specified for the ReferenceTypeAuxiliary input variable to a motion control instruction is out of range.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		Operation is not possible for relevant slave axis. Relevar slave axis decelerates to a stop if it is in motion.		
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	Instruction input parameter exceeded the valid range of the input variable.		Correct the parameter so that the valid range of the input variable is not exceeded for the relevant instruction.		Set the input parameter to the instruction so that the valid range of the input variable is not exceeded.		
Attached information	None						
Precautions/ Remarks	None						

Event name	Target Position Ring Counter Out of Range Event code		Event code	549C0000 hex		
Meaning	Operation is not po	ossible because the	target position is out	of range for the ring	counter of the exec	cuted instruction.
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation		ossible for relevant a op if it is in motion.	ixis. Relevant axis
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFault	Lvl.Active	BOOL		Axis Minor Fault C	occurrence
Cause and	Assumed cause		Correction		Prevention	
correction	High-speed homin when 0 was not in counter.		High-speed homing cannot be executed when the ring counter range does not include 0. Correct the program so that high-speed homing is not performed. Or change the settings so that the ring counter range includes 0.		High-speed homing cannot be executed when the ring counter range does not include 0. Write the program so that high-speed homing is not performed. Or make the settings so that the ring counter range includes 0.	
Attached information	None					
Precautions/ Remarks	None					
					_	
Event name	Target Position Po	sitive Software Limit	Exceeded	Event code	64400000 hex	
Meaning	The specified posi	tion exceeds the pos	itive software limit.	_		
Source	Motion Control Fu	nction Module	Source details	Axis/axes group	Detection timing At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	possible for releval stop if it is in motio If "axes group" is g	iven for the source details, operation in evant axes group. Relevant axes group.	
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFault	Lvl.Active	BOOL		Axis Minor Fault Occurrence	
	_MC_GRP[*].MFa		BOOL		Axes Group Minor Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention	
correction	The parameter spe	ecified for the <i>Posi</i> - to the instruction is e software limit.	Correct the parameter specified for the <i>Position</i> input variable to the instruction so that it is within the positive software limit.		Set the parameter specified for the <i>Position</i> input variable to the instruction so that it is within the positive software limit.	
	The first position is beyond the positive software limit and an instruction that specifies motion in the opposite direction of the software limit was executed.		Correct the program so that the travel direction for the instruction is towards the positive software limit.		If the first position is beyond the positive software limit, write the program so that the travel direction is in the direction of the positive software limit	
	The parameter that was specified for the <i>AuxPoint</i> input variable to a border point MC_MoveCircular2D (Circular 2D Interpolation) instruction is beyond the positive software limit		Correct the parameter specified for the <i>AuxPoint</i> input variable to the instruction so that it is within the positive software limit.		point MC_MoveCi	iable to the border rcular2D (Circular nstruction so that it
Attached information	Depends on the so Axis: None Axes group: Logical					
Precautions/ Remarks	None None	a and number				

Event name	Target Position Negative Software Limit Exceeded			Event code	64410000 hex			
Meaning	The specified pos	The specified position exceeds the negative software limit.						
Source	Motion Control Fu	nction Module	Source details	Axis/axes group	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program Continues.		possible for relevent stop if it is in more lift "axes group" is not possible for it is not possible for possible for possible for it is not possible for poss			s decelerates to a		
					given for the source details, operation is elevant axes group. Relevant axes group stop if it is in motion.			
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFaul	tLvl.Active	BOOL		Axis Minor Fault Occurrence			
	_MC_GRP[*].MFa	ultLvl.Active	BOOL		Axes Group Minor Fault Occurrence			
Cause and	Assumed cause		Correction		Prevention			
correction	The parameter specified for the <i>Position</i> input variable to the instruction is beyond the negative software limit.		Correct the parameter specified for the <i>Position</i> input variable to the instruction so that it is within the negative software limit.		Correct the input parameter specified for the <i>Position</i> input variable to the instruction so that it is within the negative software limit.			
	The first position is beyond the negative software limit and an instruction that specifies motion in the opposite direction of the software limit was executed		Correct the program so that the travel direction for the instruction is towards the negative software limit.		If the first position is beyond the negative software limit, write the program so that the travel direction is in the direction of the negative software limit.			
The parameter that was specified for the <i>AuxPoint</i> input variable to a border point MC_MoveCircular2D (Circular 2D Interpolation) instruction is beyond the negative software limit		Correct the parameter specified for the <i>AuxPoint</i> input variable to the instruction so that it is within the negative software limit.		Set the parameter AuxPoint input vari point MC_MoveCir 2D Interpolation) in is within the negati	iable to the border reular2D (Circular nstruction so that it			
Attached	Depends on the se	ource details.						
information	Axis: 0							
	Axes group: Logic	al axis number						
Precautions/ Remarks	None							


Event name	Command Position Overflow/Underflow		v	Event code	64420000 hex			
Meaning	, J	Positioning, an instruction in the underflow/overflow direction, or an instruction for which the direction is not specified was executed when there was an underflow/overflow in the command position.						
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	At instruction execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation	Operation is not podecelerates to a st	ossible for relevant a op if it is in motion.	xis. Relevant axis		
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFaul	tLvl.Active	BOOL		Axis Minor Fault Occurrence			
Cause and	Assumed cause		Correction		Prevention			
correction	One of the following was executed when there was a command position overflow/underflow.		Execute an error reset and then clear the overflow/underflow state by executing homing or presetting the actual position.		Make sure that overflow or underflow does not occur.			
	A positioning instruction							
	A continuous control instruction in the underflow/overflow direction							
	An instruction for which the direction is not specified (syncing or torque control)							
Attached	Depends on the s	ource details.						
information	On Axis: 0							
	Axes group: Logic	al axis number						
Precautions/ Remarks	None							

Event name	Positive Limit Input			Event code	64430000 hex		
Meaning	An instruction was executed for a motion in the positive direction when the positive limit input was ON.						
Source	Motion Control Fu	unction Module			Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	If "axis" is given for possible for relevan		s, operation is not	
				If "axes group" is g		e details, operation is	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFau	ItLvI.Active	BOOL		Axis Minor Fault Occurrence		
	_MC_GRP[*].MFa	aultLvl.Active	BOOL		Axes Group Minor Fault Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	An instruction for a motion in the positive direction was executed when the positive limit input was ON, or an instruction for a motion with no direction specification was executed when the positive limit input was ON.		form a recovery of ative direction. If again, check the positive limit sign for the positive lir	connection of the al, the logic setting nit input, and the ons for the start com-	connection, the l	e positive limit signal ogic setting for the ut, and the execute	
Attached	Depends on the s	ource details.					
information	Axis: 0	Axis: 0					
	Axes group: Logic	cal axis number					
Precautions/ Remarks	None						

Event name	Negative Limit Input			Event code	64440000 hex		
Meaning	An instruction for	An instruction for a motion in the negative direction was executed when the negative limit input was ON.					
Source	Motion Control Fu	inction Module	Source details	Axis/axes group	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program Continues.		Operation		If "axis" is given for the source details, operation is not possible for relevant axis.		
				If "axes group" is g	given for the source evant axes group.	details, operation is	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFau	ItLvI.Active	BOOL		Axis Minor Fault Occurrence		
	_MC_GRP[*].MFa	aultLvl.Active	BOOL		Axes Group Minor Fault Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	An instruction for a motion in the negative direction was executed when the negative limit input was ON, or an instruction for a motion with no direction specification was executed when the negative limit input was ON.		Execute an error reset and then perform a recovery operation in the positive direction. If this error occurs again, check the connection of the negative limit signal, the logic setting for the negative limit input, and the execution conditions for the start command, and correct any mistakes.		connection, the lo	negative limit signal gic setting for the t, and the execute	
Attached	Depends on the s	ource details.					
information	Axis: 0						
	Axes group: Logic	al axis number					
Precautions/	None None						

Event name	Servo Main Circuits OFF			Event code	74220000 hex	
Meaning	An attempt was ma	ade to turn ON the S	Servo when the main	circuit power supply	to the Servo Drive	was OFF.
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The Servo for the a	he Servo for the axis turns OFF.	
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFault	_AX[*].MFaultLvl.Active BOOL			Axis Minor Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention	
correction	An attempt was made to turn ON the Servo when the main circuit power supply to the Servo Drive was OFF.		Turn ON the Servo after turning ON the main circuit power of the Servo Drive for the axis where the error occurred.		Turn ON the Servo after turning ON the main circuit power supply to the Servo Drive.	
Attached information	None					
Precautions/ Remarks	None					

Appendices



## Index

## Index

A	MC_CombineAxes (Combine Axes)	3-272
	MC_GearIn (Start Gear Operation)	3-207
Absolute Linear Interpolation4-36	MC_GearInPOS (Positioning Gear Operation)	3-225
Absolute Positioning3-41	MC_GearOut (End Gear Operation)	3-245
Axes Group Immediate Stop4-75	MC_GroupDisable (Disable Axes Group)	4-6
7,000 Group minodiate Stop	MC_GroupEnable (Enable Axes Group)	4-2
C	MC_GroupImmediateStop	
<u> </u>	(Axes Group Immediate Stop)	4-75
Circular OD Internalation 4.40	MC_GroupReset (Group Reset)	
Circular 2D Interpolation4-42	MC_GroupSetOverride (Set Group Overrides)	
Combine Axes	MC_GroupStop (Group Stop)	
Cyclic Synchronous Velocity Control3-344	MC_Home (Home)	
D	MC_ImmediateStop (Immediate Stop)	
D	MC_Move (Positioning)	
	MC_MoveAbsolute (Absolute Positioning)	
Disable Axes Group4-6	MC_MoveCircular2D (Circular 2D Interpolation)	
Disable External Latch	MC_MoveFeed (Interrupt Feeding)	
_	MC_MoveJog (Jog)	
E	MC_MoveLinear (Linear Interpolation)	
	MC_MoveLinearAbsolute	
Enable Axes Group4-2	(Absolute Linear Interpolation)	4-36
Enable External Latch3-313	MC_MoveLinearRelative	
End Cam Operation3-202	(Relative Linear Interpolation)	4-39
End Gear Operation3-245	MC_MoveLink (Synchronous Positioning)	
	MC_MoveRelative (Relative Positioning)	
G	MC_MoveVelocity (Velocity Control)	
	MC_MoveZeroPosition (High-speed Home)	
Group Reset4-84	MC_Phasing (Shift Master Axis Phase)	
Group Stop4-66	MC_Power (Power Servo)	
	MC_Reset (Reset Axis Error)	
H	MC_ResetFollowingError	0-002
	(Reset Following Error Counter)	2 150
High-speed Home3-90	MC_SaveCamTable (Save Cam Table)	
Home	MC_SetCamTableProperty	5-0
10110	(Setting Cam Table Properties)	5.2
1	MC_SetOverride (Set Override Factors)	
<u> </u>	MC_SetPosition (Set Position)	
Immediate Stan	MC_SetTorqueLimit (Set Torque Limit)	
Immediate Stop	MC_Stop (Stop)	
Interrupt Feeding3-97	,	3-123
J	MC_SyncMoveVelocity	0.044
U	(Cyclic Synchronous Velocity Control)	
	· · · · · · · · · · · · · · · · · · ·	
Jog3-8	MC_TouchProbe (Enable External Latch)	
•	MC_Write (Write MC Setting)	
L	MC_ZoneSwitch (Zone Monitor)	
	Monitor Axis Following Error	3-338
Linear Interpolation4-10	Р	
	r	
M		
	Positioning	
MC_AbortTrigger (Disable External Latch)3-333	Positioning Gear Operation	
MC_AxesObserve (Monitor Axis Following Error) 3-338	Power Servo	3-3
MC_CamIn (Start Cam Operation)3-156		

MC\_CamOut (End Cam Operation) ......3-202

## R

Relative Linear Interpolation Relative Positioning Reset Axis Error Reset Following Error Counter	3-68 3-352
Save Cam Table	4-80 3-145 3-139 5-2 3-283 3-156 3-207 3-250
Torque Control	
Velocity Control	3-75
Write MC Setting	
Zone Monitor	3-307

Index

**OMRON Corporation Industrial Automation Company** 

Tokyo, JAPAN

Contact: www.ia.omron.com

Regional Headquarters
OMRON EUROPE B.V.
Wegalaan 67-69-2132 JD Hoofddorp
The Netherlands Tel: (31)2356-81-300/Fax: (31)2356-81-388

OMRON ASIA PACIFIC PTE. LTD.

No. 438A Alexandra Road # 05-05/08 (Lobby 2), Alexandra Technopark, Singapore 119967 Tel: (65) 6835-3011/Fax: (65) 6835-2711

OMRON ELECTRONICS LLC
One Commerce Drive Schaumburg,

IL 60173-5302 U.S.A. Tel: (1) 847-843-7900/Fax: (1) 847-843-7787

OMRON (CHINA) CO., LTD.
Room 2211, Bank of China Tower,
200 Yin Cheng Zhong Road,
PuDong New Area, Shanghai, 200120, China
Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200

**Authorized Distributor:** 

© OMRON Corporation 2011 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice.

Cat. No. W508-E1-01